

Contents A-7



Online Edition for Part no. 01 40 2 606 735 - 06 11 500

X5 xDrive35i X5 xDrive50i X5 xDrive35d X6 xDrive35i X6 xDrive50i **X5 M X6 M**

Owner's Manual for Vehicle

Thank you for choosing a BMW.

The more familiar you are with your vehicle, the better control you will have on the road. We therefore strongly suggest:

Read this Owner's Manual before starting off in your new BMW. It contains important information on vehicle operation that will help you make full use of the technical features available in your BMW. The manual also contains information designed to enhance operating reliability and road safety, and to contribute to maintaining the value of your BMW.

Please also note the additional items of onboard literature, for instance the BMW X5 M / BMW X6 M Supplementary Owner's Manual.

We wish you a safe and enjoyable drive.

BMW AG



© 2011 Bayerische Motoren Werke Aktiengesellschaft Munich, Germany Reprinting, including excerpts, only with the written consent of BMW AG, Munich. US English II/11, 03 11 500 Printed on environmentally friendly paper, bleached without chlorine, suitable for recycling.

Contents

The fastest way to find information on a particular topic or item is by using the index, refer to page 302.

Using this Owner's Manual

Notes

At a glance

- 12 Cockpit
- 18 iDrive
- 24 Voice activation system

Controls

- 28 Opening and closing
- 45 Adjusting
- Transporting children safely 56
- 61 Driving
- 71 Displays
- 81 Lamps
- 86 Safety
- 96 Driving stability control systems
- 102 Driving comfort
- 119 Climate
- 127 Interior equipment
- 134 Storage compartments

Driving tips

142 Things to remember when driving

Navigation

- 152 Navigation system
- 153 Destination entry
- 161 Destination guidance
- 168 What to do if

Entertainment

- 172 Tone
- 174 Radio
- 181 CD/multimedia
- 200 DVD system in rear

Communication

- 216 Telephone
- 227 Office
- 235 Contacts
- 237 ConnectedDrive

Mobility

- 246 Refueling
- 248 Fuel
- 252 Wheels and tires
- 263 Engine compartment
- 268 Maintenance
- 270 Replacing components
- 280 Breakdown assistance
- 285 Care

Reference

- 290 Technical data
- 295 Short commands for voice activation system
- 302 Everything from A to Z

Notes

Using this Owner's Manual

The fastest way to find information on a particular topic is by using the index.

An initial overview of the vehicle is provided in the first chapter.

Additional sources of information

Should you have any questions, your service center will be glad to advise you at any time.

Information on BMW, e.g., on technology, is available on the Internet: bmwusa.com.

Symbols

⚠ Indicates precautions that must be followed precisely in order to avoid the possibility of personal injury and serious damage to the vehicle.

- → Marks the end of a specific item of information.
- * Indicates special equipment, country-specific equipment and optional accessories, as well as equipment and functions not yet available at the time of printing.
- "..." Identifies Control Display texts used to select individual functions.
- >.... Verbal instructions to use with the voice activation system.
- »...« Identifies the answers generated by the voice activation system.
- Refers to measures that can be taken to help protect the environment.

Symbols on vehicle components

Il Indicates that you should consult the relevant section of this Owner's Manual for information on a particular part or assembly.

Your individual vehicle

You have decided in favor of a vehicle with individualized equipment and features.

This Owner's Manual describes the entire array of options and equipment available for a specific model.

As a result, the manual may contain accessories and equipment that you may not have specified for your own vehicle.

All options and special equipment are marked with an asterisk*.

For options and equipment not described in this Owner's Manual, please refer to the Supplementary Owner's Manuals.

Status of this Owner's Manual at time of printing

The manufacturer of your vehicle pursues a policy of constant development that is conceived to ensure that our vehicles continue to embody the highest quality and safety standards. In rare cases, therefore, the features described in this Owner's Manual may differ from those in your vehicle.

Updates made after the editorial deadline

Any updates made after the editorial deadline for the Owner's Manuals are located in the appendix of the printed quick reference for the vehicle.

For your own safety

Maintenance and repairs

Advanced technology, e.g., the use of modern materials and high-performance electronics, requires suitable maintenance and repair methods.

Therefore, have this work performed only by a BMW center or a workshop that works according to BMW repair procedures with appropriately trained personnel.

If this work is not carried out properly, there is the danger of subsequent damage and related safety hazards.

Parts and accessories

For your own safety, use genuine parts and accessories approved by BMW. When you purchase accessories tested and approved by BMW and Genuine BMW Parts, you simultaneously acquire the assurance that they have been thoroughly tested by BMW to ensure optimum performance when installed on your vehicle. BMW warrants these parts to be free from defects in material and workmanship. BMW will not accept any liability for damage resulting from installation of parts and accessories not approved by BMW. BMW cannot test every product made by other manufacturers to verify if it can be used on a BMW safely and without risk to either the vehicle, its operation, or its occupants. Genuine BMW Parts, BMW Accessories and other products approved by BMW, together with professional advice on using these items, are available from all BMW centers. Installation and operation of non-BMW approved accessories such as alarms, radios, amplifiers, radar detectors, wheels, suspension components, brake dust shields, telephones, including operation of any mobile phone from within the vehicle without using an externally mounted antenna, or transceiver equipment, for instance, CBs, walkietalkies, ham radios or similar accessories, may cause extensive damage to the vehicle, compromise its safety, interfere with the vehicle's electrical system or affect the validity of the BMW Limited Warranty. See your BMW center for additional information. Maintenance, replacement, or repair of the emission control devices and systems may be performed by any automotive repair establishment or individual using any certified automotive part.

California Proposition 65 Warning

California laws require us to state the following warning:

Engine exhaust and a wide variety of automobile components and parts, including components found in the interior furnishings in a vehicle, contain or emit chemicals known to the State of California to cause cancer and birth defects and reproductive harm. In addition, certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Battery posts, terminals and related accessories contain lead and lead compounds. Wash your hands after handling. Used engine oil contains chemicals that have caused cancer in laboratory animals. Always protect your skin by washing thoroughly with soap and water.

Service and warranty

We recommend that you read this publication thoroughly. Your vehicle is covered by the following warranties:

- **New Vehicle Limited Warranty**
- Rust Perforation Limited Warranty
- Federal Emissions System Defect Warranty \triangleright
- Federal Emissions Performance Warranty \triangleright
- California Emission Control System Limited Warranty

Detailed information about these warranties is listed in the Service and Warranty Information Booklet for US models or in the Warranty and Service Guide Booklet for Canadian models.

Your vehicle has been specifically adapted and designed to meet the particular operating conditions and homologation requirements in your country and continental region in order to deliver the full driving pleasure while the vehicle is operated under those conditions. If you wish to operate your vehicle in another country or region, you may be required to adapt your vehicle to meet different prevailing operating conditions and homologation requirements. You should also be aware of any applicable warranty limitations or exclusions for such country or region. In such case, please contact Customer Relations for further information.

Maintenance

Maintain the vehicle regularly to sustain the road safety, operational reliability and the New Vehicle Limited Warranty.

Specifications for required maintenance measures:

- BMW Maintenance system
- Service and Warranty Information Booklet for US models
- Warranty and Service Guide Booklet for Canadian models

If the vehicle is not maintained according to these specifications, this could result in serious damage to the vehicle. Such damage is not covered by the BMW New Vehicle Limited Warranty.

Seventh Street, SW., Washington, DC 20590. You can also obtain other information about motor vehicle safety from http://www.safercar.gov

For Canadian customers

Canadian customers who wish to report a safety- related defect to Transport Canada, Defect Investigations and Recalls, may telephone the toll-free hotline 1-800-333-0510. You can also obtain other information about motor vehicle safety from http://www.tc.gc.ca/roadsafety.

Reporting safety defects

For US customers

The following only applies to vehicles owned and operated in the US.

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration NHTSA, in addition to notifying BMW of North America, LLC, P.O. Box 1227, Westwood, New Jersey 07675-1227, Telephone 1-800-831-1117.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign.

However, NHTSA cannot become involved in individual problems between you, your dealer, or BMW of North America, LLC.


To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to http://www.safercar.gov; or write to: Administrator, NHTSA, 400





Cockpit

All around the steering wheel



- 1 Rear window safety switch 41
- 2 Power windows 40
- 3 Exterior mirror operation 53
- 4 Lamps



Instrument lighting 84



Front fog lamps* 84



Parking lamps 81



Low beams 81



Automatic headlamp control* 82

Adaptive light control* 82

High-beam Assistant* 83



Head-up Display* 117

6 Steering column stalk, left





High beams, headlamp flasher 83



High-beam Assistant* 83



Roadside parking lamps* 83



Computer 73



Settings and information about the vehicle 71

- 7 BMW X6: shifting up or down with automatic transmission 69
- 8 Instrument cluster 14
- Steering column stalk, right



Windshield wipers 67



Rain sensor 67



BMW X5: rear window wipers 68



Start/stop the engine and switch the ignition on/off 61

- 11 Ignition lock 61
- 12 Steering wheel buttons, right



Change the radio station

Select a music track

Stopping a traffic announcement



Scrolling through the redial list



Next entertainment source



Recirculated-air mode 122



Steering wheel heating* 55



Lane departure warning* 93

13 Horn, the entire surface



15 Cruise control lever



Cruise control* 108



Active cruise control* 102

16 Steering wheel buttons, left



Telephone* 216




Volume



Activate/deactivate the voice activation system* 24

17 Releasing the hood 264

Instrument cluster



- Turn signal indicator lamp
- 2 Speedometer
- 3 Indicator/warning lamps 15
- 4 Active cruise control* 102
- 5 Tachometer 72
- 6 BMW X5: current fuel consumption 72 BMW X6: engine oil temperature 72 or current fuel consumption 72
- 7 Display for
 - Clock 71

 - ▶ Indicator/warning lamps 15
 - ▶ Cruise control* 108
 - ▶ Active Cruise Control* 102

- BMW X5: reserve display for diesel exhaust fluid 249
- 8 Display for
 - Automatic transmission position 69
 - ▶ HDC Hill Descent Control 98
 - ▶ Computer 73
 - Date of next scheduled service, and remaining distance to be driven 75
 - Odometer and trip odometer 71
 - ▶ High-beam Assistant* 83
 - ▶ ▲ Check Control message present 76
 - Adaptive Drive*: Sport chassis and suspension tuning 99
- 9 Fuel gauge 73
- 10 Resetting the trip odometer 71
 Viewing service requirement display 71

Indicator/warning lamps

The concept



The indicator and warning lamps can light up in a variety of combinations and colors.

Several of the lamps are checked for proper functioning when the engine is started or the ignition is switched on, and light up briefly.

Text messages

Text messages at the upper edge of the Control Display explain the meaning of the displayed indicator and warning lamps.

Supplementary text messages

You can call up more information, e.g., on the cause of a malfunction and on how to respond, via Check Control, refer to page 76.

In urgent cases, this information will be shown as soon as the corresponding lamp comes on.

Indicator lamps without text messages

The following indicator lamps notify you that certain functions are active:

Symbol Function or system



Parking brake set, refer to page 63



Canada: parking brake set, refer to page 63



High beams/headlamp flasher, refer to page 83



Front fog lamps*, refer to page 84



Lamp flashes:

DSC or DTC controls the drive and braking forces for maintaining vehicle stability, refer to page 96



Engine malfunction with adverse effect on emissions, refer to page 269

All around the center console



- 1 Headliner 17
- 2 Control Display 19



Hazard warning system 280



Central locking system 33

- 4 Opening glove compartment 134
- 5 Automatic climate control with 2-zone control 120

Automatic climate control with 4-zone control* 124

6 Radio and CD/DVD drive* 174



7

Open the tailgate 33 36



Active seat* 49



Park Distance Control PDC* 110

Top View* 114

Backup camera* 112



HDC Hill Descent Control 97



DSC Dynamic Stability Control 96

DTC Dynamic Traction Control 97




Side View* 116

- Controller with buttons 18
- 9 Automatic Hold 64 **AUTO H**

- 10
 - Parking brake 63
- 11 Adaptive Drive* 99
- 12 Selector lever for automatic transmission 69


All around the headliner





Emergency Request* 280

4



2



Glass sunroof* 42 43

5

Interior lamps 85

3



Indicator lamp for the front passenger airbags* 87

iDrive


The concept

The iDrive combines the functions of a multitude of switches. Thus, these functions can be operated from a central location.

Using the iDrive during a trip
To avoid becoming distracted and posing
an unnecessary hazard to your vehicle's occupants and to other road users, never attempt to
use the controls or enter information unless traffic and road conditions allow this.◄

Controls at a glance

Controls



- Control Display
- 2 Controller with buttons

The buttons can be used to open the menus directly. The controller can be used to select menu items and create the settings.

The buttons can be used to open the menus directly. The controller can be used to select menu items and create the settings.

- Move in four directions, arrow 3
- Turn, arrow 4
- Push, arrow 5

Buttons on controller

Press the button	Function
MENU	Opens the main menu.
RADIO	Opens the Radio menu.
CD	Opens the CD/Multimedia menu.
NAV	Opens the Navigation menu.
TEL	Opens the Telephone menu.
BACK	Displays the previous panel.
OPTION	Opens the Options menu.


Control Display

Notes

- To clean the Control Display, follow the care instructions, refer to page 287.
- Do not place objects close to the Control Display; otherwise, the Control Display can be damaged.

Switching off

- Press the button.
- 2. "Switch off control display"



Switching on

Press the controller again to switch the screen back on.

Operating concept

Opening the main menu



Press the button.




The main menu is displayed.

All iDrive functions can be called up via the main menu.

Selecting menu items

Menu items shown in white can be selected.

1. Turn the controller until the desired menu. item is highlighted.



Press the controller.

Menu items in the Owner's Manual

In the Owner's Manual, menu items that can be selected are set in quotation marks, e.g., "Settings".


Changing between panels

After a menu item is selected, e.g., "Radio", a new panel is displayed. Panels can overlap.

Move the controller to the left. The current panel is closed and the previous panel is displayed.

The previous panel is opened again by pressing the BACK button. In this case, the current panel is not closed.

Move the controller to the right.
 A new panel is opened on top of the previous display.



White arrows pointing to the left or right indicate that additional panels can be opened.

View of an opened menu

When a menu is opened, it generally opens with the panel that was last selected in that menu. To display the first panel of a menu:

- Move the controller to the left repeatedly until the first panel is displayed.
- Press the menu button on the controller twice.

Opening the Options menu



Press the button.

The "Options" menu is displayed.



Additional options: move the controller to the right repeatedly until the "Options" menu is displayed.


Options menu

The "Options" menu consists of various areas:

- Screen settings, e.g., "Switch off control display".
- Control options for the selected main menu, e.g., for "Radio".
- If applicable, further operating options for the selected menu, for instance "Store station".

Changing settings

- Select a field.
- 2. Turn the controller until the desired setting is displayed.



3. Press the controller.

Activating/deactivating the functions

Several menu items are preceded by a checkbox. It indicates whether the function is activated or deactivated. Selecting the menu item activates or deactivates the function.


The function is activated.

The function is deactivated.

Example: setting the clock

Setting the clock

- 1. Press the button. The main menu is displayed.
- Turn the controller until "Settings" is highlighted, and then press the controller.



- 3. If necessary, move the controller to the left to display "Time/Date".
- 4. Turn the controller until "Time/Date" is highlighted, and then press the controller.



5. Turn the controller until "Time:" is highlighted, and then press the controller.



- 6. Turn the controller to set the hours and press the controller.
- 7. Turn the controller to set the minutes and press the controller.

Status information

Status field

The following information is displayed in the status field at the top right:

- Time.
- Current entertainment source.
- Sound output, on/off.
- Wireless network reception strength.
 - Telephone status.
- ▶ Traffic bulletin reception.

Status field symbols

The symbols are grouped into various categories.

Radio symbols

Symbol	Meaning
TI	Traffic bulletins* switched on.
НĎ	HD Radio* is switched on.
1.	Satellite radio* is switched on.

Telephone symbols

Symbol	Meaning
	Incoming or outgoing call*.
×	Missed call*.
atl	Wireless network reception strength* Symbol flashes: searching for network.
atl	Wireless network is not available*.
(8)	Bluetooth* is switched on.
	Roaming* is active.
\bowtie	Text message*, e-mail* was received.
 €9	Check the SIM card*.
■	SIM card* is blocked.

Symbol	Meaning
/	SIM card* is missing.
	Enter the PIN*.

Entertainment symbols

Symbol	Meaning
(3)	CD/DVD* player.
	Music collection*.
gracenote	Gracenote® database*.
	AUX-IN port.
ψ	USB audio interface*.
	Mobile phone audio interface*.

Additional symbols

Symbol	Meaning
炣	Spoken instructions* are switched off.
	Request of the current vehicle position*.

Split screen*

General information

Additional information can be displayed on the right side of the split screen, e.g., information from the computer.

In the divided screen view, the so-called split screen, this information remains visible even when you change to another menu.

Switching the split screen on and off*


- 1. Press the button.
- "Split screen"

Selecting* the display



Press the button.

- 2. "Split screen"
- Move the controller until the split screen is selected.
- Press the controller or select "Split screen content".
- 5. Select the desired menu item.



Programmable memory buttons

General information

The iDrive functions can be stored on the programmable memory buttons and called up directly, e.g., radio stations, navigation destinations, phone numbers and entry points into the menu.

The settings are stored for the remote control currently in use.

Saving a function

- 1. Highlight the function via the iDrive.
- 2. Press the desired button for more than two seconds.

Running a function

Press the button.

The function will run immediately. This means, for example, that the number is dialed when a phone number is selected.

Displaying the button assignment

Use a finger to touch the buttons. Do not wear gloves or use objects.

The key assignment is displayed at the top edge of the screen.



- To display short information: touch the button.
- To display detailed information: touch the button for an extended period.

Entering letters and numbers

- Turn the controller: select letters or numbers.
- 2. Select additional letters or numbers if needed.
- 3. "OK": confirm the entry.

Symbol	Function
l←	Press the controller: delete the letter or number.
l←	Press the controller for an extended period: delete all letters or numbers.
ш	Enter a blank space.

Switching between letters and numbers

Depending on the menu, you can switch between entering letters and numbers.

Symbol	Function
A ^B C	Enter the letters.
1 [@] +	Enter the numbers.

Switching between upper and lower case letters

Depending on the menu, you can switch between entering uppercase and lowercase letters.

Symbol	Function
▲ abc	Move the controller forward: switch from upper to lower case letters.
▲ ABC	Move the controller forward: switch from lower to upper case letters.

Entry comparison

Entry of names and addresses: the selection is narrowed down every time a letter is entered and letters may be added automatically.

The entries are continuously compared to the data stored in the vehicle.

- Only those letters are offered during the entry for which data is available.
- Destination search: town/city names can be entered using the spelling of language available on the Control Display.

Voice activation system*

The concept

- The voice activation system can be used to operate functions by means of spoken commands. The system prompts you to make your entries.
- Functions that can only be used when the vehicle is stationary cannot be operated using the voice activation system.
- The system uses a special microphone located in the area of the interior rearview mirror.
- Verbal instructions in the Owner's Manual to use with the voice activation system.

Requirements

Via the Control Display, set a language that is also supported by the voice activation system so that the spoken commands can be identified. Set the language, refer to page 80.

Using voice activation

Activating the voice activation system

- 1. Press the button on the steering wheel.
- 2. Wait for the signal.
- Say the command.
 The command appears on the Control Display.

((1/2) The symbol on the Control Display indicates that the voice activation system is active.

If no other commands are available, continue operating the function via iDrive.

Terminating the voice activation system

Briefly press the button on the steering wheel or Cancel.

Possible commands

Most menu items on the Control Display can be voiced as commands.

The available commands depend on the menu that is currently displayed on the Control Display.

The functions of the main menu have short commands.

Some list items, such as the phone book entries*, can also be selected via the voice activation system. Say the list items exactly as they are displayed on the list.

Having possible commands read aloud

To have the available commands read out loud: >Voice commands

For example, if the "Settings" menu is displayed, the commands for the settings are read out loud.

Executing functions using short commands

Functions on the main menu can be performed directly by means of short commands, irrespective of which menu item is currently selected, for instance >Vehicle status<.

List of short commands of the voice activation system, refer to page 295.

Help dialog for the voice activation system

Calling up help dialog: >Help«

Additional commands for the help dialog:

Help with examples: information about the current operating options and the most important commands for them are announced. ▶ → Help with voice activation : information about the principle of operation for the voice activation system is announced.

Example: playing back a CD

- 1. Switch on the Entertainment sound output if necessary.
- Press the button on the steering wheel.
- C D and multimedia The medium last played is played back.
- Press the button on the steering wheel.
- 5. CD track ... e.g., CD track 4.


Setting the voice dialog

You can set whether the system should use the standard dialog or a shorter version.

In the shorter variant of the voice dialog, the announcements from the system are issued in an abbreviated form.

On the Control Display:

- "Settings" 1.
- "Language/Units"
- "Speech mode:"
- 4. Select the setting.



Adjusting the volume

Turn the volume button while giving an instruction until the desired volume is set.

- The volume remains constant even if the volume of other audio sources is changed.
- The volume is stored for the remote control currently in use.

Notes on Emergency Requests


Do not use the voice activation system to initiate an Emergency Request. In stressful situations, the voice and vocal pitch can change. This can unnecessarily delay the establishment of a telephone connection.

Instead, use the SOS button*, refer to page 280, in the vicinity of the interior mirror.

Environmental conditions

- Say the commands, numbers, and letters smoothly and with normal volume, emphasis, and speed.
- Always say commands in the language of the voice activation system.
- When selecting a radio station, use the common pronunciation of the station name.
- ▶ Keep doors, windows and */panoramic glass sunroof* closed to prevent noise interference.
- Avoid making other noise in the vehicle while speaking.





Opening and closing

Remote control/key

Buttons on the remote control



- Unlocking
- 2 Locking
- 3 Opening tailgate

General information

The vehicle is supplied with two remote controls with keys.

Each remote control contains a rechargeable battery that is automatically recharged when it is in the ignition lock while the car is being driven. Use each remote control at least twice a year for longer road trips in order to maintain the batteries' charge status.

In vehicles equipped with Comfort Access*, the remote control contains a replaceable battery, refer to page 39.

The settings called up and implemented when the vehicle is unlocked depend on which remote control is used to unlock the vehicle, refer to Personal Profile.

In addition, information about service requirements is stored in the remote control, Service data in the remote control, refer to page 268.

Integrated key



Press button 1 and pull out the key.

The integrated key fits the following locks:

- Driver's door, refer to page 32.
- Cargo floor cover in cargo area, refer to page 137.

New remote controls

You can obtain new remote controls from your service center.

Loss of the remote controls

Lost remote controls can be blocked by your service center.

Personal Profile

The concept

You can set several of your vehicle's functions to suit your personal needs and preferences.

- The settings are automatically saved in the profile currently activated in the remote control.
- The remote control used is detected when the vehicle is unlocked and the stored profile is called up.
- Your personal settings will be recognized and called up again even if the vehicle has been used in the meantime by someone else with another remote control.

The individual settings are stored for a maximum of four remote controls. They are stored for two remote controls if Comfort Access* is in use.

Personal Profile settings

The following functions and settings can be stored in a profile.

More information on the settings can be found under:

- Assigning the programmable memory buttons, refer to page 22.
- Response of the central locking system when the car is being unlocked, refer to page 30.
- Automatic locking of the vehicle, refer to page **33**.
- Driver's seat, exterior mirror and steering wheel positions*, refer to page 53.
- Settings for the display on the Control Display and in the instrument cluster:
 - 12h/24h clock format, refer to page 79.
 - Date format, refer to page 79.
 - Brightness of the Control Display, refer to page 80.
 - Language on the Control Display, refer to page 80.
 - Units of measure for fuel consumption. distance covered/remaining distances, and temperature, refer to page 80.
- Show visual warning for the Park Distance Control PDC*, refer to page 111.
- ▶ Show visual warning for Top View*, refer to page 114.
- Show Side View*, refer to page 116.
- Backup camera*:
 - Function selection, refer to page 113.
 - Type of display, refer to page 114.
- ▶ Lane departure warning*: last setting, on/ off, refer to page 93.
- Head-up Display*: selection, brightness and position of the display, refer to page 117.

- Adaptive Drive*: selected chassis and suspension tuning, refer to page 99.
- Light settings:
 - Triple turn signal activation, refer to page **66**.
 - ▶ Welcome lamps, refer to page 81.
 - Headlamp courtesy delay feature, refer to page 81.
 - Daytime running lights, refer to page **82**.
 - ▶ High-beam Assistant*, refer to page **83**.
- Automatic climate control with 2-zone control: settings, refer to page 120.
- Navigation:
 - Voice activation, refer to page 163.
 - Route criteria, refer to page 161.
 - Map view settings, refer to page 164.
- **Entertainment:**
 - ▶ Tone control, refer to page 172.
 - Radio, stored stations, refer to page 180.
 - ▶ CD/multimedia, audio source listened to last, refer to page 181.
- Telephone: volume, refer to page 220.

Central locking system

The concept

The central locking system becomes active when the driver's door is closed.

The system simultaneously engages and releases the locks on the following:

- Doors.
- Tailgate.
- Fuel filler flap.

Operating from the outside

- Via the remote control.
- Via the door lock*.

In cars with Comfort Access*, via the door handles.

The following takes place simultaneously when locking/unlocking the vehicle via the remote control:

- The welcome lamps, interior lamps and courtesy lamps* are switched on and off.
- The alarm system* is armed or disarmed, refer to page 39.

Operating from the inside

Via the button for the central locking system, refer to page 33.

If the vehicle is locked from the inside, the fuel filler flap remains unlocked.

If an accident of a certain severity occurs, the central locking system unlocks automatically.

The hazard warning system and interior lamps come on.

Opening and closing: from the outside

Using the remote control

General information

Take the remote control with you
People or animals left unattended in a
parked vehicle can lock the doors from the inside. Always take the remote control with you
when leaving the vehicle so that the vehicle can
then be opened from the outside.◄

Unlocking


🔯 Press the button. The vehicle is unlocked.

You can set how the vehicle is to be unlocked.

The setting is stored for the remote control currently in use.

- 1. "Settings"
- 2. "Door locks"

3. "Unlock button:"



- Select the desired function:
 - ▶ "All doors"
 - The entire vehicle is unlocked.
 - ▶ "Driver's door only"

Only the driver's door and the fuel filler flap are unlocked. Pressing again unlocks the entire vehicle.

Convenient opening

Press and hold the button on the remote control.

The windows and the glass sunroof*/panoramic glass sunroof* open.

Locking

LOCK Press the button on the remote control.

Locking from the outside

Do not lock the vehicle from the outside if
there are people in it, as the vehicle cannot be
unlocked from inside without special knowledge.

Switching on the interior lamps, courtesy lamps*, and welcome lamps

© LOCK Press the button on the remote control with the vehicle locked.

You can also use this function to locate your vehicle in parking garages, etc.

Panic mode*

You can trigger the alarm system if you find yourself in a dangerous situation.

Press the button on the remote control for at least 3 seconds.

To switch off the alarm: press any button.

Unlocking tailgate

Press the button on the remote control for approx. 1 second and release.

The tailgate will open slightly, regardless of whether it was previously locked or unlocked.

With automatic tailgate operation*: the tailgate opens automatically.

The tailgate pivots back and up when it opens.

Ensure that adequate clearance is available before opening.

To avoid locking yourself out of the vehicle, do not place the remote control into the cargo area. The tailgate is locked again as soon as it is pushed closed.

Before and after each trip, check that the tailgate has not been inadvertently unlocked.

Provide edge protection
Sharp or angular objects can hit the rear window while driving and damage the heating wires of the rear window. Provide edge protection.

Confirmation signals from the vehicle

- "Settings"
- 2. "Door locks"
- "Flash when lock/unlock"



Retrieving the seat, mirror, and steering wheel settings*

The driver's seat, exterior mirror, and steering wheel positions* selected last are stored for the currently used remote control.

When the vehicle is being unlocked, these positions are automatically retrieved if the setting is activated.

Pinch hazard when moving back the seat If this function is used, first make sure that the footwell behind the driver's seat is empty. Failure to do so could cause injury to persons or damage to objects behind the seat as a result of a rearward movement of the seat. ◀

The adjustment procedure is interrupted:

- When a seat position switch is pressed.
- When a button of the seat and mirror memory is pressed.

Selecting automatic activation

- "Settings"
- "Door locks"
- 3. "Last seat position auto."



Malfunctions

Local radio waves may interfere with the remote control.

In this case, unlock and lock the car at the door lock with the integrated key.

If the car can no longer be locked with a remote control, the battery in the remote control is discharged. Use the remote control during an extended drive in order to recharge the battery, refer to page 28. The remote control for Comfort

Access* contains a battery that may need to be replaced, refer to page 39.

For US owners only

The transmitter and receiver units comply with part 15 of the FCC/Federal Communication Commission regulations. Operation is governed by the following:

FCC ID:

LX8766S

LX8766E

LX8CAS

LX8CAS2

Compliance statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:


- This device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modifications or changes to these devices could void the user's authority to operate this equipment.

Using the door lock

General information

Locking from the outside
Do not lock the vehicle from the outside if
there are people in it, as the vehicle cannot be
unlocked from inside without special knowledge.



When unlocking:

- 1. Turning the key once unlocks the driver's door and the fuel filler flap.
- Turning the key a second time unlocks the remaining doors and the tailgate.

Convenient operation

You can use the door lock to operate the windows and the glass sunroof*/panoramic glass sunroof*.

With the door closed, turn the key to the unlock or lock position and hold it there.

Turning the key back to the original position stops the motion.

Monitor the closing process


Monitor the closing process to ensure that
no one becomes trapped; otherwise, injuries
may result.

✓

Manual operation

If an electrical malfunction occurs, unlock or lock the driver's door using the integrated key in the door lock.

Opening and closing: from the inside



Locking and unlocking



Press the button in the vehicle.

The doors and the tailgate are locked or unlocked when the front doors are closed, but they are not secured against theft.

The fuel filler flap remains unlocked.

Automatic locking

The setting is stored for the remote control currently in use.

- 1. "Settings"
- "Door locks"
- Select the desired function:
 - "Lock if no door is opened" The vehicle locks automatically after a short period of time if a door is not opened.
 - "Lock after start. to drive" The vehicle locks automatically after you drive away.



Unlocking and opening*

- Press the button. The doors are unlocked. To open, pull the door handle above the armrest.
- Pull the door handle above the armrest twice: the door is unlocked the first time and opened the second time.

Locking



Press the button. The doors are locked.

Press the lock button of a door. To prevent you from being locked out, the opened driver's door cannot be locked using the lock button.

Take the remote control with you People or animals left unattended in a parked vehicle can lock the doors from the inside. Always take the remote control with you when leaving the vehicle so that the vehicle can then be opened from the outside. ◄

Doors

Automatic soft closing*

To close the doors, push lightly. It is closed automatically.

Danger of pinching Make sure that the closing path of the doors is clear; otherwise, injuries may result. ◀

BMW X5: upper tailgate


Opening

The tailgate pivots back and up when it opens. Ensure that adequate clearance is available before opening.

Provide edge protection

Sharp or angular objects can hit the rear window while driving and damage the heating wires of the rear window. Provide edge protection.

Opening from the inside



Press the button. The tailgate opens somewhat unless it has been locked.

Opening from the outside




Press the button, see arrow, or the button of the remote control for approx. 1 second. The tailgate opens slightly. It can be swung upward.

Opening manually

In case of an electrical malfunction:

 From the cargo area, press out the handle in the tailgate, refer to arrow, with a screwdriver and pull. The tailgate is unlocked.



Open the tailgate from the outside and press in the handle.

The tailgate is locked again as soon as it is closed.

Closing



Recessed grips on the inside trim of the tailgate can be used to conveniently pull down the tailgate.

Danger of pinching
Make sure that the closing path of the tailgate is clear; otherwise, injuries may result.

✓

Automatic soft closing*

To close the tailgate fully, press down lightly only. It is closed automatically.

Automatic tailgate operation*

Adjusting opening height

You can set how far the tailgate should open.

Adjusting the opening height When adjusting the opening height, ensure that there is a clearance of at least 4 in/ 10 cm above the tailgate. Otherwise, the ceiling may not be high enough for the open tailgate if the load situation changes. ◄

- "Settinas"
- "Tailgate"
- 3. Turn the controller until the desired opening height is selected.



Opening

The tailgate pivots back and up when it opens. Ensure that adequate clearance is available before opening.

The tailgate opens automatically to the adjusted opening height.



- Press the button on the outside of the tailgate when the vehicle is unlocked.
- Press the button in the center con-
- Press the button on the remote control for approx. 1 second and release.

The opening procedure is interrupted:

When the vehicle starts moving.

- - By pressing the button in the center console again.
- By pressing the button on the remote control for a longer period.
- By pressing the button on the outside of the tailgate.
- By pressing the button on the inside of the tailgate.

Closing

Danger of pinching

Make sure that the closing path of the tailgate is clear; otherwise, injuries may result. ◀

Function requirement:

The lower tailgate is closed and must be locked on both sides.



The tailgate closes automatically when the button on the inside of the tailgate is pressed.

To stop the closing process:

- Press the button on the inside of the tailgate.
- Press the button on the exterior of the tailgate.

Closing is not canceled when you put the vehicle into motion.

Manually opening or closing

In case of an electrical defect of the automatic tailgate operation function:

- 1. Manually release the tailgate, refer to page **34**.
- Open or close the tailgate slowly and without making sudden movements.

Do not use force to open or close

If the tailgate offers increased resistance,
do not forcefully open or close the tailgate; otherwise, injury or damage may result.

✓

BMW X5: lower tailgate

Opening



Pull the lever and swing the tailgate downward.

The opened tailgate can be loaded with up to 550 lbs/250 kg.

Closing

Fold the tailgate up and press closed.

BMW X6: tailgate

Automatic tailgate operation


Adjusting opening height

You can set how far the tailgate should open.

Adjusting the opening height
When adjusting the opening height, ensure that there is a clearance of at least 4 in/
10 cm above the tailgate. Otherwise, the ceiling may not be high enough for the open tailgate if the load situation changes.

- 1. "Settings"
- 2. "Tailgate"

Turn the controller until the desired opening height is selected.



Opening

The tailgate pivots back and up when it opens. Ensure that adequate clearance is available before opening.

The tailgate opens automatically to the adjusted opening height.



Press the button on the outside of the tailgate when the vehicle is unlocked.

Press the button in the center console.

Press the button on the remote control for approx. 1 second and release.

The opening procedure is interrupted:

- When the vehicle starts moving.
- By pressing the button in the center console again.
- By pressing the button on the remote control for a longer period.
- By pressing the button on the outside of the tailgate.
- By pressing the button on the inside of the tailgate.

Closing

Danger of pinching

Make sure that the closing path of the tailgate is clear; otherwise, injuries may result. ◄



The tailgate closes automatically when the button on the inside of the tailgate is pressed.

To stop the closing process:

Automatic closing

- ▶ Press the button on the inside of the tailgate.
- Press the button on the exterior of the tailgate.


Closing is not canceled when you put the vehicle into motion.

The tailgate closes automatically without button operation if it is weighed down by an additional weight of approx. 11 lbs/5 kg, such as snow or ice. ◀

Manually opening or closing

In case of an electrical malfunction:

 Push out cover 1 on the tailgate with a screwdriver.



Push the catch 2 in the direction of the arrow.

Open or close the tailgate slowly and without making sudden movements.

Do not use force to open or close

If the tailgate offers increased resistance,
do not forcefully open or close the tailgate; otherwise, injury or damage may result.

✓

Comfort Access*

The concept

The vehicle can be accessed without activating the remote control.

All you need to do is to have the remote control with you, e.g., in your jacket pocket.

The vehicle automatically detects the remote control when it is nearby or in the passenger compartment.

Comfort Access supports the following functions:

- Unlocking/locking of the vehicle.
- Unlocking of the tailgate separately.
- Starting the engine.
- Convenient closing.

Functional requirement


- > To lock the vehicle, the remote control must be located outside of the vehicle.
- ➤ The next unlocking and locking cycle is not possible until after approx. 2 seconds.
- The engine can only be started if the remote control is inside the vehicle.

Comparison with ordinary remote control

The functions can be controlled by pressing the buttons or via Comfort Access.

Should a short delay occur when opening or closing the windows or the glass sunroof*/panoramic glass sunroof*, the system checks whether a remote control is located in the vehicle. Please repeat opening or closing if necessary.

Unlocking



Fully grasp a door handle, arrow 1.

This corresponds to pressing the A button.

Locking



Touch the area on the door handle, arrow 2, with your finger for approx. 1 second.

This corresponds to pressing the **OLOCK** button.

To save battery power, ensure that the ignition and all electronic systems and/or power consumers are switched off before locking the vehicle.

If a remote control is detected within the vehicle, the vehicle does not lock or is unlocked again.

Convenient closing

Press the area, arrow 2, with your finger and hold.

In addition, the windows and the glass sunroof*/ panoramic glass sunroof* close.

Monitor the closing process
Watch during the closing process to be
sure that no one is injured. Removing the hand
from the door handle immediately stops the
closing process.

✓

Unlocking the tailgate separately

Press the button on the exterior of the tailgate.

This corresponds to pressing the a button.

If a remote control accidentally left in the cargo area is detected in the locked vehicle, the tailgate opens again.

The hazard warning flashers flash and a signal* sounds.

Ignition on

Pressing the Start/Stop button switches the ignition on.

When doing so, do not depress the brake pedal, otherwise the engine will start.

Starting the engine

The engine can be started or the ignition can be switched on when a remote control is inside the vehicle. It is not necessary to insert a remote control into the ignition lock, refer to page 61.

As long as no remote control is detected in the vehicle, it is only possible to restart the engine within approx. 10 seconds after it is switched off if no door has been opened.

Switching off the engine

- Remote control not in ignition lock:
 After switching off the engine, the transmission is automatically switched into transmission position P.
- Remote control in ignition lock: If transmission position N is engaged, the transmission remains in this position after the engine is switched off.

Malfunction

Comfort Access may not function properly if it experiences interference from local radio waves, e.g., mobile phones.

If this occurs, open or close the vehicle using the buttons on the remote control or use the integrated key in the door lock.

To start the engine afterward, insert the remote control into the ignition switch.

Warning lamps



The warning lamp in the instrument cluster lights up when you attempt to start the engine: the engine cannot be

started.

The remote control is not in the vehicle or has a malfunction. Take the remote control with you inside the vehicle or have it checked. If necessary, insert another remote control into the iqnition switch.



The warning lamp in the instrument cluster lights up while the engine is running: the remote control is no longer inside the vehicle.

After switching off the engine, the engine can only be started again within approx. 10 seconds if no door has been opened.



The indicator lamp in the instrument cluster comes on and a message appears on the Control Display: replace

the remote control battery.

Replacing the battery

The remote control for Comfort Access contains a battery that will need to be replaced from time to time.

- 1. Take the integrated key out of the remote control, refer to page 28.
- 2. Remove the cover.



- 3. Insert a new battery of the same type with the positive side facing upwards.
- 4. Press the cover closed.



Return used battery to a recycling collection point or to your service center.

Alarm system

The concept

The vehicle alarm system responds to:

- Opening of a door, the hood or the tailgate.
- Movements in the vehicle: interior motion sensor, refer to page 40.
- Changes in the vehicle tilt, e.g., during attempts to steal a wheel or tow the car.
 - Interruptions in battery voltage.

The alarm system briefly indicates tampering:

- By sounding an acoustic alarm.
- By switching on the hazard warning system.
- By flashing the high beams.

Arming and disarming the alarm system

When you lock or unlock the vehicle, either with the remote control or at the door lock, the alarm system is armed or disarmed at the same time.

Door lock and armed alarm system

Unlocking via the door lock will trigger the alarm on some market-specific versions.

This alarm can only be ended by pressing the button on the remote control.

Tailgate and armed alarm system

The tailgate can be opened using the remote control, even if the alarm system is armed.

Press the button on the remote control.

After the tailgate is closed, it is locked and monitored again by the alarm system. The hazard warning system flashes once.

In some market-specific versions, the tailgate can only be opened using the remote control if the vehicle was unlocked first.

Switching off the alarm

- Unlock the vehicle using the remote control, refer to page 30.
- Insert the remote control all the way into the ignition lock.

Indicator lamp on the interior rearview mirror



- The indicator lamp flashes continuously: The system is armed.
- The indicator lamp flashes after locking: The doors, hood or tailgate is not closed properly, but the rest of the vehicle is secured.

The indicator lamp flashes continuously after approx. 10 seconds. The interior motion sensor is not active.

- ➤ The indicator lamp goes out after unlocking: The vehicle has not been tampered with.
- If the indicator lamp flashes after unlocking until the remote control is inserted in the ignition, but for no longer than approx. 5 minutes:

An alarm has been triggered.

Panic mode*

In dangerous situations, trigger the alarm system:

Press the button on the remote control for at least 3 seconds.

To switch off the alarm: press any button.

Tilt alarm sensor

The tilt of the vehicle is monitored.

The alarm system responds in situations such as attempts to steal a wheel or tow the car.

Interior motion sensor

For the sensor to function properly, the windows and glass sunroof*/panoramic glass sunroof* must be closed.

Avoiding unintentional alarms

The tilt alarm sensor and interior motion sensor can be switched off together, such as in the following situations:

- In duplex garages.
- During transport on car-carrying trains, at sea or on a trailer.
- ▶ When animals are to remain in the vehicle.

Switching off the tilt alarm sensor and interior motion sensor

© LOCK Press the button on the remote control twice in succession.

The indicator lamp lights up for approx. 2 seconds and then flashes continuously.


The tilt alarm sensor and interior motion sensor remain switched off until the vehicle is locked again.

Power windows

General information

Take the remote control with you

Take the remote control with you when
leaving the vehicle so that children, for example,
cannot operate the power windows and injure
themselves.◄



Opening

Press the switch to the resistance point.

The window opens while the switch is held.

Press the switch beyond the resistance point.

The window opens automatically.

Pressing again stops the motion.

Closing

Danger of pinching Monitor the closing process and make sure that the closing path of the window is clear; otherwise, injuries may result. ◄

- Pull the switch to the resistance point. The window closes while the switch is held.
- Pull the switch beyond the resistance point.

The window closes automatically.

Pressing the switch stops the motion.

Convenient operation, refer to page 30, via the remote control or the door lock.

Convenient closing, refer to page 38, with Comfort Access*.

After the ignition is switched off

When the remote control is removed or the ignition is switched off, the windows can continue to be operated for approx. 1 minute as long as no door is opened.

Pinch protection system

If the closing force exceeds a specific value as a window closes, the closing action is interrupted. The window reopens slightly.



Danger of pinching even with pinch protection

Even with the pinch protection system, check that the window's closing path is clear; otherwise, the closing action may not stop in certain situations, e.g., if thin objects are present. ◀

Do not use window accessories Do not install any accessories in the range of movement of the windows; otherwise, the pinch protection system will be impaired. ◀

Closing without the pinch protection system

For example, if there is an external danger or if ice on the windows prevents a window from closing normally, proceed as follows:

- 1. Pull the switch past the resistance point and hold it there.
 - Pinch protection is limited and the window reopens slightly if the closing force exceeds a certain value.
- 2. Pull the switch past the resistance point again within approx. 4 seconds and hold it there.

The window closes without pinch protection.

Safety switch

With the safety switch, the rear windows are prevented from being opened or closed via the switches in the rear passenger area, such as by children.



Press the button.

The LED lights up if the safety function is switched on.

Safety switch for rear operation Press the safety switch when transporting children in the rear; otherwise, injury may result if the windows are closed without supervision. ◀

Roller sunblinds for the rear side windows*

Pull the loop of the roller sun blind and hook onto bracket.



Do not open the window while the roller sunblind is tilted

Do not open the window while the roller sunblind is tilted; otherwise, there is a risk of damage at high speeds that may result in personal injury.◀

X5: panoramic glass sunroof*

General information

The glass sunroof and the sliding visor can be operated together or separately using the switch.

Danger of pinching

Monitor the closing process and make sure that the closing path of the glass sunroof is clear; otherwise, injuries may result.

■

Take the remote control with you

Take the remote control with you when
leaving the vehicle so that children, for example,
cannot operate the roof and injure themselves.



Tilting the glass sunroof



Press the switch.

The closed sunroof is tilted and the sliding visor opens slightly.

Do not use force to close the sliding visor
Do not use force to close the sliding visor
with the glass sunroof in its tilted position, otherwise the mechanism will be damaged.◄

Opening/closing the sliding visor

You can move the sliding visor independently with the sunroof closed or tilted.



- Press the switch in the desired direction to the resistance point and hold it there.
 - The sliding visor moves while the switch is being held.
- Press the switch in the desired direction past the resistance point.
 - The sliding visor moves automatically. Pressing the switch again stops the motion.

Opening/closing the glass sunroof

With the sliding visor open, proceed as described under Sliding visor.

Opening/closing the glass sunroof and sliding visor together



Press the switch twice in the desired direction past the resistance point.

The glass sunroof and sliding visor move together. Pressing the

switch again stops the motion.

Convenient operation, refer to page 30, via the remote control or the door lock.

Convenient closing, refer to page 38, with Comfort Access*.

Comfort function



- Press the switch twice with the sunroof open:
 - The sunroof is raised.
- When the sunroof is raised, briefly press the switch twice in the opening direction:

The sunroof is opened all the way.

Comfort position

In the comfort position, the roof is not fully open. This reduces wind noise in the passenger compartment.

Each time the glass sunroof is opened or closed all the way, it stops in the comfort position. If desired, continue the motion following this with the switch.

After the ignition is switched off

The roof can still be operated for approx. 1 minute, as long as no door has been opened.

Pinch protection system

If the closing force when closing the glass sunroof exceeds a certain value, the closing movement is stopped, beginning at approximately one-third of the opening in the roof, or from the tilted position during closing.

The roof and the sliding visor open a short distance.



Danger of pinching even with pinch pro-

Despite the pinch protection system, check that the roof's closing path is clear; otherwise, the closing action may not be interrupted in certain extreme situations, such as when thin objects are present.◀

Closing without the pinch protection system

For example, if there is an external danger, proceed as follows:

Press the switch forward beyond the resistance point and hold. The roof closes without the pinch protection system.

Initialization after a power failure

After a power failure, it is only possible to raise the roof, if necessary.

Have the system initialized by your service center.

BMW X6: glass sunroof*, electric

General information

Danger of pinching

Monitor the closing process and make sure that the closing path of the glass sunroof is clear; otherwise, injuries may result. ◀

Take the remote control with you Take the remote control with you when leaving the vehicle so that children, for example, cannot operate the roof and injure themselves. ◀



Tilting the glass sunroof



Press the switch.

The closed sunroof is tilted and the sliding visor opens slightly.

Do not use force to close the sliding visor Do not use force to close the sliding visor with the glass sunroof in its tilted position, otherwise the mechanism will be damaged. ◀

Opening/closing the glass sunroof



- Press the switch in the desired direction to the resistance point and hold it there.
 - The glass sunroof moves while the switch is being held.
- Press the switch in the desired direction past the resistance point.

The glass sunroof moves automatically. Pressing the switch again stops the motion. The glass sunroof and sliding visor can be opened together. Close the sliding visor manually.

Convenient operation, refer to page 30, via the remote control or the door lock.

Convenient closing, refer to page 38, with Comfort Access*.

Opening/closing the glass sunroof automatically

Press the switch beyond the resistance point.

The following movements are also automatic:

- Pressing the switch with the sunroof open: the sunroof is tilted fully.
- Pressing the switch in the Open direction with the sunroof tilted: the sunroof is opened fully.

Pressing the switch again stops the motion.

Comfort position

In the comfort position, the roof is not fully open. This reduces wind noise in the passenger compartment.

Each time the glass sunroof is opened or closed all the way, it stops in the comfort position. If desired, continue the motion following this with the switch.

After the ignition is switched off

The roof can still be operated for approx. 1 minute, as long as no door has been opened.

Pinch protection system

If the closing force when closing the glass sunroof exceeds a certain value, the closing movement is stopped, beginning at approximately the middle of the opening in the roof, or from the tilted position during closing.

The glass sunroof opens again fully.



Danger of pinching even with pinch protection

Despite the pinch protection system, check that the roof's closing path is clear; otherwise, the closing action may not be interrupted in certain extreme situations, such as when thin objects are present.◀

Closing without the pinch protection system

For example, if there is an external danger, proceed as follows:

- Press the switch forward beyond the resistance point and hold. The pinch protection system is limited and the sunroof opens slightly if the closing force exceeds a certain value.
- Within about 4 seconds, slide the switch forward again beyond the resistance point and hold it there. The roof closes without the pinch protection system.

Initialization after a power failure

After a power failure, it is only possible to raise the roof, if necessary.

Have the system initialized by your service center.

Adjusting

Sitting safely

The ideal seating position can make a vital contribution to relaxed, fatigue-free driving.

The seating position plays an important role in an accident in combination with:

- Safety belts, refer to page 50.
- Head restraints, refer to page 51.
- Airbags, refer to page 86.

Seats

Note before adjusting

Do not adjust the seat while driving Never attempt to adjust the driver's seat while driving.

The seat could respond with unexpected movement and the ensuing loss of vehicle control could lead to an accident.◀




Do not incline the backrest too far to the

Do not incline the backrest on the front passenger side too far to the rear during driving. Otherwise, there is the danger of sliding under the safety belt in an accident. This would eliminate the protection normally provided by the belt. ◀

Adjusting manually*

Forward/backward



Pull the lever and slide the seat into the desired position. After releasing the lever, move the seat forward or back slightly to make sure it engages properly.

Thigh support*



Pull the lever and move the thigh support forward or back.

Adjusting electrically



- 1 Forward/backward
- 2 Height
- 3 Seat tilt




4 Backrest Differs depending on seat:



- 1 Backrest
- 2 Height

Additional depending on seat:



- 1 Backrest width*
- 2 Shoulder support*
- 3 Thigh support*
- 4 Lumbar support*

Backrest width*

The width of the backrest can be changed with the side wings to adjust the side support to your own needs.

Shoulder support*

This also supports the back in the shoulder area, This creates a relaxed sitting position and helps relieve stress on the shoulder muscles.

The shoulder support is also used to adjust the distance of the head restraint from the back of the seat occupant's head.

Lumbar support*



You can also adjust the contour of the backrest to obtain additional support in the lumbar region.

The upper hips and spinal column receive supplementary support to help you maintain a relaxed, upright sitting position.

- Increase or decrease curvature:
 Press front or rear section of switch.
- Shift curvature up or down:

Press upper or lower section of switch.

BMW X5: rear seats


2nd row seats

If the row of seats is divided*, each side can be adjusted separately.

Do not adjust the seat while driving Never adjust the 2nd row seats while the vehicle is moving, as otherwise the passengers on the 3rd row seats could be injured.

Make sure that the locking devices of the 2nd row seats engage properly. Otherwise the restraining effect of the safety belts during an accident could be reduced.◀


Longitudinal direction*



- 1. Pull the lever and slide the seat into the desired position.
- 2. Release the lever and move the seat slightly forward or back so that it engages properly.

Backrest*

The backrests can be adjusted in four steps.



Pull the lever and apply weight to or remove weight from the backrest as needed.

Access to 3rd row seats*



Pull the lever and fold the seat forward.

The handle recess on the interior trim of the door pillar makes climbing in easier.



Keep the footwell under the 2nd row seats clear

When folding back the 2nd row seats, make sure that the footwell under the 2nd row seats is clear. Otherwise persons in the 3rd row seats could be injured or objects damaged. ◀



Warning lamp for the 2nd row seats: lights up if the 2nd row seats are not locked. A message also appears on

the Control Display.

3rd row seats*

The 3rd row seats are divided and offer space for two persons.

Folding up backrest

Before folding up the backrest, remove the luggage compartment roller cover, refer to

page 132, and, if necessary, slide the 2nd row seats slightly forward.

 Pull the lever, refer to arrow. The backrest is unlocked.



2. Fold up and engage the backrest.



Ensure that the lock is securely engaged

Make sure that the catch engages securely. If it is not properly engaged, transported cargo could enter the passenger compartment during braking or evasive maneuvers and endanger the vehicle occupants. ◀

Push the head restraints into the top position.

Folding backrest down


- 1. Push the head restraints down, refer to page 52.
- Pull the lever, refer to arrows. The backrests are released.



3. Fold the backrest down.

Seat heating*

Front



The temperature setting progresses one step through its control sequence each time you press the button. The maximum temperature is reached when three LEDs are lit.

To switch off: press and hold the button.

The temperature is reduced, if need be, down to no heat in order to reduce the load on the battery. The LEDs remain lit.


Rear



Operation similar to front seat heating, without temperature distribution.

Active seat ventilation* and seat heating*

Front



- Seat heating
- 2 Active seat ventilation

Press button 1 or 2 once depending on the temperature or ventilation position. The LED in the respective button lights up.

The temperature and ventilation levels are displayed in bar form on the Control Display. A display of three bars indicates the highest level of seat heating or seat ventilation.

The air flow rate may be reduced or the blower may be switched off entirely to save on battery power. The LEDs remain lit.

To switch off: press and hold button 1 or 2.

Temperature distribution without active seat ventilation

The heat output can be distributed variously in the seat cushion and the backrest.

- 1. Press button 1.
- 2. "Seat heating distribution"




Turn the controller to adjust the distribution. The setting is applied.

Temperature distribution with active seat ventilation

The heat output can be distributed variously in the seat cushion and the backrest.

- 1. Press button 1.
- "Seat heating distribution"




Turn the controller to adjust the distribution.The setting is applied.

Heated rear seats

Operation similar to front seat heating, without temperature distribution, refer to page 48.

Active seat*



The seat cushion is actively varied by alternately raising and lowering the right and left half of the seat cushion. This reduces muscular tension and fatigue to help prevent lower back pain.

Press the button to switch on; the LED lights up.

The action of the system is reduced and if need be, switched off in order to reduce the load on the battery. The LED remains lit.

When the active seat is switched off, it can take up to 1 minute before the two halves of the seat cushion have returned to their initial position.

Safety belts

General information

Always make sure that safety belts are being worn by all occupants before driving away.

Although airbags enhance safety by providing added protection, they are not a substitute for safety belts.

Number of safety belts

Putting on the belt

pact and injure the abdomen.

Your vehicle has been fitted with safety belts for the safety of you and your passengers.

- ▶ BMW X5: five or seven* safety belts.
- BMW X6: four or five* safety belts.

Notes

One person per safety belt

Never allow more than one person to wear
a single safety belt. Never allow infants or small
children to ride on a passenger's lap. ◄

Lay the belt, without twisting, snugly across the lap and shoulders, as close to the body as possible. Make sure that the belt lies low around the hips in the lap area and does not press on the abdomen. Otherwise, the belt can slip over the hips in the lap area in a frontal im-

The safety belt must not lie across the neck, rub on sharp edges, be routed over solid or breakable objects, or be pinched. ◀

Avoid wearing clothing that prevents the belt from fitting properly, and pull the shoulder belt periodically to readjust the tension across your lap; otherwise, the retention effect of the safety belt may be reduced.

Using the middle safety belt
If the middle safety belt in the rear is used,
the larger section of the backrest must be
locked. Otherwise, the safety belt will not have
a restraining effect.

Buckling the belt



Make sure you hear the latch plate engage in the belt buckle.

Unbuckling the belt

- 1. Hold the belt firmly.
- 2. Press the red button in the belt buckle.
- 3. Guide the belt back into its reel.

The shoulder strap's anchorage point will be correct for adult seat occupants of every build if the seat is correctly adjusted, refer to page 45.

The two rear safety belt buckles integrated into the rear seat are for passengers sitting on the left and right. The belt buckle* embossed with the word CENTER is intended exclusively for use by passengers riding in the center position.

Safety belt reminder for the driver's and front passenger seat



The indicator lamp lights up and a signal sounds. In addition, a message appears on the Control Display. Check

whether the safety belt has been fastened correctly.

The safety belt reminder is active at speeds above approx. 5 mph/8 km/h. It can also be activated if objects are placed on the front passenger seat.

Damage to safety belts

In the case of strain caused by accidents or damage:

Have the safety belts, including the safety belt tensioners, replaced and have the belt anchors checked.

Checking and replacing safety belts Have the work performed only by your service center; otherwise, it cannot be ensured that this safety feature will function properly. ◀

Belt-force limiter

The effect of the belt-force limiter on the driver's seat is dependent on the position of the driver's seat.

To maintain the long-term accuracy of this function, the driver's seat must be calibrated if a corresponding message is displayed on the Control Display.

Calibrating driver's seat



The warning lamp lights up. A message also appears on the Control Display. Please calibrate the driver's seat.

- 1. Move the driver's seat forward until it stops.
- 2. Move the driver's seat forward again. It briefly moves toward the front in the process.
- 3. Set the desired seating position again.

The calibration is completed when the message on the Control Display disappears. Should this message continue to be displayed, repeat the calibration. If the message does not disappear even after repeated calibration, have the system checked as soon as possible.



Do not carry out calibration while the vehicle is moving

Never carry out calibration while the vehicle is moving, as this can cause accidents.

Make sure that no persons or objects become wedged during the calibration process, as this can cause injuries or damage. ◄

Head restraints

Correctly adjusted head restraints

A correctly adjusted head restraint reduces the risk of spinal injury in the event of an accident.

Adjusting the head restraint

Correctly adjust the head restraints of all occupied seats; otherwise, there is an increased risk of injury in an accident. ◀

BMW X5: push the head restraints of the 3rd row seats* into the top position.

Height

Adjust the head restraint so that its center is approx. at ear level.

Distance

Adjust the distance so that the head restraint is as close as possible to the back of the head.

Active front head restraints

In the event of a rear-end collision of sufficient severity, the active head restraint reduces the distance to the head.



Reduced protective function

- Do not use seat or head restraint cov-
- Do not hang objects, e.g., clothes hangers, directly on the head restraints.
- Only attach accessories approved by BMW to the seat or head restraint.

Otherwise, the protective function of the active head restraint will be impaired and the personal safety of the occupants will be endangered.


Have the active head restraints reset after they are triggered in a rear-end collision. Have this work performed by the service center only; otherwise, this safety feature with not be operational.◀

Please contact the service center if the front head restraints need to be removed or installed.

Front seats: adjusting the height

Adjust the head restraint so that its center is approx. at ear level.

Electrical



Adjusting electrically.

Front seats: adjusting the distance from the back of the head



Press the button and pull the headrest cushion forward or push it back.


Compromised performance
Do not place any objects behind the headrest cushion. Otherwise, you can impair the
proper function of the head restraint.

✓

Comfort seat*


The distance from the back of the seat occupant's head can be adjusted using the shoulder support, refer to page 46.

Adjusting side extensions



You can fold the side extensions on the head restraint forward for increased lateral support in the resting position.

BMW X5: rear seats and 3rd row seats* Adjusting the height



- To raise: pull.
- ▶ To lower: press the button, arrow 1, and push the head restraint down.

In vehicles equipped with 3rd row seats, the height of the middle head restraint is not adjustable.

Removing

- 1. Pull the head restraint upward to the stop.
- 2. Press the button, arrow 1, and pull the head restraint out completely.

BMW X6: rear seats

The head restraints in the rear cannot be adjusted and cannot be removed.


Seat, mirror, and steering wheel memory*

General information

Two different driver's seat and front passenger seat* positions, exterior mirror positions and steering wheel positions* can be stored and retrieved.

The adjustment of the backrest width and the lumbar support is not stored in the memory.

Storing



- 1. Switch on the radio ready state or the ignition, refer to page 61.
- 2. Set the desired seat, exterior mirror and steering wheel positions.
- Press the button. The LED in the button lights up.
- 4. Press the desired memory button 1 or 2. The LED goes out.

If the M button is pressed accidentally:



Press the button again. The LED goes

Calling up settings



Do not retrieve the memory setting while drivina

Do not retrieve the memory setting while driving, as an unexpected seat movement could result in an accident.◀

Comfort function

- 1. Open the driver's door after unlocking or switch on the radio ready state, refer to page **61**.
- 2. Briefly press the desired memory but-

The seat is automatically moved to the stored position.

The procedure stops when a switch for setting the seat or one of the memory buttons is pressed.

Safety mode

- 1. Close the driver's door and switch the ignition on or off, refer to page 61.
- Press and hold the desired memory button 1 or 2 until the setting procedure is completed.

Mirrors

Exterior mirrors


General information

The mirror on the passenger side is more curved than the driver's mirror.

Estimating distances correctly

Objects reflected in the mirror are closer than they appear. Do not estimate the distance to the traffic behind you based on what you see in the mirror, as this will increase your risk of an accident.◀

At a glance



- 1 Adjusting
- 2 Left/right, Automatic Curb Monitor*
- 3 Folding in and out*

Selecting a mirror

To change over to the other mirror: Slide the mirror changeover switch.

Adjusting electrically



The setting corresponds to the direction in which the button is pressed.

Storing positions*

Seat and mirror memory*, refer to page 53.

Adjusting manually

If an electrical malfunction occurs, for example, press the edges of the mirror glass.

Automatic Curb Monitor*

When the reverse gear is engaged, the mirror glass tilts downward slightly on the front passenger side. This improves your view of the curb and other low-lying obstacles when parking, for example.

Activating

- 1. Slide the mirror changeover switch to the driver's side mirror position.
- Engage reverse gear or move the selector lever to position R.

Deactivating

Slide the mirror changeover switch to the passenger's side mirror position.

Fold in and out*

Press button 3.

Possible up to approx. 15 mph/20 km/h.

For example, this is advantageous

- In car washes.
- In narrow streets.
- For folding back mirrors that were folded away manually.

Mirrors that were folded in are folded out automatically at a speed of approx. 25 mph/40 km/h.

A

Fold in the mirror in a car wash

Before entering an automatic car wash, fold in the exterior mirrors by hand or with the button; otherwise, they could be damaged, depending on the width of the vehicle.◀

Automatic heating

Depending on the external temperature, both exterior mirrors are automatically heated when the engine is running or the ignition is switched on.

Interior rearview mirror


Reducing the blinding effect



From behind when driving at night: turn the knob.

rerence

Interior and exterior mirrors, automatic dimming feature*



Two photocells are used for control:

- In the mirror glass, see arrow.
- On the back of the mirror.

For proper operation:

- Keep the photocells clean.
- Do not cover the area between the inside rearview mirror and the windshield.

Steering wheel


General information

Do not adjust while driving
Do not adjust the steering wheel while
driving; otherwise, an unexpected movement
could result in an accident.

◀

Adjusting

Mechanical*




- 1. Fold the lever down.
- Move the steering wheel to the preferred height and angle to suit your seating position.

Fold the lever back.

Do not use force to swing the lever back.

Do not use force to swing the lever back
up; otherwise, the mechanism will be damaged.

Electric*



The steering wheel can be adjusted in four directions.

Storing steering wheel positions, refer to Seat, mirror, and steering wheel memory, refer to page 53.

Easy entry/exit*

To facilitate entry and exit, the steering wheel temporarily moves into the uppermost position.

Steering wheel heating*

Switching on/off



Press the button.

- On: the LED lights up.
- Off: the LED goes out.

Transporting children safely

The right place for children

Note

Children in the vehicle
Do not leave children unattended in the vehicle; otherwise, they could endanger themselves and other persons, e.g., by opening the doors.

Children should always be in the rear

Accident research shows that the safest place for children is on the rear seat.

Transporting children in the rear Transport children younger than 13 years of age or shorter than 5 ft/150 cm on the 2nd row seats only, using child restraint fixing systems suitable for the age, weight, and height of the child. Otherwise, there is the increased danger of injury in an accident.

Children 13 years of age or older must wear a safety belt as soon as a suitable child restraint fixing system can no longer be used, due to their age, weight and size. ◄

Children on the front passenger seat

Should it be necessary to use a child restraint fixing system on the front passenger seat, make sure that the front and side airbags on the front passenger side are deactivated. Automatic deactivation of front passenger airbags, refer to page 87.

Deactivating the front passenger airbags If a child restraint fixing system is used in the front passenger seat, the front passenger airbags must be deactivated; otherwise, there is an increased risk of injury to the child when the airbags are triggered, even with a child restraint fixing system.

Installing child restraint fixing systems

Notes



Manufacturer's information for child restraint fixing systems

To select, mount and use child restraint fixing systems, observe the information provided by the system manufacturer; otherwise, the protective effect can be impaired.◄



Note the following in vehicles equipped with 3rd row seats

BMW X5: in vehicles with 3rd row seats*, make sure that the seat of the 2nd row seats on which the child restraint fixing system is mounted is properly locked. Otherwise, there is an increased risk of injury for the child in an accident.

Do not mount child restraint fixing systems on the 3rd row seats, as otherwise the protection provided by these child restraint fixing systems may be reduced.◀

BMW X5: before mounting a child restraint fixing system in the center seat of the 2nd row seats, move the outer seat cushions and backrests into the rearmost positions.

On the front passenger seat

After installing a child restraint fixing system on the front passenger seat, ensure that the front and side airbags on the front passenger side are deactivated.

Deactivating the front passenger airbags If a child restraint fixing system is used in the front passenger seat, the front passenger airbags must be deactivated; otherwise, there is an increased risk of injury to the child when the airbags are triggered, even with a child restraint fixing system.

Seat position and height

Before installing a child restraint fixing system, move the front passenger seat as far back as possible and adjust its height to the highest position to obtain the best possible position for the belt and to offer optimal protection in the event of an accident.

Do not change the seat position and height after this.

Backrest width*

Before mounting a child restraint fixing system on the front passenger seat, open the backrest width, refer to page 46, completely. Do not change the backrest width after this.

Backrest width for the child seat Before installing a child restraint fixing system in the front passenger seat, the backrest width must be opened completely. Do not change the adjustment after this; otherwise, the stability of the child seat will be reduced. ◀

Child seat security



The rear safety belts

- BMW X5: all safety belts of the 2nd and 3rd row seats*
- BMW X6: all safety belts of the 2nd row seats

And the safety belt for the front passenger can be locked to prevent extension in order to permit attachment of child restraint fixing systems.

Locking the safety belt

- 1. Pull out the belt webbing completely.
- 2. Secure the child restraint fixing system with the belt.

Allow the belt webbing to be pulled in and pull it taut against the child restraint fixing system. The safety belt is locked.

Unlocking the safety belt

- 1. Open the belt buckle.
- Remove the child restraint fixing system.
- 3. Allow the belt webbing to be pulled in completely.

LATCH child restraint fixing system

LATCH: Lower Anchors and Tether for Children.

Note



Manufacturer's information for LATCH child restraint fixing systems

To mount and use the LATCH child restraint fixing systems, observe the operating and safety information from the system manufacturer; otherwise, the level of protection may be reduced. ◀

Mounts for the lower LATCH anchors



Correctly engage the lower LATCH an-

Make sure that the lower LATCH anchors have properly engaged and that the child restraint fixing system is resting snugly against the backrest; otherwise, the degree of protection offered may be reduced. ◀



The mounts for the lower LATCH anchors are located at the points indicated by the arrows.

Mounting LATCH child restraint fixing systems

- Mount the child restraint fixing system; refer to the operating instructions of the system.
- Ensure that both LATCH anchors are properly connected.

Child restraint fixing system with a tether strap

Mounting points

LATCH mounting eyes


Only use the mounting eyes for the upper LATCH retaining strap to secure child restraint fixing systems; otherwise, the mounting eyes could be damaged.

BMW X5



There are three additional mounting points for child restraint fixing systems with a tether strap on the 2nd row seats, refer to arrows. Fold out before using the center mounting point.

BMW X6



For child restraint fixing systems with tether strap, there are three additional mounting points


on the back of the rear seat backrests, see arrows.

Retaining strap guide

Retaining strap

Make sure the upper retaining strap does not run over sharp edges and is not twisted as it passes to the top anchor. Otherwise, the strap will not properly secure the child restraint fixing system in the event of an accident.

BMW X5




- 1 Direction of travel
- 2 Head restraint
- 3 Hook for upper retaining strap
- 4 Mounting point
- 5 Backrest
- 6 Upper retaining strap of child restraint fixing system

When using the cargo cover, pass the upper retaining strap between the backrest of the 2nd row seats and the cargo cover.






BMW X6: outer rear seats



- 1 Direction of travel
- 2 Head restraint
- 3 Hook for upper retaining strap
- 4 Mounting point
- 5 Backrest
- 6 Upper retaining strap of child restraint fixing system

When using the cargo cover, pass the upper retaining strap between the rear seat backrest and the cargo cover.

BMW X6: center rear seat



- Direction of travel
- 2 Head restraint
- 3 Strap guide
- 4 Hook for upper retaining strap
- 5 Mounting point
- 6 Backrest
- 7 Upper retaining strap of child restraint fixing system

When using the cargo cover, pass the upper retaining strap between the rear seat backrest and the cargo cover.



Attaching the retaining strap to the backrest of the 2nd row seats

BMW X5

On outer seats:

- 1. Slide the head restraint upward.
- Guide the upper retaining strap between the supports of the head restraint.
- Attach the upper retaining strap to the mounting point with the hook.
- Slide the head restraint into the bottom position.
- 5. Pull the upper retaining strap taut.

On the center seat when equipped with two rows of seats:

- Fold the center armrest somewhat toward the front.
- Guide the tether strap through the opening in the center armrest.



- 3. Fold back and engage the center armrest.
- 4. Hook in tether strap on mounting point.
- 5. Pull tether strap taut.

On the center seat when equipped with three rows of seats:


- Slide the head restraint upward.
- Guide the tether strap between the head restraint brackets.
- 3. Hook in the tether strap on the mounting point with the hook.
- Slide the head restraint into the bottom position.
- 5. Pull tether strap taut.

BMW X6

- 1. Route the upper retaining strap over the middle of the head restraint.
- 2. Attach the upper retaining strap to the mounting point with the hook.
- Pull the retaining strap taut until it compresses the cushion of the head restraint, thus preventing the strap from sliding off.

Locking the doors and windows

Rear doors



Push the locking lever on the rear doors down. The door can now be opened from the outside only.

Safety switch for the rear



Press the button on the driver's door if children are being transported in the

rear.

This locks the rear window switches so that the windows cannot be operated from the rear: safety switch, refer to page 41.

Driving

Ignition lock

Insert the remote control into the ignition lock



Insert the remote control all the way into the iqnition lock.

Radio ready state is switched on. Individual electrical consumers can operate.

Comfort Access*

If the car is equipped with Comfort Access, only insert the remote control into the ignition lock, refer to page 37, under special circumstances.

Removing the remote control from the ignition lock



Do not forcibly pull the remote control out of the ignition lock

Do not forcibly pull the remote control out of the ignition lock as this may cause damage. ◀

Before removing the remote control, push it all the way in to release the locking mechanism.

The ignition is switched off if it was on.

Start/Stop button



Pressing the Start/Stop button switches the ignition on or off and starts the engine.

The engine starts if the brake pedal is pressed when you press the Start/Stop button.

Radio ready state

Individual electrical consumers can operate. The time and the external temperature are displayed in the instrument cluster.

Radio ready state is switched off automatically:

- When the remote control is removed from the ignition lock.
- ▶ With Comfort Access*, refer to page 37, by touching the area above the door lock.

Ignition on

All electrical consumers can operate. The odometer and trip odometer are displayed in the instrument cluster.

To save battery power when the engine is off, switch off the ignition and any unnecessary electronic systems/power consumers.

Radio ready state and ignition off

All indicator and warning lamps as well as displays in the instrument cluster go out.



Transmission position P with the ignition

When the ignition is switched off, position P is engaged automatically. When in an automatic

car wash, for example, ensure that the ignition is not switched off accidentally. ◀

For example, the ignition is not switched off in the following situations:

- The brake is applied.
- The low beams are switched on

Starting the engine

General information

Enclosed areas
Do not let the engine run in enclosed
areas; otherwise, breathing of exhaust fumes
may lead to loss of consciousness and death.
The exhaust gases contain carbon monoxide, an
odorless and colorless but highly toxic gas.

Unattended vehicle

Do not leave the car unattended with the

engine running; otherwise, it presents a potential source of danger.

Before leaving the car with the engine running, set the parking brake and place the transmission in position P or neutral to prevent the car from moving.◀

Frequent starting in quick succession
Avoid repeated futile attempts at starting
the car and avoid starting the car frequently in
quick succession. Otherwise, the fuel is not
burned or is inadequately burned, and there is
the danger of overheating and damaging the
catalytic converter.

Do not wait for the engine to warm up while the vehicle remains stationary. Start driving right away, but at moderate engine speeds.

Starting the engine



Remote control in the ignition lock or, with Comfort Access, inside the vehicle, refer to page 37.

- 1. Depress the brake pedal.
- 2. Press the Start/Stop button.

The starter operates automatically for a certain time, and stops automatically as soon as the engine has started.

Diesel engine

If the engine is cold and temperatures are below approx. 32 °F/0 °C, the start process may be delayed somewhat due to automatic preheating.

A message is displayed.

Engine stop

General information

Take the remote control with you

Take the remote control with you when
leaving the vehicle so that children, for example,
cannot operate the windows and injure themselves.◄

A

Set the parking brake and further secure the vehicle as required

Set the parking brake firmly when parking; otherwise, the vehicle could roll. On steep upward and downward inclines, further secure the vehicle, for example, by turning the steering wheel in the direction of the curb.

Switching off the engine

Procedure

- 1. Engage transmission position P with the vehicle stopped.
- Press the Start/Stop button.
- Set the parking brake.
- 4. Remove the remote control from the ignition lock, refer to page 61.

Before driving into a car wash

The vehicle is able to roll when the following steps are adhered to:

- With Comfort Access*: insert the remote control in the ignition lock.
- 2. Depress the brake pedal.
- 3. Engage transmission position N.
- 4. Release the parking brake or deactivate Automatic Hold.
- 5. Switch the engine off.

Transmission position P will be engaged:

- Automatically after approx. 30 minutes.
- If you remove the remote control from the ignition lock.

Parking brake

The concept

The parking brake is primarily intended to prevent the vehicle from rolling while parked; it brakes the rear wheels.

The parking brake can be set manually or automatically:


- Manual: by pulling and pushing the switch.
- Automatic: by activating Automatic Hold.

Setting manually



Pull the button. The parking brake is set.

The indicator lamp lights up in red. The **PARK** parking brake is set.



To set the parking brake, the remote control does not need to be in the ignition lock.



Set the parking brake and further secure the vehicle as required

Set the parking brake firmly when parking; otherwise, the vehicle could roll. On steep upward and downward inclines, further secure the vehicle, for example, by turning the steering wheel in

While driving

Use while driving:

Pull the switch and hold it. The vehicle brakes hard while the button is being pulled.

☐ The indicator lamp lights up in red, a sig-PARK nal sounds and the brake lamps light up.



Indicator lamp in Canadian models.

If the vehicle is braked to a speed of approx. 2 mph/3 km/h, the parking brake remains set.

Releasing manually



Press the button with the brake depressed.

The LED and indicator lamp go out. PARK

Indicator lamp in Canadian models.

Take the remote control with you Take the remote control with you when leaving the vehicle so that children, for example, cannot release the parking brake. ◄

Automatic Hold

The concept

This system assists the driver by automatically setting and releasing the brake, such as when moving in stop-and-go traffic.

The vehicle is automatically held in place when it is stationary.

On inclines, the system prevents the vehicle from rolling backward when driving away.

For your safety

Automatic Hold is deactivated automatically and the parking brake is set when:

- The engine is switched off.
- A door is opened and the driver's safety belt is unbuckled.
- The vehicle is braked to a standstill with the parking brake while driving.

The indicator lamp switches from green PARK to red and the letters AUTO H go out.

Indicator lamp in Canadian models.



Before driving away:


- Release the parking brake manually.
- Reactivate Automatic Hold.



Leaving the vehicle with the engine running

Before leaving the vehicle with the engine running, engage position P of the automatic transmission and ensure that the parking brake is set. Otherwise, the vehicle may begin to roll. ◀

Activating



Press the button. The LED in the button lights up and the indication AUTO H appears in the instrument panel.

Automatic Hold is activated.

If the vehicle is being held by Automatic PARK Hold, the indicator light in the instrument panel also lights up in green.

Indicator lamp in Canadian models.

Deactivating

Press the button again, the LED in the button and the indication AUTO H in the instrument panel go out.

Automatic Hold is deactivated.

If the vehicle is being held by Automatic Hold, then press on the brake pedal to deactivate it.

When the parking brake is set manually, refer to page 63, Automatic Hold is deactivated automatically.

Driving

Automatic Hold is activated: the vehicle is automatically secured against rolling when it stops.

The indicator lamp lights up in green. PARK



Indicator lamp in Canadian models.

Step on the accelerator pedal to drive off. The brake is released automatically.

The indicator lamp goes out.

Before driving into a car wash Deactivate Automatic Hold; otherwise, the parking brake will be set when the vehicle is stationary and the vehicle will no longer be able to roll.∢

Parking

The parking brake is automatically set if the engine is switched off while the vehicle is being held by Automatic Hold.

The indicator lamp changes from green PARK to red.



Indicator lamp in Canadian models.

The parking brake is not set if the engine is switched off while the vehicle is coasting to a halt. Automatic Hold is deactivated.

Take the remote control with you Take the remote control with you when leaving the vehicle so that children, for example, cannot release the parking brake. ◀

Malfunction

In the event of a failure or malfunction of the parking brake, secure the vehicle against rolling using a wheel chock, for example, when leaving it.

Releasing the parking brake manually

In the event of an electrical power loss or electrical malfunction, you can release the parking brake manually.

Secure the vehicle against rolling Before releasing the parking brake manually, and whenever you park the vehicle with the parking brake released, ensure that position P of the automatic transmission is engaged. Note the display in the instrument cluster.

In addition, secure the vehicle against rolling, e.g. with a wheel chock. Otherwise there is a danger that the vehicle could roll if parked on a steep slope.◀

Jump-starting and towing, refer to page 282.

Unlocking

- 1. Open the left-hand side panel in the cargo area.
- 2. Remove the first aid kit* and the warning triangle*. Close the bracket of the warning triangle.
- Insert the releasing tool or screwdriver, contained in the tool kit under the cargo floor panel, refer to page 270, at the releasing point.



- 4. Firmly pull the releasing tool or screwdriver upward against the mechanical resistance, refer to arrow, until a considerable increase in force is felt and the parking brake is then clearly heard to release.
- 5. Stow the releasing tool or screwdriver, warning triangle*, and first aid kit* and close the left side panel in the cargo area.

Have the malfunction corrected
Have the malfunction corrected at the
nearest service center or at a workshop that
works according to BMW repair procedures with
correspondingly trained personnel. If the parking brake has been released manually in response to a malfunction, only technicians can
return it to operation.

Following manual release, the actual status of the parking brake may deviate from that displayed by the indicator lamp.


Putting into operation after a power failure

Putting the parking brake into operation The parking brake should only be put into operation again if it was manually released due to an interruption in the supply of electrical power. Otherwise the operation of the parking brake is not ensured and there is a danger of the vehicle rolling despite the parking brake being set.

Procedure


- 1. Switch on the ignition.
- 2. Press the button with the brake depressed.

PARK cluster goes out as soon as the parking brake is ready for operation.



Any noises which occur are normal. Startup may take several seconds.

Turn signal, high beams, headlamp flasher



- 1 High beams
- 2 Headlamp flasher
- 3 Turn signal

Signaling a turn

Press the lever beyond the resistance point.

To switch off manually, press the lever to the resistance point.

Unusually rapid flashing of the indicator lamp indicates that a turn signal bulb has failed.

Signaling a turn briefly

Press the lever to the resistance point and hold it there for as long as you want the turn signal to flash.


Triple turn signal activation

Press the lever to the resistance point.

The turn signal flashes three times.

This function can be activated or deactivated:

- 1. "Settings"
- 2. "Lighting"
- 3. "Triple turn signal"




The setting is stored for the remote control currently in use.

Washer/wiper system

Do not switch on the wipers if frozen
Do not switch on the wipers if they are frozen onto the windshield; otherwise, the wiper
blades and the windshield wiper motor may be
damaged.

✓



- 1 Switching on wipers
- 2 Switching off wipers or brief wipe
- 3 Activating/deactivating the rain sensor
- 4 Cleaning the windshield and headlamps*
- 5 Setting the sensitivity of the rain sensor

Switching on wipers

Press the wiper lever upward, arrow 1.

The lever automatically returns to its initial position when released.

Normal wiper speed

Press up once.

The system switches to operation in the intermittent mode when the vehicle is stationary.

Fast wiper speed

Press up twice or press once beyond the resistance point.

The system switches to normal speed when the vehicle is stationary.

Switching off wipers or brief wipe

Press the wiper lever down, arrow 2.

The lever automatically returns to its initial position when released.


- > Brief wipe: press down once.
- ➤ To switch off normal wipe: press down once.
- To switch off fast wipe: press down twice.

Rain sensor

If the car is equipped with a rain sensor, the time between wipes is controlled automatically and depends on the intensity of the rainfall.

The rain sensor is mounted on the windshield, directly in front of the interior rearview mirror.

Activating the rain sensor



Press the button, arrow 3.

The LED in the button lights up.

Rain sensor sensitivity

Turn thumbwheel 5 up or down.

Deactivating the rain sensor

Press the button again, arrow 3.

The LED goes out.

Deactivate the rain sensor in car washes
Deactivate the rain sensor when passing
through an automatic car wash; otherwise, damage could be caused by undesired wiper activation.

✓

Cleaning the windshield and headlamps*

Pull the lever, arrow 4.

The system sprays washer fluid on the windshield and activates the wipers briefly. When the vehicle lighting system is switched on, the headlamps are cleaned at regular and appropriate intervals.



Do not use the washer system at freezing temperatures

Do not use the washers if there is any danger that the fluid will freeze on the windshield; otherwise, your vision could be obscured. For this reason, use antifreeze.

Avoid using the washer when the reservoir is empty; otherwise, you could damage the pump. ◀

Windshield washer nozzles

The windshield washer nozzles are heated automatically while the engine is running or the ignition is switched on.

BMW X5: rear window wiper



1 Intermittent wipe

When reverse gear is engaged, the system switches to continuous operation.

2 Cleaning the rear window



Do not use the washing mechanisms when the washer fluid reservoir is empty

Do not use washing mechanisms when the washer fluid reservoir is empty, otherwise you will damage the washer pump. ◀

Washer fluid

General information

Antifreeze for washer fluid
Antifreeze is flammable. Therefore, keep it away from sources of ignition.

Only keep it in the closed original container and inaccessible to children.


Follow the instructions on the container. ◄

Washer fluid reservoir

Adding washer fluid
Only add washer fluid when the engine is
cool, and then close the cover completely to

avoid contact between the washer fluid and hot engine parts.

Otherwise, there is the danger of fire and a risk to personal safety if the fluid is spilled. ◀



All washer nozzles are supplied from one reservoir.

Fill with water and – if required – with a washer antifreeze, according to the manufacturer's recommendations.

Mix the washer fluid before adding to maintain the correct mixing ratio.

Capacity

Approx. 6.3 US quarts/6 liters.

Automatic transmission with Steptronic

Transmission positions

D Drive, automatic position

Position for normal vehicle operation. All forward gears are available.

Under normal operating conditions, fuel consumption is lowest when you are driving in position D.

Kickdown

Kickdown is used to achieve maximum driving performance. Press on the accelerator beyond the resistance point at the full throttle position.

R is Reverse

Select only when the vehicle is stationary.

N is Neutral

Use in automatic car washes, for example. The vehicle can roll.

When the ignition is switched off, refer to page 61, position P is engaged automatically.

P Park

Select only when the vehicle is stationary. The drive wheels are blocked.

P is engaged automatically as soon as the engine is switched off unless N is engaged and, in vehicles with Comfort Access, the remote control is inserted in the ignition lock, refer to page 61. Before leaving the vehicle, ensure that the transmission position P is engaged; otherwise, the vehicle may begin to roll.

Engaging transmission position


- Transmission position P can only be disengaged if the engine is running and the brake pedal is pressed.
- With the vehicle stationary, press on the brake pedal before shifting out of P or N; otherwise, the shift command will not be executed: shift lock.



Press on the brake pedal until you start driving

To prevent the vehicle from creeping after you select a driving position, maintain pressure on the brake pedal until you are ready to start.

Shifting into D, R, N



Briefly push the selector lever in the desired direction, beyond a resistance point if necessary. When shifting out of P or into R, simultaneously push the unlock button 1.

The engaged transmission position is displayed on the selector lever.

After releasing the selector lever, it returns to its center position.

Engaging P



Press button P.

P is engaged if the driver's safety belt is unbuckled and the driver's door is opened while the vehicle is stationary and transmission position R or D is engaged. Before leaving the vehicle, ensure that the transmission position P is engaged; otherwise, the vehicle may begin to roll.

Sport program and manual mode M/S

Activating the sport program



Push the selector lever to the left out of transmission position D.

The Sport program is activated and DS is displayed in the instrument cluster; in the BMW X6, S4 is displayed, for example.

This position is recommended for a performance-oriented driving style.

Activating the M/S manual mode

Push the selector lever to the left out of transmission position D.

Push the selector lever forward or backward.

Manual mode becomes active and the gear is changed.

The engaged gear is displayed in the instrument cluster, e.g., M1.

- To shift down: press the selector lever forward.
- To shift up: press the selector lever backward.

The transmission only shifts up or down if the rpm and vehicle speed are appropriate. If the engine speed is too high, the transmission does not shift down.

The selected gear is briefly displayed in the instrument panel, followed by the current gear.

Ending the sport program/manual mode

Push the selector lever to the right.

D is displayed in the instrument cluster.

BMW X6: Gear change using the shift paddles on the steering wheel

The shifting paddles make it possible to quickly change gears since both hands can remain on the steering wheel.

- If the shift paddles on the steering wheel are used to shift gears while in automatic mode D, the transmission temporarily switches to manual mode.
- If the shift paddles are not used to accelerate or shift gears for a certain amount of time, the transmission switches back to automatic mode D.

With the transmission position M/S selected, the manual mode remains active.



- Shift up: pull right shift paddle.
- Shift down: pull left shift paddle.

The vehicle only shifts up or down at appropriate engine and road speeds, e.g., it does not shift down if the engine speed is too high.

The selected gear is briefly displayed in the instrument cluster, followed by the current gear.


Displays in the instrument cluster



The gear position is displayed and the engaged gear, such as M4, is displayed in manual mode.

Displays

Odometer, external temperature display, clock



- Knob in the instrument cluster 1
- Time, external temperature, and date
- 3 Odometer and trip odometer

Knob in the instrument cluster

Press the knob.

- ▶ When the ignition is switched on, the trip odometer is reset.
 - Press the knob for approx. 5 seconds:
 - View service requirement display, refer to page 75
- ▶ When the ignition is switched off, the time, external temperature and odometer are displayed.

Units of measure

To set the respective units of measure, miles or km for the odometer and °C or °F for the external temperature, refer to page 80.

The setting is stored for the remote control currently in use.

Time, date, external temperature

From radio readiness the external temperature and the time are displayed.

Set the time, refer to page 79.

Retrieving date



Press the button on turn signal lever upward; the date appears.

Set the date, refer to page 79.

Pressing the button upward or downward several times changes the display between clock, external temperature, date, and Check Control messages, refer to page 76.

External temperature warning

If the display drops to +37 °F/+3 °C, a signal sounds and a warning lamp lights up. There is the increased danger of ice.

Ice on roads

Even at temperatures above +37 °F/+3 °C, there can be a risk of ice on roads.

Therefore, drive carefully on bridges and shady roads, for example, to avoid the increased dan-

Odometer and trip odometer

Resetting trip odometer:

With the ignition switched on, press button 1 in the instrument cluster.

When the vehicle is parked

If you still want to view the time, external temperature and odometer reading briefly after the remote control has been taken out of the ignition lock:

Press button 1 in the instrument cluster.

Tachometer



Never force the engine speed up into the red warning field, see arrow. In this range, the fuel supply is interrupted to protect the engine.

Coolant temperature

A warning lamp will come on if the coolant, and therefore the engine, becomes too hot. In addition, a message will appear on the Control Display.

Check the coolant level, refer to page 267.

Current fuel consumption*



Displays the current fuel consumption. You can check whether you are currently driving in an efficient and environmentally-friendly manner.

Engine oil temperature*



- Cold engine: the pointer is at the low temperature end. Drive at moderate engine and vehicle speeds.
- Normal operating temperature: the pointer is in the middle or in the right half of the temperature display.
- Hot engine: the pointer is at the high temperature end. Switch off the engine immediately and allow it to cool down.

If the engine oil temperature is too high, a message appears on the Control Display.

Check the oil level, refer to page 265.

Fuel gauge



The vehicle inclination may cause the display to vary.

Notes on refueling, refer to page 246.

Reserve

After the reserve range is reached:

- A message is briefly displayed on the Control Display.
- The remaining range is shown on the computer.
- When a dynamic driving style is used, such as when corners are taken rapidly, engine functions are not ensured.


The message appears continuously below a range of approx. 30 miles/50 km.

Refuel promptly

At the latest, refuel when the range drops below 30 miles/50 km; otherwise, engine functions are not ensured and damage may occur. ◀

Computer

Displaying information on the instrument panel



Press the computer button on the turn signal lever.

Information is displayed in the instrument cluster.

Overview of the information

Repeatedly pressing the button on the turn signal lever displays the information on the instrument cluster in the following order:

- Range.
- Average speed*.
- Average fuel consumption.

To set the corresponding units of measure, refer to page 80.

Information in detail

Range

Displays the estimated cruising range available with the remaining fuel.

It is calculated based on your driving style over the last 18 miles/30 km.

Average speed

Periods in which the vehicle is parked with the engine stopped do not enter into the calculation.

With the trip computer, refer to page 74, you can have the average speed displayed for an additional distance.

To reset the average speed: press the button on the turn indicator lever for approx. 2 seconds.

Average fuel consumption

This is calculated for the period during which the engine is running.

You can have the average consumption for another trip displayed, refer to Displays on the Control Display below.

To reset the average consumption: press the button on the turn indicator lever for approx. 2 seconds.


Displays on the Control Display

Display the computer or trip computer on the Control Display.

- 1. "Vehicle Info"
- 2. "Onboard info" or "Trip computer"




Displays on the "Onboard info":



- Range.
- Distance to destination.
- Estimated time of arrival if a destination was entered in the navigation system*, refer to page 153.

Displays on the "Trip computer":



- Departure time.
- Trip duration.
- Trip distance.

Both displays show:

- Average fuel consumption and
- Average speed.

Resetting the fuel consumption and speed

Resetting the values for average speed and average fuel consumption:

- Select the respective menu item and press the controller.
- Press the controller again to confirm your selection.

Resetting the trip computer

Resetting all values:

- 1. "Vehicle Info"
- "Trip computer"
- 3. "Reset"

eference


Service requirements



The remaining driving distance and the date of the next scheduled service are displayed briefly immediately after you start the engine or switch on the ignition.

The current service requirements can be read out from the remote control by the service specialist.

For certain maintenance operations, you can view the distance remaining or the due date for that operation in the instrument cluster.



- 1. With the ignition switched on, press the knob in the instrument cluster, refer to page 71, for approx. 5 seconds until the service requirements are displayed.
- 2. Press the knob repeatedly to display the individual service requirement items.

Displays

Symbol	Function
mils 10000 © 12/2014	Service requirements
mis 10000 9 12/2014	Engine oil
§ 6 12/2014	Roadworthiness test*
(©) mls 10000	Front brake pads
mls 10000	Rear brake pads
(Q) © 12/2014	Brake fluid

The sequence of displayed service items may vary. First the data for the next maintenance are displayed.

Detailed information on service requirements

More information on the scope of service required can be displayed on the Control Display.

"Vehicle Info"

2. "Vehicle status"



3. Service required"

Required maintenance procedures and legally mandated inspections are displayed.

Additional information can be displayed on each entry:

Select the entry and press the controller.

To exit from the menu:

Move the controller to the left.

Symbols

Symbols	Description
OK	No service is currently required
Δ	The deadline for service or a legally mandated inspection is approaching. Please make a service appointment.
	The service deadline has already passed.


Entering dates*

Enter the dates for the required inspections.

Make sure the date on the Control Display is set correctly, refer to page 79.

- 1. "Vehicle Info"
- 2. "Vehicle status"
- 3. Service required"

4. "§ Vehicle inspection"



- 5. Open the menu for entering the deadline.
- 6. "Date:"
- 7. Create the settings.
- Press the controller to apply the setting. The year is highlighted.
- 9. Turn the controller to make the adjustment.
- Press the controller to apply the setting. The date entry is stored.

To exit from the menu:

Move the controller to the left.

Automatic Service Request*

Data regarding the maintenance status or legally mandated inspections of the vehicle are automatically transmitted to your service center before a service due date.

You can check when your service center was notified.

- 1. "Vehicle Info"
- 2. "Vehicle status"
- 3. Open "Options".
- "Last Service Request"

Check Control

The concept

The Check Control monitors vehicle functions and alerts you to any malfunctions in the systems monitored.

A Check Control message consists of indicator and warning lamps in the instrument cluster and,

in some circumstances, an acoustic signal and text messages at the top of the Control Display.

Indicator/warning lamps



The indicator and warning lamps can light up in a variety of combinations and colors.

Several of the lamps are checked for proper functioning and light up temporarily when the engine is started or the ignition is switched on.



⚠ The symbol indicates that Check Control messages have been stored. The Check Control messages can be displayed later.

Text messages

Text messages at the upper edge of the Control Display in combination with a symbol in the instrument cluster explain a Check Control message and the meaning of the indicator and warning lamps.

Supplementary text messages

Addition information, such as on the cause of a fault or the required action, can be called up via Check Control.


In urgent cases, this information will be shown as soon as the corresponding lamp comes on.

Symbols

The following functions can be selected within the supplementary text message, depending on the Check Control message.

- Service request"Contact the service partner.
- Roadside Assistance"Contact Roadside Assistance.

Hiding Check Control messages



Press the button in the turn signal lever up or down.

- Some Check Control messages are displayed continuously and are not cleared until the malfunction is eliminated. If several malfunctions occur at once, the messages are displayed consecutively.
 - These messages can be hidden for approx. 8 seconds. After this time, they are displayed again automatically.
- Other Check Control messages are hidden automatically after approx. 20 seconds.
 They are stored and can be displayed again later.

Viewing stored Check Control messages



77

 Press the button on the turn signal lever downward. "CHECK OK" or the stored Check Control messages appear on the display.

"CHECK OK" is shown if no messages are present.

Check Control messages are accompanied by text messages on the Control Display.

Press the button to display additional messages, the time and external temperature, or the date.

Displaying stored Check Control messages

- 1. "Vehicle Info"
- 2. "Vehicle status"
- 3. /\ "Check Control"
- 4. Select the text message.

Messages after trip completion

Malfunctions indicated during a trip are displayed again after the ignition is switched off.

Speed limit*

Entry of a speed limit which, when reached, should cause a Check Control message to be issued.

Renewed warning if the vehicle speed drops below the set speed limit once by at least 3 mph/ 5 km/h.

Displaying, setting or changing the limit

- 1. "Settings"
- "Speed"

3. "Warning at:"



- 4. Turn the controller until the desired limit is displayed.
- 5. Press the controller.

The speed limit is stored.

Applying your current speed as the limit

- 1. "Settings"
- 2. "Speed"
- "Select current speed"

The system adopts your current speed as the limit.

Activating/deactivating the limit

- 1. "Settings"
- 2. "Speed"
- 3. "Warning"

Settings on the Control Display

Time

The settings are stored for the remote control currently in use.

Setting the time zone*

- "Settings"
- "Time/Date"




- "Time zone:"
- 4. Select the desired time zone.

The time zone is stored.

Setting the time

1. "Settings"



- "Time/Date"
- 3. "Time:"



- Turn the controller until the desired hours are displayed.
- 5. Press the controller.

- 6. Turn the controller until the desired minutes are displayed.
- Press the controller.

The time is stored.

Setting the time format

- 1. "Settings"
- "Time/Date"
- "Format:"
- Select the desired format.

The time format is stored.

Date

The settings are stored for the remote control currently in use.


Setting the date

- "Settings"
- 2. "Time/Date"
- "Date:"
- 4. Turn the controller until the desired day is displayed.
- Press the controller.
- 6. Make the necessary settings for the month and year.

The date is stored.

Setting the date format

- 1. "Settings"
- "Time/Date"
- "Format:"
- Select the desired format.




The date format is stored.

Language

Setting the language

To set the language on the Control Display:

- 1. "Settings"
- 2. "Language/Units"
- 3. "Language:"




4. Select the desired language.

The setting is stored for the remote control currently in use.

Setting the voice dialog

To switch between a standard dialog and a short dialog.

- 1. "Settings"
- "Language/Units"
- 3. "Speech mode"
- Select the desired dialog.



Units of measure

Setting the units of measure

To set the units for fuel consumption, route/distance, temperature, and pressure:

- 1. "Settings"
- 2. "Language/Units"



- Select the desired menu item.
- 4. Select the desired unit.


The setting is stored for the remote control currently in use.

Brightness

Setting the brightness

To set the brightness of the Control Display:

- "Settings"
- "Control display"
- 3. "Brightness"




- Turn the controller until the desired brightness is set.
- 5. Press the controller.

The setting is stored for the remote control currently in use.

Depending on the light conditions, the brightness control may not be clearly visible.

Lamps

At a glance



- Lamps off and daytime running lights*
- Parking lamps and daytime running lights*
- 2 Low-beam headlamps and welcome lamps
- 3 Automatic headlamp control*, daytime running lights*, welcome lamps, adaptive light control* and High-beam Assistant*

Parking lamps/low beams, headlamp control*

Parking lamps

Switch position **D G**: the vehicle lamps light up on all sides, e.g., for parking.

Do not use the parking lamps for extended periods; otherwise, the battery may become discharged and it would then be impossible to start the engine.

When parking, it is preferable to switch on the one-sided roadside parking lamps, refer to page **83**.

When the driver's door is opened with the ignition switched off: the exterior lighting is automatically switched off when the light switch is in position 0, 2 or 3.

Switch on the parking lamps if necessary, switch position 1.

Low beams

Switch position **ID** with the ignition switched on: the low beams light up.

Welcome lamps

When parking the vehicle, leave the switch in position D or D: the parking and interior lamps light up briefly when the vehicle is unlocked.

Activating/deactivating the welcome lamps

- 1. "Settings"
- 2. "Liahtina"
- "Welcome light"



The setting is stored for the remote control currently in use.


Headlamp courtesy delay feature

The low beams stay lit for a short while after the ignition is switched off, if the lamps are switched off and the headlamp flasher is switched on.

Setting the duration

- "Settings"
- "Lighting"

3. "Pathway light.: s"



4. Set the duration.

The setting is stored for the remote control currently in use.

Automatic headlamp control*

Switch position $\mathbb{S}^{\mathcal{D}}$: the low beams are switched on and off automatically, e.g., in tunnels, in twilight or if there is precipitation. The LED next to the symbol lights up.

A blue sky with the sun low on the horizon can cause the lights to be switched on.

The low beams remain switched on independent of the ambient lighting conditions when you switch on the front fog lamps*.

Personal responsibility

The automatic headlamp control cannot serve as a substitute for your personal judgment in determining when the lamps should be switched on in response to ambient lighting conditions.

For example, the sensors are unable to detect fog or hazy weather. To avoid safety risks, you should always switch on the lamps manually under these conditions.


Daytime running lights

The daytime running lights light up in position 0, **DOS** and **DOS**. After the ignition is switched off, the parking lamps light up in position **DOS**.

Activating/deactivating

- 1. "Settings"
- 2. "Lighting"

3. "Daytime running lamps"



The setting is stored for the remote control currently in use.

Adaptive light control*

The concept

Adaptive light control is a variable headlamp control system that enables dynamic illumination of the road surface.

Depending on the steering angle and other parameters, the light from the headlamp follows the course of the road.

In sharp curves, e.g. serpentines, or during turning, up to a certain speed one of the two front fog lamps* is switched on as a turning lamp. This provides improved illumination of the area inside the curve.

Controls

Activating

Switch position \mathbf{M} with the ignition switched on.

The turning lamps are automatically switched on depending on the steering angle or the use of turn signals.

Standstill function*: to avoid blinding oncoming traffic, the Adaptive Light Control directs light towards the front passenger side when the vehicle is at a standstill.


When driving in reverse, both turning lamps are active.

Malfunction

A message is displayed.

Adaptive light control is malfunctioning or has failed. Have the system checked as soon as possible.

High beams/roadside parking lamps



- High beams
- Headlamp flasher
- Roadside parking lamps*

Left and right roadside parking lamps*

The vehicle can be illuminated on one side.

Switching on

After parking the vehicle, press the lever up or down beyond the resistance point for approx. 2 seconds, arrow 3.

The roadside parking lamps drain the battery. Therefore, do not leave them on for unduly long periods of time; otherwise, the battery might not have enough power to start the engine.

Switching off

Briefly press the lever in the opposite direction to the pressure point, arrow 3.

High-beam Assistant*

The concept

When the lights are switched on, this system automatically switches the high beams on and off. The procedure is controlled by a sensor on the front of the interior rearview mirror. The assistant ensures that the high beams are switched on whenever the traffic situation allows. The driver can intervene at any time and switch the high beams on and off as usual.

Activating the High-beam Assistant

- 2. With the low beams switched on, briefly push the turn indicator lever in the direction of the high beam.






The indicator lamp in the instrument cluster lights up. The high beams are switched on and off automatically.

The system responds to light from oncoming traffic and traffic driving ahead of you, and to adequate illumination, e.g., in towns and cities.

Switching the high beams on and off manually




- High beams on, arrow 1.
- High beams off/headlamp flasher, arrow 2.

To reactivate the High-beam Assistant, briefly push the turn indicator lever toward the high beams.

Activating/deactivating via iDrive

- "Settings"
- 2. "Lighting"
- 3. "High beam assistant"



The setting is stored for the remote control currently in use.

System limits

Personal responsibility

The High-beam Assistant cannot serve as a substitute for the driver's personal judgment of when to use the high beams. Therefore, manually switch off the high beams in situations where this is required to avoid a safety risk.

The system is not fully functional in situations such as the following, and driver intervention may be necessary:

- ▶ In very unfavorable weather conditions, such as fog or heavy precipitation.
- In detecting poorly-lit road users, such as pedestrians, cyclists, horseback riders and wagons; when driving close to train or ship traffic; and at animal crossings.
- In tight curves, on hilltops or in depressions, in cross traffic or half-obscured oncoming traffic on freeways.
- In poorly-lit towns and cities and in the presence of highly reflective signs.
- At low speeds.
- When the windshield in front of the interior rearview mirror is fogged over, dirty or covered with stickers, etc.
- If the sensor view field is dirty.

The view field of the sensor is located on the front of the interior rearview mirror.

Do not cover this area with stickers, etc.

Clean the sensor view field with a cloth moistened with a small amount of glass cleaner.

Front fog lamps*


The parking lamps or low beams must be switched on.



Press the button. The green indicator lamp in the instrument cluster lights up.

If the automatic headlamp control, refer to page 82, is activated, the low beams will come on automatically when you switch on the fog lamps.

Instrument lighting



Adjust the brightness using the thumbwheel.

Interior lamps


General information

The interior lamps, footwell lamps*, exit lamps*, cargo area lamps and courtesy lamps* are controlled automatically.

The courtesy lamps* have LED lights in the door handles to illuminate the exterior area in front of the doors.

To avoid draining the battery, all lamps inside the car are switched off about 8 minutes after the ignition is switched off, Start/Stop button, refer to page 61.

Switching the interior lamps on and off



Press the button.

To switch off permanently: press the button for approx. 3 seconds.

To clear this setting: briefly press the button.

Reading lamps




Press the button.

Reading lamps are located at the front and rear* next to the interior lamps.

Safety

Airbags



- 1 Front airbags
- 2 Head airbags
- 3 Side airbags

Front airbags

Front airbags help protect the driver and front passenger by responding to frontal impacts in which safety belts alone cannot provide adequate restraint.

Side airbags

In a lateral impact, the side airbag supports the side of the body in the chest and lap area.

Head airbags

In a lateral impact, the head airbag supports the head.

Protective action

Airbags are not triggered in every impact situation, e.g., in less severe accidents or rear-end collisions.



Information on how to ensure the optimal protective effect of the airbags

- Keep at a distance from the airbags.
- Always grasp the steering wheel on the steering wheel rim, holding your hands at the 3 o'clock and 9 o'clock positions, to keep the danger of injury to your hands or arms as low as possible if the airbag is triggered.

- ▶ There should be no people, animals, or objects between an airbag and a person.
- Do not use the cover of the front airbag on the front passenger side as a storage area.
- Keep the dashboard and window on the front passenger side clear, i.e., do not cover with adhesive labels or coverings, and do not attach holders such as for navigation instruments and mobile phones.
- Make sure that the front passenger is sitting correctly, i.e., keeps his or her feet and legs in the footwell; otherwise, leg injuries can occur if the front airbag is triggered.
- Do not place slip covers, seat cushions or other objects on the front passenger seat that are not approved specifically for seats with integrated side airbags.
- Do not hang pieces of clothing, such as jackets, over the backrests.
- Make sure that occupants keep their heads away from the side airbag and do not rest against the head airbag; otherwise, injuries can occur if the airbags are triggered.
- Do not remove the airbag restraint system.
- Do not remove the steering wheel.

- Do not apply adhesive materials to the airbag cover panels, cover them or modify them in any way.
- Never modify either the individual components or the wiring in the airbag system. This also applies to steering wheel covers, the dashboard, the seats, the roof pillars and the sides of the headliner. ◀

Even when all instructions are followed closely, injury from contact with the airbags cannot be ruled out in certain situations.

The ignition and inflation noise may lead to short-term and, in most cases, temporary hearing impairment in sensitive individuals.



In the case of a malfunction, deactivation and after triggering of the airbags

Do not touch the individual components immediately after the system has been triggered; otherwise, there is the danger of burns.

Only have the airbags checked, repaired or dismantled and the airbag generator scrapped by your service center or a workshop that has the necessary authorization for handling explosives.

Non-professional attempts to service the system could lead to failure in an emergency or undesired triggering of the airbag, either of which could result in injury. ◀

Warnings and information on the airbags are also found on the sun visors.

Automatic deactivation of the front passenger airbags

The occupation of the seat is detected by evaluating the impression on the occupied seat surface of the front passenger seat.

The front and side airbags on the front passenger side are activated or deactivated accordingly by the system.

The indicator lamp above the interior rearview mirror shows the current status of the front passenger airbags, deactivated or activated, refer to Front passenger airbag indicator lamp below.

Leave feet in the footwell

Make sure that the front passenger keeps his or her feet in the footwell; otherwise, the front passenger airbags may not function properly. ◀



Child restraint fixing system in the front passenger seat

Before transporting a child on the front passenger seat, refer to the safety notes and instructions under Children on the front passenger seat, refer to page 56. ◀

Malfunction of the automatic deactivation system

When transporting older children and adults, the front passenger airbags may be deactivated in certain sitting positions. In this case, the indicator lamp for the front passenger airbags lights

In this case, change the sitting position so that the front passenger airbags are activated and the indicator lamp goes out.

If it is not possible to activate the airbags, have the person sit in the rear.

To make sure that occupation of the seat cushion can be detected correctly:

- Do not attach seat covers, seat cushion padding, ball mats or other items to the passenger seat unless they are specifically recommended by BMW.
- Do not place objects under the seat that could press against the seat from below.

Indicator lamp for the front passenger airbags



Depending on the vehicle's equipment, the arrangement of the switches and indicator lamps may differ somewhat.

The indicator lamp for the front passenger airbags indicates the operating state of the front passenger airbags.

The lamp indicates whether the airbags are activated or deactivated.

- The indicator lamp lights up when a child in a child restraint fixing system intended for the purpose is properly detected on the seat. The airbags on the front passenger side are not activated.
- The indicator lamp does not light up when, for example, a correctly seated person of sufficient size is detected on the seat. The airbags on the front passenger side are activated.
- The indicator lamp does not light up when the seat is empty. However, the airbags on the front passenger side are not activated.

The system generally detects children seated in a child seat, especially in the child seats that were required by NHTSA when the vehicle was manufactured. After installing a child seat, make sure that the indicator lamp for the front passenger airbags lights up. This indicates that the child seat has been detected and the front passenger airbags are not activated.

Operational readiness of airbag system



In the radio ready state and beyond, refer to page 61, the warning lamp comes on briefly to indicate that the entire airbag system and the belt tensioners are operational.

Airbag system malfunction

- Warning lamp does not light up in the radio ready state.
- Warning lamp remains permanently on.



Have the airbag system checked without delay if there is a malfunction

In the event of a malfunction in the airbag system, have it checked without delay; otherwise, there is the risk that the system will not function as intended even if a sufficiently severe accident occurs.◀

FTM Flat Tire Monitor*

The concept

The system does not measure the actual inflation pressure in the tires.

It detects a pressure loss in a tire by comparing the rotational speeds of the individual wheels while moving.

In the event of a pressure loss, the diameter and therefore the rotational speed of the corresponding wheel change. This is detected and reported as a flat tire.

Functional requirements

The system must have been initialized when the tire inflation pressure was correct; otherwise, reliable signaling of a flat tire is not ensured. Initialize the system after each correction of the tire inflation pressure and after every tire or wheel change.

System limits

Sudden tire damage

Sudden serious tire damage caused by external influences cannot be indicated in advance. ◀

A natural, even pressure loss in all four tires cannot be detected. Therefore, check the tire inflation pressure regularly.

The system could be delayed or malfunction in the following situations:

- When the system has not been initialized.
- When driving on a snowy or slippery road surface.
- Sporty driving style: slip in the drive wheels, high lateral acceleration.
- When driving with snow chains*.

When driving with a compact wheel*, the Flat Tire Monitor is unable to function.

Status display

The current status of the Flat Tire Monitor can be displayed on the Control Display, e.g., whether or not the FTM is active.

- "Vehicle Info"
- 2. "Vehicle status"
- (!) "Flat Tire Monitor"

The status is displayed.

Initialization

The initialization process adopts the set inflation tire pressures as reference values for the detection of a flat tire. Initialization is started by confirming the inflation pressures.

Do not initialize the system when driving with snow chains* or with a compact wheel*.

- "Vehicle Info"
- "Vehicle status"
- 3. (!) "Reset"
- Start the engine do not drive away.
- Start the initialization with "Reset".
- 6. Drive away.

The initialization is completed while driving, which can be interrupted at any time.

The initialization automatically continues when driving resumes.

Indication of a flat tire



The warning lamp lights up red. A message appears on the Control Display. In addition, a signal sounds.

There is a flat tire or a major loss in tire inflation pressure.

Reduce your speed and stop cautiously. Avoid sudden braking and steering maneuvers.

When a flat tire is indicated, DSC Dynamic Stability Control is switched on if necessary.

Actions in the event of a flat tire

Run-flat tires

You can continue driving with a damaged tire at speeds up to 50 mph/80 km/h.



Do not continue driving without run-flat tires

If the vehicle is not equipped with run-flat tires as provided at the factory, do not continue driving. Continuing to drive could cause severe accidents.◀

Continued driving with a flat tire

If continuing to drive with a damaged tire:

- Avoid sudden braking and steering maneuvers.
- 2. Do not exceed a speed of 50 mph/80 km/h. If the defective tire continues to lose pressure, its position will be indicated to you on the Control Display.
- 3. At the next opportunity, check the inflation pressure in all four tires.

If the tire inflation pressure in all four tires is correct, the Flat Tire Monitor may not have been initialized. In this case, initialize the system.

Possible driving distance with complete loss of tire inflation pressure:

- With a light load: 1 to 2 people without luggage: Approx. 155 miles/200 km.
- With a medium load:

2 persons, cargo area full, or 4 persons without luggage:

Approx. 94 miles/150 km.

With a full load:

4 or more persons, cargo area full:

Approx. 30 miles/50 km.

The possible driving distance after a loss of tire inflation pressure depends on the cargo load and the driving style and conditions.

When the vehicle is driven with a damaged tire, its handling characteristics change, e.g., reduced lane stability during braking, a longer braking distance, and altered self-steering properties. Adjust your driving style accordingly. Avoid abrupt steering maneuvers or driving over obstacles, e. g., curbs, potholes, etc.

Because the possible driving distance depends on how the vehicle is used during the trip, the actual distance may be smaller or greater depending on the driving speed, road conditions, external temperature, cargo load, etc.

Continued driving with a flat tire

Drive moderately and do not exceed a speed of 50 mph/80 km/h.

A loss of tire inflation pressure results in a change in the handling characteristics, e.g., reduced lane stability during braking, a longer braking distance and altered self-steering properties.

Final tire failure

Vibrations or loud noises while driving can indicate the final failure of the tire. Reduce speed and stop; otherwise, pieces of the tire could come loose and cause an accident. Do not continue driving, and contact your service center.

Tire Pressure Monitor TPM*

The concept

The tire inflation pressure is measured in the four mounted tires. The system notifies you if there is a significant loss of pressure in one or more tires.

Functional requirements

The system must have been reset while the inflation pressure was correct; otherwise, reliable signaling of a flat tire is not ensured. Always use wheels with TPM electronics to ensure that the system will operate properly.

Reset the system after each correction of the tire inflation pressure and after every tire or wheel change.

System limits

Sudden tire damage
Sudden serious tire damage caused by
external influences cannot be indicated in advance. ◀

The system does not operate correctly if it has not been reset. For example, a flat tire may be indicated despite correct tire inflation pressures.

The system is inactive and cannot indicate a flat tire:

- ▶ If a wheel without TPM electronics is mounted, e.g., compact wheel*.
- When the TPM is disturbed by other systems or devices with the same radio frequency.

Status display

- 1. "Vehicle Info"
- 2. "Vehicle status"
- 3. (!) "TPM"

The status is displayed.

Status indicator on the Control Display

The tire and system status is indicated by the color of the tires.

A change in the tire inflation pressure during driving is taken into account.

A correction is only necessary if this is indicated by the $\ensuremath{\mathsf{TPM}}$

Wheels, green

The tire inflation pressure is equal to the target state.

One wheel is yellow

A flat tire or major drop in inflation pressure in the indicated tire.

All wheels are vellow

- A flat tire or major drop in inflation pressure in several tires.
- The system was not reset after a wheel change and thus issues a warning based on the inflation pressures initialized last.
- A flat tire in one or more tires while the system is being reset.

Wheels, gray

The system cannot detect a flat tire.

Reasons for this may be:

- TPM is being reset.
- Disturbance by systems or devices with the same radio frequency.
- Malfunction.

Resetting the system

Reset the system after each correction of the tire inflation pressure and after every tire or wheel change.

- "Vehicle Info"
- "Vehicle status"
- 3. (!) "Reset"
- 4. Start the engine do not drive away.
- 5. Reset the tire pressure using "Reset".
- 6. Drive away.

The tires are shown in gray and "Resetting TPM..." is displayed.

After driving for a few minutes, the set tire inflation pressures are applied as set values. The resetting process is completed automatically as you drive. The tires are shown in green and "TPM active" is shown on the Control Display.

The trip can be interrupted at any time. If you drive away again, the process resumes automatically. Do not reset the system when driving with a compact wheel*.

If a flat tire is detected while the system is resetting, all tires on the Control Display are displayed in yellow. The message "Low tire!" is shown.

Low tire pressure message

(1)



The small warning lamp lights up yellow and the large warning lamp lights up red. A message appears on the Control Display. In addition, a signal

sounds.

- There is a flat tire or a major loss in tire inflation pressure.
- The system was not reset after a wheel change and thus issues warnings based on the inflation pressures initialized last.

Reduce your speed and stop cautiously. Avoid sudden braking and steering maneuvers.

When a low inflation pressure is indicated, DSC Dynamic Stability Control is switched on if necessary.

Actions in the event of a flat tire

Run-flat tires

You can continue driving with a damaged tire at speeds up to 50 mph/80 km/h.



Do not continue driving without run-flat tires

If the vehicle is not equipped with run-flat tires as provided at the factory, do not continue driving. Continuing to drive could cause severe accidents.◀

Continued driving with a flat tire

If continuing to drive with a damaged tire:

- 1. Avoid sudden braking and steering maneuvers.
- 2. Do not exceed a speed of 50 mph/80 km/h.
- 3. Check the air pressure in all four tires at the next opportunity.

If the tire inflation pressure in all four tires is correct, the Tire Pressure Monitor may not have been reset. Reset the system.

Possible driving distance with complete loss of tire inflation pressure:

With a light load:

1 to 2 people without luggage:

Approx. 155 miles/200 km.

With a medium load:

2 persons, cargo area full, or 4 persons without luggage:

Approx. 94 miles/150 km.

With a full load:

4 or more persons, cargo area full:

Approx. 30 miles/50 km.

The possible driving distance after a loss of tire inflation pressure depends on the cargo load and the driving style and conditions.

When the vehicle is driven with a damaged tire, its handling characteristics change, e.g., reduced lane stability during braking, a longer braking distance, and altered self-steering properties. Adjust your driving style accordingly. Avoid abrupt steering maneuvers or driving over obstacles, e. g., curbs, potholes, etc.

Because the possible driving distance depends on how the vehicle is used during the trip, the actual distance may be smaller or greater depending on the driving speed, road conditions, external temperature, cargo load, etc.

Continued driving with a flat tire
Drive moderately and do not exceed a speed of 50 mph/80 km/h.

A loss of tire inflation pressure results in a change in the handling characteristics, e.g., reduced lane stability during braking, a longer braking distance and altered self-steering properties.

Final tire failure

Vibrations or loud noises while driving can indicate the final failure of the tire. Reduce speed and stop; otherwise, pieces of the tire could come loose and cause an accident. Do not continue driving, and contact your service center.

Message when the system was not reset



The yellow warning lamp lights up. A message appears on the Control Display.

The system detected a wheel change but was not reset.

Warnings regarding the current tire inflation pressure are not reliable.

Check the tire inflation pressure and reset the system.

Malfunction



The small warning lamp flashes in yellow and then lights up continuously; the larger warning lamp comes on in yellow. On the Control Display, the

tires are shown in gray and a message appears. No flat tire can be detected.

Display in the following situations:

- If a wheel without TPM electronics is fitted, for instance a compact wheel*: have the service center check it if necessary.
- Malfunction: have the system checked by your service center.
- TPM could not be fully reset. Reset the system again.
- Disturbance by systems or devices with the same radio frequency: after leaving the area of the disturbance, the system automatically becomes active again.

Declaration according to NHTSA/ FMVSS 138 Tire Pressure Monitoring Systems

Each tire, including the spare (if provided) should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label. (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale illuminates, you

should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle startups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

Lane departure warning*

The concept

This system issues a warning at speeds above approx. 40 mph/65 km/h if the vehicle is about to leave the lane on roads with lane markings.

The steering wheel begins vibrating lightly.

The system does not issue a warning if the turn signal is set before leaving the lane.

Switching on/off



Press button 1 on the steering wheel.

- On: lane markings 2 are lit.
- Off: lane markings 2 go out.

The system can issue warnings at speeds above approx. 40 mph/65 km/h.

The state is stored for the remote control currently in use.

Display



- The system is activated.
- 2 Arrows: at least one lane marking was detected and warnings can be issued.

Issuing a warning

If the vehicle begins leaving the lane and a lane marking has been detected, the steering wheel begins vibrating.

If the turn signal is set before the lane is changed, a warning is not issued.

Canceling a warning

The warning is canceled:

- Automatically after approx. 3 seconds.
- > After the vehicle returns to its lane.

- During heavy brake application.
- When the turn signal flashes.

System limits

Personal responsibility

The system cannot serve as a substitute for the driver's personal judgment of the course of the road and the traffic situation.

In the event of a warning, do not jerk the steering wheel; otherwise, you may lose control over the vehicle. ◄

The system may not be fully functional in the following situations:

- In heavy fog, rain or snowfall.
- In the event of worn, poorly visible, merging, diverging, or multiple lane markings such as in construction areas.
- When the demarcation lines are covered by snow, ice, dirt or water.
- In tight curves or on narrow lanes.
- When the demarcation lines are covered by objects.
- When driving very close to the vehicle in front of you.
- When driving toward bright lights.
- When the windshield is fogged over, dirty or covered by a sticker, etc., in front of the interior rearview mirror.

Malfunctions

Steering wheel vibration

Frequent activation of the steering wheel vibration causes the system to overheat.

This causes the lane departure warning to become deactivated.

Let the system cool and reactivate it by pressing the button.

Camera




The camera is located on the front of the interior rearview mirror.

Keep the area in front of the interior rearview mirror clear.

Brake force display*

The concept

BMW X5



- During normal brake application, the outer brake lamps light up.
- During heavy brake application, the inner brake lamps light up in addition.

BMW X6



- During normal brake application, the outer brake lamps light up.
- During heavy brake application, the inner brake lamps light up in addition.

Driving stability control systems

Antilock Brake System ABS

ABS prevents locking of the wheels during braking.

The vehicle remains steerable even during full brake applications, thus increasing active safety.

ABS is operational every time you start the enqine.

CBC Cornering Brake Control

When braking during curves or when braking during a lane change, driving stability and steering response are improved further.

Electronic brake-force distribution

The system controls the brake pressure in the rear wheels to ensure stable braking behavior.

Brake assistant

When you apply the brakes rapidly, this system automatically produces the maximum braking force boost. It thus helps to achieve the shortest possible braking distance during full braking. This system utilizes all of the benefits provided by ABS.

Do not reduce the pressure on the brake pedal for the duration of the full braking.

Dynamic Stability Control DSC

The concept

DSC prevents traction loss in the driving wheels when driving away and accelerating.

DSC also recognizes unstable vehicle conditions, such as fishtailing or nose-diving. Subject to physical limits, DSC helps to keep the vehicle on a steady course by reducing engine speed and by applying brakes to the individual wheels.

Adjust your driving style to the situation
An appropriate driving style is always the responsibility of the driver.

The laws of physics cannot be repealed, even with DSC.

Do not reduce the additional safety margin with a risky driving style, as otherwise there is a risk of an accident. ◀

Deactivating DSC: DSC OFF

When DSC is deactivated, driving stability is reduced during acceleration and when driving in bends.

To increase vehicle stability, activate DSC again as soon as possible.

Deactivating DSC



Press and hold the button, but not longer than approx. 10 seconds, until the indicator lamp for DSC lights up in the instrument cluster and DSC OFF is displayed. DTC Dynamic Traction Control and DSC are deactivated together.

A message appears on the Control Display. Please note any supplementary information that appears there.

Activating DSC

Press the button.

DSC OFF and the indicator lamp in the instrument cluster go out.

For better control



The indicator lamp flashes: DSC controls the drive forces and brake forces.

The indicator lamp lights up: DSC and DTC has failed.

DSC deactivated:



The indicator lamp lights up and DSC OFF appears in the instrument cluster.



DSC and DTC deactivated.

Dynamic Traction Control DTC

The concept

The DTC system is a version of the DSC in which forward momentum is optimized.

The system ensures maximum forward momentum on special road conditions, e.g., unplowed snowy roads, but driving stability is limited.

It is therefore necessary to drive with appropriate caution.

You may find it useful to briefly activate DTC under the following special circumstances:

▶ When driving in sand, on snowy inclines, in slush, or on unplowed, snow-covered road surfaces

- When rocking a vehicle free or starting off in deep snow, sand, or on loose ground
- When driving with snow chains*.

Deactivating/activating DTC Dynamic Traction Control

Activating the Dynamic Traction Control DTC provides maximum traction on loose ground. Driving stability is limited during acceleration and when driving in bends.

Activating DTC



Press the button.

TRACTION is displayed in the instrument cluster and the indicator lamp for DSC OFF lights up.

Deactivating DTC

Press the button again.

TRACTION and the indicator lamp in the instrument cluster go out.

For better control



The indicator lamp flashes: DTC controls the drive forces and brake forces.

The indicator lamp lights up: DSC and DTC has failed.

DTC activated:



The indicator lamp lights up and TRAC-TION appears in the instrument cluster.



DTC is activated.

xDrive

xDrive is the all-wheel-drive system of your vehicle. The combined effects of xDrive and DSC further optimize the traction and dynamic driving characteristics. The 4-wheel drive system xDrive variably distributes the drive forces to the front and rear axle depending on the driving situation and prevailing road conditions.

Dynamic Performance Control*

The concept

Dynamic Performance Control optimizes the handling characteristics of your vehicle when starting off, cornering, and during evasive maneuvers.


To achieve this, the system variably distributes the drive torque of the rear axle to the two rear wheels. This further increases the steering precision and tracking stability of your vehicle.

Display

The Control Display shows how xDrive and Dynamic Performance Control are distributing the drive forces.

1. "Vehicle Info"

2. "Torque distribution"



The current distribution of drive forces is indicated by arrows pointing to all four wheels.

The highlighted arrows show the drive forces currently present. The longer an arrow is, the greater the drive forces in the associated wheel.

The transparent arrows indicate the maximum value the drive forces over the last 10 seconds.

Malfunction

Malfunctions are displayed via Check Control, refer to page 76.

Hill Descent Control HDC

The concept

HDC is a downhill driving assistant that automatically controls vehicle speed on steep downhill gradients. The vehicle moves at approximately walking speed without braking intervention by the driver.

You can activate the Hill Descent Control at speeds below approx. 22 mph/35 km/h. When moving downhill at speeds below approx. 22 mph/35 km/h, the vehicle reduces its speed to approximately walking speed, approx. 5 mph/8 km/h and keeps it constant.


Only use HDC in transmission positions D or R.

Increasing or reducing speed

The speed can be changed in the range from approx. 4 mph/6 km/h to approx. 15 mph/25 km/h by pressing the accelerator or brake pedal lightly.


A target speed within the same range can be specified using the lever of the cruise control.

On inclines over 10 %, you can reduce the speed to approx. 3 mph/4 km/h. Pull the lever of the cruise control beyond the resistance point, arrow 3.



- Increasing speed
- Pull to the resistance point: reduce the speed to approx. 4 mph/6 km/h
- 3 Pull beyond the resistance point: on inclines over 10 %, reduce the speed to approx. 3 mph/4 km/h

Activating HDC



Press the button; the LED above the button lights up.

The LED flashes when the brakes are applied automatically.

Deactivating HDC

Press the button again; the LED goes out. HDC is automatically deactivated above approx. 37 mph/60 km/h.

Displays* in the instrument cluster



- 1 Display for target speed
- HDC display

Malfunction

HDC is temporarily unavailable in the following situations due to a high brake temperature:

- The LED in the button and the display HDC go out during HDC operation.
- The LED in the button and the HDC display do not light up when the button is pressed.

Malfunction of driving stability control systems

Adapting your driving style

When driving on poor roads, avoid using full throttle or pressing the accelerator beyond the kickdown point and also avoid heavy braking. Otherwise, the drive train may be damaged

Adaptive Drive*

The concept

Adaptive Drive reduces the body roll which occurs when cornering quickly or during fast evasive maneuvers. In addition, Adaptive Drive reduces the steering angle requirement, improves the running comfort, and enhances the dynamic driving characteristics of your vehicle.

Chassis and suspension tuning

Two chassis and suspension tunings are available for selection.


Normal:

The comfortable basic setting offers optimum comfort when traveling.

Sport:

The sporty basic setting offers increased driving agility.

Selecting chassis and suspension tuning



Press the button.

The system switches between the two chassis and suspension tuning settings.

Sport:

The LED in the button lights up and SPORT is displayed in the instrument panel.

Normal:

The LED in the button goes out.

The selection of the chassis and suspension tuning setting is stored for the remote control currently in use.

Drive-off assistant

This system supports driving away on gradients. The parking brake is not required.

- 1. Hold the vehicle in place with the foot brake.
- Release the foot brake and drive away without delay.

Depending on the vehicle load, the vehicle may roll back slightly.

Driving off without delay

After releasing the foot brake, start driving without delay, since the drive-off assistant will not hold the vehicle in place for more than approx. 2 seconds and the vehicle will begin rolling back.

Self-leveling suspension*

The concept

The self-leveling suspension on the rear axle assures a continuous ground clearance.

To do so, the height of the vehicle is measured by sensors at both rear wheels.

If the actual height deviates from the defined height, such as due to cargo in the vehicle, this difference is compensated very quickly. In addition, spring motions resulting from cornering or irregularities in the road surface are reduced to a minimum.

The system works automatically.

Malfunctions

Malfunctions are displayed via Check Control, refer to page 76.

Active steering*

The concept

The active steering actively varies the steering angle of the front wheels in relation to the steering wheel movements. In addition, it also varies the steering force required for steering depending on the vehicle's speed.

When you are driving in the low speed range, for instance in a town or when parking, the steering angle increases, i.e., steering becomes very direct. In the higher speed range, on the other hand, the steering angle is reduced more and more. This improves the handling of your vehicle over the entire speed range.

In critical situations, the system can make targeted corrections to the steering angle provided

by the driver and thus stabilize the vehicle before the driver intervenes.

Malfunction





The warning lamp lights up yellow and a message is shown on the Control Display. The active steering is defective or has been temporarily deacti-

vated. At low speeds, greater steering wheel movements are required, whereas at higher speeds, the vehicle reacts more sensitively to steering wheel movements. The stability-promoting intervention can also be deactivated. Proceed cautiously and drive defensively.

Deactivation

Active steering deactivates in order to carry out an initialization. This deactivation is displayed by means of a message. The initialization can take several minutes.

If the message does not disappear during the current trip, have the system checked.

Defect

In the event of a defect, a corresponding text message is displayed. Have the system checked.

Driving comfort

Active cruise control*

With active cruise control you can select a desired speed which is then automatically maintained when driving on open roadways and is varied to maintain a selected distance setting to slower moving vehicles ahead.

Active cruise control represents a technological advance over the familiar cruise control and is a welcome relief from the constant adjustment of speed that can accompany driving in traffic on highways or other high-speed thoroughfares. Especially on longer trips and in traffic congestion, the system can reduce fatigue and tension, while increasing your enjoyment of driving. Please use it safely and responsibly.

In addition to holding a steady cruising speed, if you encounter slower vehicles ahead, active cruise control will, within limits, adjust your vehicle's speed automatically so that you can flow with the traffic without having to make constant adjustments. If, for example, while cruising at the selected speed, you begin to approach a slower vehicle ahead of you in the same lane, the system will reduce your vehicle's speed to the same as that of the vehicle ahead to maintain your selected distance setting. You can vary the following distance, which will vary with speed. Based on your selected distance setting, the system automatically decreases the throttle setting and lightly applies the brakes if necessary. In addition, if the vehicle ahead of you slows to a complete stop, the system can follow this action within the given scope and can also accelerate from a complete stop if the vehicle ahead of you drives off again shortly thereafter. During braking, your vehicle brake lamps will automatically illuminate to alert a following driver to take action. In addition, it may be necessary for your vehicle to downshift the automatic transmission to maintain the distance setting selected. As soon as the road in front of you has no moving vehicles, the system will accelerate to your desired speed. This set speed is also maintained on downhill grades, however the vehicle speed

can drop below the set speed when driving uphill if the engine output is not sufficient.

Personal responsibility

signs, red lights, or any object that is stopped or is blocking the road. Active cruise control is not and must not be used as a collision avoidance/ warning system. Since this active cruise control system is a new technology and operates differently from conventional cruise control systems to which you may be accustomed, it is necessary that you read all of the pages relating to this system before use. Carefully read and observe the information on the system limitations, refer to page 106, to obtain a good command of the system and its range of applications.

Brake pedal feel

When the system brakes and you also depress the brake pedal, a somewhat different braking feel results.

Professional navigation system*

If the vehicle is equipped with a Professional navigation system, the system adapts the acceleration and deceleration behavior of the vehicle to the road on which you are currently driving.

To ensure that the system has the latest information on the course of the road, use the most recent version of the navigation data.


If the vehicle position is unknown, e.g., if you have left the region covered by the map, the navigation system ceases to influence vehicle behavior.

Applications

Please try the system first during sparse traffic and clear road conditions so that you can get used to the system. After you have experience and understand the system, only then use it during normal traffic. As with conventional cruise control systems, active cruise control in no way reduces or substitutes for the driver's own personal experience, responsibility, alertness and awareness in adjusting speed, braking or otherwise controlling the vehicle. The driver should decide when to use the system on the basis of road, traffic, visibility, and weather conditions. Active cruise control is intended for use on highway-type roadways where traffic is moving relatively smoothly as well as in slow-moving traffic congestion. Do not use the system in city driving; in complex driving situations; heavy traffic such as during rush hour; on curvy, winding roads, slippery roads or roads with sharp curves such as highway off-ramps; during inclement weather such as snow, strong rain or fog; or when entering interchanges, service/parking areas or toll booths. It is also important to regulate your vehicle's speed and distance setting within applicable legal limits. Always be ready to take action or apply the brakes if necessary, especially when the system is actively following a vehicle in front of you. Otherwise, driving conditions can result which lead to a violation of the law or elevated risk of an accident.

The minimum initial activation speed is 20 mph/ 30 km/h, and the maximum speed is 110 mph/ 180 km/h. The system can also be activated while the vehicle is stationary, refer to page 105.

One lever for all functions



- Storing and increasing the desired speed 103
- 2 Storing and reducing the desired speed 103

- Interrupting 104 or deactivating 105 the system
- 4 Retrieving the stored desired speed and distance 104 or driving away 105
- Selecting the distance to the vehicle ahead 104

Storing the current speed

Push the lever, arrow 1, or pull it briefly, arrow 2.



The system stores the current vehicle speed. It is indicated on the speedometer and briefly in the instrument panel.

Increasing desired speed

Press or briefly push the lever up to or beyond the resistance point, arrow 1, until the desired speed is displayed.

The displayed speed is stored and the vehicle reaches the stored speed if the road is clear.

- ▶ With each activation to the resistance point, the desired speed increases by approx. 1 mph/1 km/h.
- With each activation beyond the resistance point, the desired speed increases by a maximum of 5 mph/10 km/h.

Reducing the desired speed

Pull the lever, arrow 2, until the desired speed is displayed.

The functions are the same as those when increasing the desired speed.

Selecting the distance



- Press the rocker down briefly: Increase the distance.
- Press the rocker up briefly:
 Decrease the distance.

The selected distance is displayed in the instrument panel.

Distance display



Distance 1, closest



Distance 2



Distance 3



Distance 4, furthest

This distance is set when you activate the system.

Selecting an appropriate distance
Use good judgement to select the appropriate following distance given road conditions, traffic, applicable laws and State driving recommendations for safe following distance. Otherwise, a violation of the law or risk of an accident could result.

Interrupting the system



Press the lever up or down and additionally depress the brake if the vehicle is stationary. The mark in the speedometer changes color and the distance indicator goes out.

In addition, the system is interrupted:

- When the brakes are applied.
- When the transmission position D is disengaged.
- When DTC is activated or DSC is deactivated.
- When DSC is activated
- When the safety belt and the driver's door are opened while the vehicle is stationary.
- When the system has not detected objects for an extended period, e.g., on a road with very little traffic without road edge line markings.
- The radar sensor is dirty.



Active intervention if the system is interrupted

If the system is interrupted, actively intervene by braking and, if necessary, with evasive maneuvers; otherwise, there is the danger of an accident occurring. ◄

Calling up the stored desired speed and distance

While driving

Press button 4, refer to page 103. All of the displays in the instrument panel lights up.

Displays in instrument cluster

Before leaving the vehicle Before leaving the vehicle with the engine running, engage position P of the automatic transmission and apply the parking brake. Otherwise, the vehicle may begin to roll. ◀

While standing

If a vehicle detected ahead of you slows to a halt and your vehicle is also brought to a halt by the system:

- If the vehicle ahead of you drives away, your vehicle accelerates automatically as long as mark 1 for the desired speed in the speedometer is green.
- ▶ If the vehicle ahead of you drives away when mark 1 is orange, depress the accelerator briefly or press button 4.Rolling bars in the distance indicator 3 mean that the vehicle ahead of you has driven away.


If you are standing behind a vehicle with your brake pedal depressed and the system is deactivated or interrupted:

- 1. Select the desired speed using the lever, arrow 1 or arrow 2, or press button 4 to retrieve a stored speed.
- 2. Release the brake pedal.
- 3. When the vehicle ahead of you drives away, press on the accelerator briefly or press button 4.

Deactivating the system

- When driving, press the lever up or down twice.
- When stationary, do the same while depressing the brake pedal.
- Switch off the ignition.

The displays go out, and the stored desired speed and distance are deleted.



- Stored desired speed
 - Green: the system is active.
 - Orange: the system is interrupted.
- 2 Lights up yellow: vehicle detected ahead Display also used for warnings, please read all information on warnings.
- Selected distance to vehicle ahead The indicator lights up as soon as the system is activated.

The indicator lights up as soon as the system is activated.

The bars roll: the vehicle in front of you has driven off

4 Brief display of stored desired speed

If the display --- mph/---km/h appears briefly, the conditions necessary for operation may currently not be met.

Warning lamps



Display 2 flashes red and a signal sounds.

The system requests that the you intervene by braking and carrying out evasive maneuvers, if neces-

sary. The system cannot independently restore the distance to the vehicle ahead.

This display does not relieve the driver of the responsibility to adapt his or her desired driving speed and style to the traffic conditions.




Display 2 flashes yellow.

The conditions necessary for operation of the system are no longer met, e.g., due to ABS or DSC intervention. The system applies the brakes until you actively assume control.

Radar sensor

Position



The radar sensor is integrated in the bumper.

Dirty or covered sensor

A dirty or covered sensor may hinder the detection of vehicles.

- If necessary, clean the radar sensor. Remove layers of snow and ice carefully.
- Do not cover the view field of the radar sensor.

Malfunction

The system cannot be activated if the radar sensor is not aligned correctly. Misalignment may be caused by damage incurred during parking, for example.

For US owners only

The transmitter and receiver units comply with part 15 of the FCC/Federal Communication Commission regulations. Operation is governed by the following:

FCC ID:

OAYARS3-A

Compliance statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference, and

This device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modifications or changes to these devices could void the user's authority to operate this equipment.

System limits


Speed range

Best results are achieved when using the system on well-developed roads and highways. The desired speed can be selected between 20 mph/30 km/h and 110 mph/180 km/h.

The system can also be activated when stationary.

Comply with the legal speed limit in every situation when using the system.

Detection range



The detection capacity of the system and the automatic braking capacity are limited. Two-wheeled vehicles driving ahead of you for instance might not be detected.

Limited detection capacity

Because of the limits to the detection capacity, you should be alert at all times so that you can intervene actively, if necessary; otherwise, there is the danger of an accident occurring.

Deceleration


The system does not decelerate when a stationary obstacle is located in the same lane, e.g., a vehicle at a red traffic light or at the end of traffic congestion.

The system also does not respond to:

- Pedestrians or similarly slow road users.
- Red traffic lights.
- Stationary objects.
- Cross traffic.
- Approaching traffic.

No warnings A warning may not be issued when approaching a stationary or very slow-moving obstacle. Take action yourself, otherwise there is

Swerving vehicles




A vehicle driving in front of you is not detected until it is completely within the same lane as your vehicle.

Swerving vehicles

If a vehicle driving ahead of you suddenly swerves into your lane, the system may not be able to automatically restore the selected distance. This also applies to major speed differences to vehicles driving ahead of you, e.g., when rapidly approaching a truck. When a vehicle driving ahead of you is reliably detected, the system requests that the driver intervene by braking and carrying out evasive maneuvers, if necessary. Take action yourself, otherwise there is a risk of an accident.


✓

Unexpected lane change




If a vehicle ahead of you unexpectedly moves into another lane from behind a stopped vehicle, you yourself must react, as the system does not react to stopped vehicles.

Cornering



If the desired speed is too high for a curve, the speed is reduced slightly in the curve, although curves cannot be anticipated in advance. Therefore, drive into a curve at an appropriate speed. In tight curves, situations may result due to the restricted detection range of the system in which a vehicle driving ahead of you may not be detected at all, or not until after a considerable delay.



When approaching a curve, the system may react briefly to the vehicles in the next lane due to the bend of the curve. Any deceleration of the vehicle by the system can be compensated for by briefly accelerating. After the accelerator pedal is released, the system becomes active again and independently controls the speed.

Driving away

In some situations, the vehicle cannot drive away automatically, e.g., on steep inclines, with a heavy trailer or behind bumps in the road.

Driver interventions and your responsibility

Your actions have priority at all times. When you press on the accelerator pedal while driving, automatic braking is not performed and the bars in the distance display go out until you lift your foot from the accelerator pedal. Once you release the accelerator pedal, the desired speed is achieved again on clear roads or the selected distance to the vehicle ahead is maintained.

Making braking possible

Anytime the driver presses down on the accelerator pedal, any braking action by the system is interrupted and the distance indicator goes out until the pedal is fully released. As soon as you fully release the accelerator, the system will again control your cruising speed and distance setting. While driving with the system activated, resting your foot on the acelerator pedal will cause the system not to brake even if necessary. Be certain that floormats or other objects on the vehicle floor do not interfere with movement of the accelerator pedal.

Limits of automatic braking

While active cruise control is capable of braking your vehicle automatically when you approach a slower vehicle ahead, it is important to be aware that the ability of the system to apply the brakes is also limited, e.g. when you reduce your desired speed sharply. It uses only a portion of braking system capacity and does not utilize the full capacity of the vehicle braking system. Therefore, the system cannot decrease your speed for large differences in speed between your vehicle and the vehicle ahead. Examples:

when you approach a vehicle traveling at a much lower speed than your own speed such as approaching a toll booth or when a much slower vehicle cuts in front of you at close range. ◄

Cruise control*

The concept

The system is functional at speeds beginning at approx. 20 mph/30 km/h.

The speed specified using the lever on the steering column is maintained.

The system brakes on downhill gradients if engine braking action is insufficient.


Do not use cruise control

Do not use the system if unfavorable conditions make it impossible to drive at a constant speed, for instance:

- On curvy roads.
- In heavy traffic.
- On slippery roads, in fog, snow or rain, or on a loose road surface.

Otherwise, you could lose control of the vehicle and cause an accident.◀

One lever for all functions



- Storing and maintaining speed or accelerating
- 2 Storing and maintaining speed or decelerating
- 3 Interrupting and deactivating the system
- 4 Resuming a speed stored beforehand

Maintaining current speed

Push, arrow 1, or pull, arrow 2, the lever to the resistance point.

The car's current speed is stored and maintained. It is displayed on the speedometer and briefly in the instrument cluster.

On uphill gradients, it may prove impossible to maintain the set speed if current engine power output is insufficient. If the engine braking effect is insufficient on downhill slopes, the system will brake the vehicle slightly.

Increasing desired speed

Repeatedly press the lever to the resistance point or beyond, arrow 1, until the desired speed is reached.

- ▶ Each time the lever is pressed to the point of resistance, the desired speed increases by approx. 1 mph/1 km/h.
- ▶ Each time the lever is pressed beyond the resistance point, the desired speed is increased by up to 5 mph/10 km/h.

The system stores and maintains the speed.

Accelerating using the lever

Accelerating slightly:

Press the lever to the resistance point, arrow 1, until the desired speed is reached.

Accelerating significantly:

Press the lever beyond the resistance point, arrow 1, until the desired speed is reached.

The vehicle accelerates without pressure on the accelerator pedal. The system stores and maintains the speed.

Decreasing speed

Repeatedly pull the lever to the resistance point or beyond, arrow 2, until the desired speed is displayed.

- Each time the lever is pulled to the resistance point, the desired speed is decreased by approx. 1 mph/1 km/h.
- ▶ Each time the lever is pulled beyond the resistance point, the desired speed is reduced

by up to 5 mph/10 km/h until the minimum speed of 20 mph/30 km/h is achieved.

The system stores and maintains the speed.

Interrupting the system

Press the lever up or down, arrow 3: display 1 in the speedometer changes color, refer to page 109.

In addition, the system is interrupted:

- When the brakes are applied.
- When the transmission position D is disengaged.
- When DTC is activated or DSC is deactivated.
- When DSC or ABS is intervening.

Warning lamp



The warning lamp lights up if cruise control has been deactivated automatically, e.g., by a control interven-

tion of the DSC. A message appears on the Control Display.

Resuming cruising speed

Press button 4:

The stored speed is resumed and maintained.

Deactivating the system

- Press the lever upward or downward twice, arrow 3.
- Switch off the ignition.

The stored speed is cleared.

Displays in the instrument cluster



Stored desired speed

- Green: the system is active.
- Orange: the system is interrupted.
- 2 Selected desired speed appears briefly

If the display --- mph or --- km/h appears briefly, conditions may not be adequate to operate the system.

Call up Check Control messages, refer to page 77.

Malfunction



The warning lamp comes on when the system has failed.

A message appears on the Control Display. More information, refer to page 76.

Park Distance Control PDC*

The concept

In addition to the PDC Park Distance Control, the backup camera*, refer to page 112, can be switched on.

PDC supports you when parking. A slow approach to an object in front of or behind your vehicle is announced by:

- Signal tones.
- Visual display.

Measurement

Measurements are made by ultrasound sensors in the bumpers.

The range is approx. 6 ft/2 m.

An acoustic warning is first given:

- By the front* sensors and two rear corner sensors at approx. 24 in/60 cm.
- By the rear middle sensors at approx. 5 ft/ 1.50 m.

System limits

Check the traffic situation as well PDC cannot serve as a substitute for the driver's personal judgment of the traffic situation. Check the traffic situation around the vehi-

cle with your own eyes. Otherwise, an accident could result from road users or objects located outside of the PDC detection range.

Loud noises from outside and inside the vehicle may prevent you from hearing the PDC's signal tone. ◀



Avoid driving quickly with PDC

Avoid approaching an object quickly.

Avoid driving away quickly while PDC is not yet active.

For technical reasons, the system may otherwise be too late in issuing a warning. ◀

Limits of ultrasonic measurement

The detection of objects can reach the physical limits of ultrasonic measurement, for instance:

- With tow bars and trailer hitches.
- With thin or wedge-shaped objects.
- With low objects.
- With objects with corners and sharp edges.

Low objects already displayed, e.g., curbs, can move into the blind area of the sensors before or after a continuous tone sounds.

High, protruding objects such as ledges may not be detected.

False warnings

PDC may issue a warning under the following conditions even though there is no obstacle within the detection range:

- In heavy rain.
- When sensors are very dirty or covered in ice.
- When sensors are covered in snow.
- On rough road surfaces.
- In large buildings with right angles and smooth walls, e.g., in underground garages.
- ▶ In heavy exhaust.
- Due to other ultrasound sources, e.g., sweeping machines, high pressure steam cleaners or neon lights.

Switching on automatically

With the engine running or the ignition switched on, shift the selector lever into position R.


Switching off automatically

The system switches off and the LED goes out:

- After approx. 165 ft/50 m when driving forward.
- After approx. 22 mph/35 km/h when driving forward.

Switch on the system again if necessary.

Switching on/off manually



Press the button.

- On: the LED lights up.
- Off: the LED goes out.

Signal tones

When approaching an object, an intermittent tone is sounded that indicates the position of the object. For example, if an object is detected to the left rear of the vehicle, a signal tone sounds from the left rear speaker.

The shorter the distance to the object becomes, the shorter the intervals.

If the distance to a detected object is less than approx. 12 in/30 cm, a continuous tone is sounded.

If objects are located both in front of and behind the vehicle, an alternating continuous signal is sounded.

The intermittent tone is interrupted after approx. 3 seconds:

- If the vehicle stops in front of an object that is detected by only one of the corner sensors.
- If moving parallel to a wall.

The signal tone is switched off:

- ▶ When the vehicle moves away from an object by more than approx. 4 in/10 cm.
- When transmission position P is engaged.

Volume

You can set the volume of the PDC signal tone, refer to page 173.

The setting is stored for the remote control currently in use.

Visual warning

The approach to an object can be shown on the Control Display. Objects that are farther away are displayed on the Control Display before a signal tone sounds.



The display appears as soon as PDC is activated.

If the last image selected was the rear view camera, this is displayed again. To switch to PDC:

Switch off rear view camera

The setting is stored for the remote control currently in use.

Image on the Control Display


Switching on the rear view camera using iDrive

With PDC activated:

Rear view camera"

The image of the rear view camera is displayed. The setting is stored for the remote control currently in use.

Malfunction



A Check Control message, refer to page 76, is displayed in the instrument cluster.

The areas in front of and behind the vehicle appear in shaded form on the Control Display. PDC has failed. Have the system checked.

To ensure full operability:

- Keep the sensors clean and free of ice.
- When using high-pressure washers, do not spray the sensors for long periods and maintain a distance of at least 12 in/30 cm.

Surround View*

The concept

Surround View encompasses the following systems:

- ▶ Backup camera*, refer to page 112.
- ▶ Top View*, refer to page 114.
- Side View*, refer to page 116.

It provides assistance when parking and maneuvering and at blind driveways and intersections.

Backup camera*

The concept

The rear view camera assists you when parking and maneuvering in reverse. To accomplish this,

the region behind your vehicle is shown on the Control Display.

System limits

Check the traffic situation as well
Check the traffic situation around the vehicle with your own eyes. Otherwise, an accident could result from road users or objects located outside the picture area of the backup camera.

Detection of objects
High, protruding objects such as ledges
may not be detected by the backup camera. ◄

Switching on automatically

With the engine running or the ignition switched on, shift the selector lever into position R.

The image of the rear view camera is displayed when the system has been switched on using iDrive.


Switching off automatically

The system switches off and the LED goes out:

- After approx. 33 ft/10 m when driving forward.
- After approx. 9 mph/15 km/h when driving forward.

Switch on the system again if necessary.

Switching on/off manually



Press the button.

- On: the LED lights up.
- Off: the LED goes out.


If PDC is displayed, switch on the backup camera via the iDrive, refer to page 111.

Assistance functions

Functional requirement

- Rear view camera is switched on.
- Tailgate is completely closed.


Pathway lines



- Can be displayed in the image of the rear view camera when the transmission is in reverse.
- Help estimate the required amount of space when parking and maneuvering on a flat road surface.
- Depend on the current steering angle and are continuously adapted to movements of the steering wheel.

Show the parking aid lines via the iDrive, refer to page 114.

Turning lines




- Can be displayed in the image of the rear view camera.
- Show the path of the smallest turning circle on a flat road surface.
- When the steering wheel is turned, only one turning line is displayed.


Show the parking aid lines via the iDrive, refer to page 114.

Parking using pathway and turning lines


 Position the vehicle so that the turning lines lead into the margins of the parking space.



Turn the steering wheel to the point where the pathway line covers the corresponding turning circle line.



Obstacle marking



Three-dimensionally shaped markings can be displayed in the image of the rear view camera.

Their color gradation corresponds to the markings in PDC. This helps estimate the distance to the object pictured.

Show the obstacle marking via the iDrive, refer to page 114.

Activating assistance functions

Several assistance functions can be active at the same time.

Showing the parking aid lines

"Parking aid lines"

Pathway and turning lines are displayed.

Showing the obstacle marking

Three-dimensionally-shaped markings are displayed.

Image on the Control Display

Switching on the rear view camera using iDrive

With PDC activated:

Rear view camera"

The image of the rear view camera is displayed. The setting is stored for the remote control currently in use.

Brightness

With the rear view camera switched on:

- 1. Select the symbol.
- 2. Turn the controller until the desired setting is reached and press the controller.

Contrast

With the rear view camera switched on:

- 2. Turn the controller until the desired setting is reached and press the controller.

Camera



The lens of the rear view camera is under the grasping lip of the tailgate.

The presence of dirt can impair image quality. Clean the lens with a moist, nonabrasive cloth.

Top View*

The concept

Top View assists you when parking and maneuvering. To accomplish this, the door region and road surface region are shown on the Control Display.

Detection

Detection is carried out by two cameras integrated into the exterior mirror and the rear view camera.

The range is:

- ▶ Approx. 7 ft/2 m to the side.
- Approx. 7 ft/2 m to the rear.

Obstacles up to the height of the exterior mirrors are thus detected in a timely fashion.

System limits

Top View cannot be used in the following situations:

- With a door open.
- With the tailgate open.
- With an exterior mirror folded in.
- ▶ In poor light.

The arrows next to the vehicle are displayed in a shaded form on the Control Display and a sym-

bol appears at the corresponding location on the vehicle.

Check the traffic situation as well Check the traffic situation around the vehicle with your own eyes. Otherwise, an accident could result from road users or objects located outside the picture area of the cameras.

Switching on automatically

Select transmission position R with the engine running.

The images from Top View and PDC are displayed when the system has been switched on using iDrive.

Switching off automatically

The system switches off and the LED goes out:

- After approx. 165 ft/50 m when driving forward.
- After approx. 22 mph/35 km/h when driving forward.

Switch on the system again if necessary.

Switching on/off manually



Press the button.


- On: the LED lights up.
- Off: the LED goes out.

If Top View is displayed, switch on the backup camera via the iDrive, refer to page 114.

Visual warning

The approach to an object can be shown on the Control Display.

When the distance to an object is small, the PDC display correspondingly shows a red bar in front of the vehicle.



The display appears as soon as Top View is activated.

If the last image selected was the rear view camera, this is displayed again. To switch to Top View:

"Rear view camera" Select the symbol on the Control Display.

The setting is stored for the remote control currently in use.

Image on the Control Display

Switching on the rear view camera using iDrive

With Top View activated:

Ra "Rear view camera"

The image of the rear view camera is displayed. The setting is stored for the remote control currently in use.

Brightness

With Top View switched on:

- 1. : Brightness"
- Turn the controller until the desired setting is reached and press the controller.

Contrast

With Top View switched on:

- 1. \(\bigcap \) "Contrast"
- Turn the controller until the desired setting is reached and press the controller.

Displaying turning lines and pathway lines

- The static, red turning line shows the lateral space required when the wheel is fully turned.
- The variable, green pathway lines assist you in estimating the amount of lateral space actually required.

The pathway lines depend on the current steering angle and are continuously adapted to movements of the steering wheel.

"Parking aid lines"

Turning lines and pathway lines are displayed.

Cameras



The lenses of the Top View cameras are on the undersides of the exterior mirror housings.

The presence of dirt can impair image quality. Clean the lens with a moist, nonabrasive cloth.

Side View*

The concept

Side View provides an early look at cross traffic at blind driveways and intersections. Road users concealed by obstacles to the left and right of the vehicle can only be detected from the driver's seat at the last minute. To improve visibility, two cameras in the front of the vehicle record the traffic situation on each side.

System limits

The cameras capture a maximum range of 330 ft/100 m.

Display

The images from both cameras are shown simultaneously on the Control Display.


Check the traffic situation as well
Check the traffic situation around the vehicle on blind driveways and intersections with your own eyes. Otherwise, an accident could result from road users or objects located outside the picture area of the Side View cameras.

Switching off automatically

System switches off: above approx. 9 mph/ 15 km/h.

Switch on the system again if necessary.


Switching on/off manually



Press the button.

Image on the Control Display

The traffic area to the left and right is displayed on the Control Display.



Guidelines at the bottom of the image show the position of the front of the vehicle.

Brightness

With the Side View switched on:

- 1. 'A' "Brightness"
- 2. Turn the controller until the desired setting is reached and press the controller.

Contrast

With the Side View switched on:

- Contrast"
- 2. Turn the controller until the desired setting is reached and press the controller.

Cameras



The two camera lenses are located on the sides of the bumper.

The presence of dirt can impair image quality. Clean the lens, refer to page 287.

Head-up Display*

The concept

This system projects important information into the driver's field of vision, e.g., navigation instructions.

In this way, the driver can get information without averting his or her eyes from the road.



Switching on/off



Press the button.


Display visibility

The visibility of the displays in the Head-up Display is influenced by:

- Certain sitting positions.
- Objects on the cover of the Head-up Dis-
- Sunglasses with certain polarization filters.
- Wet roads.
- Unfavorable light conditions.

If the image is distorted, check the basic settings.

Display




- 1 Navigation instructions*
- 2 Active Cruise Control with Stop & Go function*
- 3 Lane departure warning*
- 4 Cruise control/desired speed*
- 5 Current speed

The Check Control messages are displayed briefly if needed.

Selecting displays in the Head-up Display

- 1. "Settings"
- 2. "Head-up display"
- 3. "Displayed information"
- Select the desired displays in the Head-up Display.



The settings are stored for the remote control currently in use.

Setting the brightness

The brightness is automatically adjusted to the ambient light.

The basic setting can be adjusted manually.

- 1. "Settings"
- "Head-up display"
- 3. "Brightness"
- 4. Turn the controller.

The brightness is adjusted.

With the low beams switched on, the brightness can also be adjusted with the thumbwheel of the instrument lighting.

The setting is stored for the remote control currently in use.

Height adjustment

- 1. "Settings"
- "Head-up display"
- 3. "Height"
- Turn the controller.

The height is adjusted.

The setting is stored for the remote control currently in use.

Special windshield

The windshield is part of the system.


The shape of the windshield makes it possible to display a precise image.

A film in the windshield prevents double images from being displayed.

Therefore, have the special windshield replaced by a service center only.

Climate


At a glance



- 1 Air toward the windshield and side windows
- 2 Air for the upper body
- 3 Air to footwell
- 4 Automatic climate control with 2-zone control 120

Automatic climate control with 4-zone control 124

Automatic climate control with 2-zone control



- Seat heating and ventilation, driver's side 49
- 2 Temperature, left side of passenger compartment
- 3 AUTO program
- 4 Temperature, right side of passenger compartment
- 5 Maximum cooling
- 6 Seat heating and ventilation, front passenger side 49
- 7 Passenger side
 - Manual air distribution

- Accessing setting for ventilation temperature on the Control Display
- 8 Switching cooling function on/off manually
- 9 Automatic recirculated air control/recirculated air mode
- 10 Manual air volume, switching off automatic climate control, residual heat
- 11 Rear window defroster
- 12 Defrosting windows and removing condensation
- **13** Air grill for interior temperature sensor, please keep clear and unobstructed
- 14 Driver's side
 - Manual air distribution
 - Accessing setting for ventilation temperature on the Control Display

The current setting for manual air distribution is displayed on the Control Display.

Comfortable interior climate

The AUTO program offers the optimum air distribution and air volume for virtually all conditions, refer to AUTO program below. Select a comfortable interior temperature only.

The following sections contain more detailed information on the available setting options.

Most of these settings are stored for the remote control currently in use, Personal Profile settings, refer to page 29.

AUTO program



Press the button.

Air volume, air distribution, and temperature are controlled automatically.

Depending on the selected temperature, AUTO intensity, and outside influences, the air is directed to the windshield, side windows, upper body, and into the footwell.

The cooling function is switched on automatically with the AUTO program.

At the same time, a condensation sensor controls the program in such a way that window condensation is prevented as much as possible.

To switch off the program: press the button again or manually adjust the air distribution.

Intensity of the AUTO program

Pressing the AUTO button repeatedly adjusts the intensity of the AUTO program. The selected intensity, SOFT, MEDIUM or INTENSIVE, appears on the display of the automatic climate control.

Temperature



Turn the wheel to set the desired temperature.

The automatic climate control achieves this temperature as quickly as possible, if necessary with the max-

imum cooling or heating capacity, and then keeps it constant.

Avoid rapidly switching between different temperature settings. The automatic climate control will not have sufficient time to adjust the set temperature.

Maximum heating power can be obtained with the highest setting, regardless of the external temperature.

At the lowest setting, cooling is continuous, regardless of the external temperature.


Adjusting the ventilation temperature

This function can be used to adjust the air temperature for the upper body region.

- "Settings"
- 2. "Climate"
- 3. "Driver ventilation" or "Front passenger ventilation"
- 4. Turn the controller to adjust the temperature.

Blue: colder

Red: warmer



Defrosting and defogging windows

Press the button.

Ice and condensation are quickly removed from the windshield and the front side windows.

For this purpose, also switch on the cooling function.

Rear window defroster

Press the button.

The rear window defroster switches off automatically after a certain period of time.

Depending on the vehicle equipment, upper wires are used as an antenna and are not part of the rear window defroster.

Air volume, manual



You can vary the air volume by pressing on the corresponding side. You can reactivate the automatic mode for the air flow rate

with the AUTO button.

Manual air distribution

The air flow can be guided into the vehicle interior, separately for the driver's and front passenger side, using one of the following programs:

- Upper body region.
- Upper body region and footwell.
- Footwell.
- ▶ Driver's side: in addition, the windshield, side windows, and footwell.

Selecting program



Press the button repeatedly until the desired program is shown on the Control Display.



- 1 Air toward the windshield and side windows
- 2 Air for the upper body
- 3 Air to footwell

Pressing the AUTO button cancels the manual air distribution settings.

The automatic mode for the air volume remains effective with manual air distribution.

Cooling function

The passenger compartment can only be cooled with the engine running.

₩;

Press the button.

The air is cooled and dehumidified and – depending on the temperature setting – warmed again.

The cooling function helps to prevent condensation on the windows or to remove it quickly.

Depending on the weather, the windshield may fog up briefly when the engine is started.

The cooling function is switched on automatically with the AUTO program.

When using the automatic climate control, condensation water, refer to page 144, develops that exits underneath the vehicle.

Maximum cooling



Press the button.

The system is set to the lowest temperature, maximum air volume and recirculated-air mode.

Air flows out of the vents for the upper body region. Open them for this purpose.

Air is cooled as quickly as possible:

- At an external temperature of approx. 32 °F/ 0 °C.
- When the engine is running.

Automatic recirculated air mode/ recirculated air mode

You can respond to unpleasant odors or pollutants in the immediate environment by temporarily suspending the supply of outside air. The system then recirculates the air currently within the vehicle.



Press the button repeatedly to select an operating mode:

- LEDs off: outside air flows in continuously.
- Left LED on, automatic recirculated-air control: a sensor detects pollutants in the outside air and controls the shutoff automatically.
- Right LED on, recirculated air mode: the supply of outside air into the vehicle is permanently blocked.

If the windows are fogged over, switch off the recirculated-air mode and press the AUTO button to utilize the condensation sensor. Make sure that air can flow onto the windshield.

Continuous recirculated-air mode
The recirculated air mode should not be
used for an extended period of time, as the air
quality inside the vehicle deteriorates steadily.

Residual heat

The heat stored in the engine is used to heat the interior.

Functional requirement

- Up to 15 minutes after the engine has been switched off.
- Warm engine.
- The battery is sufficiently charged.
- External temperature below 77 °F/25 °C.

Switching on

- 1. Switch off the ignition.
- 2. Press the right-hand button.



REST appears on the display of the automatic climate control when the residual heat utilization is switched on.

From radio readiness the interior temperature, the air volume and the air distribution can be set.

Switching off

You can select the lowest blower speed by pressing and holding the left side. Pressing again switches off the residual heat utilization. REST disappears from the display of the automatic climate control.

Switching on/off the automatic climate control


Switching off

With the blower at its lowest setting, press the left side of the button to switch off the automatic climate control.

Switching on

Press any button to switch the automatic climate control back on.

Front ventilation



- Use the thumbwheels to smoothly open and close the air vents
- 2 Use the lever to change the direction of the air flow

Avoiding injury

Do not drop any foreign objects into the air vents, otherwise these could be catapulted outwards and lead to injuries. ◄

Ventilation for cooling

Adjust the vents to direct the flow of cool air in your direction, for instance if the interior has become too warm.

Draft-free ventilation

Set the air vents so that the air flows past you and is not directed straight at you.


Ventilation in rear



- Use the thumbwheels to smoothly open and close the air vents
- 2 Use the lever to change the direction of the air flow

BMW X5: heating and ventilation, 3rd row seats

The air in the area of the 3rd row seats can be heated or recirculated. Air vents are located in the storage compartment area between the seats and in the footwell of the 3rd row seats.



Thumbwheel

 Activating heating and distributing air in footwell:

Turn toward front

 Distributing air in storage compartment area between seats:

Turn toward rear

2 Button for switching on the blower: LED is lit

The heating is not ready for operation without switching on the blower. After the heating is switched off, the blower can be used to recirculate the air within the vehicle, for instance at high temperatures. To do this, turn thumbwheel 1 toward the rear and switch on the blower, button 2.

Microfilter/activated-charcoal filter

The microfilter traps dust and pollen in the incoming air.

The activated-charcoal filter removes gaseous pollutants from the outside air that enters the vehicle.

The service center replaces this combined filter during routine maintenance.

More information can be found in the service requirements display, refer to page 75.

Automatic climate control with 4-zone control*

Front operation

Corresponds to the operation of automatic climate control with 2-zone control, refer to page 120.

Rear operation

The control unit is located in the center console in the rear.




- 1 Temperature, left rear seating area
- 2 AUTO program
- 3 Display
- 4 Temperature, right rear seating area
- 5 Seat heating, right rear seat
- 6 Air volume, manual
- 7 Seat heating, left rear seat

The current setting for the temperature and the air flow rate is shown on display 3.

Activation/deactivation

- 1. "Settings"
- 2. "Climate"
- 3. "Rear climate control"
- 4. Select the desired settings.



The rear automatic climate control cannot be operated if the front automatic climate control is switched off. With the defrost windows and eliminate condensation function activated, the rear automatic climate control is also not ready for operation.

מומומומו

AUTO program



The AUTO program automatically sets the air distribution toward the upper body and in the footwell, as well as the air flow rate. It also adapts your instructions for the

temperature to outside influences throughout the year.

Temperature



Set the desired temperature individually on the left and right side.

The automatic climate control achieves this temperature as quickly as possible regardless of the season, using maximum cooling or heating power if necessary, and then maintains it.

When switching between different temperature settings in rapid succession, the automatic climate control does not have sufficient time to adjust the set temperature.

Air volume, manual

The air flow rate can be varied by pressing on the corresponding side. The automatic mode for the air flow rate can be switched on again using the AUTO button.


Switching off rear automatic climate control

With the blower at its lowest setting, press the left side of the button to switch off the automatic climate control.

The automatic climate control can also be switched off with iDrive. To switch on the automatic climate control again, the system must first be reactivated, refer to Activating/deactivating.


The system is switched on again by pressing any button of the rear automatic climate control.

Ventilation in rear



- 1 Use the thumbwheels to smoothly open and close the air vents
- 2 Thumbwheels to adjust temperature in upper body region; can be adjusted separately for left and right:
 - ▶ Blue: colder
 - Red: warmer
- 3 Use the lever to change the direction of the air flow

BMW X5



- Use the lever to change the direction of the air flow
- 2 Thumbwheel to smoothly open and close air vents

For ventilation of the 3rd row seats, refer to page 123.

Parked-car ventilation*

The concept

The parked-car ventilation blows air into the passenger compartment to lower interior temperatures.

The system can be switched on and off at any external temperature, either directly or by using a preset switch-on time. It remains switched on for 30 minutes.


Since the system uses a substantial amount of electrical current, refrain from activating it twice in succession without allowing the battery to be recharged in normal operation between use.

Open the vents to allow air to flow out.

They can be operated via iDrive.

Switching on/off directly


- "Settings"
- "Climate"
- "Activate parked-car vent."



The symbol on the automatic climate control flashes if the system is switched on.

Preselecting activation times

- 1. "Settings"
- 2. "Climate"
- 3. "Activate Timer 1" or "Activate Timer 2"
- 4. "Timer 1:" or "Timer 2:"



- Set the desired time.
- # The symbol on the automatic climate control lights up when the switch-on time is activated.

He symbol on the automatic climate control flashes when the system has been switched on.

The system will only be switched on within the next 24 hours. After that, it needs to reactivated.

Interior equipment

Integrated universal remote control*

The concept

This system can replace up to three different hand-held transmitters for various types of remote-controlled equipment, such as garage doors or lighting systems.

The hand-held transmitter signal can be programmed on one of the three memory buttons.

The corresponding device can then be operated using the programmed memory button.

The LED indicates that a signal is being transmitted.

When selling the vehicle, delete the stored programs for security reasons.

During programming

During programming and before activating a device using the integrated universal remote control, ensure that there are no people, animals or objects in the range of movement of the remote-controlled device; otherwise, there is a risk of injury or damage.

Also follow the safety instructions of the handheld transmitter. ◀

Compatibility




If this symbol is printed on the packaging or in the instructions of the hand-held transmitter, the remote-controlled de-

vice is generally compatible with the universal remote control.

If you have any questions, please contact:

- Your service center.
- www.homelink.com on the Internet.

Programming



- 1 Memory buttons
- 2 **LED**

Fixed-code hand-held transmitters

- 1. Switch on the ignition, refer to page 61.
- Initial setup:

Press both outer memory buttons 1 for approx. 20 seconds until the LED flashes.

All programs of the three memory buttons 1 are cleared.

3. Hold the hand-held transmitter at a distance of approx. 1 to 3 in/2.5 to 8 cm from the memory buttons.

The required distance depends on the particular hand-held transmitter.

4. Simultaneously press the transmit button of the hand-held transmitter and the memory button of the integrated universal remote control.

The LED flashes slowly.

Release both buttons when the LED flashes rapidly.

If the LED does not flash rapidly after approx. 60 seconds, change the distance and repeat the step.

Canada: if the LED does not flash rapidly after approx. 60 seconds, change the distance and repeat the step. If programming was aborted by the hand-held transmitter, hold down the memory button and press and re-

- lease the button on the hand-held transmitter several times for 2 seconds.
- 6. To program additional hand-held transmitters, repeat steps 3 to 5.

The device can be operated using the memory button with the engine running or the ignition switched on.

Malfunction

If the device cannot be used after repeated attempts at programming, please check whether the hand-held transmitter is equipped with an alternating code system.

To do so:

- Read the instructions of the hand-held transmitter.
- Press the memory button of the universal remote control for an extended period.

If the LED of the integrated universal remote control flashes quickly for a short period and then lights up continuously, the hand-held transmitter is equipped with an alternating code system.

In this case, program the memory buttons as described under Alternating-code hand-held transmitters.

Alternating-code hand-held transmitters

Please obtain information on synchronizing the device in the operating manual of the device being set up.

Programming will be easier with the aid of a second person.

- Park the vehicle within range of the remotecontrolled device.
- Program the integrated universal remote control as described above under Fixedcode hand-held transmitters.
- 3. Locate the button on the receiver of the device to be set, e.g., on the drive.

- 4. Press the button on the receiver of the device to be set. You have approx. 30 seconds for the next step.
- Press the programmed memory button of the integrated universal remote control for approx. 3 seconds. Repeat this step up to three times if necessary.

The device can be operated using the memory button with the engine running or the ignition switched on.

Reassigning individual programs

- 1. Switch on the ignition.
- Hold the hand-held transmitter at a distance of approx. 1 to 3 in/2.5 to 8 cm from the memory buttons.
 - The required distance depends on the particular hand-held transmitter.
- 3. Press the memory button of the integrated universal remote control.
- If the LED flashes slowly after approx.
 seconds, press the transmit button on the hand-held transmitter.
- Release both buttons when the LED flashes rapidly.

If the LED does not flash rapidly after approx. 60 seconds, change the distance and repeat the step.

Canada: if the LED does not flash rapidly after approx. 60 seconds, change the distance and repeat the step. If programming was aborted by the hand-held transmitter, hold down the memory button and press and release the button on the hand-held transmitter several times for 2 seconds.


Deleting all stored programs

Press both outer memory buttons 1 for approx. 20 seconds until the LED flashes rapidly.

All stored programs are deleted.

The programs cannot be deleted individually.

Digital compass*



- 1 Adjustment button
- 2 Display

The display shows you the main or secondary compass direction in which you are driving.

Setting compass zones


Set the compass zone corresponding to the vehicle's geographic location so that the compass

Operating concept

Various functions can be called up by pressing the adjustment button with a pointed object such as a pen. The following adjustment options are displayed one after the other, depending on how long the adjustment button is pressed:

- Press briefly: switch the display on/off.
- > 3 to 6 seconds: set the compass zone.
- ▶ 6 to 9 seconds: calibrate the compass.
 - 9 to 12 seconds: set left-hand/right hand steering.
- ▶ 12 to 15 seconds: set the language.

can function correctly; refer to the world map with compass zones.



Press the adjustment button for 3-4 seconds. The number of the compass zone set is shown in the display.

To change the zone setting, briefly press the adjustment button repeatedly until the display shows the number of the compass zone corresponding to the current location.

The compass is operational again after approx. 10 seconds.

Calibrating the digital compass

The digital compass must be calibrated in the following situations:

An incorrect compass direction is shown.

- The cardinal direction displayed does not change even if the direction of travel changes.
- Not all compass directions are shown.

Procedure

- Make sure that there are no large metal objects or overhead power lines in the vicinity of the vehicle and that there is enough space to drive in a circle.
- 2. Set the currently valid compass zone.
- Press the adjustment button for 6-7 seconds to call up C. Then drive at least one full circle at a maximum speed of 4 mph/7 km/h.
 When the system is calibrated, the C is replaced by the compass directions.

Right-hand/left-hand steering

The digital compass is set for right-hand or lefthand steering at the factory.

Setting the language


Press the adjustment button for 12-13 seconds. Briefly press the adjustment button again to switch between English "E" and German "O".

The setting is automatically saved after approx. 10 seconds.

Ashtray/cigarette lighter*

Opening

Front



To open the cover, slide it forward.

Rear

BMW X6



Slide the cover back.

Emptying

Take out the insert.

Lighter



With the engine running or the ignition switched on, press in the cigarette lighter.

The lighter can be removed as soon as it pops back out.

Danger of burns

Only hold the hot lighter by its head; otherwise, there is the danger of getting burned.

Switch off the ignition and take the remote control with you when leaving the vehicle so that children cannot use the lighter and burn themselves.


Connecting electrical devices

Sockets

The lighter socket can be used as a socket for electrical equipment while the engine is running or when the ignition is switched on. The total load of all sockets must not exceed 140 watt at 12 volt.

Avoid damaging the sockets by attempting to insert plugs of unsuitable shape or size.

Front center console



Slide the cover forward.

To access the socket: remove the cap or pull out the cigarette lighter*.


Rear center console*



The arrangement of the sockets* may vary with the equipment.


To access the sockets: remove the caps.

In storage compartment under center armrest*



To access the socket*: remove the cover.

In the cargo area*



To access the socket: fold open the cover.

BMW X6: in the rear console




Slide the cover back.

To access the socket: pull off the cover.

Cargo area

BMW X5: luggage compartment roller cover



Pull out the luggage compartment roller cover and hook it into the brackets.

Do not deposit heavy objects
Do not deposit heavy or hard objects on
the luggage compartment roller cover. Otherwise, they may present a danger to occupants,
forinstance during braking and evasive maneuvers.

✓




Do not let the luggage area retractable cover snap back

Do not let the luggage compartment retractable cover snap back as this could damage the cover.◀

Removing

1. Unlock the case with the button, arrow 1.



2. Swing the case somewhat to the left, arrow 2, and remove it.

Installing

When installing, proceed in the opposite order of removal.



- Lay the case on the left-hand side and push it forward, arrow 1.
- Swing the case toward the inside, see arrow 2.
- 3. Push the case forward at the ends until it engages in the two side brackets.
- Check whether the case is properly locked in place by pulling it with a sudden movement.

BMW X6: cargo cover



Deploy cargo cover by pulling back.

Do not deposit heavy objects

Do not deposit heavy or hard objects on
the cargo cover. Otherwise, they may present a
danger to occupants, forinstance during braking
and evasive maneuvers.

Removing



- 1. Grasp retracted cargo cover underneath the upper fold on both sides.
- 2. Pull the cover back out of the side brackets.
- Depending on your vehicle's equipment package, you can store the cover under the floor panel in the cargo area.



Installing

When installing, proceed in the opposite order of removal.

- 1. Set the cargo cover into place on the left and right sides.
- 2. Lift the back of the cover slightly and slide forward until it snaps into the two side brackets.

Enlarging the cargo area

The rear seat backrest is divided. You can fold down both sides separately in order to expand the cargo area.



BMW X6: before folding the rear seat backrest forward

Before folding the rear seat backrest forward or using the ski bag, remove beverage containers from the cupholder and close the cupholder. ◄



Reach into the recess and pull toward the front.

Locking the backrest

Before letting passengers ride in the rear. engage the seat backrests, locking them in place. Otherwise, there is the danger of an accident due to unexpected seat movement. ◀

Ensure that the lock is securely engaged When folding back the backrest, be sure that it locks in place securely. The red warning field in the control display disappears. If it is not properly engaged, transported cargo could enter the passenger compartment during braking or evasive maneuvers and endanger the vehicle occupants.◀




Observe the instructions concerning the safety belt

Observe the instructions concerning the safety belt, refer to page 50. Otherwise, personal protection may be compromised. ◄

Storage compartments

Glove compartment

Opening



Press the button. The covers open upward and downward and the lighting in the glove compartment switches on.



Close the glove compartment again immediately

Close the glove compartment immediately after use while driving; otherwise, injury may occur during accidents. ◀

Closing

Press one of the two covers closed.

USB interface for data transfer



Port for importing and exporting data, such as music collections, refer to page 188, on USB devices.

Observe the following when connecting:

Do not use force when plugging the connector into the USB interface.

- Do not connect devices such as fans or lamps to the USB interface.
- Do not connect a USB hard drive.
- Do not use the USB interface to recharge external devices.

Center armrest front*

Storage compartment

A storage compartment is located under the armrest between the front seats and, depending on the vehicle's equipment, also a cover for the mobile phone cradle or the snap-in adapter.

Details on this mobile phone cradle, refer to page 225.

Opening



Push cover down slightly and press the button. The cover folds upward.

Connection for an external audio device

You can connect an external audio device such as a CD or MP3 player and play audio tracks over the car's loudspeaker system:

- AUX-IN port, refer to page 192.
- ▶ USB audio interface, refer to page 193.

Rear center armrest

BMW X6 and BMW X5 with 3rd row seats*



Pull on the loop and fold down the center armrest.

BMW X5 without 3rd row seats*



Unlock the center armrest with the button in the lower section of the opening and fold down.

Storage compartments

Compartments are located in the doors, in the center console in the front and rear* as well as in the rear console in the BMW X6.

Storage nets* are located on the backrests of the front seats.

Items in the storage nets


Do not stow hard or sharp-edged objects in the storage nets; otherwise there is an increased risk of injury in the event of an accident.◀

Clothes hooks

BMW X5

The clothes hooks are located at the grab handles in the rear.

BMW X6



To fold out, press against upper edge.

Do not obstruct view When suspending clothing from the hooks, ensure that it will not obstruct the driver's vision.◀

No heavy objects

Do not hang heavy objects from the hooks: otherwise, they may present a danger to passengers during braking and evasive maneuvers.◀

Cupholders*

Notes



Shatter-proof containers and no hot drinks

Use light and shatter-proof containers and do not transport hot drinks. Otherwise, there is the increased danger of injury in an accident. ◀

Unsuitable containers Do not forcefully push unsuitable containers into the cupholders. This may result in damage.◀

Front



Slide the cover back.

Rear

BMW X5




Unlock the center armrest with the button in the lower section of the opening and fold down.



Press the button; the cover folds forward.

With 3rd row seats*:



Fold down the center armrest. Press the button; the cupholders are opened.

The cupholders of the 3rd row seats are located in the center console between the seats.

BMW X6



Slide the cover forward.



Folding down the rear seat backrest and using the ski bag

Remove the beverage container before folding the rear seat backrest forward or using the ski bag; otherwise it may cause damage. ◀

Storage compartments in the cargo area

Depending on the vehicle's equipment, the following storage compartments can be found in the cargo area:


- Storage compartments behind the removable side panels on the right and left in the cargo area* and under the cargo floor cover, storage compartment* on the right in the cargo area.
- Storage well* under the cargo floor cover.

- Retaining straps* on the left and right side trim for fastening small objects.
- Lashing rail with lashing eyes*. You can secure heavy-duty cargo straps on the lashing eyes. They can be removed at the notches in the rails. To move the lashing eyes, press the button.

Read and comply with the information enclosed with the heavy-duty cargo straps.

Floor panel flap





To access the onboard vehicle tool kit etc.

To open, swing up the flap by the handle, refer to arrow.


The cargo floor cover is lockable*.

Adaptive fixing system*

The adaptive fixing system is used to divide up the cargo area. It consists of two brackets with a telescopic rail and retaining straps. These are quided into the two rails on the cargo area floor.

Securing cargo

Before using the adaptive fixing system, fold up and lock the rear seat backrest; otherwise, the cargo could be thrown into the vehicle interior in an accident.



- 1 Brackets
- 2 Telescopic rail
- Notch in the cargo area rail

Mounting brackets

The two brackets are connected with a telescopic rail.


- 1. Insert the brackets at the respective notch in the rail on the cargo area floor.
- 2. Press down the brackets to push them into the desired position.
- 3. Check the firm seating of the brackets. They must be clearly heard to engage.

No cargo on brackets

Do not lay cargo on the brackets, as otherwise they could be unlocked.

✓

Dividing up cargo area



The cargo can be positioned as follows:

- ▶ Between the rear seat backrest and the telescopic rail
- Between the telescopic rail and the retaining strap

Positioning cargo between telescopic rail and retaining strap:

- 1. Lay the cargo on the telescopic rail. Press the button, arrow 1, and route the retaining strap around the cargo, arrow 2.
- 2. Hook the retaining strap into the mount 3 on the telescopic rail.
- Press the button of the bracket, arrow 1. The retaining strap is tensioned.

It is also possible to hook the two retaining straps onto each other.

When the adaptive fixing system is no longer needed, unhook the retaining strap and guide it back into the bracket holding the hook to prevent damage and injury.

Then slide the fastening system toward the front in order to permit the best possible use of the cargo area.

Removing brackets

Press down the brackets, slide them up to the notches of the rails and remove them.

Depending on the vehicle's equipment, the adaptive fixing system can be stored under the cargo floor panel in the cargo area.

Ski bag*

The ski bag is designed for safe, clean transport of up to 4 pairs of standard skis or up to 2 snow-boards.


Skis with a length of up to 6 ft/2.10 m can be stowed using the ski bag. When stowing skis with a length of 6 ft/2.10 m, the capacity of the ski bag is reduced as the bag narrows.

Folding in display screen

Before loading the ski bag, fold in the display screen of the DVD systems in the rear*;
otherwise, the display screen could be damaged.

Loading

 Fold down the center armrest, press the button and open the cover.



- Press the button again; the cover in the cargo area opens. If you press the button firmly the first time, this cover also opens.
- Extend the ski bag between the front seats and fill it. The zipper facilitates access to the stowed items and drying of the ski bag.
- Attach the retaining strap:

BMW X5: insert the latch plate of the ski bag retaining strap into the center safety belt buckle that is marked CENTER.



BMW X6: attach the hook of the ski bag retaining strap to the eyelet on the backrest.



Only stow clean skis in the ski bag. Wrap sharp edges to prevent damage.

Securing cargo



After loading, secure the ski bag and its contents. Tighten the retaining strap on the tensioning buckle for this purpose.

Securing the ski bag
Secure the ski bag in this way. Failure to
do so may cause it to endanger occupants during braking or evasive maneuvers. ◄

To store the ski bag, perform the above steps in reverse order.

Removing ski bag

The ski bag can be completely removed, e.g., for faster drying or to allow it to be put to other uses.



- 1. Pull the handle forward, arrow 1.
- 2. Take out the ski bag upward, arrow 2.
- 3. Close the cover in the cargo area.

More information on the various inserts available can be obtained from the service center.



Driving tips This section provides you with information useful in dealing with specific driving and operating conditions.

Things to remember when driving

Breaking-in period

General information

Moving parts need to be broken in to adjust to each other.

The following instructions will help achieve a long vehicle life and good economy.

Engine and differential

Always obey all official speed limits.

Up to 1,200 miles/2,000 km

Do not exceed the maximum engine and road speeds:

- For gasoline engine, 4,500 rpm and 100 mph/160 km/h.
- For diesel engine, 3,500 rpm and 93 mph/ 150 km/h.

Avoid full-throttle operation and use of the transmission's kickdown mode for the initial miles.

From 1,200 miles/2,000 km

The engine and vehicle speed can gradually be increased.

Tires

Due to technical factors associated with their manufacture, tires do not achieve their full traction potential until after an initial breaking-in period.

Drive conservatively for the first 200 miles/ 300 km.

Brake system

Brakes require an initial break-in period of approx. 300 miles/500 km to achieve optimized contact and wear patterns between brake pads and rotors. Drive cautiously during this break-in period.

Following part replacement

The same breaking in procedures should be observed if any of the components mentioned above have to be renewed in the course of the vehicle's operating life.

General driving notes

Closing tailgate

Drive with the tailgate closed
Only drive with the tailgate closed; otherwise, passengers and other road users may be endangered or the vehicle may be damaged if an accident occurs or during braking or evasive maneuvers. In addition, exhaust fumes may enter the passenger compartment.

If the vehicle must be driven with the tailgate open:

- 1. Drive moderately.
- 2. Close all windows and the glass sunroof*/ panoramic glass sunroof*.
- 3. Greatly increase the blower speed.

Hot exhaust system

Hot exhaust system
High temperatures are generated in the exhaust system.

Do not remove the heat shields installed and never apply undercoating to them. Make sure that flammable materials, e. g. hay, leaves, grass, etc. do not come in contact with the hot exhaust system during driving, while in idle position mode, or when parked. Such contact could lead to a fire, and with it the risk of serious personal injury as well as property damage.

Do not touch hot exhaust pipes; otherwise, there is the danger of getting burned. ◀

Diesel particulate filter*

Soot particles are collected in the diesel particulate filter and periodically burned away at high temperatures.

During the cleaning period of several minutes:

- The engine may temporarily run less smoothly.
- A somewhat higher engine speed may be necessary to achieve the accustomed performance.
- Noises and a slight amount of smoke may emerge from the exhaust, even for a short period after the engine is switched off.

Mobile communication devices in the vehicle



Mobile communication devices in the ve-

It is not recommended to use mobile phones, such as mobile phones without a direct connection to an external aerial in the vehicle's passenger compartment. Otherwise, the vehicle electronics and mobile communication devices can interfere with each other. In addition, there is no assurance that the radiation generated during transmission will be discharged from the vehicle interior.◀

Hydroplaning

On wet or slushy roads, a wedge of water can form between the tires and road surface.

This phenomenon is referred to as hydroplaning. It is characterized by a partial or complete loss of contact between the tires and the road surface, ultimately undermining your ability to steer and brake the vehicle.

Hydroplaning

When driving on wet or slushy roads, reduce your speed to prevent hydroplaning. ◄

The risk of hydroplaning increases as the tire tread depth decreases. Minimum tread depth, refer to page 259.

Driving through water

Maximum water depth:

- BMW X5: 20 inches/50 cm.
- BMW X6: 17 inches/45 cm.



Adhere to water depth and speed limita-

Only drive through water up to the above-mentioned depth at no greater than walking speed; otherwise, the engine, electrical system, and transmission can be damaged. ◀

Braking safely

Your vehicle is equipped with ABS as a standard feature.

Applying the brakes fully is the most effective way of braking in situations when this is necessary.

The vehicle maintains steering responsiveness. You can still avoid any obstacles with a minimum of steering effort.

Pulsation of the brake pedal and sounds from the hydraulic circuits indicate that ABS is in its active mode.

Do not let your foot rest on the brake pedal Do not drive with your foot resting on the brake pedal. Even light but consistent pedal pressure can lead to high temperatures, brake wear and possibly even brake failure.◀

Objects in the area around the pedals

No objects in the area around the pedals Keep floor mats, carpets, and any other objects out of the area of motion of the pedals; otherwise, the function of the pedals could be impeded while driving

Do not place additional floor mats over existing mats or other objects.

Only use floor mats that have been approved for the vehicle and can be properly fixed in place.

Ensure that the floor mats are securely fastened again when they are returned after being removed, such as for cleaning. ◀

Driving in wet conditions

When roads are wet or there is heavy rain, briefly exert gentle pressure on the brake pedal every few miles.

Ensure that this action does not endanger other road users.

The heat generated in this process helps dry the brake discs and pads.

In this way braking efficiency will be available when you need it.

Hills

Drive long or steep downhill gradients in the gear in which the least braking is required. Otherwise, the brake system may overheat, resulting in a reduction in the brake system efficiency.

The engine braking action can be further enhanced by shifting down during manual operation of the automatic transmission, refer to page 69, if necessary all the way down to first gear.

Avoid load on the brakes
Avoid placing excessive load on the brake
system. Light but consistent brake pressure can
lead to high temperatures, brake wear and possibly even brake failure.

Do not drive in neutral
Do not drive in neutral or with the engine
stopped, as doing so disables engine braking. In
addition, steering and brake assist is unavailable
with the engine stopped.

Brake disc corrosion

Corrosion on the brake discs and contamination on the brake pads are furthered by:

- Low mileage.
- Extended periods when the vehicle is not used at all.
- Infrequent use of the brakes.

Corrosion occurs when the minimum pressure that must be exerted by the pads during brake applications to clean the discs is not reached. Should corrosion form on the brake discs, the brakes will tend to respond with a pulsating effect that generally cannot be corrected.

Condensation under the parked vehicle

When using the automatic climate control, condensation water develops that exits underneath the vehicle.

Therefore, traces of condensed water under the vehicle are normal.

Loading

Overloading the vehicle

To avoid exceeding the approved carrying capacity of the tires, never overload the vehicle. Overloading can lead to overheating and increases the rate at which damage develops inside the tires. This could result in a sudden loss of tire inflation pressure.

No fluids in the cargo area
Make sure that fluids do not leak into the
cargo area; otherwise, the vehicle may be damaged.

✓

Determining the load limit




- Locate the following statement on your vehicle's placard*:
 - The combined weight of occupants and cargo should never exceed XXX kg or YYY lbs. Otherwise, damage to the ve-

hicle and unstable driving situations may result.


- 2. Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- Subtract the combined weight of the driver and passengers from XXX kilograms or YYY pounds.
- 4. The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the YYY amount equals 1,400 lbs and there will be five 150 lbs passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs: 1,400 lbs minus 750 lbs = 650 lbs.
- Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.
- If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult the manual for transporting a trailer to determine how this may reduce the available cargo and luggage load capacity of your vehicle.

Load

BMW X5:



BMW X6:




The maximum load is the sum of the weight of the occupants and the cargo.


The greater the weight of the occupants, the less cargo that can be transported.

Stowing cargo

BMW X5




BMW X6




- Very heavy cargo: when the rear seat is not occupied, secure each of the outer safety belts in the BMW X5 in the opposite buckle.
- Heavy cargo: stow as far forward and as low as possible, ideally directly behind the backrests.
- Cover sharp edges and corners.
- Do not pile objects higher than the top edge of the backrest.
- If necessary, fold down the rear backrests to stow cargo.
- Place protective material around any sharpedged or pointed objects that could bump against the rear window while the vehicle is in motion.

Securing cargo

BMW X5



BMW X6



- Smaller and lighter items: secure with retaining straps*, a cargo net* or draw straps*.
- ▶ Larger and heavy objects: secure with cargo straps*.

Four lashing eyes* mounted in the cargo area are used to secure these cargo straps, refer to illustrations.

Adhere to the information included with the cargo straps.

Securing cargo

Stow and secure the cargo as described above; otherwise it may present a danger to the occupants, for instance during braking and avoidance maneuvers.

Do not stow any heavy and hard objects in the passenger compartment without securing them; otherwise, they may present a danger to occupants, for instance during braking and avoidance maneuvers.

Never exceed either the approved gross vehicle weight or either of the approved axle loads, refer to page 292, as excessive loads can pose a safety hazard, and may also place you in violation of traffic safety laws.

Use only the lashing eyes pictured to fasten the heavy-duty cargo straps. Do not secure cargo using the upper top tether, refer to page 57, mounting points; otherwise, these may become damaged.◀

Roof-mounted luggage rack*

Special rack system as optional accessory

A special rack system is available as an optional accessory.

Follow the directions given in the installation instructions.

Mounting

Be sure that adequate clearance is maintained for raising and opening the glass sunroof*/panoramic glass sunroof*.

Loading

Because roof racks raise the vehicle's center of gravity when loaded, they have a major effect on vehicle handling and steering response.

Therefore, note the following when loading and driving:

- Do not exceed the approved roof/axle loads and the approved gross vehicle weight, refer to page 292.
- Distribute the roof load uniformly.
- The roof load should not be too large in area.
- Always load the heaviest pieces on the bottom.
- Fasten roof-mounted cargo correctly and securely.
- Do not let objects project into the opening path of the tailgate.

Drive smoothly. Avoid sudden acceleration and braking maneuvers. Take corners gently.

Driving on poor roads

Your vehicle combines an all-wheel drive system with the advantages of a normal passenger car.



Do not drive on unpaved terrain

Do not drive on unpaved terrain, as otherwise the vehicle may be damaged. ◄

For your own safety and the safety of passengers and the vehicle, adhere to the following points:

- ▶ Familiarize yourself with the vehicle before driving; never take risks.
- Adjust speeds according to road conditions. The steeper and rougher the road surface is, the lower the speed should be.
- When driving on steep uphill and downhill grades: the engine oil and coolant should be filled nearly to the MAX mark.
 - BMW X5: the vehicle can be driven on uphill and downhill grades up to 50%.
- Use Hill Descent Control HDC, refer to page 98, on steep downhill grades. BMW X5: the vehicle can be driven away on uphill grades of up to 33%. The permissible body roll is 50%.
- Watch for stones, holes, and other obstacles and drive around these where possible.
- On bumps and rough roads, avoid contact between the vehicle body and the ground. The maximum ground clearance is 8 inches/ 20 cm and may vary with the loaded cargo.
- When driving through water, do not exceed the maximum water height.
 - BMW X5: 20 inches/50 cm
 - BMW X6: 17 inches/45 cm

Drive at walking speed only and do not stop the vehicle.

- After driving through water, press on the brake pedal several times at low speeds to dry the brakes.
- Depending on the prevailing terrain, activate Dynamic Traction Control DTC, refer to page 97, briefly.
- When the wheels spin, accelerate to enable the driving stability control systems to distribute the drive force to the individual wheels.
- ▶ BMW X5 with M Sport Package*: if the vehicle is primarily used on poor roads or unpaved surfaces, it may be advantageous, depending on the driving style, to use the stone chip guard offered by the service center. This reduces the risk of damage to painted vehicle components, such as in the area of the side skirts and wheel arches. Your service center will be glad to advise you.

After driving on poor roads

Adhere to the following points to ensure vehicle safety:

- Remove excessive accumulations of dirt and mud from the vehicle body.
- Clear mud, snow, ice, etc., from the wheels and tires and check for damage.

Saving fuel

General information

Your vehicle contains advanced technology for the reduction of fuel consumption and emissions.

Fuel consumption depends on a number of different factors.

The implementation of certain measures, driving style and regular maintenance, refer to page 268, can have an influence on fuel consumption and on the environmental impact.

Remove unnecessary cargo

Additional weight increases fuel consumption.

Remove attached parts following use

Remove unneeded auxiliary mirrors, roof or rear luggage racks after use.

Attached parts on the vehicle impair the aerodynamics and increase the fuel consumption.

Closing the windows and glass sunroof*/panoramic glass sunroof*

Driving with the glass sunroof/panoramic glass sunroof and windows open results in increased air resistance and raises fuel consumption.

Check the tire inflation pressure regularly

Check and, if necessary, correct the tire inflation pressure, refer to page 252, at least twice a month and before starting on a long trip.

Low tire inflation pressure increases rolling resistance and thus raises fuel consumption and tire wear.

Drive away without delay

Do not wait for the engine to warm up while the vehicle remains stationary. Start driving right away, but at moderate engine speeds.

This is the fastest way for the cold engine to reach its operating temperature.

Look well ahead when driving

Avoid unnecessary acceleration and braking.

By maintaining a suitable distance to the vehicle driving ahead of you.

Driving smoothly and looking ahead reduces fuel consumption.

Avoid high engine speeds

Driving at a low engine speed reduces fuel consumption and minimizes wear.

Use coasting conditions

When approaching a red light, take your foot off the accelerator and let the vehicle coast to a halt.

On a downhill gradient, take your foot off the accelerator and let the vehicle roll.

The flow of fuel is interrupted while coasting.

Switch off the engine during longer stops

Switch off the engine during longer stops, e.g., at traffic lights, railroad crossings or in traffic congestion.

Fuel savings are achieved after the vehicle is switched off for only approx. 4 seconds.

Switch off any functions that are not currently needed


Functions such as seat heating and the rear window defroster require a lot of energy and consume additional fuel, especially in city and stopand-go traffic.


Therefore, switch off these functions if they are not actually needed.

Have maintenance carried out

Have vehicles maintained regularly to achieve optimal vehicle economy and operating life. Have the maintenance carried out by your service center.

Please also note the BMW Maintenance System, refer to page 268.





Navigation system*

General information

The navigation system can determine the precise position of the vehicle, with the aid of satellites and vehicle sensors, and can reliably guide you to every entered destination.

Entries in stationary vehicle
Enter data only when the vehicle is stationary, and always give priority to the applicable traffic regulations in the event of any contradiction between traffic and road conditions and the instructions issued by the navigation system.

Failure to take to this precaution can place you in violation of the law and put vehicle occupants and other road users in danger.

Navigation data

Information on navigation data

- 1. "Navigation"
- 2. Open "Options".
- "Navigation system version" Information is displayed on the data version.

Updating the navigation data

General information

Navigation data are stored in the vehicle and can be updated.

Navigation data and authorization codes are available from your service center.

- Depending on the data volume, a data update may take several hours.
- Update during the trip to preserve battery.
- During the update, only the basic functions of the navigation system are available.
- ▶ The status of the update can be viewed.
- The system restarts after the update.
- ➤ The data carrier with the navigation data can be removed after the update is complete.

Performing an update

- 1. Insert the navigation DVD into the DVD player with the labeled side facing up.
- 2. Follow the instructions on the Control Display.
- 3. Enter the authorization code of the navigation DVD and change the DVD if needed.

If the trip is interrupted, follow the instructions on the Control Display and restart the update if necessary.


Viewing the status

- 1. Open "Options".
- 2. "Navigation update"

Removing navigation DVD

1. Press button 1.

The DVD emerges slightly from the drive.



2. Remove the DVD.

Destination entry

At a glance

In entering your destination you can select from the following options:

- Enter the destination manually, see below.
- Select the destination from the address book, refer to page 154.
- Last destinations, refer to page 156.
- Special destinations, refer to page 156.
- Destination entry via map, refer to page 157.
- Using the home address as the destination, refer to page 155.
- Destination entry by voice*, refer to page 158.
- ▶ Enter the destination via BMW Assist*, refer to page 157.

Entries in stationary vehicle Enter data only when the vehicle is stationary, and always give priority to the applicable traffic regulations in the event of any contradiction between traffic and road conditions and the instructions issued by the navigation system. Failure to take to this precaution can place you in violation of the law and put vehicle occupants and other road users in danger. ◀

Manual destination entry

General information

The system supports you in entering street names and house numbers by automatically completing the entry and providing entry comparisons, refer to page 23.

Stored town/city and street names can be called up quickly.

▶ If the existing entries should not be changed, the entries for the state/province and town/ city can be skipped.


Destination guidance is started to the town/ city center if no street is entered.

Entering a state/province



Press the button.


- 2. "Navigation"
 - "Enter address"



Select "State/Province" or the displayed state/province.

Entering a town/city

1. Select "Town/City/Postal Code" or the displayed town/city.



- The list is narrowed down further with each entry.
- Move the controller to the right.
- 4. Select the name of the town/city from the list.

If there are several towns/cities with the same name:

1. Change to the list of town/city names.

- 2. Highlight the town/city.
- 3. Select the town/city.

Entering the postal code*

- Select "Town/City/Postal Code" or the displayed town/city.
- 2. 1@+ Select the symbol.
- 3. Select the numbers.
- Change to the list of postal codes and towns/ cities.
- 5. Highlight the entry.
- Selecting an entry.

Entering a street and intersection

- 1. Select "Street" or the displayed street.
- Enter a street and intersection in the same way as you would enter a town/city.

If there are several streets with the same name:

- 1. Change to the list of street names.
- 2. Highlight the street.
- Select the street.

Alternative: enter the street address and house number

- 1. Select "Street" or the displayed street.
- Enter the street as you would the town/city.
- "House number"
- Select the numbers.
- Change to the list of house numbers.
- Select a house number or range of house numbers.


Street does not exist in the destination city/town

The desired street does not exist in the specified city/town because it belongs to another part of the city/town.

- 1. "Navigation"
- 2. "Enter address"
- 3. Select "Street" or the displayed street.
- Change to the list of street names.

Select "In" with the state/province currently displayed.

All streets of the selected state/province are offered. The associated town/city is displayed after the street name.



- Select the letters.
- Change to the list of street names.
- 8. Highlight the street.
- 9. Select the street.

Starting destination guidance after entering the destination

- "Accept destination"
- "Start guidance" or "Add as another destination"

Add, refer to page 159, a destination as a further destination.

Address book


Create contacts, refer to page 235.

Selecting a destination from the address book

- "Navigation"
- "Address book"

Contacts with addresses are displayed if these have been checked as destinations.

If the contacts with addresses from the mobile phone* are not displayed, they first need to be checked as destinations, refer to page 236.




- Select a contact in the list or, if desired, with "A-7 search".
- 4. "Business address" or "Home address"

Storing the destination in the address book

After entering the destination, store the destination in the address book.

- 1. Open "Options".
- 2. "Store as new contact" or "Add to existing contact"




- 3. Select an existing contact, if available.
- 4. "Business address" or "Home address"
- 5. Enter "Last name" and, if necessary, "First name".
- 6. "Store in vehicle"

Storing the position

The current position can be stored in the address book.

- 1. "Navigation"
- 2. Open "Options".

3. "Store position as contact" or "Add position to contact"



- Depending on the selection, choose an existing contact from the list. Select the type of address and enter the first and last name.
- "Store in vehicle"

Editing or deleting an address

- 1. "Navigation"
- "Address book"
- Highlight the entry.
- 4. Open "Options".
- "Edit in Contacts" or "Delete entry"

Using the home address as the destination

The home address must be stored. Specify the home address, refer to page 229.

- 1. "Navigation"
- "Address book"
- 3. "Home"



"Start quidance"

Last destinations

At a glance

The destinations previously entered are stored automatically.

These destinations can be called up and used as a destination for destination guidance.

Calling up the last destination

- 1. "Navigation"
- "Last destinations"



Starting destination guidance

- 1. "Navigation"
- 2. "Last destinations"
- 3. Select the destination.
- 4. "Start guidance"

Editing the destination

- 1. "Navigation"
- 2. "Last destinations"
- 3. Highlight the destination.
- 4. Open "Options".
- "Edit destination"

Deleting the last destinations

- "Navigation"
- 2. "Last destinations"
- 3. Highlight the destination.
- 4. Open "Options".
- 5. "Delete entry" or "Delete all last destinations"

Special destinations

Opening the search for special destinations

Selection of special destinations, such as hotels or tourist attractions.

- 1. "Navigation"
- 2. "Points of Interest"
- 3. Select the search function.

Online Search*

- "Google™ Search"
- 2. Select a special destination.
- 3. Select the symbol.
- 4. "Start guidance"

A-Z search

- 1. "A-Z search"
- 2. "Town/City"
- 3. Select or enter the town/city.
- 4. "Category"
- Select the category.
- 6. "Category details"

For some special destinations, multiple category details can be selected. Move the controller to the left to leave the category details.

- 7. "Keyword"
- 8. Enter the keyword.

A list of the special destinations is displayed.

Select a special destination.

Details are displayed.

If multiple details are stored, you can leaf through the pages.

If a phone number is available, a connection can be established if necessary.

- 10. ♥ Select the symbol.
- 11. "Start guidance" or "Add as another destination"

Add a destination as a further destination, refer to page 159.

"Start search": if a search term is not entered. the search is repeated with the previous search term.

Category search

- "Category search"
- 2. "Town/Citv"
- Select or enter the town/city.
- 4. "Category"
- 5. Select the category.
- 6. "Category details"

For some special destinations, multiple category details can be selected. Move the controller to the left to leave the category details.

7. "Start search"

A list of the special destinations is displayed.

8. Select a special destination.

Details are displayed.

If multiple details are stored, you can leaf through the pages.

If a phone number is available, a connection can be established if necessary.

- 9. Select the symbol.
- 10. "Start guidance" or "Add as another destination"

Add a destination as a further destination, refer to page 159.

Display of special destinations

List of special destinations: special destinations are arranged by distance and appear with a directional arrow pointing to the special destination.

On the split screen, special destinations of the selected category are displayed in the map view as symbols. The display depends on the scale of the map and the category.

Destination entry via BMW Assist*

A connection is established to the Concierge service, refer to page 238.

- "Navigation"
- "Enter address"
- 3. Open "Options".
- 4. "BMW Assist dest. entry"

Displaying special destinations in the

To display symbols of the special destinations in the map view:

- 1. "Navigation"
- "Map"
- Open "Options".
- 4. "Display Points of Interest"
- 5. Select the setting.

Destination entry by map

Selecting the destination

- 1. "Navigation"
- "Map"

The current position of the vehicle is displayed on the map.

3. 🕀 "Interactive map"



- Select the destination with crosshairs.
 - ▶ To change the scale: turn the controller.
 - ▶ To shift the map: move the controller in the required direction.
 - ▶ To shift the map diagonally: move the controller in the required direction and turn it.

Specifying the street

If the system does not recognize the street, one of the following pieces of information is displayed:

- A street name in the vicinity.
- The county.
- The coordinates of the destination.

Additional functions

Additional functions are available on the interactive map after the controller is pressed.



- Select the symbol.
 - "Start guidance" or "Add as another destination"
 - Add a destination as a further destination, refer to page 159.
- "Exit interactive map": return to the map view.
- "View in northern direction" or "View in driving direction"
- "Display destination": the map section around the destination is displayed.
- "Display current location": the map section around your current location is displayed.
- "Find points of interest": the search for special destinations is started.

Destination entry by voice*

General information

 Instructions for voice activation system, refer to page 24.

- When making a destination entry by voice, you can change between voice operation and iDrive.
- ▶ To have the available spoken instructions read out loud: ›Voice commands‹.

Saying the entries

- ▶ The town/city, street, and house number can be entered as a single command*.
- Spell the entry if the spoken language and the language of the system differ.
- Say the letters smoothly, and avoid exaggerating the pronunciation and inserting lengthy pauses between the letters.
- The methods of entry depend on the navigation data in use and the country and language settings.

Entering an address using a command*

- 1. Press the button on the steering wheel.
- Enter address
- 3. Wait for a request from the system.
- 4. Say the address in the suggested order.
- 5. Continue making the entry as prompted by the system.

If necessary, individually name the separate components of the address, e.g., the town/city.

Entering a town/city separately

The town/city can be said as a complete word*. With the destination entry menu displayed:

- 1. Press the button on the steering wheel.
- City or Spell city
- Wait for the system to prompt you for the town/city.
- 4. Say the name of the town/city, or name at least the first three letters.

Depending on the entry, up to 20 towns/cities may be suggested.

- 5. Select a location:
 - Select a recommended town/city: >Yes<.</p>
 - Select a different town/city: >New entry<.</p>
 - Select an entry: Entry ..., for instance, entry 2.
 - Spell an entry: Spell city.
- 6. Continue making the entry as prompted by the system.

If there are several towns/cities with the same name:

Towns/cities of the same name are grouped in a list and displayed as one location followed by an ellipsis.

- 1. Select an entry: Yes or Entry ..., e. g., Entry 2.
- 2. Select the desired town/city.

Entering a street or intersection separately

Enter a street and intersection in the same way as you would enter a town/city.

Entering a house number separately

Depending on the data in the navigation system, house numbers up to number 2,000 can be entered.

- →House number«
- 2. Say the house number.
 - Say each digit separately.
- 3. Continue making the entry as prompted by the system.

Starting destination guidance


Start guidance

Planning a trip with intermediate destinations

New trip

A trip can be planned with several intermediate destinations.

- 1. "Navigation"
- "Map"
- Move the controller to the left if necessary.
- 4. ♥ "Guidance"
- "Enter new destination"
- Select the type of destination entry.



- Enter the intermediate destination.
- "Start quidance"

Entering intermediate destinations

A maximum of 30 intermediate destinations can be entered for a trip.

- "Enter new destination"
- Select the type of destination entry.
- Enter the intermediate destination.
- "Add as another destination" The intermediate destination is entered in the destination list and is highlighted.
- Turn the controller until the intermediate. destination is located at the desired location in the list.
- Press the controller.

Starting the trip

1. After all intermediate destinations are entered, highlight the first destination.

If the second destination, for example, is highlighted when destination guidance is started, the first destination is skipped.

2. "Start guidance"

This symbol marks the active leg of the trip.

Storing a trip

Up to 30 trips can be stored in the trip list. If necessary, delete existing trips to be able to store new trips.

- 1. Open "Options".
- 2. "Store trip"
- 3. Enter a name for the trip.
- 4. "OK"

Selecting a stored trip

- 1. "Navigation"
- 2. "Stored trips"
- 3. Select a stored trip.
- 4. "Start guidance"

Changing the trip direction

Intermediate destinations are displayed in reverse order in the list.

- 1. "Map"
- 2. P "Guidance"
- 3. Open "Options".
- "Reverse order of trip dest."

Intermediate destination options

- 1. "Map"
- Guidance
- 3. "Display all trip destinations"
- 4. Select an intermediate destination.
 - "Edit destination"
 - "Reposition dest. in the trip": move an intermediate destination to another position in the list.
 - "Delete dest. in the trip"
 - "Go to next dest. in the trip"

Some options are not available for certain trips.

Deleting a stored trip

- 1. "Navigation"
- 2. "Stored trips"
- 3. Highlight the desired trip.
- 4. Open "Options".
- 5. "Delete all trips" or "Delete trip"

Opening the most recent trip

- 1. "Navigation"
- 2. "Stored trips"
- 3. "Last trip"
- 4. "Start guidance"

Destination guidance

Starting destination guidance

- "Navigation"
- Make a destination entry, refer to page 153.
- "Accept destination"
- 4. "Start guidance"

The route is shown on the Control Display.

The distance to the destination/intermediate destination and the estimated time of arrival are displayed in the map view.

The arrow view is displayed in the Head-up Display* and in some cases on the Control Display.

Terminating destination quidance

- "Navigation"
- "Map"
- Guidance"
- "Stop guidance"

Continuing destination guidance

If the destination was not reached during the last trip, destination guidance can be resumed.

"Resume guidance"

Route criteria


General information

- The route calculated can be influenced by selecting certain criteria.
- ▶ The route criteria can be changed when the destination is entered and during destination guidance.

- Road types are part of the navigation data and are taken into consideration when planning a route, e.g., avoid highways.
- ▶ The recommended route may differ from the route you would take based on personal experience.
- The settings are stored for the remote control currently in use.
- Destination guidance with traffic bulletins, refer to page 167.

Changing the route criteria

- "Navigation"
- "Map"
- 3. ♦ /\t ✓ "Route preference"
- 4. Select the criterion:
 - ▷ 'Ö' "Fast route": time-optimized route, being a combination of the shortest possible route and the fastest roads.
 - ▶ //★ "Efficient route": optimized combination of the fastest and shortest route.
 - ▶ "Short route": short distance, irrespective of how fast or slow progress will be.
 - "Alternative routes": if available, alternative routes are suggested during active destination guidance. The individual suggestions are highlighted in color.



- Specify additional criteria for the route, if necessary:
 - "Avoid highways": highways are avoided wherever possible.

- "Avoid toll roads": toll roads are avoided wherever possible.
- "Avoid ferries": ferries are avoided where possible.

Route

Different views of the route are available during destination guidance:

- Arrow view.
- List of route sections.
- Map view, refer to page 163.
- Arrow view in the Head-up Display*, refer to page 117.

Arrow view

The following information is displayed during destination guidance:

- Large arrow: indicates the current direction of travel.
- Small arrow: indicates the next change in direction.
- Intersection view.
- Lane information.
- Traffic bulletins.
- Distance to the next change in direction.
- Street name at the next change in direction.

Lane information

On multi-lane roads, the recommended lanes are marked in the arrow view by a triangle.

- Solid triangle: best lane.
- Empty triangle: possible lane. However, another lane change may be needed shortly.

Displaying a list of route sections

When destination guidance has been started, a list of the route sections can be displayed. The driving distance and traffic bulletins are displayed for each route section.

- 1. "Navigation"
- "Route information"


3. Highlight a route section.

The route section is displayed on the split screen.

Bypassing a section of the route

Calculate a new route for a route section.

- 1. "Navigation"
- 2. "Route information"
- "New route for"



- Turn the controller. Enter the number of kilometers within which you would like to return to the original route.
- Press the controller.

Resuming the original route

If the route section should no longer be bypassed:

- "Navigation"
- 2. "Route information"
- 3. "New route for:"
- "Remove blocking"

Gas station recommendation

The remaining range is calculated and gas stations along the route are displayed.

- "Navigation"
- "Route information"
- "Recommended refuel"A list of the gas stations is displayed.

4. Highlight a gas station.

The position of the gas station is shown on the split screen.

- Select the gas station.
- 6. Select the symbol.
- 7. "Start guidance": destination guidance to the selected gas station is started.
 - "Add as another destination": the gas station is added to the route.

Destination guidance through voice instructions

Switching spoken instructions on/off

The setting is stored for the remote control currently in use.

- "Navigation"
- "Map"
- IVoice instructions

Repeating a spoken instruction

- 1. "Navigation"
- 2. "Map"
- W Highlight the symbol.
- Press the controller twice.

Volume of spoken instructions

Turn the volume button while giving an instruction until the desired volume is set.

The setting is stored for the remote control currently in use.

Saving the spoken instructions on the programmable memory buttons


The function for switching the spoken instructions on/off can be stored on a programmable memory button, refer to page 22, for quick access.

Map view

Selecting the map view

- "Navigation"
- "Map"

At a glance



- Function bar
- 2 Route section with traffic obstruction
- 3 Traffic sign for traffic obstruction
- Planned route
- Current location
- 6 Upper status field
- 7 Lower status field

Lines in the map

Streets and routes are displayed in different colors and styles depending on their classification. Dashed lines represent railways and ferry connections. Country borders are indicated by thin lines.

Traffic obstructions

Small triangles along the planned route indicate route sections with traffic obstructions, depending on the map scale. The direction of the triangles indicates the direction of the obstruction.

The traffic signs indicate the significance of the obstruction.

- Red traffic sign: the obstruction affects the planned route or direction.
- Grey traffic sign: the obstruction does not affect the planned route or direction.

Traffic bulletins, refer to page 165.

Planned route

After destination guidance is started, the planned route is displayed on the map.

Status fields

Show/hide: press the controller.

- Upper status field: time, telephone, and entertainment details.
- Lower status field: symbol for active destination guidance, status of traffic bulletins, time of arrival, and distance to destination.

Function bar

The following functions are available in the function bar:

Function
Start/end destination guidance.
Switch spoken instructions on/ off.
Change the route criteria.
Search for a special destination.
Display traffic bulletins.
Open the interactive map.
Set the map view.
Change the scale.

To change to the function bar, move the controller to the left.

Changing the map section

- ⊕ "Interactive map"
- ➤ To shift the map: move the controller in the required direction.
- ➤ To shift the map diagonally: move the controller in the required direction and turn it.

Changing the scale

- 1. Q[±] Select the symbol.
- 2. To change the scale: turn the controller.

Automatically scaled map scale

In the map view facing north, turn the controller in any direction until the AUTO scale is displayed. The entire route between the current location and the destination is displayed on the map.

Settings for the map view

The settings are stored for the remote control currently in use.

- "Navigation"
- 2. "Map"
- 3. Open "Options".
- 4. "Settings"
- To set the map view:
- "Day/night mode"

Select and create the necessary settings depending on the light conditions.

- "Traffic conditions/gray map" active: the setting is disregarded.
- "Satellite images"

Depending on availability and resolution, satellite images* are displayed at scales of approx. 1 mile to 600 miles/2 km to 1,000 km.

- "Perspective view in 3D"
 - Prominent areas that are contained in the navigation data are displayed on the map in 3D.
- ▶ "Traffic conditions/gray map"

The map is optimized for displaying traffic bulletins, refer to page 166.

Symbols for the special destinations are no longer displayed.

Split screen map view

The map view can be selected for the split screen independently from the main screen.

- 1. Open "Options".
- "Split screen"
- 3. Move the controller to the right repeatedly until the split screen is selected.

- 4. Select "Split screen content" or the scale.
- 5. Select the map view.
 - "Arrow display"
 - "Map facing north"
 - "Map direction of travel"
 - "Map view with perspective"
 - "Position"
 - "Exit ramp view": selected blind driveways are displayed three dimensionally.
 - "Traffic conditions/gray map"
- 6. To change the scale: select the split screen and turn the controller.

Traffic bulletins*

At a glance

Display the traffic bulletins from radio stations that broadcast the TI Traffic Information of a traffic information service. Information on traffic obstructions and hazards is updated continuously.

Certain BMW models equipped with navigation have the capability to display realtime traffic information. If your system has this capability the following additional terms and conditions apply:

An End-User shall no longer have the right to use the Traffic Data in the event that the End-User is in material breach of the terms and conditions contained herein.

A. Total Traffic Network, a division of Clear Channel Broadcasting, Inc. ("Total Traffic Network") holds the rights to the traffic incident data and RDS-TMC network through which it is delivered. You may not modify, copy, scan or use any other method to reproduce, duplicate, republish, transmit or distribute in any way any portion of traffic incident data. You agree to indemnify, defend and hold harmless BMW of North America, LLC. ("BMW NA") and Total Traffic Network, Inrix, Inc (and their affiliates) against any and all claims, damages, costs or other expenses that arise directly or indirectly out

- of (a) your unauthorized use of the traffic incident data or the RDS-TMC network, (b) your violation of this directive and/or (c) any unauthorized or unlawful activities by you in connection herewith.
- B. Total Traffic Network traffic data is informational only. User assumes all risk of use. Total Traffic Network, BMW NA, and their suppliers make no representations about content, traffic and road conditions, route usability, or speed.
- C. The licensed material is provided to licensee "as is," and "where is". Total Traffic Network, including, but not limited to, any and all third party providers of any of the licensed material, expressly disclaims, to the fullest extent permitted by law, all warranties or representations with respect to the licensed material (including, without limitation, that the licensed material will be errorfree, will operate without interruption or that the traffic data will be accurate), express, implied or statutory, including, without limitation, the implied warranties of merchantability, non-infringement fitness for a particular purpose, or those arising from a course of dealing or usage of trade.
- D. Neither Total Traffic Network, Inrix, Inc. or BMW NA will be liable to you for any indirect, special, consequential, exemplary, or incidental damages (including, without limitation, lost revenues, anticipated revenues, or profits relating to the same) arising from any claim relating directly or indirectly to use of the traffic data, and even if Total Traffic Network, Inrix, Inc., or BMW NA are aware of the possibility of such damages. These limitations apply to all claims, including, without limitation, claims in contract and tort (such as negligence, product liability and strict liability). Some states do not allow the exclusion or limitation of incidental or consequential damages, so those particular limitations may not apply to you.
- The traffic bulletins are indicated on the map by symbols.

➤ The traffic bulletins for the surrounding area are stored in a list.

⚠ The symbol in the function bar of the map view turns red if there are traffic bulletins that affect the calculated route.

Switching the reception on/off

- 1. "Navigation"
- 2. Open "Options".
- 3. "Receive Traffic Info"

Opening the list of traffic bulletins

- 1. "Navigation"
- 2. "Map"
- 3. A "Traffic Info"

First, traffic bulletins for the calculated route are displayed.

The traffic bulletins are sorted by their distance from the current position of the vehicle.

- 4. Select a traffic bulletin.
 - "More information": display additional information.
- 5. Scroll to the next or previous traffic bulletin if required.

Traffic bulletins on the map

"Traffic conditions/gray map" active:

The Control Display changes to a black and white display. This enables a better view of the traffic bulletins. The day/night mode is disregarded in this setting. Symbols and special destinations are not displayed.

- 1. "Navigation"
- "Map"
- 3. Open "Options".
- 4. "Settings"
- 5. "Traffic conditions/gray map"

Symbols in the map view

Depending on the scale of the map and the location of the traffic obstruction along the route, the symbols for the traffic obstructions are displayed.

Additional information in the map view

Depending on the map scale, a traffic obstruction's length, direction, and impact are displayed in the map using triangles or gray bars along the calculated route.

- Red: traffic congestion
- Orange: stop-and-go traffic
- Yellow: heavy traffic
- Green: clear roads
- Gray: general traffic bulletins such as road construction

The displayed information depends on the particular traffic information service.

Filtering traffic bulletins

You can set which traffic bulletins appear on the map.

- "Navigation"
- 2. "Map"
- 3. Open "Options".
- 4. "Traffic Info categories"
- Select the desired category.



Traffic bulletins of the selected category are displayed on the map.

- Traffic bulletins that are relevant to the route are always shown.
- For your own safety, traffic bulletins that notify you of potentially dangerous situations, such as wrong-way drivers, cannot be hidden.

Destination guidance with traffic bulletins

Semi-dynamic destination guidance

When traffic bulletin reception is switched on, semi-dynamic destination guidance is active.

The destination guidance system takes the available traffic information into account. A message is displayed depending on the route, the traffic bulletins, and the possible detour routes. A detour is suggested in the event of a traffic obstruction. In addition, distance and time differences between the original route and the detour are displayed.

To accept the detour:

• "Detour"

In the event of special hazards, e.g., objects on the road, a message is displayed without a detour suggestion.

Detours can also be accepted if the traffic messages are called up in the list.

- 1. "Navigation"
- "Map"
- Traffic Info"
- 4. "Detour information"
- 5. 6 "Detour"

Dynamic destination guidance

The route is automatically changed in the event of traffic obstructions.

- ▶ The system does not point out traffic obstructions along the original route.
- Traffic bulletins continue to be displayed on the map.
- Depending on road type and the kind and extent of the traffic obstruction, the calculated route may lead through the traffic obstruction.
- Dangerous situations are displayed regardless of the setting.

To activate dynamic destination guidance:

1. "Navigation"

- Open "Options".
- "Dynamic guidance"

What to do if...

The current transmission position cannot be displayed?

The vehicle is located in an unrecognized region, is in a poor reception area, or the system is currently determining the position. Reception is usually best when you have an unobstructed view of the sky.

- The destination without street information is not used for route guidance?
 When city has been input, no downtown can be determined. Input any street in the se-
- The destination is not used for route guidance?

lected city and start destination guidance.

The destination data are not contained in the navigation data. Select a destination that is as close as possible to the original.

Letters for destination input cannot be selected?

The stored data do not contain the data of the destination. Select a goal that is as close as possible to the original.

- Is the map displayed in shades of gray?"Traffic conditions/gray map" active:
 - The Control Display changes to a black and white display. This enables a better view of the traffic bulletins.
- Spoken instructions are no longer output during route guidance in front of intersections?

The area has not yet been fully recorded, or you have left the recommended route and the system requires a few seconds to calculate a new route suggestion.





Tone

General information

The sound settings are stored for the remote control currently in use.

Treble, bass, balance, and fader


- "Treble": treble adjustment.
- "Bass": depth adjustment.
- ▶ "Balance": left/right volume distribution.
- "Fader": front/rear volume distribution.

Setting treble, bass, balance, and fader

- 1. "CD/Multimedia", "Radio" or "Settings"
- 2. "Tone"



3. Select the desired tone settings.




- 4. To adjust: turn the controller.
- 5. To store: press the controller.

Equalizer*

Setting for individual audio frequency ranges.

Adjusting the equalizer

- "CD/Multimedia", "Radio" or "Settings"
- 2. "Tone"
- 3. "Equalizer"
- 4. Select the desired setting.




- 5. To adjust: turn the controller.
- 6. To store: press the controller.

Multi-channel playback, surround*

Choose between stereo and multi-channel playback, surround.

Setting multi-channel playback, surround

- 1. "CD/Multimedia", "Radio" or "Settings"
- "Tone"
- 3. "Surround"



When surround is activated, multi-channel playback is simulated when a stereo audio track is played.

Volume

- "Speed volume": speed-dependent volume
- "PDC": volume of the PDC signal* compared to the entertainment sound output.
- "Gong": volume of the signal, such as the safety belt reminder, compared to the entertainment sound output.
- "Microphone": volume of the microphone* during a phone call.
- "Loudspeak.": volume of the loudspeakers* during a phone call.

The following volumes are only stored for the respective paired telephone: "Microphone", "Loudspeak.".

Adjusting the volume

- "CD/Multimedia", "Radio" or "Settings"
- 2. "Tone"
- 3. "Volume settings"
- 4. Select the desired volume setting.



- 5. To adjust: turn the controller.
- 6. To store: press the controller.


Resetting the tone settings

All tone settings can be reset to the default setting.

- "CD/Multimedia", "Radio" or "Settings"
- 2. "Tone"
- "Reset"

Radio

Controls



- 1 Volume, on/off
- 2 Change wave band
- 3 Change entertainment sources
- 4 Change station/track
- 5 Programmable memory buttons

Sound output

Switching on/off

When the ignition is switched off: press ON/OFF button on the radio.

Muting


When the ignition is switched on or the engine is running: press the ON/OFF button on the radio.

AM/FM station

Selecting a station

- 1. "Radio"
- "FM" or "AM"

3. Select the desired station.



All saved stations are stored for the remote control currently in use.

Changing the station

Turn the controller and press it

or




Press the button

O

Press the buttons on the steering wheel, refer to page 12.

Storing a station

- 1. "Radio"
- 2. "FM" or "AM"
- 3. Highlight the desired station.



- 4. Press the controller for an extended period.
- 5. Select the desired memory location.

The stations are stored for the remote control currently in use.

The stations can also be stored on the programmable memory buttons, refer to page 22.

Selecting a station manually

Station selection via the frequency.

- 1. "Radio"
- "FM" or "AM"
- "Manual"
- 4. To select the frequency: turn the controller.




To store the station: press the controller for an extended period.

RDS*

RDS broadcasts additional information, such as the station name, in the FM wave band. When playing a station with multiple frequencies, the system automatically switches to the frequency with the best reception, if needed.

Switching the RDS on/off

- "Radio"
- 2. "FM"
- Open "Options".
- 4. "RDS"



The setting is stored for the remote control currently in use.

HD Radio™ reception*

Many stations broadcast both analog and digital signals.

License conditions

HD Radio™ technology manufactured under license from iBiquity Digital Corp. U.S. and Foreign Patents. HD Radio™ and the HD and HD Radio logos are proprietary trademarks of iBiquity Digital Corp.

Activating/deactivating digital radio reception

- 1. "Radio"
- "FM" or "AM"
- Open "Options".
- "HD Radio Reception"

The setting is stored for the remote control currently in use.

H) This symbol is displayed in the status line when the audio signal is digital.

In areas in which the station is not continuously received in digital mode, the playback switches between analog and digital reception. Due to time delayed broadcasting, there may be repetitions or interruptions. In this case, switch off digital radio reception.

Displaying additional information

Some stations broadcast additional information on the current track, such as the name of the artist.

- 1. Select the desired station.
- Open "Options".
- "Station info"

Selecting a substation

- ☐ This symbol indicates that a main station also broadcasts additional substations. The station name of the main station ends in HD1. Station names of the substations end in HD2, HD3, etc.
- Select the desired station.
- Press the controller.
- Select the substation.

When reception is poor, the substation is muted for several seconds. If reception is interrupted for an extended period, it switches back to the main station.

Satellite radio*

General information

The channels are offered in predefined packages. The packages must be enabled by telephone.

Navigation bar overview

Symbol	Function
G G	Change the list view.
G.	Select the category.
C.	Direct channel entry
()	Timeshift
☆ ☆*	Open the My Favorites category/ open a favorite.
☆ +	Manage the favorites.
A	Traffic Jump

The functions of the navigation bar symbols can also be stored on the programmable memory buttons, refer to page 22.

Managing a subscription

To be able to enable or unsubscribe from the channels, you must have reception. It is usually at its best when you have an unobstructed view of the sky. The channel name is displayed in the status line.

Enabling channels

The Unsubscribed Channels category contains all disabled channels.

- 1. "Radio"
- "Satellite radio"




- Select the Unsubscribed Channels category.
- Select the desired channel.
 The phone number and an electronic serial number, ESN, are displayed.
- Select the phone number to have the channel enabled.



You can unsubscribe from the channels again via this phone number.

Unsubscribing from channels

- 1. "Radio"
- 2. "Satellite radio"
- Open "Options".
- 4. "Manage subscription"



- 5. The phone number and an electronic serial number, ESN, are displayed.
- 6. Call Sirius to unsubscribe from the channels.

Selecting channels

You can only listen to enabled channels.

The selected channel is stored for the remote control currently in use.

Via the iDrive

- 1. "Radio"
- "Satellite radio"
- Select "All channels" or the desired category.
- Select the desired channel.



Via the button on the radio



Press the button.

The next channel is selected.

Via direct channel entry

- 1. "Radio"
- "Satellite radio"
- C^{*} "Set channel"
- 4. Turn the controller until the desired channel is reached and press the controller.

Storing a channel

- 1. "Radio"
- "Satellite radio"
- 3. If necessary, open "All channels" or the desired category.
- 4. Select the desired channel.

- 5. Press the controller again.
- 6. Press the controller again to confirm the highlighted channel.



7. Select the desired memory location.

The channels are stored for the remote control currently in use.

The channels can also be stored on the programmable memory buttons, refer to page 22.

Changing the list view

The list view changes every time the first symbol on the navigation bar is pressed.

Information on the channel is displayed.

Symbol	Meaning
G	Channel name
Q	Artist
C,	Track

Selecting a category

- 1. "Radio"
- "Satellite radio"
- Category
- Select the desired category.


Timeshift

Approx. one hour of the program being broadcast on the channel currently being listened to is stored in a buffer. Prerequisite: the signal must be available.

The stored audio track can be played with a delay following the live broadcast. When the buffer is full, the older tracks are overwritten. The buffer is cleared when a new channel is selected.

Opening the timeshift function

- 1. "Radio"
- "Satellite radio"



- The red arrow shows the current playback position.
- ▶ The time difference to the live broadcast is displayed next to the buffer bar.
- ▶ For live transmissions "live".

Timeshift menu

Symbol	Function
(Go to the live broadcast
$\triangleright \Pi$	Playback/pause
\triangleright	Next track
\bowtie	Previous track
\gg	Fast forward
\ll	Reverse
1	Automatic timeshift deactivated/activated

Automatic timeshift

When the function is activated, audio playback is stopped automatically in the event of:

- Incoming and outgoing telephone calls.
- Activation of the voice activation system.
- Muting.

The audio playback then continues with a time delay.

To activate:

- 1. "Radio"
- "Satellite radio"

To deactivate:

"Automatic time shift"

Storing favorites

Up to 30 favorites can be stored in the favorites list. Available favorites are artist, track, game, league, and team.

Storing the artist, track, or game

It is only possible to store favorites that are currently being broadcast. The channel information must be available.

- 1. "Radio"
- 2. "Satellite radio"
- If necessary, open "All channels" or the desired category.
- 4. Select the desired channel.
- 5. Press the controller again.
- 6. Select the artist, track, or game.

Storing the league or team

Leagues or teams can be added to the favorites from a selection list.

- 1. "Radio"
- 2. "Satellite radio"
- 3. * "Manage favorites"
- "Add sports information"



- 5. Select the league.
- 6. Select "Add all teams" or the desired team.

Opening the favorites

If an activated favorite is played back, the following message appears for approx. 20 seconds "Favorite alert!".

☆* "Favorites"

Select the symbol while the message is shown.



The displayed favorite is played.

If there is no message, the system changes to the My Favorites category. All favorites currently being broadcast can be selected from a list.

Managing the favorites

Activating/deactivating the favorites

Favorites can be activated and deactivated globally and individually.

- 1. "Satellite radio"
- ☆ "Manage favorites"
- Select "Activate alert" or the desired favorites.

The setting is stored for the remote control currently in use.

Deleting favorites

- "Satellite radio"
- 2. ★ "Manage favorites"
- 3. Highlight the desired favorite.
- 4. Open "Options".
- 5. "Delete entry"

Traffic Jump

Traffic and weather information for a selected region is broadcast every few minutes.

Selecting a region

- 1. "Radio"
- "Satellite radio"
- Open "Options".
- 4. "Set jump"
- Select the desired region.

The region is stored for the remote control currently in use.

Activating/deactivating the jump

- 1. "Radio"
- "Satellite radio"
- Jump to:"

Information for the selected region is broadcast as soon as it is available.

A new panel opens.

Canceling the Traffic Jump: "Cancel".

Symbol	Meaning
₽ ô	Information will be broadcast shortly.
Ø	Information is currently being broadcast.

Select one of the symbols to deactivate Traffic Jump.

Automatic update

About twice a year, Sirius performs an update of the channel names and positions. The update takes place automatically and may take several minutes.

Notes

- Reception may not be available in some situations, such as under certain environmental or topographic conditions. The satellite radio has no influence on this.
- ▶ The signal may not be available in tunnels or underground garages; next to tall buildings; or near trees, mountains or other powerful sources of radio interference.

Stored stations

General information

It is possible to store up to 40 stations.

Calling up a station

- 1. "Radio"
- 2. "Presets"
- 3. Select the desired station.

Storing a station

The station currently selected is stored.

- 1. "Radio"
- 2. "Presets"
- 3. "Store station"



4. Select the desired memory location.

The list of stored stations is stored for the remote control currently in use.


The stations can also be stored on the programmable memory buttons, refer to page 22.

Deleting a station

- 1. "Radio"
- 2. "Presets"
- 3. Select the desired station.
- 4. Open "Options".
- 5. "Delete entry"

CD/multimedia

Controls



- Volume, on/off
- 2 Eiect CD/DVD
- 3 CD/DVD drive
- Change the entertainment source
- Change station/track
- Programmable memory buttons

Sound output

Switching on/off

When the ignition is switched off: press ON/OFF button on the radio.

Muting

When the ignition is switched on or the engine is running: press the ON/OFF button on the radio.

CD/DVD

Playback

Loading the CD/DVD player

Insert the CD/DVD with the printed side up.

Playback begins automatically.

Reading can take a few minutes with compressed audio files.

Starting playback

A CD/DVD is located in the CD/DVD player or in the CD/DVD changer*.

- "CD/Multimedia"
- "CD/DVD" 2.
- Select the desired CD or DVD.



Symbol	Meaning
⑤	CD/DVD player
©1 ©6	CD/DVD changer*
	CD/DVD player, rear*

Playable formats

- DVD: DVD-ROM, DVD-R, DVD+R, DVD-RW. DVD+RW. DVD-R DL. DVD+R DL. DVD audio (video part only), DVD video*.
- ▷ CD: CD-ROM, CD-R, CD-RW, CD-DA, VCD*, SVCD*.
- Compressed audio files: MP3, WMA, AAC*, M4A*.

Audio playback

Selecting the track using the button



Press the button for the appropriate direction as often as necessary until the desired track is played back.

Selecting the track using the iDrive

Audio CDs



Select the desired track to begin playback.

CDs/DVDs with compressed audio files

Depending on the data, some letters and numbers of the CD/DVD may not be displayed correctly.

 Select the directory if necessary.
 To change to a higher level directory: move the controller to the left.



2. Select the desired track to begin playback.



Displaying* information on the track




If information about a track has been stored, it is displayed automatically:

- Interpret.
- Album track.
- Number of tracks on the CD/DVD.
- File name of track.

Random playback

- 1. "CD/Multimedia"
- 2. "CD/DVD"
- Select the desired CD or DVD.
- 4. Open "Options".
- 5. "Random"



CDs/DVDs with compressed audio files: all tracks within the selected directory are played in random order.

Random mode is switched off when the audio source is changed and the ignition is switched off.

Fast forward/reverse



Press and hold the button.

Automatic repeat*

The selected CDs/DVDs are repeated automatically.

Video playback*

Country codes

Only DVDs with the code of the home region can be played back; also refer to the information on the DVD.

Code	Region
1	USA, Canada
2	Japan, Europe, Middle East, South Africa
3	Southeast Asia
4	Australia, Central and South America, New Zealand
5	Northwest Asia, North Africa
6	China
0	All regions

Playback

The video image is displayed on the Control Display up to a speed of approx. 2 mph/3 km/h; in some countries, it is only displayed while the parking brake is set or the automatic transmission is in position P.

DVD video

- 1. "CD/Multimedia"
- 2. "CD/DVD"
- Select a DVD with video content.

4. Property "DVD menu"



5. Start the DVD via the DVD menu.

VCD/SVCD

- 1. "CD/Multimedia"
- 2. "CD/DVD"
- 3. Select a CD with video content.
- 4. Select track"
- 5. Select the desired track.

Video menu

To open the video menu: turn the controller during playback.

Press the controller when "Back" is displayed.

Symbol	Function
DVD	Open DVD menu
\triangleright	Starting playback
П	Pause
	Stop
\bowtie	Next chapter
\bowtie	Previous chapter
\gg	Fast forward
\ll	Reverse

In fast forward/reverse: the speed increases every time the controller is pressed. To stop, start playback.

DVD menu

 If necessary, turn the controller to open the video menu. 2. PP "DVD menu"

The DVD menu is displayed. The display depends on the contents of the DVD.

To select menu items: move the controller and press it.

To change to the video menu: turn the controller and press it.


DVD/VCD settings

For some DVDs, settings can only be made via the DVD menu; refer also to the information on the DVD.

Selecting the language*

The languages that are available depend on the DVD.

- 1. Turn the controller during playback.
- 2. Open "Options".
- 3. "Audio/language"




Select the desired language.

Selecting the subtitles*

The subtitles that are available depend on the DVD.


- Turn the controller during playback.
- 2. Open "Options".

- "Subtitles"
- 4. Select the desired language or "Do not display subtitles".



Setting the brightness, contrast and color

- 1. Turn the controller during playback.
- 2. Open "Options".
- 3. "Display settings"
- 4. "Brightness", "Contrast" or "Color"




5. Turn the controller until the desired setting is reached and press the controller.

Selecting the zoom

Display the video image on the entire screen.

- 1. Turn the controller during playback.
- 2. Open "Options".

- "Additional options"
- 4. "Zoom mode"



Selecting a track

DVD video:

- 1. Turn the controller when the DVD menu is displayed.
- 2. Open "Options".
- 3. "Additional options"
- 4. "Select title"
- Select the desired track.

VCD/SVCD:

- Select track
- Select the desired track.

Selecting the camera angle*

The availability of a different camera angle depends on the DVD and the current DVD track.

- Turn the controller during playback.
- 2. Open "Options".
- 3. "Additional options"
- 4. "Viewing angle"
- Select the desired camera angle.

Opening the main menu, back

These functions are not contained on every DVD. Therefore, they may not be available for use.


CD/DVD changer*

In the glove compartment



The BMW CD/DVD changer for six CDs/DVDs is located in the glove compartment.

Controls and displays



- 1 Empty CD/DVD compartments
- 2 LEDs on the CD/DVD slot
- Buttons for CD/DVD compartments 3
- CD/DVD slot 4
- Load CD/DVD compartments 5

Loading the CD/DVD compartments individually

LOAD Press the button. 1.

> The LED on the first empty compartment flashes.

- 2. Select another compartment if necessary.
- Wait for the LEDs on the DVD slot to flash.
- Insert a single CD or DVD in the middle. The CD/DVD is drawn in automatically and placed into the selected compartment.

Sliding in CDs/DVDs

Do not insert the CD/DVD until the LEDs on the DVD slot are flashing; otherwise, the CD/DVD or the CD/DVD changer could be damaged.

Do not continue to push on the CD/DVD; this may cause it to jam and prevent it from being able to eject again. ◀

Filling all vacant CD/DVD compartments

- Press the button for a longer period.
 The LEDs on the empty CD compartments flash.
- Wait for the LEDs on the DVD slot to begin flashing and then insert each CD or DVD into the center of the slot.

The CDs/DVDs are drawn in automatically and placed into the vacant compartments.

A Sliding in CDs/DVDs

Do not insert the CD/DVD until the LEDs on the DVD slot are flashing; otherwise, the CD/DVD or the CD/DVD changer could be damaged.

Do not continue to push on the CD/DVD; this may cause it to jam and prevent it from being able to eject again. ◀

After they are inserted, it may take several minutes for the CDs/DVDs to be read in.

Removing a single CD/DVD

- 1. Press the button.
- Select the CD/DVD compartment. The CD/DVD is partially ejected.
- 3. Remove the CD/DVD.

Removing all CDs/DVDs

- 1. Press the button for a longer period.
- Remove the CDs/DVDs.

Malfunctions

If all LEDs on the CD/DVD changer flash rapidly, the system is malfunctioning.

To eliminate the malfunction:

- 1. Press one of the buttons:
 - LOAD

The CD/DVD last inserted is ejected.

2. Remove the CD/DVD.

If the LEDs stop flashing rapidly, the CD/DVD changer is functional again.

Audio playback*

The audio track of a DVD can be played back even if video playback is not possible in the vehicle.

Only the main film without the previews or extras can be played back.

Starting playback

A DVD is located in the DVD changer.

- 1. "CD/Multimedia"
- 2. "CD/DVD"
- Select the desired DVD.

Selecting a chapter using the button

Press the button repeatedly until the desired chapter is played.

Selecting a chapter using iDrive

- "CD/Multimedia"
- "CD/DVD"
- Select the desired DVD.
- 4. Select the desired chapter.

Fast forward/reverse

Press and hold the button.

Selecting the language*

The languages that are available depend on the DVD.

- "CD/Multimedia"
- "CD/DVD"
- Select the desired DVD.
- Open "Options".
- 5. "Audio/language"
- Select the desired language.

Notes

CD/DVD player and changer

Do not remove the cover BMW CD/DVD players and changers are officially designated Class 1 laser products. Do not operate if the cover is damaged; otherwise, severe eye damage can result.◀

CDs and DVDs



Use of CDs/DVDs

- Do not use self-recorded CDs/DVDs with labels applied, as these can become detached during playback due to heat buildup and can cause irreparable damage to the device.
- Only use round CDs/DVDs with a standard diameter of 4.7 in/12 cm and do not play CDs/DVDs with an adapter, e.g., single CDs; otherwise, the CDs or the adapter may jam and no longer eject.
- Do not use combined CDs/DVDs, e.g., DVD Plus, as the CDs/DVDs can jam and will no longer eject.◀

General malfunctions

- ▷ CD/DVD changers and players have been optimized for performance in vehicles. In some instances they may be more sensitive to faulty CDs/DVDs than stationary devices would be.
- ▶ If a CD/DVD cannot be played, first check whether it has been inserted correctly.

Humidity

High levels of humidity can lead to condensation on the CD/DVD or the laser's scan lens, and temporarily prevent playback.

Malfunctions involving individual CDs/ **DVDs**

If malfunctions occur only with particular CDs/ DVDs, this can be due to one of the following causes:

Home-recorded CDs/DVDs

- Possible reasons for malfunctions with home-recorded CDs/DVDs are inconsistent data creation or recording processes, or poor quality or old age of the blank CD/DVD.
- ▶ Only label CDs/DVDs on the upper side with a pen intended for this purpose.

Damage

- Avoid fingerprints, dust, scratches and moisture.
- Store CDs/DVDs in a sleeve.
- Do not subject CDs/DVDs to temperatures over 122 °F/50 °C, high humidity or direct sunlight.

CDs/DVDs with copy protection

CDs/DVDs are often provided with a copy protection feature by the manufacturer. This can mean that some CDs/DVDs cannot be played or can only be played to a limited extent.

MACROVISION

This product contains copyrighted technology that is based on multiple registered US patents and the intellectual property of the Macrovision Corporation and other manufacturers. The use of this copy protection must be approved by Macrovision. Media protected by this product unless otherwise agreed with Macrovision - may only be used for private purposes. Copying of this technology is prohibited.

DTS Digital Surround™

Manufactured under license under U.S. Patent Numbers: 5,451,942; 5,956,674; 5,974,380; 5,978,762; 6,487,535 & and other patents granted and registered in the USA and worldwide. DTS and the logo are registered trademarks & DTS Digital Surround and the DTS logos are trademarks of DTS Inc. © DTS, Inc. All rights reserved.

Music collection*

Storing music

General information

Music tracks from CDs/DVDs and USB devices can be stored in the music collection on a hard disc in the vehicle and played from there.

- Audio CD: tracks are converted into a compressed audio format. If available, information on the album, such as the artist, is stored as well.
- CD/DVD or USB device with compressed audio files: the entire content of the CD/DVD or the USB device is stored in the vehicle as an album. The WMA, MP3, M4A*, and AAC* formats are stored. Individual tracks and directories can be deleted later, Deleting a track and directory, refer to page 191.

Tracks with DRM copy protection can be stored but cannot be played back.

Backing up music data
Regularly back up the music data; otherwise, it could be lost if there is a fault on the hard disc.

Music recognition technology and related data are provided by Gracenote®.

Gracenote is the industry standard in music recognition technology and related content delivery. For more information, please visit www.gracenote.com.

CD and music-related data from Gracenote, Inc., copyright © 2000-2010 Gracenote. Gracenote Software, copyright © 2000-2010 Gracenote.

This product and service may practice one or more of the following U.S. Patents: #5,987,525; #6,061,680; #6,154,773, #6,161,132, #6,230,192, #6,230,207, #6,240,459, #6,330,593, and other patents issued or pending. Some services supplied under license from Open Globe, Inc. for U.S. Patent: #6,304,523.

Storing from a CD/DVD

- Insert a CD or DVD into the CD/DVD player.
- 2. "CD/Multimedia"
- 3. "CD/DVD"
- 4. Select the symbol for the CD/DVD player.
- 5. "Store in vehicle"



The music collection is displayed and the first track of the CD/DVD is played back. During the storage process, the tracks are played in sequence.

Observe the following during the storage process:

Do not switch to the CD/DVD player and do not remove the CD/DVD from the CD/DVD player as this will interrupt the storage process. You can switch to the other audio sources without interrupting the storage process. Tracks from the current CD/DVD that have already been stored can be called up.

Interrupting storage

- 1. "CD/Multimedia"
- "CD/DVD"



"Cancel storing"

The storage process is interrupted and can be continued at any time.

Continuing the storage process

- "CD/Multimedia"
- "CD/DVD"
- 3. Select the symbol for the CD/DVD player.
- 4. "Continue storing"

Storage of the CD/DVD continues at the beginning of the track at which storage was interrupted.

Album information

During storage, information such as the name of the artist is stored with the track, if this information is available in the vehicle database or on the CD.

To update the database, contact your service center.

Storing from a USB device

To store music, a suitable device must be connected to the USB interface in the glove compartment.

- Suitable devices: USB mass storage devices, such as USB flash drives or MP3 players with a USB interface.
- Unsuitable devices: USB hard drives, USB hubs, USB memory card readers with multiple inserts, Apple iPod/iPhone. Music from the Apple iPod/iPhone can be played via the USB audio interface* in the center armrest.

- Connect the USB device to the USB interface in the glove compartment, refer to page 134.
- "CD/Multimedia"
- "Music collection"
- 4. Open "Options".
- "Music data import/export"
- "Import music (USB)"



Playing music

Music search

All tracks for which additional information has been stored can be accessed by the music search. Tracks without additional information can be called up via the corresponding album, refer to page 190.

- "CD/Multimedia"
- "Music collection"
- "Music search"



4. Select the desired category.



- Select the desired entry.
 - Select "A-Z search", refer to page 23, and input the desired entry.
 - Select the desired entry from the list.
- Select other categories if you wish.

The tracks found are listed in alphabetical order.

Not all categories need to be selected. For example, to search for all tracks by a certain artist, call up that artist only. All of the tracks by that artist are then displayed.

7. "Start play"

The list of tracks is repeated automatically.

Restarting the music search

"New search"

Music search by voice*

Instructions for voice activation system, refer to page 24.

- 1. Press the button on the steering wheel.
- 2. →Music search
- 3. Open the desired category, e. g., >Select artist.
- 4. Say the desired entry in the list.
- 5. Select other categories if you wish.

To select a track directly: >Title ...<

Say the voice command and the name of the desired track in a single command.

Current playback

The list of tracks that was generated last by the music search, or the album that was selected last.

- "CD/Multimedia"
- "Music collection"
- 3. "Current playback"



4. Select the desired track, if necessary.

Top 50

The 50 most frequently played tracks.

- 1. "CD/Multimedia"
- "Music collection"
- 3. "Top 50"
- Select the desired track, if necessary.

Albums

All stored albums, listed in order of their storage dates.

Symbol	Format
(3)	Audio CD
	Compressed audio files

- 1. "CD/Multimedia"
- 2. "Music collection"
- Select the desired album.

Depending on the album, the tracks or the subdirectories of the album are displayed.

The first track is played automatically, if possible.



Change directories if needed to select tracks.

To go up a level in the directory: move the controller to the left.

Random playback

All tracks of the selection are played back in random order.

- 1. "CD/Multimedia"
- "Music collection"
- Open "Options".
- 4. "Random"



Managing music

Albums

Renaming an album*

The name of the album, if available, is automatically entered when the album is stored. If the name is not available, it can be changed later if desired.

- "CD/Multimedia"
- "Music collection"

- Highlight the desired album.
- 4. Open "Options".
- 5. "Rename album"



Select the letters individually.

Deleting an album

An album cannot be deleted while a track from that album is being played.

- "CD/Multimedia"
- "Music collection"
- Highlight the desired album.
- 4. Open "Options".
- "Delete album"

Deleting a track and directory

A track cannot be deleted while it is being played.

A directory cannot be deleted while a track from that directory is being played.

- "CD/Multimedia"
- "Music collection"
- Highlight the directory or track.
- Open "Options".
- "Delete folder" or "Delete track"

Free memory capacity

Display the free memory capacity in the music collection.

- 1. "CD/Multimedia"
- "Music collection"
- Open "Options".
- "Free memory"

Music collection

Backing up the music collection


The entire music collection can be stored on a USB device. Make sure there is enough free memory capacity on the USB device.

Depending on the number of tracks, backing up the music collection may take several hours. Therefore, it is best to perform the backup during a long trip.

- 1. Starting the engine.
- Connect the USB device to the USB interface in the glove compartment, refer to page 134.
- 3. "CD/Multimedia"
- 4. "Music collection"
- 5. Open "Options".
- 6. "Music data import/export"



7. "Backup music on USB"



Storing the music collection in the vehicle

When storing from the USB device, the existing music collection in the vehicle is replaced.

- 1. "CD/Multimedia"
- 2. "Music collection"

- 3. Open "Options".
- 4. "Music data import/export"
- 5. "Restore music from USB"

Deleting the music collection

- 1. "CD/Multimedia"
- 2. "Music collection"
- 3. Open "Options".
- 4. "Delete music collection"

External devices

At a glance

Symbol	Meaning
P	AUX-IN port
ψ	USB audio interface*
<u></u>	Mobile phone audio interface*
(8)	Bluetooth audio*

AUX-IN port

At a glance

- For connecting audio devices, e.g., MP3 player. The sound is output on the vehicle loudspeakers.
- Recommendation: use medium tone and volume settings on the audio device. The tone depends on the quality of the audio files.

Connecting



The AUX-IN port is in the center armrest.

Connect the headphone connector or line-out connector of the device to the AUX-IN port.

Playback

- 1. Connect the audio device, switch it on and select a track on the audio device.
- "CD/Multimedia"
- 3. If necessary, "External devices"
- 4. / "AUX front"


Sound is output on the vehicle loudspeakers.

Volume

The volume of the sound output is dependent on the audio device. If this volume differs markedly from the volume of the other audio sources. it is advisable to adjust the volumes.

Adjusting the volume

- "CD/Multimedia"
- If necessary,"External devices"
- 3. \(\mathbb{/} \) "AUX front"
- 4. "Volume"



5. Turn the controller until the desired volume is set and press the controller.

USB audio interface*/mobile phone audio interface*

At a glance

It is possible to connect external audio devices. They can be operated via iDrive. The sound is output on the vehicle loudspeakers.

Connectors for external devices

- Connection via USB audio interface: Apple iPod/iPhone, USB devices, e.g., MP3 players, USB flash drives, or mobile phones that are supported by the USB audio interface.
- Connection via snap-in adapter, refer to page 225, when equipped with extended connectivity of the music player in the mobile phone: Apple iPhone or mobile phones. Playback is only possible if no audio device is connected to the analog AUX-IN port.

Due to the large number of different audio devices available on the market, it cannot be ensured that every audio device/mobile phone is operable on the vehicle.

Ask your service center about suitable audio devices/mobile phones.

Audio files

Standard audio files can be played back:

- MP3.
- WMA.
- WAV (PCM).
- AAC*, M4A*.
- Playback lists: M3U, WPL, PLS.

Connecting



The USB audio interface is in the center armrest.

Connection of Apple iPod/iPhone via USB audio interface

Connect using a flexible adapter cable.

Connect the Apple iPod/iPhone to the USB interface.

The Apple iPod/iPhone menu structure is supported by the USB audio interface.

Connection of a USB device via the USB audio interface

Connect using a flexible adapter cable to protect the USB audio interface and the USB device against physical damage.

Connect the USB device to the USB interface.

After connecting for the first time

Information on all music tracks, e.g. artist or type of music, as well as playback lists are transmitted into the vehicle. This may take some time, depending on the USB device and the number of tracks.

During transmission, the tracks can be called up via the file directory.

Number of tracks

Information from up to four USB devices or for approx. 36,000 tracks can be stored in the vehicle. If a fifth device is connected or if more than 36,000 tracks are stored, information on existing music tracks may be deleted.

Copy protection

Music tracks with integrated Digital Rights Management (DRM) cannot be played.

Playback

- 1. "CD/Multimedia"
- "External devices"
- Select the
 ^⁴ or
 ^⁴ symbol.



The playback starts with the first track.

On the split screen*, the CD cover for the music track might be displayed after a few seconds.

Track search

Selection is possible via:

- Playback lists.
- ▶ Information: type of music, artist, and, if available, composer, album, track.
- ▶ In addition, for USB devices: file directory and, if available, composer.

Tracks are displayed if they have been saved in the Latin alphabet.

Starting the track search

- "CD/Multimedia"
- 2. "External devices"
- 4. Q "Search"
- Select the desired category, e.g., "Genre" or "Artist".

All entries are displayed in a list.

 Open "A-Z search" and input the desired entry. When a letter is entered, the results are filtered using this letter as the first letter. If multiple letters are entered, all results that contain that sequence are displayed.

Select the desired entry from the list.



6. Select other categories if you wish.

Not all categories need to be selected. For example, if all of the tracks by a certain artist are to be displayed, call up that artist only. All of the tracks by that artist are then displayed.

7. "Start play"

Restarting a track search

"New search"

Playback lists

Calling up playback lists.

- 1. "CD/Multimedia"
- 2. "External devices"
- Select the ‡ or symbol.
- 4.

 J

 "Playlists"

Current playback

List of tracks currently being played.

- 1. "CD/Multimedia"
- 2. "External devices"

Random playback

The current list of tracks is played back in random order.

- 1. "CD/Multimedia"
- "External devices"
- 3. Open "Options".
- 4. "Random"

Fast forward/reverse



Press and hold the button.

Video playback*

At a glance

Video playback via snap-in adapter possible. They can be operated via iDrive. The sound is output on the vehicle loudspeakers.

Playback

The video image is displayed on the front Control Display up to a speed of approx. 2 mph/3 km/ h; in some countries, it is only displayed while the parking brake is set or the automatic transmission is in position P.

- "CD/Multimedia"
- "External devices"
- Select the symbol.
- 4. "" "Video"
- Select the directory if necessary.

To go up a level in the directory: move the controller to the left.

Select the desired video file to begin playback.

Video menu

Symbol	Function
\bowtie	Next video file
\bowtie	Previous video file
	Double-click on an icon to play back previous video file.

Notes

Do not expose the audio device to extreme environmental conditions, such as very high temperatures; refer to the audio device operating instructions.

Depending on the configuration of the audio files, e.g., bit rates greater than 256 kbit/s, the files may not play back correctly in each case.

Information on connection

- The connected audio device is supplied with a max. power of 500 mA if supported by the device. Therefore, do not additionally connect the device to a socket in the vehicle; otherwise, playback may be compromised.
- Do not use force when plugging the connector into the USB interface.
- Do not connect devices such as fans or lamps to the USB audio interface.
- Do not connect USB hard drives.
- Do not use the USB audio interface to recharge external devices.

Bluetooth audio*

At a glance

- Music files on external devices such as audio devices or mobile phones can be played back via Bluetooth.
 - Use of a mobile phone as an audio source, refer to page 217.
- Bluetooth® is a registered trademark of Bluetooth® SIG, Inc.
- The sound is output on the vehicle loudspeakers.
- The volume of the sound output is dependent on the device. If necessary, adjust the volume on the device.
- Up to four external devices can be paired with the vehicle.

Requirements

The device is suitable. Details can be found at www.bmw.com/bluetooth.

- ▶ The device is ready for operation.
- ▶ The ignition is switched on.
- Bluetooth is activated on the vehicle, refer to page 217, and on the device.
- Bluetooth presettings must be made on the device, such as for a connection without confirmation or visibility; refer to the device operating instructions.
- A number with at least four and a maximum of 16 digits is defined as the Bluetooth passkey. It is only required once for pairing.

Pairing and connecting

Pairing a device
To avoid becoming distracted and posing an unnecessary hazard both to your own vehicle's occupants and to other road users, only pair the device while the vehicle is stationary.

- 1. "CD/Multimedia"
- 2. "Bluetooth® (audio)"
- 3. If necessary, "Bluetooth® audio".
- 4. "Add new phone"

The Bluetooth name of the vehicle is displayed.




 Perform additional steps on the device, refer to the device operating instructions: for instance, search for or connect the Bluetooth device or a new device.

The Bluetooth name of the vehicle appears on the device display.


6. Select the Bluetooth name of the vehicle on the device display.

You are prompted by the iDrive or device to enter the same Bluetooth passkey.

7. Enter the passkey and confirm.



- 8. Select the desired functions with which the device is to be connected, for instance "Audio".
- 9. "OK"



If pairing was successful, the device is displayed as connected.

White symbol : the device is active as an audio source.

If pairing was unsuccessful: What to do if..., refer to page 198.

Connecting a specific device

A device that has already been paired can be connected as an active audio source.

Connecting is not possible when data is exchanged via a mobile phone connected via Bluetooth.

Requirements

If necessary, activate the audio connection of the desired device from the list of paired devices.

- 1. "CD/Multimedia"
- 2. "Bluetooth® (audio)"
- If necessary, "Bluetooth® audio".

- Select the desired device from the list of paired devices.
- Open "Options".
- 6. "Configure phone"
- Activate "Audio".
- "OK"

Connecting the device

- "CD/Multimedia"
- "Bluetooth® (audio)"
- If necessary, "Bluetooth® audio".
- 4. Select the desired device from the list of paired devices.



White symbol 🎵 : the device is active as an audio source.

Playback

General information


- The display of music track information depends on the device.
- Operation can takes place on the device or iDrive.
- Playback is interrupted when data is exchanged via a mobile phone connected via Bluetooth.

Starting playback

- 1. Connect the device.
- "CD/Multimedia"
- "External devices"

4.

Select the symbol.



Select the desired track from the list, if necessary.

Playback menu*

Depending on the particular device, some of the functions may not be available.

Symbol	Function
N	Next track Fast forward: press and hold the symbol.
\bowtie	Previous music track Reverse: press and hold the symbol.

Disconnecting the audio connection

- 1. "CD/Multimedia"
- "Bluetooth® (audio)"
- Highlight the desired device.
- 4. Open "Options".
- 5. "Configure phone"
- 6. "Audio"
- 7. "OK"

Unpairing a device

- 1. "CD/Multimedia"
- 2. "Bluetooth® (audio)"
- 3. If necessary, "Bluetooth® audio".
- Highlight the device that is to be unpaired.

- 5. Open "Options".
- 6. "Remove phone from list"



What to do if...

Information on suitable devices can be found at www.bmwusa.com/bluetooth.

Suitable mobile phones, refer to page 216.

The device is not supported by the vehicle.

Perform a software update*, refer to page 199, if needed.

The device could not be paired or connected.

- Do the Bluetooth passkeys on the device and the vehicle match? Enter the same passkey on the device and via iDrive.
- Did it take longer than 30 seconds to enter the passkey? Repeat the pairing procedure.
- Are too many Bluetooth devices connected to the device or vehicle? Delete connections with other devices if necessary.
- Is the mobile phone in power-save mode or does it have only a limited remaining battery life? Charge the mobile phone in the snapin adapter or via a charging cable.
- Depending on the mobile phone, it is possible that only one device can be connected to the vehicle. Unpair the connected device from the vehicle and pair and connect only one device.
- The device no longer reacts? Switch the device off and on again.
- Repeat the pairing procedure.

Music cannot be played back.

 Start the program for playing back music data on the device and select a track on the device if necessary.

Switch the radio on and off again.

Music files can only be played back softly.

Adjust the volume settings on the device.

Playback is disturbed when buttons are pressed or by other messages on the device.

Switch off the button tones and other signal tones on the device.

Playback is interrupted by a telephone call or traffic bulletin and is not resumed automatically.

Switch the radio on and off again.

Playback is not possible if the mobile phone is connected both via Bluetooth Audio and via the extended connectivity of the music player in the mobile phone*.

Disconnect one of the two connections; for example, disconnect the audio connection, refer to page 198, and restart playback.

If all points in this list have been checked and the required function is still not available, please contact the hotline or service center.

Software Update*

The vehicle supports various external devices depending on the current software version. With a software update, the vehicle can support new cell phones or new external device, for example.

USB.

Software updates and related current information is available at www.bmw.com/update.

Displaying the current version

The currently installed software is displayed.


- 1. "Settings"
- "Software update"
- "Show current version"

Select desired version* to display additional information*.

Updating software via USB*

The software may only be updated when the vehicle is stationary.

- 1. Store the file for the software-update in the main director of a USB flash drive.
- Insert the USB flash drive into the USB interface of the USB audio interface in the center armrest. An update via the USB interface in the glove compartment is not possible.
- "Settings"
- "Software update"
- "Update software"



- If necessary. "USB".
- 7. "Start update"
- "OK"

All listed software updates are installed.

Restoring the previous version

If it should become necessary, the software version prior to the last software update can be restored.

The previous version can only be restored when the vehicle is stationary.

- 1. "Settings"
- "Software update"
- "Restore previous version"
- "OK" Double-click.

All listed software updates are removed.

Note

While the software is being updated or a previous version is being restored, BMW Assist*, Office functions*, and the connected devices are temporarily unavailable. Wait several minutes for the functions to become available again.

DVD system in rear*

General information

With the DVD system in the rear you can play CDs and DVDs with audio, video and image data. The DVD system can also play data from attached external audio and video devices. Audio output is possible both via headphones and via the vehicle speakers.

You can control the DVD system using the buttons on the CD-/DVD player or using the remote control.

Some functions are operated using the remote control.


Enabling DVD system

The DVD system can be enabled via iDrive.

- 1. "Settings"
- 2. "Allow rear control"
- 3. "Rear DVD system active"



Controls



- 1 Display screen
- 2 Infrared interface for headphones
- 3 CD/DVD player
- 4 Headphone connection: jack plug
- 5 12 V sockets 131

Folding in display screen

When using the ski bag or when transporting bulky pieces of luggage, the display screen should be folded in, as otherwise it may be damaged.



Note when the display screen is folded down

When the screen is folded down, do not open the lid of the center armrest or rest your arm on the screen; otherwise, you may damage the screen. ◄




- Turn the display screen, arrow 1
 The display screen switches off.
- 2. Fold down the display screen, arrow 2.

The display screen is folded out in the reverse order.

CD/DVD player

Controls



- Press: switch the DVD system on/off
 Turn: left headphone volume and vehicle volume
- 2 Eject CD/DVD
- 3 Beginning of track
 - Stop
 - Playback, pause, freeze frame
 - Next track
- 4 CD/DVD slot
- 5 Connectors for external device: cinch sockets
- 6 Press: switch the DVD system on/off Turn: right headphone volume and vehicle volume

Connecting headphones


You can connect headphones with a jack plug or operate them using the infrared interface.

To enable optimal use of the infrared interface, use infrared headphones that comply with the IEC 61603-2 standard.

Compatible infrared headphones and information about supported headphones are available at your service center.

When using infrared headphones, it is important not to interrupt the infrared connection between the headphones and the infrared interface. This means that no obstacle should come between the two and that the cover of the infrared interface should not be covered or scratched. Unfavorable lighting conditions such as glare from outside can interfere with reception.

Remote control



- Menu navigation
- 2 Volume for headphones with jack plug
- 3 Changing track or chapter during CD-, DVDor AUX playback, fast forward/rewind
- 4 Headphones right/left
- 5 Open start menu for DVD system

Menu navigation

You can use the thumbwheel and buttons 1 to navigate through the menus.

- Turn the thumbwheel: select a menu item.
- Press the arrow buttons: change between fields.
- > M Press the button: activate the menu item.

Changing batteries



- Press the detent and remove the cover.
- Change the batteries. The type and installation position are marked on the bottom of the battery compartment.
- Close the cover.



Take the used battery to a recycling center or to your service center.

Setting the language of the DVD system

- Select a CD/DVD track.
- 2. Press the button.
- Select "Tone".
- Press the button.
- 5. Switch to the top window.
- 6. Select "Language".
- Press the button.
- 8. Select the desired language.
- Press the button.

Sound output via speakers

In addition to the headphones, you can also play the sound via the vehicle speakers.

- 1. "CD/Multimedia"
- 2. "External devices"
- 3. "AUX rear"

- 4. "Volume"
- Turn the controller until the desired volume is set and press the controller.

Switching DVD system on/off

Press the button on the CD-/DVD player or under the desired screen.

The DVD system switches on automatically when a CD or DVD is inserted.

Playing CD/DVD

Use the following menu items to access data from a CD/DVD:

- Video data via "DVD"
- Audio data via "CD"
- Images "Photo"



Sancespooling.

Playing videos from CDs/ DVDs

Country codes of DVDs

Your DVD player only plays DVDs with the coding of your home region, e.g., Europe=2. The country codes supported by your DVD are contained in the information on your DVD.

An overview of the coding zones:

Code	Region
1	USA, Canada
2	Japan, Europe, Middle East, South Africa

Region
Southeast Asia
Australia, Central and South America, New Zealand
Northwest Asia, North Africa
China

DVDs with the code 0 can be played on all devices.

Starting playback

- Push the CD/DVD into the drive with the labeled side facing upward. The CD/DVD is automatically pulled in.
 - Playback begins automatically after a few seconds.
 - ▶ Otherwise: select "DVD".
- If the DVD control or the DVD-specific menu is displayed when a DVD is inserted, use the remote control buttons for menu navigation to select the desired option.

Or:

Press the button on the CD/DVD player.

You can control the playback with the buttons on the CD/DVD player or the DVD control.

Video CDs (VCDs) and Super Video CDs (SVCDs) can only be played if they do not have a DVD-specific menu.

Eject CD/DVD

Press the button on the CD/DVD player. The DVD emerges slightly from the drive.

DVD control

With the DVD control, you can select the title and chapter, open the DVD-specific menu, and operate functions such as Language, Fast forward and Reverse or Freeze frame.

A DVD can briefly deactivate functions of the DVD control, under certain circumstances while the entire DVD is being played. It is not possible to operate the DVD control under these circum-

stances. In this case, try to make the selection using the DVD-specific menu.

Press the button on the remote control during playback.



MANDSSENGEA

- Press the buttons on the remote control or turn the thumbwheel to select the desired function.
- 3.

 Press the button.

Sym	bol	Function
₽		Exit DVD control
"SE	Τ"	Settings for playing DVDs.
•		Start playback.
-		Stop playback.
ш		Activate and deactivate freeze frame.
I44	≯≯I	Skip a chapter.
44	>>	Fast forward/reverse.
"Me	nu"	Open the DVD-specific menu.

The DVD control disappears again after a short time if you have not selected a function.

Or:

Press the button on the remote control to exit the DVD control.

Fast forward/reverse

Forward/reverse with DVD control

- Press the button on the remote control during playback.
- Select the symbol.
- 3. Press the button.
- 4. Press the button several times to increase the fast forward/reverse speed.

The DVD playback will be distorted.

To cancel fast forward/reverse:

- Select the symbol.
- 2.

 Press the button.

Or:

Press the button on the CD/DVD player. The DVD will start play at the point selected.

Forward/reverse with remote control

Press and hold the button until you reach the desired point.

Or:

- During playback, turn the thumbwheel. Fast forward/reverse is interrupted.
- Continue to turn the thumbwheel. The speed is increased.
- 3. Press the button on the CD/DVD player. Fast forward/reverse is interrupted. The DVD will start play at the point selected.

Skipping chapter

You can change to the next or previous chapter during playback.

- Press the button on the remote control during playback.
- I⁴⁴ ➤ Select the symbol.
- 3. Press the button repeatedly, continuing until you reach the desired chapter.

Or:

Press the button on the left or right on the remote control repeatedly until you reach the desired chapter.

Freeze frame

 Press the button on the remote control during playback.



2. II Select the symbol.

ON Press the button.

To continue playback:

- 1. Select the ▶ or symbol.
- 2.

 Press the button.

As an alternative, you can also stop and continue playback with the button on the CD/DVD player.

Making settings for DVD

1. Press the button during playback.



2. Make the settings with the remote control:

- "Video settings":
 - "Brightness", "Color", and "Contrast" on the screen.
 - After switching to the top window, you can change other settings.

"Language": the system language of the DVD system

"Display": background brightness of the screen.

- "Treble / Bass" and "Balance": separately adjustable for the left and right headphones and the infrared headphones.
- "Reset": the settings are reset to the default values.
- "DVD format":

"Tone":

- "Standard"
- "Zoom": full-screen playback.
- "Language": language of the DVD playback. The language advances one setting each time the menu item is selected.
- ▶ "Subtitles": language of the subtitles or turn off the subtitles.
- "Title": select individual tracks on the DVD.
- "Angle of view": camera angle.

Information or symbols that appear during the playback of a film generally point out different camera angles. These are usually only briefly available.

- "Menu": open the DVD-specific menu.
- "Return": exit the menu, or:
 - Press the buttons on the remote control.

Many DVDs offer dialogs and subtitles in various languages or scene descriptions for the hearing impaired. These functions are stored on the DVD.

With some DVDs, it is only possible to select language, subtitles, camera angle, or title by using the DVD-specific menu. Consult the information accompanying your DVD.

Opening the DVD-specific menu

Additional functions may be available on DVDs. It is thus possible, for example, to select from among several possible actions or to access information about the film.

- 1. Press the button on the remote control during playback.
- Select "Menu".
- Press the button.

On some DVDs, you can use "Main menu" and "Title" to access additional menus in which you can select music scenes, for example.

To make a selection:

- ↑ → ← Select the symbol.
- Press the button until the desired function is selected.
- Press the button.

To return to the start menu:

- Select the arrow.
- Press the button.

You can also select language, subtitles, camera angle, or title in the DVD-specific menu. Consult the information accompanying your DVD.

Compressed video files

Playback

Select the directory if necessary.



- Press the button.
- Select a track.



Press the button.

- 5. Select "Play".
- 6. Press the button.

To change the directory:

1. Select the directory.



2.

Press the button.

Playback functions

- 1. Select a track.
- Press the button.
- 3. Select a menu item:
 - ▶ "Pause": stop and continue playback.
 - "Repeat track": repeat the selected track.
 - "Repeat directory": repeat the tracks in the current directory.
- Press the button.

Playing audio tracks from CD/DVD

Starting playback

Push the CD/DVD into the drive with the labeled side facing upward. The CD/DVD is automatically pulled in.


- Playback begins automatically after a few seconds.
- Otherwise: select "CD".
 - Press the button.

CDs/DVDs with compressed audio files, refer to page 207, can take approx. 1 minute to read, depending on their directory structure.

To play back audio tracks from a DVD, refer to Compressed audio files, refer to page 207.

To start playback if a CD is already in the drive:

- Open the start menu with the remote control.
- 2. Select "CD".
- 3. on Press the button.



As an alternative, you can also control the play-back with the buttons on the CD/DVD player.

To eject CD/DVD:

Press the button on the CD/DVD player.

Selecting a track

Buttons on CD/DVD player

Press the button for the corresponding direction repeatedly until you reach the desired track.

Playback begins at the start of the track.

Using the remote control

Press the button for the corresponding direction repeatedly or turn the thumbwheel until you reach the desired track.


Playback begins at the start of the track.



WWW.

Settings and playback functions for audio CDs

- Select "SFT".
- OR Press the button.



- 3. Make the settings with the remote control:
- "Tone":
 - "Treble / Bass" and "Balance": separately adjustable for the left and right headphones and the infrared headphones.
 - ▶ "Reset": the settings are reset to the default values.
- "Pause": stop and continue playback.
- "Random": the CD tracks are played back once in random sequence.
- ▶ "Scan": brief samples of all CD tracks are automatically played one after another.
- "Repeat": repeat the current track. Select again to end.

To exit from the menu:

Press the buttons on the remote control.

Fast forward/reverse

Buttons on the CD/DVD player:

Press and hold the button for the corresponding direction.


Compressed audio files

Playback

1. Select the directory if necessary.



- Press the button.
- Select a track.



- Press the button.
- Select "Play".
- Press the button.

To change the directory:

1. Select the directory.



Press the button.

Settings and playback functions for compressed audio files

Select a track.

- 2. Press the button.
- 3. Make the settings with the remote control:
- "Tone":
 - "Treble / Bass" and "Balance": separately adjustable for the left and right headphones and the infrared headphones.
 - "Reset": the settings are reset to the default values.
- ▶ "Pause": stop and continue playback.
- "Scan directory": briefly sample the tracks in the current directory.
- "Scan all": briefly sample all tracks.
- "Random directory": play the tracks in the current directory in a random sequence.
- "Random all": play all tracks in a random sequence.
- "Repeat track": repeat the selected track.
- ▶ "Repeat directory": repeat the tracks in the current directory.
- "Details": display any stored information on the current track.

To exit from the menu:

Press the buttons on the remote control.

Displaying images from CD/DVD

- Push the CD/DVD into the drive with the labeled side facing upward. The CD/DVD is automatically pulled in.
- Open the start menu with the remote control.
- 3. Select "Photo".
- 4. Press the button.

Displaying overview

1. Select the subdirectory if necessary.

2. Select "Overview".



On Press the button.

It may take some time until the overview is completely displayed.

If a symbol appears instead of an image, the image cannot be displayed in the overview.

Displaying images

- 1. Use the buttons or the thumbwheel of the remote control to select an image.
- Press the button.



3. Displaying images:

- Scroll using the menu navigation buttons of the remote control.
- Display the slide show: turn the thumbwheel to set the display duration of the images.
 - Stop the slide show: select "Stop".

Information on CD/DVD player

Safety notes

Do not remove the cover

The BMW CD/DVD player is a Class 1 laser product. Do not operate if the cover is damaged; otherwise, severe eye damage can result. ◄

Suitable media

Use of CDs/DVDs

- Do not use self-recorded CDs/DVDs with labels applied, as these can become detached during playback due to heat buildup and can cause irreparable damage to the device.
- Only use round CDs/DVDs with a standard diameter of 4.7 in/12 cm and do not play CDs/DVDs with an adapter, e.g., single CDs; otherwise, the CDs or the adapter may jam and no longer eject.
- ▶ Do not use combined CDs/DVDs, e.g., DVD Plus, as the CDs/DVDs can jam and will no longer eject.◀

The CD/DVD player can play the following media:

- Video DVD.
- CD-DA (audio CD).
- CDs/DVDs with compressed image data.
- CDs/DVDs with compressed audio data.
- CDs/DVDs with compressed video data.

The DVD player does not support DVD audio. However, many audio DVDs available in stores also contain a video track in the DVD Video format in addition to the audio track. These DVDs can be played back by the DVD player. Refer to the information on your DVD to determine whether your audio DVD contains an additional video track. Depending on the authoring used, it is possible that not all functions are available during playback.

Dual-sided DVDs available from retail suppliers are coated on both sides and bear no markings. This means both sides are information carriers.



Select a menu item:

Press the button.

Adjusting

Symbol	Function
₽	Return to the photo menu.
"SET"	Adjust the "Display". "Language": after switching to the top window, the system lan- guage can be changed.
>	Start the slide show.
н	Display the first/last image of the current directory.
₹	Rotate the image by 90°.
"Overview"	Change to the image overview.

Ending display

- Press the button.
- Select the symbol.
- Press the button.

Eject CD/DVD

Press the button on the CD/DVD player.

To play the information on the other side, turn over the DVD.

Supported formats

Depending on the compression method used, not all files of the specified formats can be opened.

Images

JPEG/JPG.

With very large image files, it can take longer for the images to be displayed.

Compressed audio files

- ▶ MP3.
- WMA.
- ▶ OGG.
- ▶ AAC.

Compressed video files

- ▷ SVCD.
- ▶ MPEG1.
- ▶ MPEG2.
- ▶ MPEG4/DivX.

Digital Rights Management (DRM)

In some cases, it may not be possible to play CDs/DVDs with integrated Digital Rights Management (DRM).

General malfunctions

- CD/DVD changers and players have been optimized for performance in vehicles. In some instances they may be more sensitive to faulty CDs/DVDs than stationary devices would be.
- If a CD/DVD cannot be played, first check whether it has been inserted correctly.

Foreign bodies/liquids in the CD/DVD slot

Make sure that no foreign objects or liquids get into the CD/DVD slot; otherwise, the

CD/DVD player will be damaged.

Humidity

High levels of humidity can lead to condensation on the CD/DVD or the laser's scan lens, and temporarily prevent playback.

Malfunctions involving individual CDs/DVDs

If malfunctions occur only with particular CDs/ DVDs, this can be due to one of the following causes.

Copied or self-recorded CDs/DVDs

- Possible reasons for malfunctions with home-recorded CDs/DVDs are inconsistent data creation or recording processes, or poor quality or old age of the blank CD/DVD.
- Only label CDs/DVDs on the upper side with a pen intended for this purpose.

Damaged CDs/DVDs

- Avoid fingerprints, dust, scratches and moisture.
- Store CDs/DVDs in a sleeve.
- Do not subject CDs/DVDs to temperatures over 122 °F/50 °C, high humidity or direct sunlight.

CDs/DVDs with copy protection

CDs/DVDs are often provided with a copy protection feature by the manufacturer. As a result, some CDs/DVDs cannot be played, can only be played to a limited degree, or cause the system to switch off. In this case, wait a short while and then switch the system back on again. Then remove the CD/DVD from the drive.

CDs/DVDs with compressed audio files

If the language set for the CD/DVD player does not match the language of the music track, the music tracks may be displayed incorrectly.

External device

Connecting



Connections for audio/video cables. Watch the colors of the sockets when connecting.

Yellow socket: video

White socket: audio on left

Red socket: audio on right

2 Power supply for external device: socket with removable cap.

Playback

- 1. Switch on the external device and start the playback.
- 2. Open the start menu with the remote control.
- Select "AUX".
- Press the button.



For devices without a video signal, for instance MP3 players, "No video signal" appears on the display. The sound is nevertheless played.

Settings for external devices

1. Press the button during playback.



- Make the settings with the remote control:
- "Video settings":
 - "Brightness", "Color", and "Contrast" of the video playback.
 - ▶ "NTSC color": the color can be adjusted on an external device with the NTSC standard.
 - ▶ "Standard": the DVD system can be adapted to external devices with different TV standards; to do so, consult the operating manual of the external device.
 - "Reset": The settings are reset to the default values.
- "Tone":
 - "Treble / Bass" and "Balance": separately adjustable for the left and right headphones and the infrared headphones.
 - "Reset": your settings are reset.
 - After switching to the top window, you can change other settings.
 - "Audio": adjust the volume of the external device to the volume of the CD/DVD player.
 - "Language": the system language of the DVD system.
 - "Display": background brightness of the screen.
- "Video Format":
 - "Standard"
 - "Zoom": full-screen playback.

To exit from the menu:





Telephone*

At a glance

The concept

Mobile phones or other external devices such as audio players can be connected to the vehicle via Bluetooth.

Bluetooth® is a registered trademark of Bluetooth® SIG, Inc.

After these devices are paired once, they are recognized automatically when the ignition is switched on as soon as they are in the vehicle and can then be operated via iDrive, the buttons on the steering wheel, and via voice activation*.

Depending on their functionality, external devices can be used via the vehicle as a telephone or as an audio source. The telephone functions are described in the following. Operating the audio functions, refer to page 196.

Up to four external devices can be paired.

Certain functions may need to be enabled by the mobile phone provider or service provider.

Using the mobile phone while driving Make entries only when traffic and road conditions allow. Do not hold the mobile phone in your hand while you are driving; use the hands-free system instead. If you do not observe this precaution, you can endanger the vehicle occupants and other road users.

Snap-in adapter*

The snap-in adapter is used to:

- Hold the mobile phone.
- Recharge the battery.
- Connect the mobile phone to an outside antenna of the vehicle.

This provides for better network reception and consistent sound quality.

Approved mobile phones

Details on which mobile phones and external devices with a Bluetooth interface are sup-

ported by the mobile phone preparation package can be obtained at www.bmwusa.com/bluetooth.

Displaying the vehicle identification number and software part number

The vehicle identification number and software part number are needed to determine which mobile phones are supported by the mobile phone preparation package. The software version of the mobile phone may also be required.

- 1. "Telephone"
- Open "Options".
- 3. "Bluetooth® info"
- 4. "Display system information"

These approved mobile phones with a certain software version, support the vehicle functions described below.

Malfunctions may occur with other mobile phones or software versions.

Do not operate a mobile phone that is connected to the vehicle on the mobile phone keypad, as this may lead to a malfunction.

A software update, refer to page 199, can be performed if necessary.

Pairing/unpairing the mobile phone

General information

The following functions are available:

- Use of a mobile phone as a telephone.
- Use of a mobile phone as an additional telephone.
- Use of a mobile phone as an audio source.
- Use of an audio device as an audio source, refer to page 196.

Requirements

- ▶ The mobile phone is suitable, refer to page 216.
- The mobile phone is ready for operation.
- Bluetooth is activated in the vehicle and on the mobile phone.
- Bluetooth presettings may need to be made on the mobile phone, e.g., for a connection without confirmation or visibility, refer to the mobile phone operating instructions.
- Deactivate Bluetooth audio if necessary.
- A number with at least four and a maximum of 16 digits was defined as the Bluetooth passkey. It is only required once for pairing.
- The ignition is switched on.

Activating/deactivating Bluetooth

Bluetooth is not permitted everywhere. Comply with all safety guidelines and regulations.

- 1. "Telephone"
- 2. Open "Options".
- "Bluetooth®"



Additional functions

Activating/deactivating the additional **functions**

Activate the functions before pairing to be able to use them in the vehicle. Information on suitable mobile phones, refer to page 216, that support this function.

- "Telephone"
- 2. "Bluetooth® (phone)"

- Open "Options".
- Select the desired additional function.
 - "Additional telephone"
 - "Office"
 - "Bluetooth® audio"

An additional function cannot be assigned to a telephone while it is deactivated.

Additional telephone*

A mobile phone can be used as an additional telephone.

The additional telephone can be used to accept incoming calls, refer to page 220. While a call is active on the additional telephone, received calls are displayed on the Control Display.

Audio source

A mobile phone can be used as an audio source.

Pairing and connecting a device

Pairing a device

To avoid becoming distracted and posing an unnecessary hazard both to your own vehicle's occupants and to other road users, only pair the device while the vehicle is stationary. ◀

- 1. "Telephone"
- "Bluetooth® (phone)"
- "Add new phone"


The Bluetooth name of the vehicle is displayed.



4. To perform additional steps on the mobile phone, refer to the mobile phone operating instructions: for instance, search for or connect the Bluetooth device or a new device.

The Bluetooth name of the vehicle appears on the mobile phone display.

- 5. Select the Bluetooth name of the vehicle on the mobile phone display.
 - You are prompted by the iDrive or mobile phone to enter the same Bluetooth passkey.
- 6. Enter the passkey and confirm.



- 7. Select the functions for which the mobile phone is to be used.
- 8. "OK"

If the pairing was successful, the mobile phone appears at the top of the list of mobile phones.

The functions supported by the mobile phone and audio device are displayed as symbols when paired.

White symbol: the function is active.

Gray symbol: the function is inactive.

Symbol	Function
A	Telephone.
\$	Additional telephone.
IJ	Audio source.

Four devices can be paired with the vehicle at once. Three devices can be connected with the vehicle at once.

If pairing was unsuccessful: What to do if..., refer to page 219.

Following the initial pairing

The mobile phone is detected/connected in the vehicle within a short period of time when the engine is running or the ignition is switched on.

- The phone book entries of the telephone stored on the SIM card* or mobile phone are transmitted to the vehicle after detection, depending on the mobile phone.
- Four devices can be paired.
- Specific settings may be necessary in some mobile phones, e.g., authorization or a secure connection; refer to the mobile phone operating instructions.

Connecting a specific device

If more than one device is detected by the vehicle, the device at the top of the list is connected. A different device can be connected by selecting it.

- 1. "Telephone"
- 2. "Bluetooth® (phone)"
- Select the device that is to be connected.



The functions that were assigned to the device before unpairing are assigned to the device when it is reconnected. If the device is already connected, these functions are deactivated.

Configuring the devices

Additional functions can be activated or deactivated for paired and connected devices.

- 1. "Telephone"
- 2. "Bluetooth® (phone)"
- 3. Highlight the device to be configured.
- Open "Options".
- 5. "Configure phone"
- At least one function must be selected.
 - ▶ "Telephone"
 - "Additional telephone"

"Audio"

7. "OK"

If a function has already been assigned to another connected device, the function is deactivated in that device and the device is unpaired when the function is assigned to a new device.

Swapping the telephone and additional telephone

The function of the telephone and additional telephone can be swapped automatically.

- "Telephone"
- 2. "Bluetooth® (phone)"
- "Swap phone/addit. phone"

Unpairing a device

- 1. "Telephone"
- "Bluetooth® (phone)"
- 3. Highlight the device that is to be unpaired.
- 4. Open "Options".
- 5. "Remove phone from list"



What to do if...

Information on suitable mobile phones, refer to page 216.

The mobile phone could not be paired or connected.

- Is Bluetooth activated in the vehicle and on the mobile phone? Activate Bluetooth on the vehicle and on the mobile phone.
- Do the Bluetooth passkeys on the mobile phone and the vehicle match? Enter the same passkey on the mobile phone and via iDrive.

- Did it take longer than 30 seconds to enter the passkey? Repeat the pairing procedure.
- Are too many Bluetooth devices connected to the mobile phone or vehicle? Delete connections with other devices if necessary.
- Is the audio connection activated? Deactivate the audio connection.
- Is the mobile phone in power-save mode or does it have only a limited remaining battery life? Charge the mobile phone in the snapin adapter* or via the charging cable.
- Depending on the mobile phone, it is possible that only one device can be connected to the vehicle. Unpair the connected device from the vehicle and pair and connect only one device.
- ▶ The mobile phone no longer reacts? Switch the mobile phone off and on again. Repeat the pairing procedure.

The telephone functions are not available.

- Is the mobile phone paired as an additional telephone and is the additional telephone function deactivated? Activate the function.
- ▶ Is an outgoing call not possible? Connect the mobile phone as a telephone.

No phone book entries or only some phone book entries are displayed, or they are incomplete.

- Transmission of the phone book entries is not yet complete.
- It is possible that only the phone book entries of the mobile phone or the SIM card* are transmitted.
- ▶ It may not be possible to display phone book entries with special characters.
- ▶ The number of phone book entries to be stored is too high.
- Is the data volume of the contact too large, e. a., due to stored information such as notes? Reduce the data volume of the contact.
- ▶ Is the mobile phone connected as an audio source or additional telephone? The mobile phone must be connected as a telephone.


The phone connection quality is poor.

- The strength of the Bluetooth signal on the mobile phone can be adjusted, depending on the mobile phone.
- Insert the mobile phone into the snap-in adapter* or place it in the area of the center console.
- Adjust the volume of the microphone and loudspeakers separately.

If all points in this list have been checked and the required function is still not available, please contact the hotline or service center.

Controls

Adjusting the volume



Turn the knob until the desired volume is selected. The setting is stored for the remote control currently in use.

The vehicle automatically adjusts the volume of the microphone on the telephone and the volume of the called party. Depending on the mobile phone, the volumes may need to be adjusted. The settings can only be created during a call and must be adjusted separately for each telephone. The settings are deleted when the telephone is unpaired.

- "Settings"
- 2. "Tone"
- "Volume settings"
- Select the desired setting: "Microphone" or "Loudspeak."
- 5. To adjust: turn the controller.
- 6. To store: press the controller.

Incoming call

Receiving calls

If the number of the caller is stored in the phone book and is transmitted by the network, the name of the contact is displayed. Otherwise, only the phone number is displayed.

If more than one phone number is assigned to a contact, only the name of the contact is displayed.

For calls on the additional telephone, the number is only displayed if it is transmitted by the network.

An incoming call to the additional telephone is automatically rejected if there is an active call on the other telephone.


Accepting a call



Press the button on the steering wheel.

or

Naccept"



Rejecting a call

% "Reject"

Ending a call




Press the button on the steering wheel.

or

- "Telephone"
- 2. "Active calls"

3. Na "End call"



Entering a phone number

Dialing a number

- 1. "Telephone"
- 2. "Dial number"
- 3. Select the digits individually.
- 4. Select the symbol.



The phone number can also be entered by voice.

Calls with multiple participants

General information

You can switch between calls or connect two calls to a single conference call. These functions must be supported by the mobile phone and service provider.

Accepting a call while speaking to another party

This function might have to be activated by the service provider and the mobile phone must be adjusted accordingly.

If a second call comes in during an ongoing call, a call waiting signal is sounded.

N "Accept"

The call is accepted and the existing call is put on hold.

Establishing a second call

Establish an additional call during an active call.

- . "Telephone"
- "Active calls"
- 3. %" "Hold"

The existing call is put on hold.



- Dial the new phone number or select it from a list.
- [™] "Return"

The call on hold is resumed.

Switching between two calls, hold call

The active call is displayed in color.

The call on hold is displayed in gray.

% "Swap calls"

The call on hold is resumed.

Establishing a conference call

Two calls can be connected to a single telephone conference call.

- 1. Establish two calls.
- 2. A "Conference call"

When terminating a conference call, both calls are ended. If one call is terminated by another party, the other call can be continued.

Switching the microphone to mute

When a call is active, the microphone can be muted.

1. "Telephone"

- "Active calls"
- 3. "Microphone mute"

A microphone that has been switched to mute is automatically reactivated:

- When a new connection is established.
- When switching between call parties.

DTMF suffix dialing

DTMF suffix dialing can be used for gaining access to network services or for controlling devices, e.g., to make a remote inquiry of an answering machine. The DTMF code is needed for this purpose.

- 1. "Telephone"
- Select the contact from a list or "Dial number".
- 3. # "Keypad dialing"
- 4. Enter the DTMF code via iDrive.

Phone book

Displays

The phone book accesses the contacts and shows all contacts for which a phone number has been stored. The entries can be selected to make a call.

- 1. "Telephone"
- "Phone book"

A symbol indicates the storage location of the contacts.



Calling a contact

Symbol	Meaning
9	Contact with one stored phone number.
	Contact with more than one stored phone number.
%	Call not possible; mobile phone without reception or network, or Service Request* is active.

For contacts with one stored phone number: select the required contact. The connection is being established.

For contacts with more than one stored phone number: select the required contact and the phone number. The connection is being established.

Editing a contact

Changing the entries in "Contacts". When a contact is changed, the changes are not stored on the mobile phone. A copy of the entry is stored in the vehicle.

- Highlight the contact.
- 2. Open "Options".
- "Edit entry"

The contact can be edited.

Redialing

General information

The list of dialed numbers in the mobile phone is transmitted to the vehicle depending on the mobile phone. Possibly only those numbers are displayed that were dialed from the vehicle.

The 20 phone numbers dialed last are displayed. The sorting order of the phone numbers depends on the particular mobile phone.

Dialing the number via the iDrive

1. "Telephone"

"Redial"



3. Select the desired entry and the phone number if necessary.

The connection is established.

Saving an entry in the contacts


- 1. Highlight the entry.
- 2. Open "Options".
- "Store as new contact" or "Add to existing contact"
- 4. Select \(\gamma\) "New phone number" or contact.
- 5. Select the type of number: "Home", "Business", "Mobile", or "Other"
- 6. Complete the entries if necessary.
- 7. If necessary, "Store contact in vehicle".

Received calls

Displaying calls

The 20 calls that were last received are displayed.

- "Telephone"
- 2. "Received calls"



Saving an entry in the contacts

1. Highlight the entry.

The connection is established.

- Open "Options".
- "Store as new contact" or "Add to existing contact"
- 4. Select % "New phone number" or contact.
- 5. Select the type of number: "Home", "Business", "Mobile", or "Other"
- Complete the entries if necessary.
- 7. If necessary, "Store contact in vehicle".

Hands-free system

General information

Calls that are being made on the hands-free system can be continued on the mobile phone and vice versa.

From the mobile phone to the handsfree system

Calls that were begun outside of the Bluetooth range of the vehicle can be continued on the hands-free system with the ignition switched on.

Depending on the mobile phone, the system automatically switches to the hands-free system.

If the system does not switch over automatically, follow the instructions on the mobile phone display; refer also to the mobile phone operating instructions.

From the hands-free system to the mobile phone

Calls that are made on the hands-free system can in some cases be continued on the mobile phone; this depends on the mobile phone.

Follow the instructions on the mobile phone display; refer also to the mobile phone operating instructions.

Calling a number from the list

Selecting an entry.

Voice operation*

Vehicles equipped with the voice activation system: operation, refer to page 24.

Vehicles not equipped with the voice activation system: depending on the equipment, the mobile phone can be voice operated as described below.

The list of short commands in the operating manual does not apply to this type of voice operation.

The concept

- The mobile phone can be operated without taking your hands from the steering wheel.
- In many cases, the entries are accompanied by announcements or questions.
- >.... Verbal instructions for voice operation.

Using voice activation

Activating the voice activation system

- 1. Briefly press the button on the steering wheel.
- 2. Say the command.

Terminating the voice activation system



Briefly press the button on the steering wheel or Cancel.

Possible commands

Having possible commands read aloud



Briefly press the button on the steering wheel. Helps.

Possible commands are announced.

The digits from zero to nine are recognized. The digits can be spoken separately or combined in a sequence to accelerate the entry.

Using alternative commands

The system often recognizes a number of different commands to run a function; for instance:

Dial name or Name

Example: dialing a phone number

- 1. Briefly press the button on the steering wheel.
- 2. →Dial number«

The system says: »Please say the number«.

- 3. For instance, >123 456 790 The system says: >123 456 790. Continue?
- Diak

The system says: »Dialing number«.

Calling

Dialing a phone number

- 1. →Dial number«
- Say the phone number.
- 3. →Diak

Correcting the phone number

The sequence of digits can be deleted after the system has repeated the digits.

→Correct number«

The command can be repeated as often as necessary.

Deleting a phone number

>Delete<

All digits entered up to that point are deleted.

Redialing

»Redial«

Voice phone book*

Depending on how your vehicle is equipped, it may be necessary to create your own voice phone book.

The entries must be entered using voice activation and are separate from the memory in the mobile phone. Up to 50 entries can be set up.

Saving an entry

- Save name
- Say the name. Do not exceed the speaking duration of approx. 2 seconds.
- 3. Say the phone number after being prompted to do so by the system.
- 4. Save

Deleting an entry

- Delete name
- 2. Say the name after being prompted to do so.
- 3. Confirm the guery with >Yes.

Deleting all entries

- 1. →Delete phone book« The dialog for deleting the phone book is opened.
- 2. Confirm the guery with Yes.
- 3. Confirm the query again with >Yes.


Reading and selecting entries

- ¬Read phone book The dialog for reading the phone book is opened.
- 2. Say Dial number when the desired entry is read.

Selecting an entry

- Dial name
- 2. Say the name after being prompted to do so.
- 3. Confirm the query with >Yes.

Adjusting the volume



Turn the knob during an announcement.

- The volume remains constant even if the volume of other audio sources is changed.
- The volume is stored for the remote control currently in use.

Notes

Do not use the voice activation system to initiate an Emergency Request. In stressful situations, the voice and vocal pitch can change. This can unnecessarily delay the establishment of a telephone connection.

Instead, use the SOS button*, refer to page 280, in the vicinity of the interior mirror.

Environmental conditions

- Say the commands, numbers, and letters smoothly and with normal volume, emphasis, and speed.
- Always say commands in the language of the system. The language for the mobile phone voice operation is preset and cannot be changed in the Control Display.
- Keep the doors, windows, and glass sunroof* closed to prevent noise interference.
- Avoid making other noise in the vehicle while speaking.


Snap-in adapter*

Installation position


In the center armrest.

Inserting/removing the snap-in adapter

Press button 1 and remove the cover.




2. Insert the snap-in adapter at the front, arrow 1, and press down, arrow 2, until it engages.






Removing the mobile phone




Press the button and remove the mobile phone.



To remove the snap-in adapter: press button 1.

Inserting the mobile phone



- 1. Depending on the mobile phone, remove the protective cap from the antenna connector and from the USB connection of the mobile phone.
- 2. With the buttons facing up, slide the mobile phone up toward the electrical contacts and press it down until it engages.

Office*

At a glance

General information

Contacts, appointments, tasks, notes, text messages, and e-mails* from the mobile phone can be displayed on the Control Display if the mobile phone provides compatible support of these functions and the necessary Bluetooth standards.

Information about which mobile phones support the Office functions can be found at www.bmwusa.com/bluetooth. A limited number of compatible mobile phones is available for Office.

Contents are only displayed in full length when the vehicle is stationary.

The mobile phone has read-access only.

Do not use Office while driving
To avoid becoming distracted and posing
an unnecessary hazard to your vehicle's occupants and to other road users, never attempt to
use the controls or enter information unless traffic and road conditions allow this.◄

Requirements

- A suitable mobile phone is paired with the vehicle and connected. In some mobile phones, data access must be confirmed on the mobile phone.
- The time, time zone, and date, refer to page 78, are correctly set on the Control Display and on the mobile phone, for instance to correctly display appointments.
- Office is activated, refer to page 217.

Updating

Data are updated every time the mobile phone is connected to the vehicle. Appointment entries, tasks, notes and reminders can be updated separately.


- 1. "Office"
- "Current office", "Calendar", "Tasks", "Notes" or "Reminders"
- 3. Open "Options".
- 4. "Update data"

Cell phone data are transmitted again to the vehicle.

Office information

The number of unread messages and active tasks as well as the upcoming appointments are displayed.

- 1. "Office"
- 2. "Current office"
- 3. Select the desired entry to display details.



Contacts

At a glance

Contacts can be created and edited. The contacts from the mobile phone* are displayed as well if this function is supported by the mobile phone. The addresses can be adopted as destinations for navigation and the phone numbers can be dialed.

Displaying contacts

General information

1. "Office"

2. "Contacts"



All contacts are listed in alphabetical order. Depending on the number of contacts, an A-Z search is offered, refer to page 23.

A symbol indicates the storage location of the contacts.


Symbol	Storage location
No sym- bol	In the vehicle; the address has not been checked as a destination.
(2)	In the vehicle; the address has been checked as a destination*.
*	Mobile phone*.

Dialing phone numbers*

- 1. Select the desired contact.
- Select the phone number.The connection is established.

Editing a contact

- 1. Select the desired contact.
- "Edit contact"



- Change the entries.
- 4. "Store contact in vehicle"

When a contact is edited, the changes are not stored on the mobile phone. A copy of the entry is stored in the vehicle.

Selecting the contact as a navigation destination*

- Select the desired contact.
- 2. Select the address.

When contacts from the mobile phone are used, the address may need to be matched to the navigation data contained in the vehicle. In this case:

Correct the address.

"Start guidance" or "Add as another destination"

Checking the address as a destination*

An address that is to be used for destination guidance must match the navigation data contained in the vehicle. The address can be checked for this purpose.

- Select the desired contact and highlight the address.
- 2. Open "Options".
- 3. "Check as destination"
- 4. Correct and store the address if necessary.


If the address is corrected and stored, a copy of it is stored in the vehicle. The address is not changed on the mobile phone.

New contact

A contact can have up to 8 phone numbers, 2 addresses, 3 e-mail addresses and one Internet address.

- "Office"
- 2. "Contacts"
- 3. Open "Options".

"New contact"



- 5. The entry fields are still filled with the previous entries: "Delete input fields"
- 6. Fill in the entry fields: select the symbol next to the entry field.
- 7. Enter the text and assign the contact type.
- 8. If the vehicle is equipped with a navigation system: enter the address. Only addresses contained in the navigation data in the vehicle can be entered. This ensures that destination guidance is possible for all addresses.

If necessary, "Accept address".

9. "Store contact in vehicle"

Contact types

Various contact types can be assigned to phone numbers and addresses.

Symbol	Meaning
6	Home phone number.
E	Business phone number.
	Mobile phone number.
8	Other phone number.
	Home address.
iii	Business address.

Specifying the home address

A home address can be stored. It appears at the top of the contact list.

- 1. "Office"
- "Contacts"

- "Home"
- Create a contact.
- "Store contact in vehicle"

Selecting the sorting order of the names*

Names can be displayed in a different order.

- 1. "Office"
- 2. "Contacts"
- Open "Options".
- 4. "Display: last, first name" or "Display: first, last name"

Depending on how the contacts were stored on the mobile phone, the sorting order of the names may differ from the selected sorting order.

Show contact pictures

Pictures stored with the contacts are stored in the vehicle when the mobile phone is connected to the vehicle. The number of transmitted pictures depends on the mobile phone. The mobile phone must support this function.

- 1. "Office"
- "Contacts"
- 3. Open "Options".
- 4. "Show images"

Display of all contact pictures is activated or deactivated.

Deleting contacts

Only contacts that are stored in the vehicle are deleted. The contacts on the mobile phone* cannot be deleted.

- 1. "Office"
- "Contacts"
- Highlight the contact.
- Open "Options".
- "Delete contact" or "Delete all contacts"
- 6. If necessary, "Yes"

Messages

General information

Whether or not text messages and e-mails from the mobile phone are displayed depends on whether transmission from the mobile phone to the vehicle is supported. Text messages and e-mails may not be supported by the service provider, or the function may need to be enabled separately. After the mobile phone is first paired, transmission may take several minutes. Messages are only displayed in full length when the vehicle is stationary. Messages from the additional telephone are not transmitted.

Display of different messages:

- Text messages.
- Message from My Info*.
- Messages from the BMW Assist Concierge service*.
- ▶ E-mails from the mobile phone*.

Displaying messages

- 1. "Office"
- "Messages"

A symbol identifies the type of message.

Symbol	Message type
\boxtimes	Text messages.
⊠į	My Info
⊠i	Message from the Concierge service.
⊠	E-mail from mobile phone.

Filtering the message list

The message list can be filtered, when more than one type of message exists.

1. "Filter:"



- Select the type of message.
 - > "All"

All messages are displayed.

"E-mail"

Only e-mails from the mobile phone are displayed.

"Service message"

Only messages from the BMW Assist Concierge service and My Info are displayed.

"Text message"

Only text messages from the mobile phone are displayed.

Deleting messages

Messages from the Concierge service and My Info can be deleted.

Delete a message:

- 1. "Office"
- 2. "Messages"
- Select the desired message.
- 4. Open "Options".
- 5. "Delete message"

Delete all messages:

- 1. "Office"
- 2. "Messages"
- 3. Open "Options".
- "Delete all messages" or "Delete service messages"

Text messages

Using contact data

Contact data from appointments, tasks, text messages, e-mails, and notes can be saved or selected*, refer to page 233.

Reading the text message out loud*

Read the text message out loud, refer to page 234.

My Info

Starting destination guidance

- 1. Select the desired message.
- "Start guidance" or "Add as another destination"

Dialing the number in the message

Up to 4 phone numbers can be transmitted with a message.

- 1. Select the desired message.
- 2. % "Call":

If the message contains a number, the connection is established.

□ "Select phone number":


If the message contains more than one number, select the desired number from the list. The connection is established.

Message from the Concierge service*

Starting destination guidance

1. Select the desired message.

Start guidance" or "Add as another destination"



Start destination guidance, if necessary.

Dialing the number in the message

Up to 4 phone numbers can be transmitted with a message.

- 1. Select the desired message.
- 2. % "Call":

If the message contains a number, the connection is established.

□ "Select phone number":

If the message contains more than one number, select the desired number from the list. The connection is established.

Storing an address

- 1. Select the desired message.
- 2. Open "Options".
- "Store contact in vehicle"

Displaying additional information

- 1. Select the desired message.
- "Further information"

E-mail*

Displaying e-mails

- 1. "Office"
- "Messages"
- 3. Select the desired e-mail.

Displaying e-mail contacts

If the sender and recipient of an e-mail are transmitted by the mobile phone, this information is displayed in the e-mail.

△ "Sender/Recipient"

If the e-mail addresses are stored in the contacts, the contact is displayed. Select the contact to display details.

If the e-mail addresses are not stored in the contacts, only the e-mail address is displayed.

Using contact data

Contact data from appointments, tasks, text messages, e-mails, and notes can be saved or selected*, refer to page 233.

Deactivating the full display

When an e-mail is opened in the vehicle, the email is fully transmitted to the vehicle. This may result in charges.

- 1. "Office"
- 2. "Messages"
- 3. Open "Options".
- "Fully download e-mails"Only a part of the email from the ce

Only a part of the email from the cell phone is loaded into the vehicle.

Reading the e-mail out loud*

Read the e-mail out loud, refer to page 234.

Calendar

Display the calendar

Appointments during the last 20 days and the next 50 days can be displayed.

- 1. "Office"
- 2. "Calendar"

The appointments on the current day are displayed.

Selecting the calendar day

Select the date.



- 2. Select the desired day or date.
 - "Next day"
 - "Date:"
 - "Previous day"
 - "Today"

Display the appointment

- 1. Select the desired appointment.
- Scroll through the appointment if necessary:
 - ▶ Turn the controller.
 - Select the symbol.

Using contact data

Contact data from appointments, tasks, text messages, e-mails, and notes can be saved or selected*, refer to page 233.

Reading the appointment out loud*

Read the appointment out loud, refer to page 234.

Tasks


Displaying the task list

Display tasks that are due within the next 90 days.

- "Office"
- "Tasks"

Sorting the task list

1. Select the header in the task list.



- Select the sorting criterion:
 - "Priority (!)"*
 - "Subject"
 - "Due date"

Displaying the task

- Select the desired task.
- 2. Scroll in the task if necessary:
 - Turn the controller.
 - Select the symbol.

Using contact data

Contact data from appointments, tasks, text messages, e-mails, and notes can be saved or selected*, refer to page 233.

Reading the task out loud*

Read the task out loud, refer to page 234.

Notes


Displaying notes

- 1. "Office"
- 2. "Notes"

All notes are displayed.

Displaying the note

Select the desired note.



- 2. Scroll in the note if necessary:
 - Turn the controller.
 - Select the symbol.

Using contact data

Contact data from appointments, tasks, text messages, e-mails, and notes can be saved or selected*, refer to page 233.

Reading the note out loud*

Read the note out loud, refer to page 234.

Reminders

Displaying reminders

Reminders of pending appointments and tasks are displayed. After an appointment or after a task is due, the reminder is no longer displayed.

- "Office"
- 2. "Reminders"
- Select the desired reminder.

The corresponding appointment or the task are displayed.

Using contact data

At a glance

Contact data from appointments, tasks, text messages, emails, and notes can be stored or selected*.

Displaying contact or selecting phone number

- 1. Use contact data"
- Display the contact or select the phone number:
 - Select the contact to display contact details.
 - Select the phone number to establish a connection directly.

Storing contact data

- 1. Use contact data"
- Highlight the phone number or e-mail address.
- 3. Open "Options".
- "Add to existing contact" or "Store as new contact"

Reading out loud*

Text messages, e-mails, appointment entries, tasks, and notes can be read out loud.

- Select the desired message, appointment, task, or note.
- 2. > Select the symbol.

The following options are available during reading:

- ▶ II "Pause" Interrupt reading. Select again to restart reading.
- ▶ III "Back to beginning"
 Start reading the message again from the beginning.
- Select the symbol.Go back one paragraph.
- $\qquad \qquad \text{To end reading, turn the controller to the left.}$

What to do if...

Information on suitable mobile phones, refer to page 216.

Appointments, tasks, notes, text messages, or e-mails from the mobile phone are not displayed.

- The mobile phone is not capable of the missing function or is not connected correctly.
- The Office function is deactivated.
- The mobile phone is connected as an additional phone.
- Appointments are older than 20 days or are more than 50 days in the future.
- The tasks have been marked as completed or have a due date that lies more than 90 days in the future.
- Depending on the number of stored appointments, task notes, and messages in the mobile phone, not all are displayed in the vehicle.

Not all appointments and tasks from the mobile phone are displayed at the right time?

The time zone, time, or date is incorrectly set on the Control Display and mobile phone.

The e-mail attachment is not displayed.

E-mails are transmitted without an attachment.

Entries are not displayed in full length.

- ▶ Text were already transmitted from the mobile phone in a shortened form.
- Synchronization between the mobile phone and vehicle may take several minutes.

The contact pictures are not being displayed?

Up to 200 contact pictures can be stored in the vehicle.

The E-mail is displayed with a delay?

Check the e-mail settings on the telephone and adjust if necessary.

If all points in this list have been checked and the required function is still not available, please contact the hotline or service center.

Contacts*

General information

Contacts can be created and edited and the addresses can be adopted as destinations for navigation.

New contact

- 1. "Contacts"
- "New contact"



- 3. The entry fields are still filled with the previous entries: "Delete input fields"
- 4. Fill in the entry fields: select the symbol next to the entry field.



- 5. Enter the text, refer to page 23. In vehicles equipped with a navigation system: it is only possible to enter addresses that are contained in the vehicle navigation data. This ensures that destination guidance is possible for all addresses.
- 6. If necessary, "Store".
- "Store contact in vehicle"

Specifying the home address

A home address can be stored. It appears at the top of the contact list.

- 1. "Home"
- Create a contact.
- "Store contact in vehicle"


My contacts

General information

List of all contacts.

Displaying contacts

- 1. "Contacts"
- "My contacts"



All contacts are listed in alphabetical order. Depending on the number of contacts, an A-Z search is offered, refer to page 23.

A symbol indicates the storage location of the contacts:

Symbol	Storage location
No symbol	In the vehicle; the address has not been checked as a destination.
a	In the vehicle; the address has been checked as a destination.

Editing a contact

- "My contacts"
- Select the desired contact.

3. "Edit contact"



- 4. Change the entries.
- 5. Move the controller to the left.
- 6. "Yes"

Selecting the contact as a navigation destination*

- 1. Select the desired contact.
- 2. Select the address.
- "Start guidance" or "Add as another destination"

Checking the address as a destination*

An address that is to be used for destination guidance must match the navigation data contained in the vehicle. The address can be checked for this purpose.

- Select the desired contact and highlight the address.
- 2. Open "Options".
- 3. "Check as destination"
- 4. Correct and store the address if necessary.

Selecting the sorting order of the names

Names can be displayed in a different order.

- "My contacts"
- 2. Open "Options".
- 3. "Display: last, first name" or "Display: first, last name"

Deleting contacts

- 1. "My contacts"
- 2. Highlight the contact.
- 3. Open "Options".
- 4. "Delete contact" or "Delete all contacts"

Connected Drive*

BMW Assist*

General information

BMW Assist provides you with certain services, e.g., transmission of the position data of your vehicle to the BMW Assist Response Center if an Emergency Request* has been initiated.

Many BMW Assist services depend on the individually agreed upon contract.

After your contract has expired, the BMW Assist system will be deactivated by the BMW Assist Response Center without your having to visit a service center. After the BMW Assist system has been deactivated, no BMW Assist services will be available. The BMW Assist system can be reactivated by a service center after you sign a new contract.

Requirements

- The installed BMW Assist system is logged in to a wireless communications network. This network must be capable of transmitting the services.
- ▶ To transmit position data, the vehicle must be able to determine the current position.
- The BMW Assist service contract was signed with your service center or with the BMW Assist Response Center, Enabling must have been completed.
- BMW Assist is activated.

Services offered

- ▶ Emergency Request: when you press the SOS button, a connection to the BMW Assist Response Center is established. The BMW Assist Response Center then speaks with you and takes further steps to help you.
- Automatic Collision Notification; under certain conditions, a connection is established to the BMW Assist Response Center after a serious accident. If possible, the BMW As-

- sist Response Center then speaks with you and takes further steps to help you.
- Enhanced Roadside Assistance: BMW Roadside Assistance* can be contacted if assistance is needed in the event of a breakdown. If possible, the vehicle and position data are transmitted in the process.
- Customer Relations: connection with Customer Relations for information on all aspects of your vehicle.
- TeleService: data on your vehicle's service status or required inspections are transmitted to your service center, either automatically before a service due date or when you request a BMW service appointment.
- Remote Door Unlock: the BMW Assist Response Center provides assistance if, for example, the remote control is not available and the vehicle needs to be opened.
- Stolen Vehicle Recovery: after you report that your vehicle was stolen to the police, the BMW Assist Response Center can determine its position.
- In addition to these services, the optional Convenience Plan offers Concierge service and information for route planning, traffic, and weather. A limited number of calls can be made via the BMW Assist Response Center with Critical Calling if, for example, the mobile phone is not available or discharged.

Press the SOS button to contact the BMW Assist Response Center.

TeleService*

General information

TeleService supports communication with your service center.

Data on the vehicle's service requirements can be sent directly to the service center. In this way, the service center can plan its work

- in advance. This shortens the duration of the service appointment.
- In the event of a breakdown, data on the vehicle's condition can be sent directly to Roadside Assistance*.
- The service varies by country.
- Connection costs may ensue.
- > Services may be restricted abroad.

Requirements

- BMW Assist is activated.
 - If BMW Assist is not activated, a mobile phone that has been recommended by BMW for TeleService and that is configured for mobile data communication must be connected with the vehicle.
- Wireless reception is available.
- The engine is running.

Using BMW TeleService*

BMW TeleService are typically activated in the vehicle.

Even if the BMW TeleService are not active, a voice contact to Roadside Assistance* is still possible.

To continue using or to deactivate the services, please contact your service partner or the BMW customer hotline.

Concierge service*

General information

The BMW Assist Concierge service offers information on events, gas stations, and hotels, and provides phone numbers and addresses. Hotels can be booked directly by the BMW Assist Concierge service. The Concierge service is part of the optional Convenience Plan.

Starting the Concierge service

1. "BMW Assist" or "ConnectedDrive"

2. "Concierge"



3. "Start service"

A voice connection is established with the BMW Assist Concierge service. Phone numbers and addresses can be transmitted to the vehicle.

Messages

Information on messages, refer to page 230.

Roadside Assistance

At a glance

BMW Roadside Assistance* can be contacted if assistance is needed in the event of a breakdown.

Roadside Assistance* can also be contacted via a Check Control message, refer to page 76.

Starting Roadside Assistance without BMW Assist or TeleService

- 1. "BMW Assist" or "ConnectedDrive"
- 2. "Roadside Assistance"

The Roadside Assistance number is displayed. If the mobile phone* is paired, a con-

nection is established to Roadside Assistance.




Starting Roadside Assistance with **BMW Assist or TeleService**

General information

In vehicles equipped with TeleService, support is first offered by TeleService Diagnosis and then, if necessary, by TeleService Help.

- "BMW Assist" or "ConnectedDrive"
- "Roadside Assistance"
- 3. "Start service"



TeleService Diagnosis*

TeleService Diagnosis enables the wireless transmission of detailed vehicle data that are important for vehicle diagnosis. These data are transmitted automatically.

After the data are transmitted, the voice connection to Roadside Assistance is re-established.

TeleService Help*

TeleService Help enables an in-depth diagnosis of the vehicle by Roadside Assistance via wireless transmission.

TeleService Help can be started after a prompt by Roadside Assistance and the termination of the voice connection.

Starting TeleService Help

- 1. Park the vehicle in a safe place.
- 2. Set the parking brake.
- The ignition is switched on.
- 4. "TeleService Help"

After completion of TeleService Help, a voice connection is established to Roadside Assistance.

BMW Online*

At a glance

A business search can be opened via BMW Online.

License conditions

This product contains NetFront Browser software of ACCESS Co., Ltd. Copyright © 2007 ACCESS Co., Ltd. All rights reserved.

NetFront is a trademark or registered trademark of ACCESS CO., LTD., in Japan and other countries.

This software is based in part on the work of the Independent JPEG Group.

Requirements

- Subscription to the optional Convenience
- The date setting on the Control Display is current.
- The vehicle is located within wireless network coverage.

Starting BMW Online

"BMW Assist" or "ConnectedDrive"

2. "BMW Online"



3. If necessary, "OK".

The BMW Online home page is displayed.


Operating BMW Online

To start a search:

- ▶ Turn the controller to highlight an element.
- Press the controller to display an element.

Opening the start page

- 1. Open "Options".
- 2. "Display start page"



Loading a new page

- 1. Open "Options".
- 2. "Reload"

Cancel

- 1. Open "Options".
- 2. "Cancel loading"

Customer Relations

At a glance

Contact Customer Relations for information on all aspects of your vehicle.

Calling Customer Relations

Vehicle not equipped with BMW Assist or TeleService

- 1. "BMW Assist" or "ConnectedDrive"
- 2. "Customer Relations"

The Customer Relations phone number is displayed. If the mobile phone* is paired, a connection is established to Customer Relations.



Vehicle equipped with BMW Assist or TeleService

- "BMW Assist" or "ConnectedDrive"
- 2. "Customer Relations"
- "Start service"

Service Request*

At a glance

Sends information to your service partner to request the arrangement of a service appointment. The TeleService data is transmitted during a Service Request. If possible, your service partner will establish contact with you.

Starting a Service Request

- "BMW Assist" or "ConnectedDrive"
- "Service Request"

"Start service"



A Service Request can be started via a Check Control message, refer to page 76.

Automatic Service Request*

The TeleService data necessary for servicing the vehicle are automatically sent to your service partner prior to the service deadline. If possible, the service partner will contact you and a service appointment can be arranged.

To check when your service partner was notified:

- "Vehicle Info"
- "Vehicle status"



- 3. Open "Options".
- 4. "Last Service Request"


Services status*

Displaying available services

Display of all services available in the vehicle.

- "BMW Assist" or "ConnectedDrive"
- "Service Status"

"Available services"



Updating BMW Assist

Manual update of TeleService* and BMW Assist*.

- 1. "BMW Assist" or "ConnectedDrive"
- "Service Status"
- "Update BMW Assist"

Data transfer*

During the updating of BMW services, display the status of the data transfer.

- 1. "BMW Assist" or "ConnectedDrive"
- Open "Options".
- "Data transfer"

Apps*

At a glance

Certain software applications of a suitable cell phone can be integrated in the vehicle. These software applications are displayed on the Control Display.

They are operated via iDrive.

Requirements

- The mobile phone is suitable.
- The mobile phone operating system supports the software applications of Apps.
- Software applications are installed on the cell phone and ready to use.
- Corresponding mobile wireless contract.

- Any additionally incurred costs are not a part of Apps.
- Use only BMW approved software applications; otherwise, it may result in malfunctions.

Information about suitable cell phones, available software applications and their installation can be found at www.bmw.com/connectivity or at the service center.

Create the entries.

Make entries only when traffic and road conditions allow. Otherwise, the vehicle occupants and other road users may be put in danger because of the distraction from driving.

For reasons of safety, some software applications are usable only while the vehicle is stationary. ◀

Operating Apps

- Connect the cell phone via the snap-in adapter or via the USB audio interface.
- 2. "ConnectedDrive"
- Select the desired software application.

Displaying status

Information about the currently available software applications can be displayed.

- "ConnectedDrive"
- 2. "BMW apps"

PlugIn*

Selected functions of the cell phone are displayed on the Control Display. They can be operated via iDrive.

- 1. Connect cell phone via the snap-in adapter.
- "ConnectedDrive"
- 3. "Plualn"
- "Activate Plugln"
- Navigate to the displayed functions via the controller and select, for example, a desired category or track.



Press button to switch within the cell phone functions to a higher level or back.




Press button twice to switch back to the main menu.

Notes

- The ranges of Apps that can be displayed on the Control Display depend on the range of installed software applications on the mobile phone.
- The data transmission of the software applications from the cell phone to the vehicle can last some time. Some software applications depend on the speed of the available Internet connection of the cell phone.
- Some mobile phones cannot simultaneously use Apps and the Bluetooth handsfree system.

If necessary, restart the software application on the cell phone after a phone conversation.



Mobility In order to always ensure your mobility, you will find important information on operating fluids, wheels and tires, maintenance and Roadside Assistance in the following.

Refueling

Notes

Switch off the engine before refueling
Always switch off the engine before refueling; otherwise, fuel cannot be added to the tank and a message will be displayed.




Observe when handling fuel

- Take all precautionary measures and observe all applicable regulations when handling fuel.
- Do not carry any spare fuel containers in your vehicle. They can develop a leak and cause an explosion or cause a fire in the event of an accident. ◀

Fuel cap

Opening

 Briefly press the rear edge of the fuel filler flap.



- Turn the fuel cap counterclockwise.
- Place the fuel cap in the bracket attached to the fuel filler flap.

Closing

- Fit the fuel cap and turn it clockwise until you clearly hear a click.
- Close the fuel filler flap.


Do not pinch the retaining strap
Do not pinch the retaining strap attached
to the cap; otherwise, the cap cannot be closed
properly and fuel vapors can escape. ◄

A message* is displayed if the cap is loose or missing.

Manually unlocking fuel filler flap

In the event of a malfunction, the fuel filler flap can be released manually:

- Open the right-hand side panel in the cargo area.
- Pull the knob with the gas pump symbol.



Observe the following when refueling

When refueling, insert the filler nozzle completely into the filler pipe. Lifting up the fuel pump nozzle during refueling causes:

- Premature pump shutoff.
- Reduced efficiency in the fuel-vapor recovery system.

The fuel tank is full when the filler nozzle clicks off the first time.

Mandling fuels

Follow the safety instructions provided at gas stations; otherwise, there is a danger of personal injury and property damage.

Fuel tank capacity

Approx. 22.5 US gallons/85 liters, including the reserve capacity of approx. 2.1 US gallons/8 liters.

X5 xDrive50i/X6 xDrive50i: reserve capacity of approx. 3.2 gallons/12 liters.

Refuel promptly

At the latest, refuel when the range drops below 30 miles/50 km; otherwise, engine functions are not ensured and damage may occur.

Fuel

Fuel specifications

Gasoline engine: required fuel

Do not use fuels that are labeled at the fuel pump as containing metals.



Only refuel with lead-free gasoline without metal additives

Do not refuel with leaded gasoline or gasoline with metal additives, e. g., manganese or iron; otherwise, the catalytic converter and other components will be permanently damaged. ◀

Do not refuel with ethanol E85
Do not refuel with E85, i.e., fuel with an ethanol content of 85 %, or with Flex Fuel, as this would damage the engine and fuel supply system.

Super Premium Gasoline/AKI 91

This gasoline is highly recommended.

However, you may also use gasoline with less AKI. The minimum AKI Rating is:

- ▶ BMW X5: 87
- ▶ BMW X6:89

If you use gasoline with this minimum AKI Rating, the engine may produce knocking sounds when starting at high outside temperatures. This has no affect on the engine life.

Minimum fuel grade
Do not use any gasoline below the minimum specified fuel grade; otherwise, engine damage may occur.

✓

Use high-quality brands

Field experience has indicated significant differences in fuel quality: volatility, composition, additives, etc., among gasolines offered for sale in the United States and Canada. Fuels containing up to and including 10% ethanol or other oxygenates with up to 2.8% oxygen by weight, that is, 15% MTBE or 3% methanol plus an equiva-

lent amount of co-solvent, will not void the applicable warranties with respect to defects in materials or workmanship.

Minimum fuel grade

The use of poor-quality fuels may result in driveability, starting and stalling problems especially under certain environmental conditions such as high ambient temperature and high altitude.

Should you encounter driveability problems which you suspect could be related to the fuel you are using, we recommend that you respond by switching to a recognized high-quality brand such as gasoline that is advertised as Top Tier Detergent Gasoline.

Failure to comply with these recommendations may result in unscheduled maintenance. ◀

BMW X5 with BMW Advanced Diesel: required fuel

Ultra-Low Sulfur Diesel

The engine of your BMW is designed for diesel with a low sulfur content:

Ultra-low sulfur diesel ASTM D 975-07a.

Only refuel with ultra-low sulfur diesel.

The percentage of biodiesel in the fuel

must not exceed 5%, referred to as B5. Do not refuel with gasoline. If the vehicle has been refueled with incorrect fuel such as gasoline, do not start the engine; otherwise, there is a danger of engine damage. ◀

If you added the wrong fuel, contact the service center.

The fuel filling neck is designed for refueling with diesel nozzles.

If the nozzle cannot be inserted into the fuel filler pipe of your BMW, please check to make sure that you are refueling with a diesel fuel pump and whether this is equipped with a diesel nozzle. In the event the Ultra-Low Sulfur Diesel fuel cannot be fully inserted into the fuel filler neck, please contact BMW Roadside Assistance for instructions on how to add fuel. For more information on BMW Roadside Assistance, refer to page 281.

Winter diesel

To ensure that the diesel engine remains operational in the winter, use winter diesel.

It is available at gas stations during winter months.

The standard fuel filter heating prevents the supply of fuel from stalling during driving.

No diesel additives

Do not add additives, including gasoline; otherwise, engine damage may occur. ◀

BMW recommends BP fuels



BMW X5 with BMW Advanced Diesel

The concept

BMW Advanced Diesel reduces nitrogen oxides in the diesel exhaust of your vehicle by injecting the reducing agent diesel exhaust fluid into the exhaust line. In the catalytic converter, a chemical reaction occurs that minimizes nitrogen oxides.

In order to be able to start the engine in the usual way, there must be a sufficient supply of diesel exhaust fluid in the separate reservoir.

System heating

In order to bring the system to operating temperature after a cold start of the engine, the automatic transmission shifts into the next higher gear at a later point.

Reserve display

A display in the instrument panel informs you about the remaining distance can be covered with the amount of fuel currently in the tank.



The reserve display appears approx. 1,000 miles/1,600 km before the tank is empty.

As soon as the reserve display has appeared in the instrument panel, have the diesel exhaust fluid refilled to prevent the engine from being unable to restart.

Diesel exhaust fluid at minimum



Even with a display of -- mls, the engine will continue to run, provided that it is not switched off, and all other operating requirements are met, e.g. sufficient fuel.

No engine start

Do not drive until the displayed remaining distance runs out. Otherwise, it may not be possible to restart the engine. ◀

Incorrect fueling



The warning lamp lights up:

The reservoir has been filled with an incorrect fluid.

Please contact your service center.

Have diesel exhaust fluid refilled

This exhaust fluid is refilled by your service center during regular maintenance. If you adhere to this maintenance schedule, it is usually not necessary to refill any fluids between the maintenance dates.

Under certain circumstances, for example, due to a particularly sporty driving style or operation of the vehicle at high altitudes, it may be necessary to refill fluids between maintenance dates.

As soon as the reserve display has appeared in the instrument panel, have the diesel exhaust fluid refilled to prevent the engine from being unable to restart.

You can have the fluid refilled by a service center.

Diesel exhaust fluid at low temperatures

Due to its physical properties, it may be necessary to replenish the level of diesel exhaust fluid at temperatures below +23 °F/ -5 °C, even between the regular maintenance dates.

If the fluid needs to be refilled, this will be indicated with the reserve display in the instrument cluster, refer to page 249.

Only refill the diesel exhaust fluid yourself in exceptional circumstances

To be able to reach the nearest service center with your vehicle, you may refill the diesel exhaust fluid yourself, making sure to heed the warning notices specified below.

Handling diesel exhaust fluid
Do not allow diesel exhaust fluid to come
into contact with you. This can lead to skin and
eye irritation. Wear protective goggles and
gloves as needed. Follow the safety instructions
on the bottle. When opening the bottle or res-

ervoir, pungent smelling vapors can escape. Before refilling, close the vehicle completely so that the vapors do not get into the interior of the vehicle. When handling diesel exhaust fluid in enclosed spaces, make sure to have sufficient ventilation. After handling diesel exhaust fluid, wash hands thoroughly. Failure to do so may lead to irritation, for instance, due to inadvertent contact with the eyes. If eye irritation occurs, immediately rinse eyes with ample water and contact a doctor if necessary. If diesel exhaust fluid comes into contact with surfaces of your vehicle, rinse the affected surfaces with water or else damage may occur. Keep diesel exhaust fluid out of reach of children.

Suitable diesel exhaust fluid

- Preferred: BMW Diesel Exhaust Fluid. This bottle and its special adapter permit convenient refilling with diesel exhaust fluid.
- Alternative: NOx reduction agent AUS 32

Diesel exhaust fluid can be obtained from your service center.

Refilling quantity

Refilling quantity at the start of the reserve display:

Approx. 0.75 gallons/2.7 liters

Open reservoir for diesel exhaust fluid

- 1. Open the hood, refer to page 264.
- Fit the releasing tool from the tool kit, refer to page 270, into place and open the lock, see arrow.




MACSESSON


Mobility

Refilling BMW diesel exhaust fluid

1. Set bottle into place and rotate until it comes into contact with the stop, refer to arrow.




2. Press bottle down, refer to arrow. The reservoir of the vehicle is filled.



3. The reservoir is full when the fill level in the bottle stops changing. It is not possible to

Pull bottle back, refer to arrow, and unscrew it.



Closing reservoir

After the reservoir is filled, close it again with the releasing tool.

After refilling diesel exhaust fluid

Incorrect fluid

Incorrect fluids

After refilling with the incorrect fluid, e.g., antifreeze for windshield wiper fluid, do not start the engine because this could result in a fire hazard.∢

Contact your service center.

Bottle disposal



Diesel exhaust fluid bottles can be disposed of by your service center.

Only dispose of empty bottles in your household garbage if the local legal regulations permit it.

Reserve display



After refilling, the reserve continues to appear after the engine is restarted. After the vehicle has been driven for a few more minutes, this display will disappear.

Wheels and tires

Tire inflation pressure

Safety information

It is not merely the tires' service life, but also driving comfort and, to a great extent, driving safety that depend on the condition of the tires and the maintenance of the specified tire pressure.

Checking the pressure

Only check the tire inflation pressure when the tires are cold. This means after a maximum of 1.25 miles/2 km driving or when the vehicle has been parked for at least 2 hours. When the tires are warm, the tire inflation pressure is higher.

Check the tire inflation pressure regularly Check the tire inflation pressure regularly and correct it if necessary, even in the compact wheel*: usually twice monthly or before embarking on a long trip. If you fail to observe this precaution, you may be driving on tires with incorrect tire pressures, a condition that may not only compromise your vehicle's driving stability, but also lead to tire damage and the risk of an accident.

Do not drive with depressurized or flat tires, except for run-flat tires. A flat tire will seriously impair your vehicle's handling and braking response. Attempts to drive on a flat tire can lead to a loss of control over the vehicle.

After adjusting the tire inflation pressure, reset the Tire Pressure Monitor, refer to page 90, or reinitialize the Flat Tire Monitor, refer to page 88.

Pressure specifications

The tables below provide all the correct inflation pressures for the specified tire sizes at ambient temperature.

The inflation pressures apply to the tire sizes approved and tire brands recommended by

BMW; a list of these is available from your service center.

For correct identification of the right tire inflation pressures, observe the following:

- Tire sizes of your vehicle.
- Maximum allowable driving speed.

Tire inflation pressures for driving up to 100 mph or 160 km/h

For normal driving up to 100 mph/160 km/h, adjust pressures to the respective tire inflation pressures listed on the following pages in the column for traveling speeds up to 100 mph/160 km/h to achieve optimum driving comfort.

These tire inflation pressures can also be found on the driver's side door pillar when the driver's door is open.



lack

Do not exceed the maximum permissible speed

The maximum permissible speed for these tire pressures is 100 mph/160 km/h Do not exceed this speed; otherwise, tire damage and accidents could occur.◀

Tire inflation pressures for driving above 100 mph or 160 km/h

Adjust the tire inflation pressures
To drive at maximum speeds in excess of
100 mph/160 km/h, adjust pressures to the respective tire inflation pressures listed on the following pages in the column for traveling speeds
including those exceeding 100 mph or 160 km/

h. Otherwise, tire damage and accidents could occur. \blacktriangleleft

Observe all national and local maximum speed limits; otherwise, violations of the laws could occur.

Tire inflation pressures X5 xDrive35i/X5 xDrive35d with two rows of seats

Tire size	Pressure specifications in psi/kPa			
	Traveling speeds of up to 100 mph/160 km/h		Traveling spe those exceed 160 km/h	_
All pressure specifications in the table are indicated in psi/kilopascal with cold tires. Cold = ambient temperature	* * * * +	†/©	* * * * +	
Compact wheel*: T 155/90 D 18 113 M T 155/80 R 19 114 M	60/420	60/420	60/420	60/420
Without Sport Package:				
255/55 R 18 109 H M+S XL RSC	32/220	36/250	35/240	41/280
255/50 R 19 107 H M+S XL RSC	32/220	38/260	35/240	42/290
Front: 255/50 R 19 107 V XL RSC Rear: 285/45 R 19 111 V XL RSC	32/220 -	- 35/240	35/240	- 38/260
Front: 275/40 R 20 106 W XL RSC Rear: 315/35 R 20 110 W XL RSC	33/230	- 35/240	35/240	- 38/260
Front: 285/35 R 21 105 W XL RSC Rear: 325/30 R 21 108 W XL RSC	33/230 -	- 38/260	36/250	- 41/280
With Sport Package:				
255/55 R 18 109 H M+S XL RSC	32/220	36/250	35/240	41/280
255/50 R 19 107 H M+S XL RSC	32/220	38/260	35/240	42/290
Front: 255/50 R 19 107 V XL RSC Rear: 285/45 R 19 111 V XL RSC	32/220	- 35/240	39/270 -	- 42/290
Front: 275/40 R 20 106 W XL RSC Rear: 315/35 R 20 110 W XL RSC	33/230 -	- 35/240	38/260	- 41/280

Tire size	Pressure specifications in psi/kPa				
Front: 285/35 R 21 105 W XL RSC	33/230	-	38/260	-	
Rear: 325/30 R 21 108 W XL RSC - 38/260 - 45/310 More details on the permissible load and weights, refer to page 292.					

Tire inflation pressures X5 xDrive50i with two rows of seats

Tire size	Pressure specifications in psi/kPa			
	Traveling speeds of up to 100 mph/160 km/h		Traveling speeds include those exceeding 100 m 160 km/h	
All pressure specifications in the table are indicated in psi/kilopascal with cold tires. Cold = ambient temperature	***	†/D	* † * † +	
Compact wheel*: T 155/90 D 18 113 M T 155/80 R 19 114 M	60/420	60/420	60/420	60/420
Without Sport Package:				
255/55 R 18 109 H M+S XL RSC	32/220	36/250	35/240	41/280
255/50 R 19 107 H M+S XL RSC	32/220	39/270	36/250	44/300
Front: 255/50 R 19 107 W XL RSC Rear: 285/45 R 19 111 W XL RSC	32/220 -	- 35/240	36/250	- 38/260
Front: 275/40 R 20 106 W XL RSC Rear: 315/35 R 20 110 W XL RSC	33/230	- 36/250	35/240	- 39/270
Front: 285/35 R 21 105 Y XL RSC Rear: 325/30 R 21 108 Y XL RSC	33/230	- 39/270	36/250	- 41/280
With Sport Package:				
255/55 R 18 109 H M+S XL RSC	32/220	36/250	35/240	41/280
255/50 R 19 107 H M+S XL RSC	32/220	39/270	36/250	44/300
Front: 255/50 R 19 107 W XL RSC Rear: 285/45 R 19 111 W XL RSC	32/220	- 35/240	41/280	- 45/310
Front: 275/40 R 20 106 W XL RSC Rear: 315/35 R 20 110 W XL RSC	33/230	- 36/250	42/290	- 46/320

Mobility

Tire size	Pressure specifications in psi/kPa			
Front: 285/35 R 21 105 Y XL RSC Rear: 325/30 R 21 108 Y XL RSC	33/230	- 39/270	38/260	- 45/310
More details on the permissible load a	nd weights ref	er to nage 202		

Tire inflation pressures X5 xDrive35i/X5 xDrive35d with three rows of seats

Tire size	Pressure specifications in psi/kPa			
	Traveling speeds of up to 100 mph/160 km/h			eeds including ling 100 mph/
All pressure specifications in the table are indicated in psi/kilopascal with cold tires.	*****		* * * * * * * * * * / D	
Cold = ambient temperature	¥	¥	*	¥
Without Sport Package:				
255/55 R 18 109 H M+S XL RSC	33/230	41/280	38/260	45/310
255/50 R 19 107 H M+S XL RSC	36/250	44/300	41/280	48/330
Front: 255/50 R 19 107 V XL RSC Rear: 285/45 R 19 111 V XL RSC	32/220	- 38/260	35/240	- 42/290
Front: 275/40 R 20 106 W XL RSC	33/230	-	35/240	42/290
Rear: 315/35 R 20 110 W XL RSC	-	39/270	-	42/290
Front: 285/35 R 21 105 W XL RSC	35/240	-	38/260	-
Rear: 325/30 R 21 108 W XL RSC	-	42/290	-	45/310
With Sport Package:				
255/55 R 18 109 H M+S XL RSC	33/230	41/280	38/260	45/310
255/50 R 19 107 H M+S XL RSC	36/250	44/300	41/280	48/330
Front: 255/50 R 19 107 V XL RSC	32/220	-	41/280	-
Rear: 285/45 R 19 111 V XL RSC	-	38/260	-	48/330
Front: 275/40 R 20 106 W XL RSC	33/230	-	41/280	-
Rear: 315/35 R 20 110 W XL RSC	-	39/270	-	48/330
Front: 285/35 R 21 105 W XL RSC	35/240	-	42/290	-
Rear: 325/30 R 21 108 W XL RSC	-	42/290	-	49/340
More details on the permissible load and weights, refer to page 292.				

Tire inflation pressures X5 xDrive50i with three rows of seats

Tire size	Pressure specifications in psi/kPa				
	Traveling speeds of up to 100 mph/160 km/h		Traveling speeds including those exceeding 100 mph 160 km/h		
All pressure specifications in the table are indicated in psi/kilopascal with cold tires.	* * * * * * * * * * * * * * * * * * * *		* * * * * * *	+ † /©	
Cold = ambient temperature	•	•	•	•	
Without Sport Package:					
255/55 R 18 109 H M+S XL RSC	33/230	41/280	38/260	45/310	
255/50 R 19 107 H M+S XL RSC	36/250	44/300	41/280	48/330	
Front: 255/50 R 19 107 W XL RSC	32/220	-	35/240	-	
Rear: 285/45 R 19 111 W XL RSC	-	38/260	-	42/290	
Front: 275/40 R 20 106 W XL RSC	33/230	-	35/240	-	
Rear: 315/35 R 20 110 W XL RSC	-	39/270	-	42/290	
Front: 285/35 R 21 105 Y XL RSC	35/240	-	38/260	-	
Rear: 325/30 R 21 108 Y XL RSC	-	42/290	-	45/310	
With Sport Package:					
255/55 R 18 109 H M+S XL RSC	33/230	41/280	38/260	45/310	
255/50 R 19 107 H M+S XL RSC	36/250	44/300	41/280	48/330	
Front: 255/50 R 19 107 W XL RSC	32/220	-	41/280	-	
Rear: 285/45 R 19 111 W XL RSC	-	38/260	-	48/330	
Front: 275/40 R 20 106 W XL RSC	33/230	-	42/290	-	
Rear: 315/35 R 20 110 W XL RSC	-	39/270	-	49/340	
Front: 285/35 R 21 105 Y XL RSC	35/240	-	41/280	-	
Rear: 325/30 R 21 108 Y XL RSC	-	42/290	-	46/320	
More details on the permissible load and weights, refer to page 292.					

Tire inflation pressure X6 xDrive35i

Tire size	Pressure specifications in psi/kPa			
	Traveling speeds of up to 100 mph/160 km/h		Traveling speeds including those exceeding 100 mph/ 160 km/h	
All pressure specifications in the table are indicated in psi/kilopascal with cold tires. Cold = ambient temperature	* * * * + •	**/©	* * * * * +	**/©
255/50 R 19 107 H M+S XL RSC 255/50 R 19 107 V M+S XL RSC	32/220	35/240	36/250	44/300
Front: 255/50 R 19 107 V XL RSC Rear: 285/45 R 19 111 V XL RSC	32/220 -	- 32/220	36/250 -	- 38/260
Front: 275/40 R 20 106 W XL RSC Rear: 315/35 R 20 110 W XL RSC	32/220	- 32/220	36/250 -	- 36/250
Front: 285/35 R 21 105 W XL RSC Rear: 325/30 R 21 108 W XL RSC	32/220	- 33/230	38/260 -	- 39/270
Compact wheel* T 155/90 D 18 113 M T 155/80 R 19 114 M	60/420	60/420	60/420	60/420
More details on the permissible load and weights, refer to page 292.				

Tire inflation pressures for X6 xDrive50i

Tire size	Pressure specifications in psi/kPa				
	Traveling speeds of up to 100 mph/160 km/h		Traveling speeds inclu those exceeding 100 n 160 km/h		
All pressure specifications in the table are indicated in psi/kilopascal with cold tires. Cold = ambient temperature	* * * * * * * * * * * * * * * * * * *		∦ † ∦ † + †	\ *\\\D\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	
255/50 R 19 107 H M+S XL RSC 255/50 R 19 107 V M+S XL RSC	33/230	36/250	41/280	44/300	
Front: 255/50 R 19 107 W XL RSC Rear: 285/45 R 19 111 W XL RSC	36/250 -	- 36/250	42/290 -	- 42/290	

Tire size	Pressure spe	- 44/300 - 44/300 - 44/300 - 45/310 - 45/310		
Front: 275/40 R 20 106 W XL RSC Rear: 315/35 R 20 110 W XL RSC	36/250 -	- 36/250	44/300 -	- 44/300
Front: 285/35 R 21 105 W XL RSC Rear: 325/30 R 21 108 W XL RSC	36/250 -	- 36/250	45/310 -	
Compact wheel* T 155/90 D 18 113 M T 155/80 R 19 114 M	60/420	60/420	60/420	60/420

More details on the permissible load and weights, refer to page 292.

Tire identification marks

Knowledge of the labeling on the side of the tire makes it easier to identify and choose the right tires.

Tire size

Example: 255/55 R 19 107 V 255: nominal width in mm

55: aspect ratio in %

R: radial tire code

19: rim diameter in inches

107: load rating, not for ZR tires

V: speed rating, before the R on ZR tires

Speed letter

Q = up to 100 mph/160 km/h

T = up to 118 mph/190 km/h

H = up to 131 mph/210 km/h

V = up to 150 mph/240 km/h

W = up to 167 mph/270 km/h

Y = up to 186 mph/300 km/h

Tire Identification Number

Tires with DOT codes meet the guidelines of the U.S. Department of Transportation.

DOT code:

DOT xxxx xxx 3410

xxxx: manufacturer code for the tire brand

xxx: tire size and tire design

3410: tire age

Tire age

The tire manufacturing date is contained in the tire identification mark: DOT ... 3410 means that the tire was manufactured in the week 34 of 2010.

BMW recommends that you replace all tires after 6 years at most, even if some tires may last for 10 years.

Uniform Tire Quality Grading

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width. For example:

Treadwear 200 Traction AA

Temperature A

DOT Quality Grades

Treadwear

Traction AA ABC

Temperature A B C

Conform to Federal Safety Requirements
All passenger car tires must conform to

Federal Safety Requirements in addition to these grades. ◀

Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified gov-

eference

ernment test course. For example, a tire graded 150 would wear one and one-half (11/2) times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

Traction

The traction grades, from highest to lowest, are AA, A, B, and C.

Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

Temperature

The temperature grades are A, the highest, B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

Temperature grade for this tire
The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

RSC – Run-flat tires

The symbol identifying run-flat tires is a circle with the letters RSC on the sidewall, refer to page 261.

M+S

Winter and all-season tires.

These have better winter properties than summer tires.

XL

Designation for specially reinforced tires.

Tire tread

Summer tires

Do not drive with a tire tread depth of less than 0.12 in/3 mm.

There is an increased danger of hydroplaning if the tread depth is less than 0.12 in/3 mm.

Winter tires

Do not drive with a tire tread depth of less than 0.16 in/4 mm.

Below a tread depth of 0.16 in/4 mm, tires are less suitable for winter operation.

Minimum tread depth



Wear indicators are distributed around the tire's circumference and have the legally required minimum height of 0.063 in/1.6 mm.

They are marked on the side of the tire with TWI, Tread Wear Indicator.

Wheel/tire damage

Due to low-profile tires, please note that wheels, tires and suspension parts are more susceptible to road hazard and consequential damages.

Inspect your tires often for damage, foreign objects lodged in the tread, and tread wear.

Indications of tire damage or other vehicle defects:

- Unusual vibrations during driving.
- Unusual handling such as a strong tendency to pull to the left or right.

In case of tire damage
If there are indications of tire damage, reduce your speed immediately and have the wheels and tires checked right away; otherwise, there is the increased risk of an accident.

Drive carefully to the next service center or tire shop.

If necessary, have the vehicle towed. ◀

Repair of tire damage
For safety reasons, the manufacturer of
your vehicle recommends that you do not have
damaged tires repaired; they should be replaced. Otherwise, damage can occur as a result.

Changing wheels and tires

Mounting

Information on mounting tires
Have mounting and balancing performed only by a service center or tire specialist.

If this work is not carried out properly, there is the danger of subsequent damage and related safety hazards.◀

Wheel and tire combination

Information on the right wheel and tire combination and rim version for your vehicle can be obtained from the service center.

Incorrect wheel and tire combinations impair the function of a variety of systems such as ABS or DSC.

To maintain good handling and vehicle response, use only tires with a single tread configuration from a single manufacturer.

Following tire damage, have the original wheel and tire combination remounted on the vehicle as soon as possible.

Approved wheels and tires

The manufacturer of your vehicle recommends that you use only wheels and tires that have been approved for your particular vehicle model.

For example, despite having the same official size ratings, variations can lead to body contact and with it, the risk of severe accidents.

The manufacturer of your vehicle cannot evaluate non-approved wheels and tires to determine if they are suited for use, and therefore cannot ensure the operating safety of the vehicle if they are mounted.◀

Wheels with electronics for TPM Tire Pressure Monitor

When mounting new tires or changing from summer to winter tires or vice versa, only use wheels with TPM electronics; otherwise, the Tire Pressure Monitor will not be able to detect a flat tire, refer to page 90. Your service center will be glad to advise you.

Recommended tire brands



For each tire size, the manufacturer of your vehicle recommends certain tire brands. These can be identified by a star on the tire sidewall.

With proper use, these tires meet the highest standards for safety and handling.

Retreaded tires

The manufacturer of your vehicle does not recommend the use of retreaded tires.

Retreaded tires

Possibly substantial variations in the design and age of the tire casing structures can limit service life and have a negative impact on road safety. ◀

Winter tires

The manufacturer of your vehicle recommends winter tires for winter roads or at temperatures below +45 °F/+7 °C.

Although so-called all-season M+S tires do provide better winter traction than summer tires. they do not provide the same level of performance as winter tires.

Maximum speed of winter tires

If the maximum speed of the vehicle is higher than the permissible speed for the winter tires. then display a corresponding sign in the field of vision. You can obtain this sign from the tire specialist or from your service center.

Maximum speed for winter tires Do not exceed the maximum speed for the winter tires; otherwise, tire damage and acci-

Run-flat tires

For your own safety, only use run-flat tires. Your service center will be glad to advise you.

Rotating wheels between axles

The manufacturer of your vehicle advises against swapping wheels between the front and rear axles.

This can impair the handling characteristics.

Rotating the tires is not permissible when using different types of tires*.

Storage

Store wheels and tires in a cool, dry place with as little exposure to light as possible.

Always protect tires against all contact with oil, grease and fuels.

Do not exceed the maximum tire inflation pressure indicated on the side wall of the tire.

Run-flat tires

Label



RSC label on the tire sidewall.

The wheels are composed of special rims and tires that are self-supporting, to a limited degree.

The support of the sidewall allows the tire to remain drivable to a restricted degree in the event of a pressure loss.

Driving with a damaged tire:

- ▶ Flat Tire Monitor FTM*, refer to page 88
- Tire Pressure Monitor TPM*, refer to page 90

Snow chains*

Only certain fine-link snow chains have been tested by BMW, classified as safe for use and recommended. Consult your service center for more information.

BMW X5: use only in pairs on the rear wheels, equipped with tires of the following size:

- 255/55 R 18
- 255/50 R 19

BMW X6: use only in pairs on rear wheels of size 255/50 R 19.

Observe the manufacturer's instructions when mounting snow chains. Do not exceed a speed of 30 mph/50 km/h when using snow chains.


Do not initialize the Flat Tire Monitor if snow chains are mounted; otherwise, the instrument might issue an incorrect reading.

When driving with snow chains, it can be beneficial to temporarily activate DTC, refer to page 97.

Engine compartment

Important features in the engine compartment


BMW X5



- Filler neck for washer fluid for the headlamp and window washer system 67
- 2 Starting aid terminal 281

- Coolant expansion tank 267
- 4 Engine oil filler neck 266

BMW X6



- Filler neck for the washer fluid for the headlamp and window washer system 68
- Engine oil filler neck 266

- Starting aid terminal 281
- Coolant expansion tank 267

Hood

Opening the hood

Working in the engine compartment Never attempt to perform any service or repair operations on your vehicle without the necessary professional technical training.

If you are unfamiliar with the statutory guidelines, have any work on the vehicle performed only by a service center.

If this work is not carried out properly, there is the danger of subsequent damage and related safety hazards.◀

1. Pull the lever.



2. Press the release handle and open the hood.



Closing the hood



Drop the hood from a height of approx. 16 in/ 40 cm. It must be clearly heard to engage.

Hood open when driving If you see any signs that the hood is not completely closed while driving, pull over immediately and close it securely.

Danger of pinching Make sure that the closing path of the hood is clear; otherwise, injuries may result. ◀

Engine oil

Checking the engine oil level

Your car is equipped with an electronic engine oil level check.

Requirements

- ▶ The engine must be running and warm after the vehicle has been driven for at least 6.2 miles/10 km.
- The vehicle is stopped or being driven on a level roadway.

Displaying the oil level

1. "Vehicle Info"

"Vehicle status"



"Engine oil level"

Possible messages

- "Engine oil level OK"
- "Measurement not possible at this time."
 - "Measuring engine oil level..."

Duration with the engine running: approx. 3 minutes.

Duration while driving: approx. 5 minutes. If engine oil was added, it may take up to 30 minutes to obtain an oil level reading.

"Engine oil level below minimum. Add 1 quart!"

Add a maximum quantity of 1 US quart/1 liter of engine oil at the next opportunity, refer also to Adding engine oil below.

"Engine oil level too high! Have this checked."


Too much engine oil Have the vehicle checked immediately; otherwise, surplus oil can lead to engine damage. ◄

"Measurement inactive. Have this checked."Do not add engine oil. It is possible to continue driving. Note the newly calculated remaining mileage until the next oil service, refer to page 75. Have the system checked as soon as possible.


Adding engine oil

Filler neck

BMW X5



BMW X6



Add a maximum quantity of 1 US quart/1 liter of oil only after the corresponding message appears on the Control Display.

Add oil promptly

Add oil within the next 125 miles/200 km;
otherwise, engine damage could result.

✓

Keep oil, grease, etc., out of reach of children and heed the warnings on the containers to prevent health risks.◀

Oil types for refilling

Protect children

Notes

No oil additives

Do not use oil additives as these may cause engine damage. ◀

Viscosity classes of engine oils

When selecting an engine oil, ensure that the engine oil belongs to one of the viscosity classes SAE 0W-40, SAE 0W-30, SAE 5W-40, or SAE 5W-30, or malfunctions or engine damage may occur. ◀

The engine oil quality is critical for the life of the engine.

Due to national regulations, some oil types are not available in every country.

Approved oil types

Gasoline engine

BMW High Performance SAE 5W-30

BMW Longlife-01

BMW Longlife-01 FE

Diesel engine

BMW Longlife-04

Further information on approved oil types can be obtained from the service center.

Alternative oil types

If the approved engine oils are not available, up to 1 US quart/liter of an oil with the following specification can be used:

Gasoline engine

API SM or higher

Diesel engine

API ILSAC GF-5

Oil change

An oil change should be carried out by the service center only.

BMW recommends (acastrol)



Disposal

Comply with the appropriate environmental protection regulations when disposing of coolant additives.

Coolant

General information

Danger of burns from hot engine Do not open the cooling system while the engine is hot; otherwise, escaping coolant may cause burns.◀

Suitable additives Only use suitable additives; otherwise, engine damage may occur. The additives are harmful to your health. ◄

Coolant consists of water and additives.

Not all commercially available additives are suitable for your vehicle. Ask your service center for suitable additives.

Checking the coolant level

- 1. Do not open the hood until the engine has cooled down.
- 2. Turn the expansion tank cap counterclockwise slightly to allow any accumulated pressure to escape; then continue turning to open.
- 3. The coolant level is correct if it is between the maximum and minimum marks in the filler neck, refer also to the diagram next to the filler neck.
- 4. If the coolant is low, slowly add coolant up to the specified level; do not overfill.
- 5. Turn the cap until there is an audible click.
- 6. Have the cause of the coolant loss eliminated as soon as possible.

Maintenance

BMW maintenance system



The maintenance system provides information on required maintenance measures and thus provides support in maintaining road safety and the operational reliability of the vehicle.

Setting the correct date

Make sure the date is set correctly, refer
to page 79; otherwise, the effectiveness of CBS
Condition Based Service is not ensured.

Storage periods

Storage periods during which the vehicle battery was disconnected are not taken into account.

If this occurs, have a service center update the time-dependent maintenance procedures, such as checking brake fluid and, if necessary, changing the engine oil and the microfilter/activated-charcoal filter.

Condition Based Service CBS

Sensors and special algorithms take into account the driving conditions of your vehicle. Based on this, Condition Based Service determines the maintenance requirements.

The system makes it possible to adapt the amount of maintenance you need to your user profile.

Details on the service requirements, refer to page 75, can be displayed on the Control Display.

On the Control Display, the remaining distances and times for selected maintenance requirements and any legally required deadlines can be displayed individually, refer to page 75.

Service data in the remote control

Information on the required maintenance is continuously stored in the remote control. Your service center will read out this data and suggest the right array of service procedures for your vehicle.

Therefore, hand your service specialist the remote control that you used most recently.


Service and Warranty Information Booklet for US models and Warranty and Service Guide Booklet for Canadian models

Please consult your Service and Warranty Information Booklet for US models and Warranty and Service Guide Booklet for Canadian models for additional information on service requirements.

Maintenance and repair should be performed by your service center. Make sure to have regular maintenance procedures recorded in the vehicle's Service and Warranty Information Booklet for US models, and in the Warranty and Service Guide Booklet for Canadian models. These entries are proof of regular maintenance.

eference

Socket for OBD Onboard Diagnosis



On the driver's side is an OBD socket for checking the primary components in the vehicle emissions.

with suitable devices, particularly when the vehicle is serviced. The data obtained in this way provide valuable information for service processes and repair or for optimizing and developing vehicle functions further. In addition, if you signed a service contract for Assist, certain vehicle data can be sent directly from the vehicle to facilitate the desired services.

stored in the remote control and can be read out

Emissions



- The warning lamp lights up: Emissions are deteriorating. Have the vehicle checked as soon as possible.
- The warning lamp flashes under certain circumstances:

This indicates that there is excessive misfiring in the engine.

Reduce the vehicle speed and have the system checked immediately; otherwise, serious engine misfiring within a brief period can seriously damage emission control components, in particular the catalytic converter.



Display of the previously described malfunctions on Canadian models.

Fuel cap



The indicator lamp lights up.

If the fuel cap is not properly tightened, the OBD system may conclude that


fuel vapor is escaping. If the cap is then tightened, the display should go out in a short time.

Data memory

Your vehicle records data relating to vehicle operation, faults and user settings. These data are

Replacing components

Tool kit



The tool kit is stowed under the cargo floor panel in the cargo area.


Wiper blade replacement



Do not fold down the wipers without wiper blades

Do not fold down the wipers if wiper blades have not been installed; this may damage the windshield.◀

Front



- 1. Fold up the wiper arm.
- 2. Fold the wiper blade upwards.
- Remove the wiper blade toward the windshield, refer to arrow.

BMW X5: rear



- Lift off the wiper arm completely and pull off the wiper blade, refer to arrow.
- Mount the new wiper blade and press on until it is heard to engage.

Lamp and bulb replacement

General information

Lamps and bulbs make an essential contribution to vehicle safety.

The manufacturer of your vehicle recommends that you entrust corresponding procedures to your service center if you are unfamiliar with them or they are not described here.

You can obtain a selection of replacement bulbs at your service center.

Danger of burns

Only change bulbs when they are cool; otherwise, there is the danger of getting burned. ◄

Working on the lighting system
When working on the lighting system, you should always switch off the lights affected to prevent short circuits.

To avoid possible injury or equipment damage when replacing bulbs, observe any instructions provided by the bulb manufacturer. ◀

Do not touch the bulbs

Do not touch the glass of new bulbs with your bare hands, as even minute amounts of contamination will burn into the bulb's surface. and reduce its service life.

Use a clean tissue, cloth or something similar, or hold the bulb by its base. ◄

Light-emitting diodes LED

Light-emitting diodes installed behind translucent lenses serve as the light source for many of the controls, displays and other equipment in vour vehicle.

These light-emitting diodes, which operate using a concept similar to that applied in conventional lasers, are officially designated as Class 1 light-emitting diodes.

Do not remove the covers

Do not remove the covers, and never stare into the unfiltered light for several hours; otherwise, irritation of the retina could result. ◀

Headlamp glass

Condensation can form on the inside of the external lamps in cool or humid weather. When the light is switched on, the condensation evaporates after a short time. The headlamp glasses do not need to be changed.

If there is a large amount of moisture, e.g., water droplets form in the lamp, have the lamp checked by your service center.

BMW X5: bulb replacement

Xenon headlamps

Because of the long life of these bulbs, the likelihood of failure is very low. Switching the lamps on and off frequently shortens their life.

If a bulb fails, switch on the front fog lamps* and continue the trip with great care. Comply with local regulations.



Do not perform work/bulb replacement on xenon headlamps

Have any work on the xenon lighting system, including bulb replacement, performed only by a service center.

Due to the high voltage present in the system, there is the danger of fatal injuries if work is carried out improperly. ◀


Parking lamps, roadside parking lamps, daytime running lights*

These lamps are made using LED technology. Contact your service center in the event of a malfunction.

Turn signals, front

24-watt bulb, PY24W

1. Rotate bulb holder to the left and remove it along with the bulb.



Rotate the bulb to the right along with the socket and replace.

Install in the reverse order.

Side marker lamps, rear

Contact the service center for bulb replacement.

Tail lamps

- Turn signal, brake lamp: 21-watt bulb, P21W.
- Brake force display: 21-watt bulb, P21W.
- Backup lamp: 16-watt bulb, W16W
 - Tail lamp: LED technology. Contact your service center in the event of a malfunction.

Arrangement of tail lamps




- 1 Tail lamp
- 2 Brake force display
- 3 Brake lamp
- 4 Tail lamp/side marker lamp
- 5 Backup lamp
- 5 Turn signal

Turn signals, brake lamps and backup lamps

The bulbs are integrated in a single bulb holder.

- 1. Open the side panel in the cargo area.
- 2. Remove the first aid kit* and warning triangle* if necessary. Fold up the insulation.



- 3. Press the button, arrow 1, down, press the catches, arrows 2, outward slightly, and remove the bulb holder.
- Apply gentle pressure to the P21W bulb while turning it to the left for removal and replacement.
 - Remove the W16W bulb and replace.
- 5. Re-engage the bulb holder so that it audibly clicks into place.
- 6. Remount the side panel.

Brake Force Display

 Carefully remove the cover in the tailgate panel with a screwdriver.



2. Push the catch on the bulb holder to the left, arrow, and remove it.



- Apply gentle pressure to the bulb while turning it to the left for removal and replacement.
- Re-engage the bulb holder so that it audibly clicks into place.
- 5. Before installing the cap, unclip the cargo area lamp.

Then lay the cap on its upper side and close it, refer to arrow.



Position the cargo area lamp and clip it in, refer to arrow.



License plate lamps

These lamps are made using LED technology. Contact your service center in the event of a malfunction.

Center brake lamp

This lamp uses LED technology for operation. Contact your service center in the event of a malfunction.

BMW X6: bulb replacement

Xenon headlamps

Because of the long life of these bulbs, the likelihood of failure is very low. Switching the lamps on and off frequently shortens their life.

If a bulb fails, switch on the front fog lamps* and continue the trip with great care. Comply with local regulations.



Do not perform work/bulb replacement on xenon headlamps

Have any work on the xenon lighting system, including bulb replacement, performed only by a service center.

Due to the high voltage present in the system, there is the danger of fatal injuries if work is carried out improperly. ◄


Parking lamps, roadside parking lamps, daytime running lights*

35-watt bulb, H8

Wear protective goggles and gloves
Halogen bulbs are pressurized. Therefore,
wear protective goggles and gloves. Otherwise,
there is a danger of injuries if the bulb is accidentally damaged during replacement.


✓

1. Turn the cover to the left and remove.



Left side of vehicle: rotate the bulb holder to the right, see arrow, and remove.

Right side of vehicle: rotate the bulb holder to the left and remove.




- 3. Disconnect plug and replace bulb.
- Install in the reverse order.

Side marker lamps

5-watt bulb, WY5W XLL

Rotate the bulb holder to the left and remove.



- Pull the bulb out of the bulb holder and replace.
- Install in the reverse order.

Turn signals, front

24-watt bulb, PY24W

1. Rotate bulb holder to the left and remove it along with the bulb.



- 2. Rotate the bulb to the right along with the socket and replace.
- Install in the reverse order.

Tail lamps

- ▶ Turn signal, backup lamp: 21-watt bulb, H21W.
- Brake lamp, brake force display: 21-watt bulb, P21W
- Tail lamp: LED technology.
 Contact your service center in the event of a malfunction.


Arrangement of tail lamps



- 1 Brake force display/rear lamps
- 2 Brake lamp/rear lamp
- 3 Backup lamp
- 4 Turn signal

Brake lamps

- 1. Open the side panel in the cargo area.
- Remove the first aid kit* and warning triangle* if necessary.
- Rotate the relevant bulb socket to the left and remove.



 Apply gentle pressure to the bulb while turning it to the left for removal and replacement.


5. Install in the reverse order.

Turn signal

- 1. Open the side panel in the cargo area.
- Remove the first aid kit* and warning triangle* if necessary.

Mobility


3. Remove bulb holder along with bulb and re-



Install in the reverse order.

Backup lamp


- 1. Open the side panel in the cargo area.
- 2. Remove the first aid kit* and warning triangle* if necessary.
- 3. Remove bulb holder along with bulb and replace.




Install in the reverse order.

Brake force display

1. Carefully remove the cover in the tailgate panel with a screwdriver.



Rotate the bulb socket to the left and remove.



- 3. Apply gentle pressure to the bulb while turning it to the left for removal and replacement.
- 4. Insert the bulb socket in the tailgate and engage it.
- Replace the cover.

License plate lamps

These lamps are made using LED technology. Contact your service center in the event of a malfunction.

Center brake lamp

This lamp uses LED technology for operation. Contact your service center in the event of a malfunction.

Changing wheels

Notes

Your vehicle is equipped with run-flat tires, refer to page 261, as standard equipment.


They do not need to be replaced immediately in the event of a puncture.

When mounting new tires or changing from summer to winter tires or vice versa, use run-flat tires for your own safety.

BMW X6: do not rotate the front wheels to the rear or vice versa, as otherwise the handling characteristics will be negatively affected.

The tools for changing wheels are available as accessories from your service center.

Jacking points for the vehicle jack



The jacking points for the vehicle jack are located in the positions shown.

Compact wheel*



Safety precautions in the event of a flat tire or wheel change

Park the vehicle as far as possible from passing traffic and on solid ground. Switch on the hazard warning system.

Set the parking brake and engage transmission position P.

Have all vehicle occupants get out of the vehicle and ensure that they remain outside the immediate area in a safe place, such as behind a guardrail.

If a warning triangle or portable hazard warning lamp* is required, set it up on the roadside at an appropriate distance from the rear of the vehicle. Comply with all safety guidelines and regulations.

Change the wheel only on a level, firm surface which is not slippery. The vehicle or the jack could slip to the side if you attempt to raise the vehicle on a soft or slippery surface such as snow, ice, tiles, etc.

Position the jack on a firm support surface.

Do not use a wooden block or similar object as a support base for the jack, as this would prevent it from extending to its full support height and reduce its load-carrying capacity.

To avoid serious or fatal injury: never lie under the vehicle, and never start the engine while it is supported by the jack.◀

What you will need

To avoid rattling noises later on, note the positions of the tools before removing them, then return them to their initial positions after completing work.

The tools are located in the mount under the floor panel flap.




- 1 Vehicle jack*
- 2 Vehicle jack crank*
- 3 Lug bolts wrench*

Removing compact wheel

The compact wheel is located in the cargo area under the floor panel.





- Remove the tool mount.
- 2. Release the wing nut 1.
- 3. Remove the washer 2 laterally.
- 4. Remove the compact wheel.

Preparing wheel change

- 1. Observe the safety precautions above.
- 2. Loosen the lug bolts a half turn.


Jacking up vehicle

1. Position the vehicle jack at the jacking point closest to the wheel so that the entire surface of the jack base rests on the ground perpendicularly beneath the jacking point.



The vehicle jack is designed for changing wheels only.

The vehicle jack is designed for changing wheels only. Do not attempt to raise another vehicle model with it or to raise any load of any kind. To do so could cause accidents and personal injury.◀



Guide the jack head into the rectangular recess of the jacking point when cranking up, refer to illustration detail.



3. Jack the vehicle up until the wheel you are changing is raised from the ground.

Mounting a wheel

- 1. Unscrew the lug bolts and remove the wheel.
- 2. Remove accumulations of mud or dirt from the mounting surfaces of the wheel and hub. Also clean the lug bolts.
- Position the new wheel or compact wheel. Secure the wheel by screwing at least two lug bolts into opposite bolt holes.
 - When you mount wheels other than Genuine BMW light-alloy wheels, different lug bolts may also be required.
- 4. Screw in the remaining lug bolts. Tighten all the bolts securely in a diagonal pattern.
- 5. Lower the vehicle and remove the jack from beneath the vehicle.

After mounting

1. Tighten the lug bolts in a diagonal pattern.

Checking that the lug bolts are tight To ensure safety, always have the lug bolts checked with a calibrated torque wrench as soon as possible to ensure that they are tightened to the specified torque. Otherwise, incorrectly tightened lug bolts are a hidden safety risk. The tightening torque equals 101 lb ft/140 Nm. ◄

2. Stow the defective wheel in the cargo area.

- The defective wheel cannot be stored under the floor panel flap due to its size.
- 3. Check and correct the tire inflation pressure at the earliest opportunity.
- 4. Initialize the Flat Tire Monitor, refer to page 88, or reset the Tire Pressure Monitor, refer to page 90.
- 5. Replace the damaged tire as soon as possible and have the new wheel/tire balanced.

Driving with compact wheel



Do not exceed a speed of 50 mph/80 km/

Drive conservatively and do not exceed a speed of 50 mph/80 km/h. Otherwise, changes in the driving characteristics could result, for example reduced track stability on braking, extended braking distance, and altered self-steering characteristics in the limit range. In conjunction with winter tires, these characteristics are more pronounced.◀

Only mount one compact wheel Only one compact wheel may be mounted. Restore the wheels and tires to their original size as quickly as possible. Failure to do so is a safety risk.◀

Vehicle battery

Maintenance

The battery is maintenance-free, i.e., the electrolyte will last for the life of the battery.

Your service center will be glad to advise you on questions regarding the battery.

Battery replacement

Use approved vehicle batteries Only use vehicle batteries that have been approved for your vehicle by the manufacturer; otherwise, the vehicle could be damaged and systems or functions may not be fully available.◀

After a battery replacement, have the battery registered on the vehicle by your service center to ensure that all comfort functions are fully available.

Charging the battery

In the vehicle, only charge the battery via the terminals in the engine compartment, refer to page 281, with the engine switched off.

Power failure

After a temporary power loss, some equipment needs to be reinitialized.

Individual settings need to be reprogrammed:

- Seat and mirror memory: store the positions again, refer to page 53.
- Time: update, refer to page 78.
- Date: update, refer to page 79.
- Radio station: save again, refer to page 174.
- Navigation system: wait for the navigation system to be operational.
- Glass sunroof/panoramic glass sunroof: it may only be possible to raise the roof. Have the system initialized by the service center.
- Digital compass: recalibrate, refer to page 129.
- Active steering: the system automatically initializes for a short time as you drive. During this time, the system is deactivated, refer to page 101.
- xDrive: the system automatically initializes as you drive. During this time, indicator lamps light up. If the lamps do not disappear during the current trip, have the system checked.

Disposing of old batteries



Have old batteries disposed of by your service center or bring them to a recyclina center.

Maintain the battery in an upright position for transport and storage. Secure the battery so that it does not tip over during transport.

Fuses

Replacing fuses

Never attempt to repair a blown fuse and do not replace a defective fuse with a substitute of another color or amperage rating; this could lead to a circuit overload, ultimately resulting in a fire in the vehicle.


In interior

The fuses are located in the front passenger footwell on the underside of the instrument cluster.

 Unscrew screws, refer to arrows, of footwell trim panel.




- 2. Lay the trim panel in the footwell.
- 3. Release the screw, arrow 1, and fold the fuse carrier down, arrow 2.



- 4. Replace the fuse concerned.
- Installation is carried out in the reverse order of removal. Ensure correct and secure attachment of the footwell trim panel in the process.

In cargo area



Open the right-hand side panel in the cargo area.

Breakdown assistance

Hazard warning flashers



The button for the hazard warning system is located on the center console.

Emergency Request*

Requirements

- ▶ Equipment version with full preparation package mobile phone.
 - An Emergency Request can be made, even if no mobile phones are paired with the vehicle.
- BMW Assist is activated.
- Radio readiness is switched on.
- The BMW Assist system is logged in to a wireless communications network supported by BMW Assist.
- ▶ The Assist system is operable.

Only press the SOS button in an emergency.

Emergency Request not guaranteed For technical reasons, the Emergency Request cannot be guaranteed under unfavorable conditions.

Service contract

After your contract with BMW Assist has expired, the BMW Assist system can be deactivated by the service center without you having to visit a workshop.

- After deactivation, an Emergency Request is no longer possible.
- Under certain circumstances, the system can be reactivated by a service center after you sign a new contract.

Initiating an Emergency Request

1. Press the cover briefly to open it.



- Press the SOS button until the LED in the button lights up.
- The LED lights up: an Emergency Request was initiated.
 - If the circumstances allow this, remain in the vehicle until the connection has been established.
- The LED flashes if the connection to the BMW Assist Response Center has been established.

Once the BMW Assist Response Center has received your Emergency Request, the BMW Assist Response Center contacts you and takes further steps to help you.

Even if you are unable to respond, the BMW Assist Response Center can take further steps to help you under certain circumstances.

For this purpose, data that are used to determine the necessary rescue measures, such as the current position of the vehicle if it can be established, are transmitted to the BMW Assist Response Center.

If the LED is flashing but the BMW Assist Response Center cannot be heard on the hands-free system, the hands-free system may be malfunctioning. However, the BMW Assist Response Center may still be able to hear you.

Initiating an Emergency Request automatically

Under certain conditions, an Emergency Request is automatically initiated immediately after a severe accident. Automatic Collision Notification is not affected by pressing the SOS button.

Roadside Assistance*

Service availability

Roadside Assistance can be reached around the clock in many countries. You can obtain assistance there in the event of a vehicle breakdown.

Roadside Assistance

The Roadside Assistance, refer to page 238 phone number can be viewed on the iDrive or a connection to Roadside Assistance* can be established directly.

Warning triangle*

The warning triangle is located in the cargo area.

First aid kit*

The first aid kit is located in a storage compartment on the right side in the cargo area.

Some of the articles contained in the first aid pouch have a limited service life.

Check the expiration dates of the contents regularly and replace any items promptly.

Jump-starting

Notes

If the battery is discharged, an engine can be started using the battery of another vehicle and two jumper cables*. Only use jumper cables with fully insulated clamp handles.

To prevent personal injury or damage to both vehicles, adhere strictly to the following procedure.

Do not touch live parts

To avoid the risk of potentially fatal injury, always avoid all contact with electrical components while the engine is running.◀

Preparation


- 1. Check whether the battery of the other vehicle has a voltage of 12 volts and approximately the same capacitance in Ah. This information can be found on the battery.
- Switch off the engine of the assisting vehicle.
- 3. Switch off any electronic systems/power consumers in both vehicles.

Bodywork contact between vehicles There must not be any contact between the bodies of the two vehicles, otherwise there is a danger of shorting.◀


Starting aid terminals

Connecting order

Connect the jumper cables in the correct order; otherwise, there is the danger of injury from sparking.◀



The so-called starting aid terminal in the engine compartment acts as the battery's positive terminal. Fold open the cover. To do so, pull the tab.



The body ground or a special nut acts as the negative terminal.

Connecting jumper cables

- 1. Fold open the cover of the BMW starting-aid terminal. To do so, pull the tab.
- Attach one terminal clamp of the positive jumper cable to the positive terminal of the battery, or to the corresponding starting aid terminal of the vehicle providing assistance.
- Attach the other end of the cable to the positive terminal of the battery, or to the corresponding starting aid terminal of the vehicle to be started.
- Attach one terminal clamp of the negative jumper cable to the negative terminal of the battery, or to the corresponding engine or body ground of the vehicle providing assistance.
- Attach the other end of the cable to the negative terminal of the battery, or to the corresponding engine or body ground of the vehicle to be started.

Starting the engine

Never use spray fluids to start the engine.

- Start the engine of the assisting vehicle and let it run for several minutes at an increased idle speed.
 - If the vehicle being started has a diesel engine: let the engine of the assisting vehicle run for approx. 10 minutes.
- Start the engine of the vehicle being started in the usual way.
 - If the first starting attempt is not successful, wait a few minutes before making another attempt in order to allow the discharged battery to recharge.
- 3. Let both engines run for several minutes.
- Disconnect the jumper cables in the reverse order.

Check the battery and recharge if necessary.

Tow-starting and towing

No additional passengers

Do not transport any passengers other than the driver in a vehicle that is being towed.

✓

Transporting the vehicle

Note


Your vehicle is not permitted to be towed. Therefore, contact a service center in the event of a breakdown.

Do not have the vehicle towed

Have your vehicle transported on a loading
platform only; otherwise, damage may occur.

✓

Tow truck



Do not tow with only the front or rear axle raised

Do not tow the BMW with just the front or rear axle raised; otherwise, the wheels could lock up and the transfer case could be damaged. ◄

Do not lift the vehicle Do not lift the vehicle by the tow fitting or body and chassis parts; otherwise, damage may result.◀

Towing other vehicles

General information

Light towing vehicle Your vehicle must not be lighter than the vehicle being towed; otherwise, it will not be possible to control vehicle response. ◀

Attaching the tow bar/tow rope correctly Attach the tow bar or tow rope to the tow fitting; connecting it to other vehicle parts may cause damage. ◀

- Switch on the hazard warning system, depending on local regulations.
- If the electrical system has failed, clearly identify the vehicle being towed by placing a sign or a warning triangle in the rear window.

Towing methods when towing other vehicles

Tow bar

The tow fittings used should be on the same side on both vehicles.

Should it prove impossible to avoid mounting the tow bar at an offset angle, please observe the following:

- Clearance and maneuvering capability will be sharply limited during cornering.
- ▶ The tow bar will generate lateral forces if it is attached offset.

Tow rope

When starting to tow the vehicle, make sure that the tow rope is taut.

To avoid jerking and the associated stresses on the vehicle components when towing, always use nylon ropes or nylon straps.

Attaching the tow rope correctly Only secure the tow rope on the tow fitting; otherwise, damage can occur when it is secured on other parts of the vehicle. ◀

Tow fitting

The screw-in tow fitting should always be carried in the vehicle. It can be screwed in at the front or rear of the BMW.

It is stored with the tool kit under the cargo floor cover in the cargo area, refer to page 270.



Tow fitting, information on use

- Use only the tow fitting provided with the vehicle and screw it all the way in.
- Use the tow fitting for towing on paved roads only.
- Avoid lateral loading of the tow fitting, e.g., do not lift the vehicle by the tow fitting.

Otherwise, damage to the tow fitting and the vehicle can occur.◀


Screw thread

Left/right cover in the bumper: press on the arrow symbol on the cover.

BMW X5: front



BMW X6: front



Rear



Tow-starting

Note

Do not tow-start your vehicle.

Due to the automatic transmission, the engine cannot be started by tow-starting.

Have the cause of the starting difficulties remedied.

Care

Car washes

Notes

Steam jets or high-pressure washers When using steam jets or high-pressure washers, hold them a sufficient distance away and use a maximum temperature of 140 °F/ 60 °C.

Holding them too close or using excessively high pressures or temperatures can cause damage or preliminary damage that may then lead to long-term damage.

Follow the operating instructions for the highpressure washer.



Cleaning sensors/cameras with highpressure washers

When using high-pressure washers, do not spray the exterior sensors and cameras, for Park Distance Control* or the backup camera*, for instance, for extended periods of time and only from a distance of at least 12 in/30 cm. ◀

Wash your vehicle frequently, particularly in winter.

Intense soiling and road salt can damage the vehicle.

Washing in automatic car washes

Your vehicle can be washed in automatic car washes right from the start.

Give preference to cloth car washes or those that use soft brushes in order to avoid paint damage.

Notes

Note the following:

- Make sure that the wheels and tires are not damaged by the transport mechanisms.
- ▶ Fold in the exterior mirrors; otherwise, they may be damaged, depending on the width of the vehicle.

- Deactivate rain sensor, refer to page 67, to prevent unintentional wiper action.
- ▶ BMW X5: deactivate the rear window wiper and protect it from damage. Ask the car wash operator about any necessary protective measures.
- Remove additional attachments, for instance a spoiler or telephone antenna, if there is a risk that these may be damaged.

Guide rails in car washes Avoid car washes with guide rails higher than 4 in/10 cm; otherwise, the vehicle body could be damaged. ◀

Before driving into a car wash

The vehicle is able to roll if the following steps are taken.

- 1. Insert the remote control into the ignition lock, even with Comfort Access.
- Engage transmission position N.
- 3. Release the parking brake.
- 4. Deactivating Automatic Hold, refer to page **64**.
- Switch the engine off.
- 6. Leave the remote control in the ignition lock so that the vehicle can roll.

Mixed tires*

Note the vehicle width Before driving into a car wash, make sure that the vehicle width is not too large for the car wash, as otherwise the vehicle and the car wash

Headlamps

- Do not rub dry and do not use abrasive or caustic cleansers.
- Soak areas that have been soiled e.g. due to insects, with shampoo and wash off with water.

Thaw ice with de-icing spray; do not use an ice scraper.

After washing the vehicle

After washing the vehicle, apply the brakes briefly to dry them; otherwise, braking action can be reduced and corrosion of the brake discs can occur.

Vehicle care

Car care products

BMW recommends using cleaning and care products from BMW, since these have been tested and approved.



windows.

Car care and cleaning products
Follow the instructions on the container.

When cleaning the interior, open the doors or

Only use products intended for cleaning vehi-

Cleansers can contain substances that are dangerous and harmful to your health. ◄

Vehicle paint

Regular care contributes to driving safety and value retention.

Environmental influences can act on the vehicle paint. Tailor the frequency and extent of your car care to these influences.

Leather care

Remove dust from the leather often, using a cloth or vacuum cleaner.

Otherwise, particles of dust and road grime chafe in pores and folds, and lead to increased wear and premature degradation of the leather surface.

To guard against discoloration, such as from clothing, provide leather care roughly every two months.

Clean light-colored leather more frequently as dust and dirt are more noticeable.

Use leather care products; otherwise, dirt and grease will gradually break down the protective layer of the leather surface.

Suitable care products are available from the service center.

Upholstery material care

Vacuum regularly with a vacuum cleaner.

If they are very dirty, e.g., beverage stains, use a soft sponge or microfiber cloth with a suitable interior cleaner.

Clean the upholstery down to the seams using large sweeping motions. Avoid rubbing the material vigorously.

A

Damage from Velcro® fasteners

Open Velcro® fasteners on pants or other articles of clothing can damage the seat covers. Ensure that any Velcro® fasteners are closed.

Caring for special components

Light-alloy wheels

Use wheel cleaner, particularly during the winter months. Do not use aggressive, acidic, strongly alkaline or abrasive cleaners, or steam jets above 140 $^{\circ}$ F/60 $^{\circ}$ C; follow the manufacturer's instructions.

Chrome surfaces*

Carefully clean components such as the radiator grille or door handles with an ample supply of water, possibly with shampoo added, particularly when they have been exposed to road salt.

Aluminum running boards*

A rust film on the aluminum running boards can be removed with a special cleaning agent.

Rubber components

Aside from water, treat only with rubber cleansers.

When cleaning rubber seals, do not use any silicon-containing car care products in order to avoid damage or reduced noise damping.

Fine wood parts*

Clean fine wood facing and fine wood components only with a moist rag. Then dry with a soft cloth.

Plastic components

These include:

- Imitation leather surfaces.
- Headliner.
- Lamp lenses.
- Instrument cluster cover.
- Matte black spray-coated components.

Clean with a microfiber cloth.

Moisten the cloth lightly and use plastic cleanser, if necessary.

Do not soak the headliner.



Do not use cleansers that contain alcohol or solvents

Do not use cleansers that contain alcohol or solvents, such as lacquer thinners, heavy-duty grease removers, fuel, or such; this could lead to surface damage.◀

Safety belts

Dirty belt straps impede the reeling action and thus have a negative impact on safety.

No chemical cleaning

Do not clean chemically; this can destroy the webbing.◀

Use only a mild soapy solution, with the safety belts clipped into their buckles.

Do not allow the reels to retract the safety belts until they are dry.

Carpets and floor mats*

No objects in the area around the pedals Keep floor mats, carpets, and any other objects out of the area of motion of the pedals; otherwise, the function of the pedals could be impeded while driving

Do not place additional floor mats over existing mats or other objects.

Only use floor mats that have been approved for the vehicle and can be properly fixed in place.

Ensure that the floor mats are securely fastened again when they are returned after being removed, such as for cleaning. ◄

Floor mats can be removed from the passenger compartment for cleaning.

When returning the floor mats, secure them again to prevent slipping.

If the floor carpets are very dirty, clean with a microfiber cloth and water or a textile cleaner. To prevent matting of the carpet, rub back and forth in the direction of travel only.

Sensors/cameras

To clean sensors or cameras, use a cloth moistened with a small amount of glass cleaner.

Displays/screens

Use a microfiber cloth to clean the Control Display or instrument cluster, for example.



Cleaning displays

Do not use chemical or household cleansers.

Keep all fluids and moisture away from the unit.

Otherwise, they could affect or damage surfaces or electrical components.

Avoid pressing too hard when cleaning and do not use abrasive materials; otherwise, damage

Long-term vehicle storage

Your service center can advise you on what to consider when storing the vehicle for longer than three months.



Reference This chapter contains technical data, short commands for the voice activation system, and an index that will quickly take you to the information you need. Online Edition for Part no. 01 40 2 606 735 - 03 11 500

Technical data

Engine specifications


BMW X5		X5 xDrive35i	X5 xDrive50i	X5 xDrive35d
Displacement	cu in/ cm³	182/2,979	268/4,395	183/2,993
No. of cylinders		6	8	6
Maximum output	hp	300	400	265
at engine speed	rpm	5,800-6,250	5,500-6,400	4,200
Maximum torque	lb ft/Nm	300/407	450/610	425/580
at engine speed	rpm	1,300-5,000	1,750-4,500	1,750-2,250

BMW X6 X6 xDrive35i X6 xDrive50i Displacement cu in/ cm³ 182/2,979 268/4,395 No. of cylinders 6 8 Maximum output hp 300 400 at engine speed rpm 5,800-6,200 5,500-6,400 Maximum torque lb ft/Nm 300/407 450/610 at engine speed rpm 1,300-5,000 1,750-4,500				
cm³ No. of cylinders 6 8 Maximum output hp 300 400 at engine speed rpm 5,800-6,200 5,500-6,400 Maximum torque lb ft/Nm 300/407 450/610	BMW X6		X6 xDrive35i	X6 xDrive50i
Maximum output hp 300 400 at engine speed rpm 5,800-6,200 5,500-6,400 Maximum torque lb ft/Nm 300/407 450/610	Displacement		182/2,979	268/4,395
at engine speed rpm 5,800-6,200 5,500-6,400 Maximum torque lb ft/Nm 300/407 450/610	No. of cylinders		6	8
Maximum torque	Maximum output	hp	300	400
	at engine speed	rpm	5,800-6,200	5,500-6,400
at engine speed rpm 1,300-5,000 1,750-4,500	Maximum torque	lb ft/Nm	300/407	450/610
	at engine speed	rpm	1,300-5,000	1,750-4,500

Reference


Dimensions

BMW X5



All dimensions given in inches/mm. Smallest turning circle dia.: 42.0 ft/12.8 m With mixed tires* the vehicle width may exceed the specified dimension.

BMW X6



All dimensions given in inches/mm.

Smallest turning circle dia.: 42.0 ft/12.8 m

Height with roof rack*: 66.9 in/1,699 mm

With mixed tires* the vehicle width may exceed the specified dimension.

Weights

BMW X5		X5 xDrive35i	X5 xDrive50i	X5 xDrive35d
Approved gross vehicle weight	lbs/kg	6,371/2,890	6,669/3,025	6,581/2,985
without 3rd row seats	lbs/kg	6,052/2,745	6,327/2,870	6,261/2,840
Load	lbs/kg	1,290/585	1,290/585	1,290/585

BMW X5		X5 xDrive35i	X5 xDrive50i	X5 xDrive35d
without 3rd row seats	lbs/kg	1,102/500	1,102/500	1,102/500
Approved front axle load	lbs/kg	2,800/1,270	3,020/1,370	2,976/1,350
without 3rd row seats	lbs/kg	2,800/1,270	3,020/1,370	2,976/1,350
Approved rear axle load	lbs/kg	3,792/1,720	3,858/1,750	3,858/1,750
without 3rd row seats	lbs/kg	3,439/1,560	3,549/1,610	3,483/1,580
Approved roof load capacity	lbs/kg	220/100	220/100	220/100
Trunk capacity	cu ft/li- ter	35.8-75.2/620-1, 750	35.8-75.2/620- 1,750	35.8-75.2/620-1, 750

Never exceed either the approved axle loads or the gross vehicle weight.

BMW X6		X6 xDrive35i	X6 xDrive50i
Approved gross vehicle weight	lbs/kg	6,008/2,725	6,250/2,835
Load	lbs/kg	937/425	937/425
Approved front axle load	lbs/kg	2,822/1,280	3,042/1,380
Approved rear axle load	lbs/kg	3,263/1,480	3,351/1,520
Approved roof load capacity	lbs/kg	220/100	220/100
Trunk capacity	cu ft/li- ter	25.6-59.7/570- 1,450	25.6-59.7/570-1, 450

Never exceed either the approved axle loads or the gross vehicle weight.

Capacities

BMW X5			Notes
Fuel tank	US gal/liters	Approx. 22.4/85	Fuel specifications, refer to page 248
Including reserve of			
X5 xDrive35i, X5 xDrive35d	US gal/liters	approx. 2.1/8	

BMW X5			Notes
X5 xDrive50i	US gal/liters	approx. 2.6/10	
Window washer system With headlamp washer system	US qt/liters	approx. 6.9/6.5	Details, refer to page 68

BMW X6			Notes
Fuel tank	US gal/liters	Approx. 22.4/85	Fuel specifications, refer to page 248
Including reserve of			
X6 xDrive35i	US gal/liters	approx. 2.1/8	
X6 xDrive50i	US gal/liters	approx. 3.2/12	
Window washer system With headlamp washer system	US qt/liters	approx. 6.9/6.5	Details, refer to page 68

Short commands for voice activation system*

General information

Instructions for voice activation system, refer to page 24.

To have the available spoken instructions read out loud: >Voice commands<

The following short commands apply to vehicles equipped with a voice activation system. They have no function in vehicles in which only the mobile phone is operated using the voice.

Adjusting

Vehicle

Function	Command
Opens the main menu.	Main menu
Open the options.	Options
Open the settings.	>Settings<
Settings on the Control Display.	Control display
Open the time and date.	Time and date
Open the language and units.	Language and units
Open the speed limit.	Speed
Open the light.	>Lighting<
Open the door lock.	Door locks

Equipment*

Function	Command
Open the air conditioning settings.	›Climate‹
Open the Head-up Display.	head up display
Enable the rear.	Allow rear control

Vehicle information

Computer

Function	Command
Open the computer.	Onboard info
Open the trip computer.	Trip computer

Vehicle

Function	Command
Open the vehicle information.	›Vehicle info
Open the vehicle status.	›Vehicle status‹

Navigation*

General information

Emaking	Commond
Function	Command
Navigation menu.	»Navigation«
Open the destination entry.	Enter address
Enter the address.	>Enter address<
Open destination guidance.	∍Guidance (
Start destination guidance.	Start guidance
Terminate destination guidance.	Stop guidance
Open the home address.	›Home address‹
Open the route criteria.	Route preference
Open the route.	Route information
Switch on the spoken instruction.	Switch on voice instructions
Repeat the spoken instruction.	Repeat voice instructions
Switch off the spoken instruction.	Switch off voice instructions
Display the address book.	»Address book«
Display the most recent destinations.	>Last destinations

Function	Command
Open the traffic bulletins.	→Traffic Info
Special destinations.	Points of interesto

Мар

Function	Command
Display the map.	»Мар«
Map facing north.	Map facing north
Map facing the direction of travel.	Map in direction of travek
Perspective map.	Map perspective view
Automatic scaling of the map.	Map with automatic scaling
Scalefeet.	Map scale feet
Scalemeters.	Map scale meters e.g., map scale 100 meters
Scalekilometers.	Map scale kilometers e.g., map scale 5 kilometers
Scalemiles.	Map scale miles e.g., map scale 5 miles

Split screen settings

Function	Command
Split screen.	Switch on splitscreen
Switch off the split screen.	Turn off split screen
Adjust the split screen.	Split screen content
Split screen, map facing north.	Split screen map facing north
Split screen, current position.	Split screen current position
Split screen, facing the direction of travel.	Split screen map in direction of travelo
Split screen, perspective.	Split screen perspective
Split screen, expanded intersection zoom.	Splitscreen Exit ramp view
Split screen scalefeet.	»Split screen scale feet e.g., split screen scale 100 feet

Function	Command
Split screen scalemeters.	Split screen scale meters e.g., split screen scale 100 meters
Split screen scalekilometers.	Split screen scale kilometers e.g., split screen scale 5 kilometers
Split screen scalemiles.	Split screen scale miles e.g., split screen scale 5 miles
Split screen, highlight the traffic situation.	Split screen, Traffic conditions
Split screen, computer.	Split screen on board info
Split screen, trip computer.	Splitscreen trip computer
Split screen, scale automatically.	»Split screen automatic scaling«

Destination guidance with intermediate destinations

Function	Command
Enter a new destination.	>Enter address
Trip list.	Stored trips

Radio

FM

Function	Command
Open a frequency.	Frequency megahertz e.g., 93.5 megahertz or frequency 93.5
Open the radio.	>Radio<
Open the FM stations.	∍F Mα
Open the manual search.	»Manual«
Open the manual search. Select a frequency range.	»Manual« »Select frequency«

AM

Function	Command
Open a frequency.	>Frequency Kilohertz< e.g., frequency 753 or 753 kilohertz
Open the AM stations.	»A M«
Open the manual search.	»Manual«

Satellite radio*

Function	Command
Open the satellite radio.	Satellite radio
Switch on the satellite radio.	>Satellite radio on
Select a satellite radio channel.	Select satellite radio e.g., satellite radio channel 2

Stored stations

Function	Command
Open the stored stations.	›Presets‹
Choose a stored station.	Select preseto
Select a stored station.	Preset e.g., stored station 2

CD/multimedia*

CD/DVD drive

Function	Command
Select a track.	Track e.g., track 5
	or
	CD track e. g., CD track 5
Play back a CD.	»C D on«
Select a CD.	>Select C D<
Select a CD and track.	CD track e.g., CD 3 track 5
Open the CD and Multimedia menu.	C D and multimedia

Function	Command
CD and DVD.	»C D«
Select a DVD.	»D V D‹ e.g., DVD 3
Display the entertainment details on a split screen*.	>Entertainment details<

Music collection

Function	Command
Search for music, open a menu.	Music search
Open the current playback.	Current playback
Open the music collection.	Music collection
Play back the music collection.	Music collection on
Play back the most frequently played tracks.	→Top fiftyc

External devices

Function	Command
Open the external devices.	>External devices
Open the Bluetooth devices.	»Bluetooth«

Tone

Function	Command
Open the tone settings.	>Tone<

Telephone*

Function	Command
Dial a phone number.	Dial number
Open the Telephone menu.	>Telephone
Display the phone book.	»Phonebook«
Redialing.	Redial
Display received calls.	Received calls

Function	Command
List of messages.	»Messages«
Open the Bluetooth devices.	>Bluetooth

Office*

Function	Command
Open the Office menu.	Office
Display Office Today.	Current office
Display the contacts.	>Contacts<
Display the messages.	»Messages«
Display the messages. Display the calendar.	»Messages« »Calendar«
Display the calendar.	»Calendar«

Contacts*

Function	Command
Select a name.	Choose name
My contacts.	My contacts
Open the contacts.	Contacts
New contact.	New contact

ConnectedDrive* or BMW Assist*

Function	Command
Open BMW Assist.	∍B M W Assist⊲
Open ConnectedDrive.	Connected Drive
Open BMW Online.	»B M W Online«

Everything from A to Z

Index

0 - 9

3rd row seats 47

A

ABS, Antilock Brake System 96 ACC Active Cruise Control 102 Access to 3rd row seats 47 Accident, refer to Emergency Request, initiating 280 Acoustic signal, refer to Check Control 76 Activated-charcoal filter 124 Active Cruise Control ACC 102 Active cruise control, indicator lamp 105 Active Cruise Control, radar sensor 106 Active Cruise Control, selecting the distance 104 Active Cruise Control, warning lamps 105 Active seat 49 Active seat ventilation 49 Active steering 100 Adaptive brake lights, refer to Brake force display 94 Adaptive Drive 99 Adaptive fixing system 137 Adaptive light control 82 Additional telephone 216 Additives, coolant 267 Additives, engine oil 266 After washing vehicle 286 Airbags 86 Airbags, indicator/warning light 88 Air circulation, refer to Recirculated air mode 122

Air distribution, automatic 120, 125 Air distribution, manual 121 Air drying, refer to Cooling function 122 Air flow rate 121 Air flow rate, blower, refer to Air volume 125 Airing, refer to Ventilation 123 Air pressure, refer to Tire inflation pressure 252 Air vents 119 Air vents, refer to Ventilation 123 AKI, refer to Fuel specifications 248 Alarm system 39 Alarm system - Avoiding unintentional alarms 40 - Ending an alarm 39 - Interior motion sensor 40 Tilt alarm sensor 40 All around the headliner 17 All-season tires, refer to Winter tires 261 All-wheel drive, refer to xDrive 98 Alternating-code hand-held transmitter 128 AM/FM station 174 Announcement, navigation, refer to Spoken instructions 163 Antifreeze, coolant 267 Antifreeze, washer fluid 68 Antilock Brake System, **ABS 96** Anti-slip control, refer to Dynamic Stability Control **DSC 96** Anti-theft protection 30 Appointments 232

Approved axle loads, refer to Weights 292 Approved engine oils 266 Approved gross vehicle weight, refer to Weights 292 Armrest, refer to Center armrest 134 Arrival time, refer to Computer 74 Ashtray 130 Ashtray, front 130 Ashtray, rear 130 Assist 237 Assistance, Roadside Assistance 281 Assistance with driving off, refer to Drive-off assistant 100 Assistance with starting engine, refer to Jump-startina 281 Audio CD with rear DVD system 206 Audio device, external 134 Audio playback 181 Audio playback, Bluetooth 196 Automatic, air distribution 120, 125 Automatic air distribution 125 Automatic, air flow rate 120 Automatic car wash 285 Automatic climate control 119 Automatic climate control, automatic air distribution 120, 125 Automatic climate control, in rear 124 Automatic climate control in rear, activating on Control Display 124 Automatic climate control in rear, air supply 125

Automatic climate control in rear, deactivating on Control Display 124 Automatic climate control in rear, switching off 125 Automatic climate control, switching off 123, 125 Automatic climate control, ventilation in rear 123 Automatic climate control, with 2-zone control 120 Automatic climate control, with 4-zone control 124 Automatic, cruise control 108 Automatic Cruise Control 102 Automatic Curb Monitor 54 Automatic headlamp control 81, 82 Automatic Hold 64 Automatic Hold, activating 64 Automatic Hold, deactivatina 64 Automatic Hold, parking 65 Automatic recirculated air control 122 Automatic Soft Closing, doors 33 Automatic Soft Closing, tailgate 34 Automatic tailgate operation 34, 36 Automatic transmission with Steptronic 69 Automatic transmission with Steptronic - Kickdown 69 AUTO program with automatic climate control 120, 125 AUX-IN port 134, 192 Average fuel consumption 74 Average fuel consumption, setting the units 80 Average speed 73 Average speed, refer to Computer 73 Axle loads, refer to Weights 292

В

Backrest curvature, refer to Lumbar support 46 Backrest width 46 Back seats, adjusting the head restraints 52 Backup camera 112 Backup camera, cleaning 114 Backup camera, obstacle marking 113 Backup camera, pathway lines 113 Backup camera, turning lines 113 Balance 172 Band-aids, refer to First aid kit 281 Bass 172 Batterv - Remote control 28 Battery change, remote control for rear DVD system 202 Battery disposal 278 Battery, refer to Vehicle battery 278 Battery replacement, remote control for vehicle 39 Before entering the car wash 285 Belts, refer to Safety belts 50 Belt tensioners, refer to Safety belts 50 Beverage holder, refer to Cupholder 135 Black and white map display 166 Blower, refer to Air flow rate 121 Bluetooth audio 196 Bluetooth connection, activating/deactivating 217 BMW Advanced Diesel 249 BMW Apps 241 BMW Apps, video playback 195 BMW Assist 237 BMW Assist, refer to ConnecBMW EfficientDynamics, refer to Saving fuel 148 BMW homepage 6 BMW Internet page 6 BMW maintenance system 268 BMW Online 239 BMW TeleService 237 Bottle holder, refer to Cupholder 135 Brake assistant 96 Brake discs, breaking in 142 Brake fluid, refer to Service requirements 75 Brake force display 94 Brake force distribution, electronic 96 Brake lamps, brake force display 94 Brake lights, adaptive 94 Brake pads, breaking in 142 Brakes, BMW maintenance system 268 Brakes, parking brake 63 Brakes, service requirements 75 Brake system, BMW maintenance system 268 Braking, notes 143 Breakdown assistance 281 Breakdown, transporting the vehicle 282 Breaking in 142 Brightness, on the Control Display 80 Bulb replacement, refer to Lamp and bulb replacement 270 Button for starting the engine, refer to Start/Stop button 61

C

Calendar 232 Calibration, driver's seat 51 California Proposition 65 Warning 7 Camera, care 287

tedDrive 237

	amera, refer to Backup cam-
	era 112
Ca	amera, Side View 117
Ca	amera, Top View 116
	an holder, refer to Cu-
p	holder 135
	ar battery, refer to Vehicle
b	attery 278
Ca	ar care products 286
Ca	are 285
Ca	are, displays 287
	are, vehicle 286
	argo 144
	argo area
	Comfort Access 38
Ca	argo area, capacities 292
	argo area, enlarging 133
	argo area lamp, refer to Inte-
	ior lamps 84
	argo area lid, refer to Tail-
	gate 33, 36
_	argo area, opening/closing,
	efer to Lower tailgate 36
	argo area, opening/closing,
	efer to Tailgate 33, 36
	argo area, opening from the
	nside 34
	argo area, opening from the
	outside 34
	argo area, refer to Cargo
	irea 132
Ca	argo cover, refer to Luggage
	compartment roller
	over 132
	argo, securing with ski bag,
	efer to Securing cargo 139
	argo straps, securing
	argo 146
	ar key, refer to Integrated
	ey/remote control 28
	arpet, care 287
	ar phone, installation loca-
	ion, refer to Center arm-
	est 134
	ar phone, refer to Tele-
	phone 216
	ar vacuum cleaner, connect-
	ng, refer to Connecting elec-
t	rical devices 131

Car wash 285
Catalytic converter, refer to
Hot exhaust system 142
CBC, refer to Cornering Brake
Control 96
CBS Condition Based Serv-
ice 268
CD/DVD 181
CD/DVD changer 185
CD/DVD in rear 201
CD/DVD notes 187
CD, refer to Playing audio
tracks, rear DVD system 206
CDs, storing 188
Cell phone 216
Cell phone, installation loca-
tion, refer to Center arm-
•
rest 134
Center armrest, front 134
Center armrest, rear 135
Center brake lamp 273, 275
Center console, refer to
Around the center con-
sole 16
Central locking
- Comfort Access 37
– From the inside 33
 Setting the unlocking char-
acteristics 30
Central locking system
 From the outside 29
– Principle 29
Central screen, refer to Control
Display 19
Changes, technical, refer to
Safety 6
Changing wheels/tires 260
Chassis number, refer to En-
gine compartment 263
Check Control 76
Children, transporting 56
Child restraint fixing system
LATCH 57
Child restraint fixing sys-
tems 56
Child restraint fixing systems,
mounting 56
Child safety locks 60
Child seat, mounting 56
Orma seat, mounting 30

Child seats, refer to Transporting children safely 56 Chrome parts, care 286 Cigarette lighter, connecting electrical devices 131 Cigarette lighter, refer to Lighter 130 Cigarette lighter socket 131 Circulation of air, refer to Recirculated air mode 122 Cleaning, displays 287 Cleaning your BMW, refer to Care 285 Clock 71 Clock, 12h/24h mode 79 Closing - From the inside 33 - From the outside 30 Clothes hooks 135 Cockpit 12 Cold start, refer to Starting the engine 62 Combination instrument, refer to Instrument cluster 14 Combination switch, refer to Turn signal/high beams/ headlamp flasher 66 Combination switch, refer to Washer/wiper system 67 Comfort Access Battery replacement 39 Comfort area, refer to Around the center console 16 Compact wheel, inflation pressure 252, 253 Compartment for remote control, refer to Ignition lock 61 Compartments, refer to Storage compartments 134, 135 Compass, digital 129 Computer 73 Computer, displaying information 73 Computer, displays on the Control Display 74 Concierge service 238 Condensation on windows, removing 121

Condensation under the vehicle 144 Condition Based Service **CBS 268** Confirmation signals for locking/unlocking the vehicle 31 ConnectedDrive 237 Connecting, mobile phone, refer to Pairing the mobile phone 216 Consumption, refer to Average fuel consumption 74 Contacts 227, 235 Control Display 19 Control Display, care 287 Control Display, setting the brightness 80 Controller, refer to Controls 18 Controls and displays 12 Controls, rear DVD system 200 Control systems, driving stability 96 Convenient operation - Glass sunroof 30, 32 - Window 30 Coolant 267 Coolant, checking the level 267 Coolant temperature 72 Cooling function, switching on and off 122 Cooling, maximum 122 Cooling system, refer to Coolant 267 Cornering Brake Control CBC 96 Corrosion on brake discs 144 Courtesy lamps, refer to Interior lamps 84 Cradle for telephone or mobile phone, refer to Snap-in adapter 225 Cruise control 108 Cruise control Malfunction 110

Cruise control, active 102

Cupholder 135

Curb weight, refer to Weights 292 Current fuel consumption 72 Current location, storing 155 Curve lights, refer to Adaptive light control 82 Cylinders, number of, refer to Engine data 290

D

Dashboard lighting, refer to Instrument lighting 84 Dashboard, refer to Cockpit 12 Data memory 269 Data, technical 290 Date 71 Date, display format 79 Date, retrieving 71 Date, setting 79 Daytime running lights 82 Defroster, rear window 121 Defrosting windows 121 Defrost setting, refer to Defrosting windows 121 Destination entry via the address book 154 Destination guidance 161 Destination guidance with intermediate destinations 159 Destination input, navigation 153 Diesel exhaust fluid, at low temperatures 250 Diesel exhaust fluid, at minimum 249 Diesel exhaust fluid, having refilled 250 Diesel exhaust fluid, refilling vourself 250 Diesel particulate filter 143 Digital clock 71 Digital compass 129 Digital radio 175 Dimming mirrors 55 Directional indicators, refer to Turn signals 66

data 290 Display in front windshield 117 Display lighting, refer to Instrument lighting 84 Displays and controls 12 Displays, care 287 Displays, cleaning 287 Displays, refer to Instrument cluster 14 Disposal, coolant 267 Disposal, vehicle battery 278 Distance control, refer to Active Cruise Control 102 Distance, selecting, with Active Cruise Control 104 Distance warning, refer to Park Distance Control PDC 110 Divided screen view, split screen 22 Door key, refer to Remote control with integrated key 28 Door lock 32 Doors, manual operation 32 Doors, unlocking and locking - Confirmation signals 31 - From the inside 33 From the outside 30 DOT Quality Grades 258 Downhill control 98 Draft-free ventilation 123 Drive-off assistant 100 Driver's seat, calibrating 51 Driving away on inclines, refer to Drive-off assistant 100 Driving notes, breaking in 142 Driving notes, general 142 Driving on poor roads 147 Driving stability control systems 96 Driving through water 143 Driving tips, refer to Driving notes 142 Dry air, refer to Cooling function 122 DSC Dynamic Stability Control 96

Displacement, refer to Engine

DTC Dynamic Traction Control 97	Energy-conscious driving, re- fer to Current fuel consump-	ESP Electronic Stability Program, refer to Dynamic Sta-
DTMF suffix dialing 222	tion 72	bility Control DSC 96
DVD/CD 181	Energy, saving, refer to Saving	Exchanging wheels/tires 260
DVDs, storing 188	fuel 148	Exhaust system 142
DVD system in rear 200	Engine, breaking in 142	Exterior mirrors 53
DVD, video 183	Engine compartment 263	Exterior mirrors, adjusting 53
Dynamic destination guidance 167	Engine coolant, refer to Coolant 267	Exterior mirrors, automatic dimming 55
Dynamic Performance Control 98	Engine oil, adding 266 Engine oil, additives, refer to	Exterior mirrors, automatic heating 54
Dynamic Stability Control DSC 96	Approved engine oils 266 Engine oil, alternative oil	Exterior mirrors, folding in and out 54
Dynamic Traction Control DTC 97	types 266 Engine oil, BMW maintenance	External audio device 134 External devices 192
E	system 268 Engine oil change intervals, re-	External temperature dis- play 71
	fer to Service require-	External temperature display,
Easy entry/exit 55	ments 75	changing the units of meas-
EfficientDynamics, refer to	Engine oil, checking the	ure, changing the units of
Saving fuel 148	level 265	measure on the Control Dis-
Electrical malfunction	Engine oil, filling capacity 293	play <mark>80</mark>
– Door lock 32	Engine oil temperature 72	External temperature warn-
- Driver's door 32	Engine oil types, alterna-	ing 7 1
- Fuel filler flap 246	tive 266	Eyes for securing cargo 146
Electrical malfunction of upper	Engine oil types, ap-	
tailgate 34	proved 266	F
Electrical malfunction, parking	Engine, overheating, refer to	
brake 65	Coolant temperature 72	Fader 172
Electric seat adjustment 46	Engine power, refer to Engine	Failure messages, refer to
Electric steering wheel adjust-	data 290	Check Control 76
ment 55	Engine, RPM 290	False alarm
Electronic brake-force distri-	Engine start, assistance 281	 Avoiding unintentional
bution 96	Engine, starting 62	alarms 40
Electronic engine oil level	Engine, starting	– Ending an alarm 39
check 265	Comfort Access 37	Fastening safety belts, refer to
Electronic Stability Program	Engine, starting, Start/Stop	Safety belts 50
ESP, refer to Dynamic Stabil-	button 61	Fault messages, refer to
ity Control DSC 96	Engine, stopping, Start/Stop	Check Control 76
Emergency operation	button 61	Filling capacities 293
- Door lock, refer to Manual	Engine, switching off 62	Filter, refer to Microfilter/acti-
operation 32	Entry lamps, refer to Interior	vated-charcoal filter 124
Emergency operation, fuel	lamps 84	Fine wood, care 287
filler flap, unlocking man-	Environmentally friendly driv-	First aid kit 281
ually 246	ing, refer to Current fuel con-	Fitting for towing 283
Emergency Request 280	sumption 72	Fixing system, adaptive 137
Emergency service, refer to	Equalizer 172	Flashing when locking/unlock-
Roadside Assistance 281	Equipment, interior 127	ing 31
	,	Flat Tire Monitor FTM 88

Flat Tire Monitor FTM, snow chains 261 Flat tire, run-flat tires 261 Flat tire. Tire Pressure Monitor **TPM 90** Flat tire, warning lamp 89, 91 Flat tire, wheel change 275 Flooding, refer to Driving through water 143 Floor carpet, care 287 Floor mats, care 287 FM/AM station 174 Fog on windows, removing 121 Foldable rear seat backrest 133 Foot brake 143 Footwell lamps, refer to Interior lamps 84 For your own safety 6 Four-wheel drive, refer to xDrive 98 Front airbags 86 Front fog lamps 84 Front fog lamps, indicator lamp 84 FTM Flat Tire Monitor 88 **Fuel 248** Fuel - Refer to Average fuel consumption 74 Fuel, average consumption 74 Fuel cap 246 Fuel cap, closing 246 Fuel consumption display Average fuel consumption 74 Fuel consumption display, current fuel consumption 72 Fuel-efficient driving, refer to Current fuel consumption 72 Fuel filler flap, closing 246 Fuel filler flap, opening 246 Fuel filler flap, unlocking in case of an electrical malfunction 246 Fuel gauge 73 Fuel, high-quality brands 248

Fuel, quality 248 Fuel, saving 148 Fuel, specifications 248 Fuel tank capacity, refer to Filling capacities 293 Fuel tank contents, refer to Filling capacities 293 Fuel tank, refer to Filling capacities 293 Fuse 279 G Garage door opener, refer to Integrated universal remote control 127 Gasoline gauge, refer to Fuel gauge 73 Gasoline, refer to Required fuel 248 Gas station recommendation 162 Gear change, automatic transmission with Steptronic 70 Gear change, via shift paddles 70 General driving notes 142 Glass sunroof, closing 43 Glass sunroof, electric Convenient operation 30 Remote control 30 Glass sunroof, initializing 44 Glass sunroof, opening 43 Glass sunroof, pinch protection 44 Glass sunroof, power failure 44 Glass sunroof, refer to Panoramic glass sunroof 42 Glass sunroof, tilting 43 Glove compartment 134 Glove compartment USB interface 134 Glove compartment, lighting 134 GPS navigation, refer to Navigation system 152

н

Handbrake, refer to Parking brake 63 Hand-held transmitter, alternating code 128 Hands-free microphone 16 Hazard warning system 16, 280 HDC Hill Descent Control 98 HD Radio 175 Head airbags 86 Headlamp control, automatic 81, 82 Headlamp courtesy delay feature 81 Headlamp flasher 66, 83 Headlamp flasher, indicator lamp 15 Headlamps 81 Headlamps, care 285 Headlamps, cleaning 67 Headlamps, cleaning, washer fluid 68 Headliner 17 Headphones, connecting, rear DVD system 201 Head restraints 51 Head-up Display 117 Head-up Display, care 287 Heatable rear window 121 Heating 119 Heating Seats 48 Heating, interior 119 Heating, mirrors 54 Heating, residual heat 122 Heating with the engine switched off, refer to Residual heat 122 Heavy cargo, refer to Stowing cargo 145 Height, refer to Dimensions 291 High-beam Assistant 83 High beams 83 High beams/low beams, automatic, refer to High-beam Assistant 83

Weights 292

Gross vehicle weight, refer to

High beams, indicator lamp 15	Ignition, switched off 61 Ignition, switched on 61
High-pressure washers 285	Images, displaying, rear DVD
Hill Descent Control HDC 98	system 208
Hill drive-off assistant, refer to	Indication of a flat tire 89, 91
Drive-off assistant 100	Indicator and warning
Hills 144	lamps 15
Holder for beverages 135	Inflation pressure monitor, re-
Holder for remote control, re-	fer to Flat Tire Monitor 88
fer to Ignition lock 61	Inflation pressure, refer to Tire
Homepage 6	inflation pressure 252
Hood 264	Information on the navigation
Hood, opening 264	data 152
Horn 12	Initialization after power fail-
Hot exhaust system 142	ure 278
Hotline 240	Initializing
House number, entering for navigation 154	 Compass, refer to Calibrat- ing 129
Hydraulic brake assistant 96	– Panoramic glass sunroof 43
Hydroplaning 143	Initializing, Flat Tire Monitor FTM 89
I	Initializing, glass sunroof 44
	Initializing, refer to Setting the
Ice warning, refer to External	date 79
temperature warning 71	Initializing, refer to Setting the
lcy roads, refer to External	time 79
temperature warning 71	Initializing, Tire Pressure Mon-
Identification marks, tires 258	itor TPM 91
iDrive 18	Installation location, tele- phone 134
iDrive, changing settings 78	Instrument cluster 14
iDrive, changing the lan-	Instrument lighting 84
guage 80	Instrument panel, refer to In-
iDrive, changing the units of	strument cluster 14
measure and display for- mat 80	Instruments, refer to Cock-
iDrive, setting the bright-	pit 12
ness 80	Integrated key 28
iDrive, setting the date 79	Integrated universal remote
iDrive, setting the time 79	control 127
Ignition 61	Interactive map 157
Ignition key position 1, refer to	Interior equipment 127
Radio ready state 61	Interior lamps 84

Interior temperature, setting, automatic climate control 119 Intermediate destinations 159 Internet page 6 Intersection, entering for navigation 154 iPod/iPhone 193 J Jacking points for the vehicle jack 276 Jack, refer to Vehicle jack 276 Joystick, refer to Selector lever 69 Jump-starting 281 K Keyless Go, refer to Comfort Access 37

Keyless opening and closing, refer to Comfort Access 37 Key Memory, refer to Personal Profile 28 Key, refer to Integrated key/remote control 28 Kickdown

 Automatic transmission with Steptronic 69 Knocking control 248

Label, run-flat tire 261 Lamp and bulb replacement, lamp replacement 270 Lamps 81 Lamps, automatic headlamp control 81, 82 Lamps, High-beam Assistant 83 Lamps, parking lamps/low beams 81 Lamps, replacing, refer to Lamp and bulb replacement 270

Lane departure warning 93

Ignition key position 2, refer to

Ignition key, refer to Remote

control with integrated

Ignition on 61

Ignition lock 61

key 28

Interior rearview mirror, auto-

Interior rearview mirror, com-

Interior lamps

pass 129

- Remote control 30

matic dimming 55

Interior mirror 54

Lane margin, warning 93 Language, changing on Control Display 80 Lap-and-shoulder belt, refer to Safety belts 50 Lashing eyes, securing cargo 146 LATCH child restraint fixing system 57 Leather, care 286 LEDs, light-emitting diodes 271 Length, refer to Dimensions 291 Letters and numbers, entering 23 License plate lamps, replacing bulbs 273, 275 Light-alloy wheels, care 286 Light-emitting diodes, LEDs 271 Lighter 130 Lighting - Instruments 84 Lighting, vehicle, refer to Lamps 81 Light switch 81 Limit, refer to Speed limit 78 Load 145 Loading 144 Lock buttons, doors, refer to Locking 33 Locking - From the inside 33 From the outside 30 Setting the confirmation signals 31 - Without remote control, refer to Comfort Access 37 Locking the vehicle From the inside 33 - From the outside 30 Locks, doors, and windows 60 Longlife oils, alternative oil types 266 Longlife oils, refer to Approved engine oils 266 Low beams 81

Low beams - Automatic 82 Low beams, automatic 81 Low beams, automatic, refer to High-beam Assistant 83 Lower back support, refer to Lumbar support 46 Lower tailgate 36 Low-sulfur diesel 248 Luggage compartment roller cover 132 Luggage rack, refer to Roofmounted luggage rack 147 Lumbar support 46

M

Main inspection, refer to Service requirements 75 Maintenance 268 Maintenance, refer to Service booklet Maintenance, refer to Service requirements 75 Maintenance requirements 268 Maintenance system **BMW 268** Malfunction - Door lock 32 Fuel filler flap 246 Malfunction of upper tailgate 34 Malfunction, parking brake 65 Malfunction warnings, refer to Check Control 76 Manual air distribution 121 Manual mode, automatic transmission with Steptronic 70 Manual operation - Door lock 32 Driver's door 32 Manual operation, fuel filler flap 246 Manual operation of upper tailgate 34 Manual operation, Side

View 115 Map, destination entry 157 Map display in black and white 166 Map in split screen 164 Map view 163 Marking on approved tires 260 Master key, refer to Remote control with integrated key 28 Maximum cooling 122 Maximum speed, winter tires 261 Medical kit, refer to First aid kit 281 Memory, refer to Seat and mirror memory 53 Menus, operating, iDrive 18 Menus, refer to iDrive operating concept 19 Message list, traffic bulletins 165 Messages 230 Microfilter 124 Minimum tread, tires 259 Mirror - Mirror memory, refer to Seat and mirror memory 53 Mirrors 53 Mirrors Automatic Curb Monitor 54 Mirrors, folding in and out 54 Mirrors, heating 54 Mirrors, interior mirror 54 Mobile communication devices in the vehicle 143 Mobile phone, installation location, refer to Center armrest 134 Mobile phone, refer to Telephone 216 Modifications, technical, refer to Safety 6 Monitor, refer to Control Display 19 Mounting of child restraint fixing systems 56

Manual operation, Top

View 116

MP3 player 192 Multimedia 181
Music collection 188 Music search 189
Music, storing 188
N

Navigation 152

Navigation data 152
Navigation data, updating 152
Navigation system

- Destination entry by
voice 158
Neck restraints, refer to Head
restraints 51
Nets, refer to Storage compartments 135
New wheels and tires 260
Notes 6, 233
Nozzles of automatic climate
control 119
Nozzles, refer to Ventilation 123

0

OBD Onboard Diagnostics 269 OBD socket, refer to Socket for OBD Onboard Diagnosis 269 Octane numbers, refer to Fuel specifications 248 Odometer 71 Office 227 Oil additives 266 Oil consumption 265 Oil level 265 Oil, refer to Engine oil 265 Oil types, alternative 266 Oil types, approved 266 Old batteries, disposal 278 Onboard Diagnostics OBD 269 Onboard monitor, refer to Control Display 19 Onboard vehicle tool kit 270

Opening and closing

- Comfort Access 37

- From the inside 33

- From the outside 30

- Using the door lock 32

- Using the remote control 30
Opening height, adjusting 34, 36
Operating concept, iDrive 18
Outside-air mode, automatic climate control 122
Outside air, refer to Recirculated air mode 122
Overheating of engine, refer to Coolant temperature 72

P

Paint, vehicle 286 Pairing, mobile phone 216 Panic mode 30 Panoramic glass sunroof Convenient operation 30 - Initializing 43 - Opening, closing 42 - Pinch protection 43 - Power failure 43 Remote control 30 Tilting 42 Park Distance Control **PDC 110** Parked-car ventilation 125 Parked vehicle, condensation 144 Parking aid, refer to Park Distance Control PDC 110 Parking assistant, refer to Park Distance Control PDC 110 Parking brake 63 Parking brake, Automatic Hold 64 Parking brake, releasing manually 64, 65 Parking brake, setting manually 63 Parking lamps 81 Parking lamps/low beams 81 Parking with Automatic Hold 65

Particulate filter, refer to Diesel particulate filter 143 Passenger airbags, deactivat-Passenger side mirror, tilting 54 PDC Park Distance Control 110 Personal information 227 Personal Profile 28 Pinch protection Panoramic glass sunroof 43 Windows 41 Pinch protection, glass sunroof 44 Plastic, care 287 Playing videos, rear DVD system 202 Plugln 242 Pollen, refer to Microfilter/activated-charcoal filter 124 Poor road operation 147 Position, storing 155 Postal code, entering in navigation 154 Power, refer to Engine data 290 Power windows Safety switch 41 Power windows, opening and closing 40 Power windows, refer to Windows 40 Preheating, refer to Diesel engine 62 Prescribed engine oils, refer to Approved engine oils 266 Pressure, tires 252 Pressure warning, tires 88 Profile depth, refer to Minimum tread depth 259 Profile, tires 259 Programmable memory buttons, iDrive 22 Protection function, refer to Pinch protection 44 Protection function, refer to Pinch protection Panoramic glass sunroof 43

Protective function, refer to Pinch protection - Windows 41 Push-and-turn switch, refer to Controls 18

R

Radiator fluid, refer to Coolant 267 Radio-operated key, refer to Remote control with integrated key 28 Radio ready state 61 Radio ready state, switched off 61 Radio ready state, switched on 61 Radio setting, refer to Radio ready state 61 Rain sensor 67 Random 182 Random playback 182 Range 73 **RDS 175** Reading lamps 85 Reading out loud 234 Rear entertainment, refer to DVD system in rear 200 Rear lamps, refer to Tail lamps 271, 274 Rear seat backrest, foldable 133 Rear seats, adjusting 47 Rear seats, adjusting the head restraints 52 Rear seats, heating 48 Rear socket 131 Rear ventilation 123 Rear ventilation, 3rd row seats 123 Rear ventilation, automatic climate control in rear 124 Rearview mirror, refer to Mirrors 53 Rear window defroster 121 Rear window, washing 68 Rear window wiper 68

Recirculated air mode 122

Recommended tire brands 260 Redialing 222 Refueling 246 Remaining distance to destination, refer to Computer 74 Remaining range for service, refer to Service requirements 75 Remaining range, refer to Range 73 Reminders 233 Remote control Battery replacement 39 - Comfort Access 37 - Malfunction 31, 38 - Tailgate 31 Remote control, garage door opener 127 Remote control, rear DVD system 201 Remote control, removing from the ignition lock 61 Remote control, service data 268 Remote control, universal 127 Remote inquiry 222 Replacement fuse 279 Replacement remote con-Replacing wheels/tires 260 Reporting safety defects 8 Reserve warning, refer to Fuel gauge 73 Reservoir for washer fluid, refer to Washer fluid reservoir 68 Resetting, Tire Pressure Monitor TPM 91 Residual heat 122 Restraining systems - Refer to Safety belts 50 Restraint systems for children 56 Retaining straps, securing cargo 146 Retreaded tires 261 Road, avoiding 161 Road detour 161

Roadside Assistance 238 Roadside parking lamps 83 Roller sunblinds 41 Roof load capacity 292 Roof-mounted luggage rack 147 Rope, refer to Towing 283 Route 162 Route criteria, route 161 Route, displaying 162 Route section, bypassing 162 RPM, refer to Engine data 290 RSC Runflat System Component, refer to Run-flat tires 261 Rubber components, care 286 Run-flat tires 261 Run-flat tires, tire inflation pressure 252 Running lights, refer to Parking lamps/low beams 81

S

Safe braking 143 Safety 6 Safety belts 50 Safety belts - Damage 50 Safety belts, care 287 Safety belts, indicator/warning lamp 50 Safety belts, reminder 50 Safety switch for rear windows 41 Safety systems - Safety belts 50 Safety systems, airbags 86 Safety tires, refer to Run-flat tires 261 Satellite radio 176 Saving fuel 148 Scale, changing during navigation 164 Screen, folding open/closed, rear DVD system 200

Screen, refer to Control Dis-	Settings, clock, 12h/24h	Speed limit 78
play 19	mode 79	Speed limit, setting 78
Search, refer to BMW On-	Settings, configuring, refer to	Speedometer 14
line 239	Personal Profile 28	Speed, with winter tires 261
Seat adjustment, electric 46	Settings, DVD 184	Split screen 22
Seat adjustment, manual 45	Settings on the Control Dis-	Split screen map settings 164
Seat and mirror memory 53	play, changing 78	Spoken instructions, naviga-
Seat belts	Shifting, automatic transmis-	tion 163
- Refer to Safety belts 50	sion with Steptronic 70	Sport program, automatic
Seat heating 48, 49	Shift paddles 70	transmission with Step-
Seat heating, rear 48	Short commands, voice acti-	tronic 70
Seats	vation 295	Spray nozzles, refer to Clean-
 Adjusting electrically 46 	Side airbags 86	ing the windshield and head-
- Heating 48	_	_
- Memory, refer to Seat and	Side View 116	lamps 67
mirror memory 53	Side windows, refer to Win-	Spray nozzles, refer to Wind-
- Sitting safely 45	dows 40	shield washer nozzles 68
- Storing the setting, refer to	Size, refer to Dimensions 291	Stability control systems 96
Seat and mirror memory 53	Ski bag 138	Start/Stop button 61
 Ventilation, refer to Active 	Slide/tilt glass roof, refer to	Start/Stop button, starting the
seat ventilation and seat	Glass sunroof 43	engine 62
heating 49	Slide/tilt glass roof, refer to	Start/Stop button, switching
Seats, adjusting 45	Panoramic glass sunroof 42	off the engine 62
Seats, backrest width 46	Slot for remote control 61	Starting the engine 62
Seats in the rear 47	Smokers' package, refer to	Start problems, refer to Jump-
Seats, shoulder support 46	Ashtray 130	starting 281
2nd row seats 47	Snap-in adapter, mobile	State/province, selecting for
Selector lever, automatic	phone 225	navigation 153
transmission with Step-	Snap-in adapter, refer to Stor-	Stations, stored 180
tronic 69	age compartment of center	Station, storing 174
Selector lever lock, releas-	armrest 134	Status information, iDrive 21
ing 69	Snow chains 261	Status of Owner's Manual 6
Self-leveling suspension 100	Socket, OBD Onboard Diag-	Steam jets 285
Sensors, care 287	nosis 269	Steering wheel 55
Service and warranty 7	Socket, refer to Connecting	Steering wheel, adjusting 55
Service data in the remote	electrical devices 131	Steering wheel, easy entry/
control 268	Software applications,	exit 55
Service interval display, refer	iPhone 241	Steering wheel lock 61
to Condition Based Service	Software part number 216	Steering with variable transla-
CBS 268	Software update 199	tion, refer to Active steer-
Service interval display, refer	Soot particulate filter, refer to	ing 100
to Service requirements 75	Diesel particulate filter 143	Steptronic, refer to Sport pro-
Service requirements 75	SOS, refer to Emergency Re-	gram and manual mode M/
Service requirements, CBS	quest, initiating 280	S 70
Condition Based Serv-	Sound output 174, 181	Stopping, engine 62
	Spare fuse 279	
ice 268	Special destinations, naviga-	Storage compartment nets 135
Service, Roadside Assis-		
tance 281	tion 156	Storage compart-
	Speed, average 73	ments 134, 135

Storage, tires 261 Storing the seat position, refer to Seat and mirror memorv 53 Storing the vehicle 287 Street, entering for navigation 154 Summer tires, refer to Wheels and tires 252 Summer tires, tread 259 Sunblinds, roller sunblinds 41 Surround View 112 Switches, refer to Cockpit 12 Switching off, engine 62 Switching off, vehicle 62 Switch-on times, parked-car ventilation 126 Symbols 6

Т

Tachometer 72 Tailgate - Comfort Access 38 - Remote control 31 Tailgate, adjusting the opening height 34, 36 Tailgate, automatic operation 36 Tail lamps 271, 274 Tank gauge, refer to Fuel gauge 73 Tasks 232 Technical changes, refer to Safety 6 Technical data 290 Telephone 216 Telephone, adjusting the volume 220 Telephone, installation location, refer to Center armrest 134 TeleService 237 Temperature, adjusting in upper body region 121 Temperature, coolant, refer to

Coolant temperature 72

Temperature display External temperature 71 - External temperature warnina 71 Temperature display, setting the units 80 Temperature, engine oil 72 Temperature, setting with automatic climate control 121, 125 Temperature warning 71 Text messages 230 Theft alarm system, refer to Alarm system 39 Thigh support adjustment 45 Third brake lamp, refer to Center brake lamp 273, 275 Seats, 3rd row seats 47 Tilting the passenger side mirror 54 Time, setting 79 Tire age 258 Tire identification marks 258 Tire inflation pressure 252 Tire inflation pressure, checking 252 Tire pressure monitor, refer to Flat Tire Monitor 88 Tire Pressure Monitor **TPM 90** Tire Quality Grading 258 Tires - Inflation pressure 252 Tires, breaking in 142 Tires, changing 260 Tires, condition 259 Tires, damage 260 Tire size 258 Tires, minimum tread 259 Tires, retreaded tires 261 Tires, run-flat tires 261 Tires, storage 261 Tire tread 259 Toll roads, route 161 Tone 172 Tool kit, refer to Onboard vehicle tool kit 270 Tools, refer to Onboard vehicle tool kit 270

Top View 114 Torque, refer to Engine data 290 Tow bar 283 Tow fitting 283 Towing 282 Town/city, navigation 153 Tow rope 283 Tow-starting 282, 284 TPM Tire Pressure Monitor 90 Traction control 97 Traffic bulletins, navigation 165 Transmission, automatic transmission with Steptronic 69 Transmission positions, automatic transmission with Steptronic 69 Transporting children safely 56 Treble, tone 172 Trip computer, refer to Displays on the Control Display 74 Trip-distance counter, refer to

Trip odometer 71 Triple turn signal activation 66 Trip odometer 71 Trips, planning 159 Trunk lid, refer to Tailgate 36

Turning circle, refer to Dimensions 291 Turning lamps, refer to Adap-

tive light control 82 Turn signal, indicator lamp 14 Turn signals 66

Turn signals, triple turn signal activation 66

U

Uniform Tire Quality Grading/ **UTQG 258** Unintentional alarms, avoiding 40

Units, average fuel consumption 80 Units, temperature 80 Universal garage door opener, refer to Integrated universal remote control 127 Universal remote control 127 Unlocking - From the outside 30 - Setting the unlocking characteristics 30 - Tailgate 38 - Without remote control, refer to Comfort Access 37 Unlocking, from the inside 33 Unlocking, hood 264 Updates made after the editorial deadline 6 Update, software 199 Upholstery care 286 Upper tailgate 33 Upper tailgate, automatic operation 34 Upper tailgate, closing 34 Upper tailgate, emergency operation, refer to Opening manually 34 Upper tailgate, opening from the inside 34 Upper tailgate, opening from the outside 34 Upper tailgate, opening manually 34 USB audio interface 193

V

refer to Connecting electrical devices 131
Vehicle
- Identification number 216
- Identification number, refer to Engine compartment 263
Vehicle battery, changing 278
Vehicle, breaking in 142
Vehicle care 286
Vehicle care, refer to
Care 285

Vacuum cleaner, connecting,

Vehicle jack 276 Vehicle paint 286 Vehicle storage 287 Vehicle, switching off 62 Vehicle wash 285 Ventilation 123 Ventilation, 3rd row seats 123 Ventilation, automatic climate control in rear 125 Ventilation, draft-free 123 Ventilation, in rear 123 Ventilation, refer to Parked-car ventilation 125 Vents of automatic climate control 119 Version of the navigation data 152 Video playback 183 Video playback, iPhone 195 Video playback, snap-in adapter 195 Voice activation Navigation 158 Voice activation, mobile phone 224 Voice activation, short commands 295 Voice activation system 24

W

Volume, setting 172

Warning and indicator lamps 15 Warning messages, refer to Check Control 76 Warning signal volumes 173 Warning triangle 281 Washer/wiper system 67 Washer/wiper system, rain sensor 67 Washer/wiper system, washer fluid 68 Washer/wiper system, windshield washer nozzles 68 Washer fluid 68 Washer fluid reservoir 68 Washing, vehicle 285

Waste tray, refer to Ashtray 130 Water on roads, refer to Driving through water 143 Weights 292 Welcome lamps 81 Wheelbase, refer to Dimensions 291 Wheel change 275 Wheels and tires 252 Wheels, changing 260 Wheels, Flat Tire Monitor **FTM 88** Wheels, Tire Pressure Monitor **TPM 90** Width, refer to Dimensions 291 Window, convenient operation 30 Windows - Safety switch 41 Windows, defrosting and defogging, automatic climate control 121 Windows, pinch protection 41 Windshield, cleaning 67 Windshield, defrosting, refer to Defrosting windows 121 Windshield wash 67 Windshield washer fluid 68 Windshield wash, rear window 68 Windshield wash, reservoir for washer fluid 68 Windshield wash, washer fluid 68 Windshield wash, washer nozzles 68 Windshield wiper blades, changing 270 Windshield wiper, refer to Washer/wiper system 67 Winter diesel 249 Winter storage, care 287 Winter tires, setting the speed limit 78 Winter tires, suitable tires 261 Winter tires, tread 259 Wiper blades, changing 270

Wiper fluid 68
Wood, care 287
Word match concept, navigation 23
Working in the engine compartment 264
Wrench/screwdriver, refer to
Onboard vehicle tool kit 270



xDrive 98 Xenon headlamps 271



Your individual vehicle 6
Your individual vehicle
- Settings, refer to Personal
Profile 28



bmwusa.com