

Owner's Manual

Saab 9-3 Model Year 2009

Safety	11
Security	47
9-3 Convertible	61
Instruments and controls	81
Interior equipment	117
Starting and driving	149
Car care	201
Customer Assistance and Information	277
Technical data	283
Index	297




Introduction

This manual provides practical guidance on driving and caring for your Saab.

Although this manual describes the most important differences between model variants, it does not specify the equipment or features included on individual models.

Importation and distribution of Saab automobiles, spare parts and accessories are handled exclusively by Saab Cars USA, Inc. in the United States and by General Motors of Canada Limited in Canada.

We recommend that you read through the manual before taking the car out for the first time and keep it in the car for future reference.



To find a specific item, use the overviews given at the start of the manual. A list of content is given at the beginning of each section of the manual, and there is also a comprehensive index at the back of the book.

Supplied with the car is a Warranty and Service Record booklet which contains important warranty information and specifies the regular maintenance to be carried out. Also included is a Quick Reference Guide, an Infotainment System manual, tire warranties and (U.S. customers), a dealer directory with Roadside Assistance Program information.

WARNING

Failure to heed warnings may cause personal injury.

NOTICE

NOTICE texts warn of potential damage to the car if the recommendations are not followed.

Since the policy at Saab is one of continual improvement, we retain the right to incorporate modifications and to alter specifications during production without prior notice.



*Asterisk means: equipment not fitted in all cars (can depend on model variant, engine variant, market specification, options or accessories).

If you have any questions concerning your car, its equipment, the warranty conditions, etc., your Saab dealer will be pleased to help, or you may call the Saab Customer Assistance Center in the U.S. at 1-800-955-9007 or email them at saab-crm@saabusa.com. In Canada, please contact the Saab Customer Assistance Center at 1-800-263-1999.

Enjoy the road ahead!

Saab Automobile AB

Saab Automobile AB does not accept liability for any damage caused by the fitting of spare parts, exchange parts or accessories that are not approved by Saab Automobile AB.




Instrument panel

Fuel gauge _____	89
Odometer and trip meter _____	90
Speedometer _____	87
Tachometer _____	87
Temperature gauge _____	88
Turbo gauge _____	88
Warning and indicator lights _____	82
Saab Information Display (SID) _____	89

Cruise Control _____	169
Direction indicators _____	101
High/Low beam switch _____	99

Changing bulbs _____	218
Front fog lights _____	100
Headlight levelling _____	98
High/low beam _____	99
Parking lights _____	98
Rear fog light _____	101



Washers and wipers _____	103
Washer fluid _____	217
Replacing wiper blades _____	216

Automatic climate control _____	107
Hazard warning lights _____	102
Seat heating, ACC _____	114
Car care and maintenance _____	273

Power Outlet _____	134
Cigarette lighter _____	134

B9411

Exterior

Maximum loads _____	284
Mounting holes for roof carriers _____	192
Roof load _____	192

Hood _____	202
Washing the engine bay _____	267

Moonroof _____	128
Touching up paintwork _____	270
Washing _____	267
Waxing and polishing _____	270
Anti-corrosion treatment _____	271
Service program _____	278
Body _____	270

High/Low beam switch _____	97
Direction indicators _____	101
Front lights _____	220
Headlight levelling (xenon) _____	98
Headlight switches _____	97
Headlight washers _____	217
Changing bulbs _____	218

Brake lights _____	225
Light switches _____	97
Taillights _____	225
Changing bulbs _____	218

Central locking _____	48
Child safety locks _____	52
Lock buttons _____	48
Trunk lock _____	51

Folding down the rear seat _____	136
Lighting _____	225
Load-through hatch _____	138
Spare wheel _____	140
Tools _____	140
Trunk _____	136

Braking _____	170
Changing wheels _____	258
Spare wheel _____	256
Tire pressure _____	291
Tires _____	240
Wheels _____	288
Winter driving _____	185

Economical motoring _____	183
Fuel filler door _____	156
Fuel gauge _____	89
Fuel grade _____	287
Refueling _____	156

Towing _____	193
Towing hook eyes _____	193
Towing a trailer _____	188

Interior

Interior rear view mirror _____	123
Vanity mirror _____	132
Door mirrors _____	122

Interior light switches _____	131
Moonroof _____	128
Interior lighting: changing bulbs ____	231

Airbag _____	32
Steering wheel adjustment _	118

Safety belts _____	12
Airbag _____	32
Child safety locks _____	52
Child seats _____	24
Safety belt care _____	266

Fuses _____	233
-------------	-----


Glove box _____	134
Storage compartments _____	134

Electric windows _____	119
------------------------	-----

Automatic transmission ____	162
Changing gears _____	161
Manual transmission _____	161

Safety belts _____	12
Child seats _____	24
Folding down the rear seat _____	136
Rear seat _____	136
Seat adjustment _____	18
Seat heating _____	114
Upholstery care _____	266

Ignition switch _____	150
Starting the engine _____	152
Power Outlet _____	134
Break-In Period _____	160
Driving in hot/cold climates _____	185
Parking brake _____	177
Parking _____	177



B4412

6

Engine bay, 4-cyl

Color code _____	292
Engine number _____	292
Gearbox number _____	292
Warning labels _____	8
Vehicle identification number _____	292

Ignition system _____	287
Alternator _____	215
Drive belt _____	215
Exhaust emission control _____	154
Simple troubleshooting (ACC) _____	273
Spark plugs _____	287
Turbo gauge _____	88

Engine oil: checking level _____	208
----------------------------------	-----

Automatic transmission _____	162
Manual transmission _____	161

Oil grade and viscosity _____	286
Engine: description _____	203
Engine: technical data _____	286
Important considerations for driving _____	153

Power steering _____	213
Fluid: checking/topping up _____	213


Coolant: checking/topping-up _____	210
Driving in hot climates _____	187
Radiator _____	286
Temperature gauge _____	88

ABS brakes _____	170
Brake pads _____	212
Brake system _____	287
Brake fluid _____	212

Fuse table _____	238
Changing a fuse _____	233
Fuses _____	233
Relays _____	238

Wash/wipe stalk switch _____	103
Washer fluid _____	217
Washer jets _____	217
Topping-up fluid _____	217

Battery _____	214
Jump starting _____	197
Battery charge _____	214



B1447

Warning labels



Radiator fan

Radiator fan may start at any time.

A/C system

Refrigerant at high pressure.

Do not loosen or remove the A/C system fittings before discharging the A/C system. Improper service methods may cause personal injury. **System to be serviced by qualified personnel only.** For instructions consult dealer manual.

The A/C system complies with SAE J639.

Charge: 4 cyl. - 680 g and 6 cyl. - 650 g R134a.


Compressor oil: 150 cc PAG oil SP-10 alt.

Saab oil 4759106



Battery

- No sparks, naked flames or smoking
- Always shield eyes. Explosive gases can cause blindness or injury
- Keep the battery out of reach of children
- The battery contains sulfuric acid which could cause blindness or serious burn injuries
- See the Owner's Manual for further information
- Explosive gas may be present in the vicinity of the battery.



CANADA
NETTOYER LE BOUCHON DE REMPLISSAGE AVANT DE L'ENLEVER. UTILISER SEULEMENT DU LIQUIDE DOT 4 PROVENANT D'UN CONTENANT SCÉLLÉ.



Coolant

Never open when engine hot!

WARNING

EVEN WITH ADVANCED AIR BAGS

- Children can be killed or seriously injured by the air bag.
- The back seat is the safest place for children.
- Never put a rear-facing child seat in the front.
- Always use seat belts and child restraints.
- See owner's manual for more information about air bags.



MÊME AVEC DES SACS GONFLABLES INTELLIGENTS

- Les enfants peuvent être tués ou gravement blessés par le sac gonflable.
- Le siège arrière est l'endroit le plus sûr pour les enfants.
- Ne jamais placer à l'avant un dispositif de protection pour enfant faisant face à l'avant.
- Toujours utiliser les ceintures de sécurité et les ensembles de retenue pour enfant.
- Voir le Guide du propriétaire pour plus d'information à propos des sacs gonflables.


EVEN WITH ADVANCED AIR BAGS

- Children can be killed or seriously injured by the air bag.
- The back seat is the safest place for children.
- Never put a rear-facing child seat in the front.
- Always use seat belts and child restraints.



Contact a Saab dealer if a xenon headlight requires replacement.

This label is only found on cars with xenon headlights.



Changing wheels

- Use only on specified vehicle.
- Safe working load 2425 lbs. (1100 kg).
- Use on level firm ground only.
- Do not get under a vehicle that is supported only by a jack, use vehicle support stands.



All-wheel drive cars
Do not test this vehicle on a 2-wheel dynamometer.

Safety



Safety belts _____	12
Seats _____	18
Head restraints _____	23
Child safety _____	24
Airbag _____	32

* Asterisk means: equipment not fitted in all cars (can depend on model variant, engine variant, market specification, options or accessories).

12 Safety

Safety belts

WARNING

- Buckle up and adjust your safety belt before driving off so that you can pay full attention to the traffic.
- Safety belts must be worn **at all times** by all occupants.
- Child safety, see page 24.
- Check that the locking tongue is properly locked in the belt lock.
- In the event of a crash, a rear-seat passenger not wearing a safety belt will be thrown forward against the front-seat backrests. The stresses imposed on the front seat passengers and belts are multiplied and can result in needless injury or even death for all car occupants.

Three-point inertia-reel safety belts are provided for all seats.

The results of studies show that it is equally important to wear safety belts in the rear seat as in the front seats.

Safety belt reminder

When the ignition is switched on, the safety belt reminder will come on if the driver or/and the front seat passenger has not buckled up.

The reminder for the driver is in the main instrument and for the front seat passenger on the instrument panel.

The reminder for the driver has an additional audible signal which sounds for 6 seconds, or until the driver fastens his belt.

The following applies to the both front seats: If the belt is not fastened before the car starts to move there will be an additional reminder when the speed exceeds 15 mph. The text **Use your seat belt.** is lit on the Saab Information Display (SID) and the symbol will flash.


If the belt is not fastened then an audible signal will come on after 30 seconds.

The text in the SID can be turned off by the CLR-button on the steering wheel.



Driver seat safety belt reminder

Passenger seat safety belt reminder





Correct seating position

Correct position for safety belt

WARNING

Proper positioning of the safety belt is extremely important.

- An out of position safety belt can result in the wearer sliding underneath the belt in a crash (submarining) and injury can result from the lap portion cutting into the abdomen.
- **Never** fasten the safety belt with the shoulder belt behind the body or pull the belt off the shoulder and under the arm.
- Two people must **never** share one safety belt. In the event of a crash those sharing a belt risk being crushed together and injured.

Consider this:

- Position the lap strap snugly and low across the hips so that it just touches the thighs. The shoulder strap must be as far in on the shoulder as possible.

- Check to ensure that the belt is not twisted or rubbing against any sharp edges.
- There should not be any slack in the belt. Pull the belt tight – particularly important when thick outer clothing is worn. It is advisable to remove thick items of clothing.
- Refrain from tilting the backrest more than necessary, as the safety belt provides better protection when the seat is in the more upright position.
- Only one person per safety belt!
- For most of the time a safety belt is worn, the retractor will allow the wearer freedom of movement. The retractor locks up automatically if the belt is jerked or withdrawn sharply, the car tilts, the brakes are applied hard or a crash occurs.
- Children up to 6 years of age must always be seated in a child seat. Saab recommends the use of a child seat for children up to the age of 10.
- Children who have grown out of a child seat should be restrained by the car's standard three-point belts. Make sure that the shoulder belt is not in contact with the neck or throat. If it is, a booster seat/cushion may be necessary.


14 Safety



To fasten the belt



Press the red button to release the belt



The belt guide on door pillar, SportSedan and SportCombi

Front safety belts

Fasten the belt by pulling the belt and inserting the tongue in the buckle. Check that it is securely fastened.

Position the lap part low across the hips.

Grasp the shoulder belt close to the buckle and pull the belt towards the shoulder to tighten the lap belt part.

The belt must be as far in on the shoulder as possible.

Press the red button on the belt buckle to release the belt.

The front safety belts have their lower anchorage points on the seats. The safety belts follow the seats when the legroom is adjusted.


Refer to page 266 for how to check the function of the safety belts, cleaning, etc.

Belt height adjustment, SportSedan and SportCombi

The belt guide on the door pillar for the front safety belts can be set at different heights. The front belt guide in the Convertible is not adjustable due to the belt being incorporated into the seat.

Adjust the belt so that it is as high up as possible without rubbing against the neck. To avoid chafing in the case of a short person, the guide can be lowered until the belt comes about an inch (a few centimeters) from the throat but still provides safe restraint.

Raise the belt guide by pushing it upward to the desired position. To lower it, depress the catch release button while lowering the guide. Check that the guide locks in its new position.



Safety belt use during pregnancy

Pregnant women must **always** wear a safety belt to protect both themselves and the unborn child.

The lap belt should be placed low, across the hips and over the upper thighs.

16 Safety

Safety belt pretensioners

WARNING

If the car is involved in a crash, the safety belts, belt pretensioners and other components must be inspected and replaced as necessary. We recommend that you contact a Saab dealer.

Never make any alterations or repairs to the safety belt yourself. We recommend that you contact a Saab dealer for any necessary repairs.

SportSedan and SportCombi: The front safety belts are equipped with pretensioners and force limiters. The pretensioners are activated in the event of a violent frontal or side-on crash. The safety belt pretensioners are only activated if the safety belt in question is in use but not activated should the car roll over.

The safety belt pretensioners serve to reduce the forward movement of the body by tensioning the belt. The force limiters reduce belt loads on the body by "slackening" the safety belt slightly to absorb the body's kinetic energy as gradually as possible.

Convertible: The front and rear safety belts are equipped with pretensioners and force limiters. The pretensioners are activated in the event of a violent frontal or side-on crash. The front safety belt pretensioners are only activated if the safety belt in question is in use.

The safety belt pretensioners serve to reduce the movement of the body by tensioning the belt, including in a roll over crash. The force limiters reduce belt loads on the body by "slackening" the safety belt slightly to absorb the body's kinetic energy as gradually as possible.

Safety belts, rear seat, SportSedan and SportCombi

Safety belts rear seat, Convertible, see page 75.


WARNING

- Make sure that the belt does not become trapped when the backrest is folded down or raised (see page 136).
- If cargo has to be placed on a seat, it must be properly secured with the safety belt. This reduces the risk of the cargo being thrown about during hard braking or a crash, which could cause personal injury.
- Check that the belt is not twisted or lying against sharp edges.
- Make sure you use the correct safety belt buckle. The buckles for the center and left-hand rear seats are close together.

The three rear seats all have three-point safety belts with inertia reels.

Fasten the belts by pulling the belt across you and inserting the tongue into the buckle. Check that it is securely fastened.

Grasp the shoulder belt close to the buckle and pull the belt towards the shoulder to tighten the lap belt part.




Rear safety belts, SportSedan and SportCombi

The belt must be as far in on the shoulder as possible.

Press the red button on the buckle to release the belt.

See page 266 for the **checking of belt function, cleaning, etc.**

Securing an item on the rear seat



18 Safety

Seats

⚠ WARNING

Never adjust the driver's seat except when the car is stationary.

Manually adjusted front seats *

The following front seat adjustments can be made to achieve a comfortable driving position:

- **Height ***
- **Legroom**
- **Backrest rake angle**
- **Lumbar support firmness ***
- **Head restraint height**

We recommend that adjustments to the driver's seat be performed in the following order:

- 1 Height
- 2 Legroom
- 3 Backrest rake angle
- 4 Head restraint height


Lastly, adjust the position of the steering wheel (see page 118).

Electrically adjustable front seats *

See page 20.

Electric heating, front seats *


See pages 114.



Height adjustment *

Lift the lever to raise the seat. The lever is spring-loaded to return to its neutral position. Repeated lifting of the lever will increase the height in steps.

Press down the lever to lower the seat. Repeated downward presses of the lever will lower the seat in steps.




Adjusting the legroom

Legroom adjustment

Lift the lever under the front of the seat and slide the seat to the desired position.

WARNING

Check that the seat is locked in the new position. If not, it may move while the car is being driven and it could result in injury to the occupant in the event of a crash.




Adjusting the backrest

Backrest rake angle

WARNING

The backrest should be upright during driving, so that the safety belt, airbag and backrest can provide optimum protection in the event of emergency braking or a crash, in particular a rear-end crash.

To find the most comfortable position, turn the knob to provide stepless adjustment of the backrest.



Adjusting the lumbar support

Lumbar support *

Adjust the firmness of the lumbar support by turning the knob.

20 Safety

Electrically adjustable front seats ✱


⚠ WARNING

- The seats are actuated by powerful motors. Bear this in mind when adjusting the seat, and make sure that nothing gets caught and damaged. Ensure that nothing can be trapped behind the seat when adjusting it.
- Bear in mind that children can be injured if they play with the electrically-operated seats.
- **Always** remove the remote control when you leave the car to prevent personal injury caused by the electrically adjustable seats, for example, due to children playing. Electrically adjustable front seats with memory function, see page 21.

With the doors closed the seats can only be adjusted when the ignition is ON.

However, there are two exceptions:

- To facilitate getting into the car, both seats can be adjusted when either of the front doors is open.
- The seats can be adjusted up to 2 minutes after both doors have been closed (applicable only to cars without window and sunroof pinch protection).




Adjusting the height and angle

Height adjustment and seat angle

Adjust the height of the seat with the rear section of the front lever.


Adjust the angle of the seat with the front section of the front lever.




Adjusting the legroom

Legroom adjustment

Adjust the legroom with the front lever.



Adjusting the rake angle



*Adjusting the lumbar support
Driver's seat in SportSedan and Sport-
Combi*



Memory function buttons

Backrest rake angle

WARNING

The backrest should be upright during driving, so that the safety belt, airbag and backrest can provide optimum protection in the event of emergency braking or a crash, in particular a rear-end crash.

Adjust the rake angle of the backrest with the rear lever.


Lumbar support *

Adjust the firmness of the lumbar support by turning the knob.

Memory function *

WARNING

The legroom of the electrically operated driver's seat can always be adjusted, whether or not a front door is open and irrespective of the position of the ignition switch.



22 Safety

When the ignition is ON, all seat settings can be adjusted. When the door is open and before the remote control has been inserted into the ignition switch, all seat settings can be adjusted for up to 20 minutes.





The memory also includes the door mirror settings.

Storing and restoring settings

- 1 Adjust the seat and the door mirrors. The lumbar support is not included by the memory function.
- 2 Press and hold the M-button and then press one of the preselect buttons (1, 2 or 3). A chime will sound to confirm that the settings have been saved.

To recall programmed settings, press and hold the desired memory button until the seat and door mirrors adopt their programmed positions. The memory function also includes the door mirror settings.

To facilitate reversing, the passenger-side door mirror can be angled down, refer to page 122.



Head restraints

SportSedan and SportCombi

Head restraint, Convertible, see page 74.

WARNING


- Adjust the head restraint so that the head is optimally supported and the center of the head restraint is at ear height, thus reducing the likelihood of neck injury in a crash.
- Raise the head restraints in the seats that are occupied.

The front seats are equipped with Saab Active Head Restraints (SAHRs). These are designed to reduce the risk of neck injury if the car is hit from behind.

The SAHR is a mechanical system, actuated by body weight. The mechanism is built into the top of the backrest, where it is connected to the head restraint.


In the event of a rear-end crash, the body is forced back against the backrest. This, in turn, causes the mechanism to press the head restraint forward and upward, thus limiting the backward movement of the head.

Therefore, the SAHR does not normally need to be replaced or repaired after a rear-end crash.



The front and rear head restraints can be raised and lowered to a number of positions.

- Raising: grasp the head restraint on both sides and pull it straight up.
- Lowering the front head restraints: press in the **left** catch and press the head restraint down.



- Lowering the rear head restraints: press the head restraint forward and downward.

The rear head restraints can be fully lowered to improve rearward vision when the rear seats are unoccupied.

Child safety

WARNING



- Children can be killed or seriously injured by the airbag
- The **BACK SEAT** is the **SAFEST** place for children 12 and under or shorter than 55 inches (140 cm)
- **ALWAYS** use **SAFETY BELTS** and **CHILD RESTRAINTS**
- **NEVER** put a rear-facing child seat in the front
- Sit as far back as possible from the airbag

Car safety tips

WARNING

- **Never** leave children unattended in a car, even for a short time.
 - Children can suffer heat stroke, perhaps die, in a matter of minutes.
 - Children can put the car into gear and hurt themselves or others.
- At gas stations, take the remote control out of the car while filling the tank.
- **Never** allow children to climb on top of or under motor vehicles.
- **Always** look for children before backing your car out of a garage or driveway.
- To avoid carbon monoxide poisoning, **never** let a car idle in an enclosed garage.
- Supervise young children around buckets of water while washing your car. Small children can drown in a short time in less than an inch of water.

WARNING

Protect children from getting trapped in the trunk of your car

- Teach children not to play in or around cars.
- Watch children when loading or unloading the car so they don't get locked in by mistake.
- **Always** lock the doors and trunk of your car, and keep the keys out of children's sight and reach.
- Keep the rear fold-down seat closed to help prevent children from getting into the trunk from inside the car.

For **Trunk Release Handle** information see page 53 and 139.

General information on child safety

The same attention must be given to child safety in the car as is given to adults.

Children travel most safely when properly restrained. However, the type of restraint must be appropriate for the size of the child. We recommend that you always consult your Saab dealer before fitting a child seat, child restraint or booster cushion.

The backseat is the safest place for children.

Make sure you are acquainted with the legal requirements for seating children in the car.

When fitting child restraints in cars you must always read the instructions supplied by the child restraint manufacturer.

Make sure that it is possible to fit a child restraint in accordance with the manufacturer's child restraint instructions.

Saab recommends the use of a rear-facing child seat for as long as this is possible - for all children under 18 kg (40 lbs.) as a minimum. Use a child seat approved for the weight of the child.

Saab recommends the use of a booster seat for children up to the length of 140 cm (55 in.) or the weight of 36 kg (80 lbs.).

LATCH

LATCH (Lower Anchorages & Top tethers for CHildren) is a US/Canadian safety standard for a uniform method of fitting child restraints without using the standard safety belts. Only certain child restraints are equipped to utilize the LATCH system.

The LATCH system is installed in the car to facilitate proper fitting of child restraints designed for and equipped with LATCH attachments.

The LATCH system consists of top tether and lower anchorages. In this vehicle, LATCH is installed at the two outboard seating positions in the rear seat, and there is a top tether on the rear center position (not Convertible).

The top tethers are located on top of the parcel shelf (SportSedan), see page 28, on the back of the rear seat (SportCombi), see page 29 and behind the head restraints (Convertible) see page 30.

The lower anchorages are located where the seat cushion and seat back come together. There is a label above the anchorages, see picture on next page. Label consists of a symbol of a child restrained in a seat inside a circle.

When fitting child restraints in cars you must always read the instructions supplied by the child restraint manufacturer.

If you have any questions regarding LATCH please contact your Saab dealer.

WARNING


If a LATCH-type child restraint is not attached to its anchor points, the restraint will not be able to protect the child correctly. In a crash, the child could be seriously injured or killed. Make sure that a LATCH-type child restraint is properly installed using the anchor points, or use the vehicle's safety belts to secure the restraint, following the instructions that came with that restraint, and also the instructions in this manual.

WARNING


Child top tether anchorages are designed to withstand only those loads imposed by correctly fitted child restraints.

Under no circumstances are they to be used for adult safety belts.

26 Safety




Lower anchorages in the rear seat, SportSedan and SportCombi



Lower anchor and top tether anchor locations, SportSedan and SportCombi. Convertible has two top tether anchors, one behind each head restraint

Lower anchorages in the rear seat, Convertible



(Lower Anchor): Seating positions with two lower anchors.

(Top Tether Anchor): Seating positions with top tether anchors.


The right side and left side rear passenger seating positions have exposed metal anchors located in the crease between the seatback and the seat cushion.

LATCH child seat installation


Before starting the installation, please read through this instruction, and the child seat installation instruction.

- 1 Place the child restraint on one of the designated outboard rear seat cushions.
- 2 Slide the attachment on the child restraint in between the seat cushion and backrest.
- 3 Press the child restraint down on the seat, **1** in illustration.
- 4 Press the child restraint rearward, lining up the inner restraint attachment arm with the label, **2** in illustration.
- 5 Connect the restraint attachment arms to the anchorages **3** in illustration.
- 6 Follow the child restraint instructions to confirm that both restraint attachment arms are properly attached to the bars.
- 7 Attach the top tether strap to the in-car anchorage and tighten according to the restraint instructions, see page 28 and 30.
- 8 Pull the child restraint to make a second check that the restraint is securely attached at both the lower anchorage bars and the top tether strap.

For the top tether, only use the strap supplied with the child restraint.



Rigid 2-point lower anchorage with top tether



Semi-rigid 2-point lower anchorage with top tether

When fitting child restraints in cars you must always read the instructions supplied by the child restraint manufacturer.

Use the integrated harness to restrain the child, according to the child restraint manufacturer's instructions.

The availability of LATCH child restraints is limited.

28 Safety

Child top tether anchorages for forward facing child seats

SportSedan



! WARNING

Child top tether anchorages are designed to withstand only those loads imposed by correctly fitted child restraints.


Under no circumstances are they to be used for adult safety belts.

Child restraints with a tether strap must be attached according to Canadian and U.S. safety standards.

If you have any questions regarding child anchorages please contact your Saab dealer.

The car is provided with three top tether anchorages. Use the one that is right behind the seating position in which the child restraint is to be installed and attach the restraint as follows:

- 1 Open the cover that is right behind the child restraint, **1** in illustration.
- 2 Place the child restraint in the rear seat.
- 3 Secure the lower part of the child restraint by means of the lower anchor-



Child top tether anchorages in parcel shelf, SportSedan

ages or the safety belts as described in the child restraint installation instruction.

- 4 Lower the headrest and route the tether over it.
- 5 Attach the tether to the anchorage, **2** in illustration.
- 6 Close the cover to the middle position, **3** in illustration.
- 7 Tighten the tether so that the back of the child restraint is pressed hard against the backrest.
- 8 Pull the child restraint to make a second check that the restraint is securely attached at both the lower anchorages bars on the safety belts and the top tether strap.

Child top tether anchorages for forward facing child seats

SportCombi



! WARNING

Child top tether anchorages are designed to withstand only those loads imposed by correctly fitted child restraints.


Under no circumstances are they to be used for adult safety belts.

If a cargo net is fitted, do not pull the top tether strap through the cargo net in such a way that there is slack in the strap to the child seat.

Child restraints with a tether strap must be attached according to Canadian and U.S. safety standards.

If you have any questions regarding child anchorages please contact your Saab dealer.

The top tether anchors are located on the back of the rear seat frame above the floor for each rear seating position.



Child top tether anchorages, SportCombi

The car is provided with three top tether anchorages. Use the one that is right behind the seating position in which the child restraint is to be installed and attach the restraint as follows:

- 1 If the anchor for the desired seating position is not in the upright position then fold down the rear seatback(s) to access the anchor(s).
- 2 Fold the backrest back upright.
- 3 Place the child restraint in the rear seat.
- 4 Secure the lower part of the child restraint by means of the lower anchorages or the safety belts as described in the child restraint installation instruction.
- 5 Lower the headrest and route the tether over it.
- 6 Attach the tether to the anchorage.
- 7 Tighten the tether so that the back of the child restraint is pressed hard against the backrest.
- 8 Pull the child restraint to make a second check that the restraint is securely attached at both the lower anchorages bars on the safety belts and the top tether strap.

30 Safety

Child top tether anchorages for forward facing child seats

Convertible



! WARNING

Child top tether anchorages are designed to withstand only those loads imposed by correctly fitted child restraints.


Under no circumstances are they to be used for adult safety belts.

Child restraints with a tether strap must be attached according to Canadian and U.S. safety standards.

If you have any questions regarding child anchorages please contact your Saab dealer.

The car is provided with two top tether anchorages. Use the one that is right behind the seating position in which the child restraint is to be installed and attach the restraint as follows:


- 1 Remove the head restraint on the seating position where the child restraint shall be fitted.
- 2 Place the child restraint in the rear seat.



How to take away the head restraint

- 1 Raise the head restraint
- 2 Push the catch forward and pull the head restraint straight upward

- 3 Secure the lower part of the child restraint by means of the lower anchorages or the safety belts as described in the child restraint installation instruction.
- 4 Attach the tether to the anchorage.
- 5 Tighten the tether so that the back of the child restraint is pressed hard against the backrest.
- 6 Pull the child restraint to make a second check that the restraint is securely attached at both the lower anchorages bars on the safety belts and the top tether strap.



Top tether anchorages in the rear seat

- 7 Put the head restraint back on and make sure it is securely mounted. Adjust it in its highest position.

! WARNING

If the size of the child restraint makes it impossible to put the head restraint back on, place it in the trunk.

Installation of child restraint using the standard safety belt

WARNING

Failure to follow all the manufacturer's instructions on the use of child restraint systems can cause your child to strike the vehicle's interior during a sudden stop or crash.

Child restraints that are approved for rearward facing installation in the rear seat can be positioned in any of the three rear places.

Make sure that it is possible to fit it in accordance with the manufacturer's instructions.

When fitting child restraints in cars you must always read the instructions supplied by the child restraint manufacturer.

If fitting a child restraint that is intended to be secured in position by the standard safety belt, make use of the locking function of the belt.

Locking the belt lessens the risk that the seat will work loose while the car is in motion.

- 1 Position the child restraint in the back seat.
- 2 Route the belt in the restraint according to the installation instruction of the restraint.
- 3 Pull out the belt completely until it stops. Then let the belt slowly pull in the slack. Clicking sound indicates that the lock function is in work.
- 4 Pull the shoulder belt tight to secure the child restraint in position.
- 5 Check for correct locking function by pulling on the belt. The belt must not unreel.

The safety belt locking function will be deactivated when the safety belt is retracted.

- 1 Disengage the safety belt latch from the buckle.
- 2 Disengage the safety belt from the child restraint, according to the instructions from the child restraint manufacturer.
- 3 Let the safety belt retract until the clicking sound ceases.

32 Safety

Airbag



WARNING

To reduce risk of death or serious injury:

- **Always** wear your safety belt.
- **Always** adjust your seat so that you are as far back as possible but still able to operate the pedals and reach the steering wheel and controls comfortably.
- Passengers 12 and under or shorter than 59 inches (150 cm) must **always** travel in the rear seat as the car is fitted with a passenger airbag.
- **Never** fit a child seat in front of the passenger airbag.

Airbag system components

- Airbag in steering wheel
- Airbag in instrument panel in front of passenger seat
- Side airbags in front seat backrests
Convertible: The side airbags help protect the head also
- Inflatable curtains along length of headlining (from front to rear roof pillars) (SportSedan and SportCombi only)
- Safety belt pretensioners for front seats
Convertible: and outer rear seats.

The airbag system supplements the protection provided by the safety belts to further enhance the safety of occupants taller than 59 in. (150 cm).

When the system is activated at the moment of impact, the airbag inflates and then deflates through holes in the back. The whole operation takes roughly 0.1 second, quicker than the blink of an eye.

The steering wheel and passenger airbags are so-called smart airbags. The driver and passenger airbag system compensates for safety belt usage and the force of the crash at the moment of impact.

There are two impact sensors on the front bumper, under the lacquered shell. Very soon after the moment of impact, these register that the car is involved in a crash. Using this information and data from the central sensor in the control module, the control module determines whether or not to inflate the airbags. The control module also controls whether other components of the airbag system are to be deployed: safety belt pretensioners, inflatable curtains (SportSedan and SportCombi) and roll over bars (Convertible).


Which airbag system components are deployed depends on a number of factors, such as the force of the crash and the angle of impact.

If the airbag system registers forces equivalent to a high-speed crash (airbags inflated to Stage II), the inflatable curtains will also be activated (SportSedan and SportCombi) see page 42.


If a fault arises in the airbag system during a journey, the airbag warning lamp on the main instrument panel will come on and the Saab Information Display (SID) will display:



**Airbag malfunction.
Contact service.**



*Inflated airbag (driver's side).
Inflation and deflation of airbag takes
approx. 0.1 s*



Both front airbags inflated

When the airbag system is activated all of the doors are unlocked while the interior/exterior lighting and the hazard warning lights are illuminated at the same time.

The driver and passenger front airbags are triggered by violent front-end crashes. They are not activated by minor front-end impacts, if the car overturns or by rear- and side-impacts.


The car is equipped as standard with a passenger airbag.

Note

Impact sensors react differently depending on whether or not the front safety belts on the driver's and passenger sides are used. Situations can therefore arise where only one of the airbags inflates. It is also possible for only the safety belt pretensioners to be activated and for the airbags to remain uninflated.


If only Stage I is activated at the moment of impact, Stage II will automatically be activated later to neutralize the gas generator in the airbag.

34 Safety



Airbag system

- 1 Steering wheel with integral airbag
- 2 Passenger airbag
- 3 Side airbag
- 4 Inflatable curtain (SportSedan and SportCombi)
- 5 Sensors in front bumper
- 6 Sensor, side-impact protection
- 7 Sensor, side-impact protection (SportSedan and SportCombi)
- 8 Electronic control module and central sensor (SDM)



Accessories and other equipment must not be fitted to the surfaces marked as these are where the airbags inflate in the event of a crash.

 **WARNING**


- Even if the car is equipped with AIR-BAGS, safety belts must still **always** be worn by **all** occupants.
- Note that because an airbag inflates and deflates extremely rapidly, it will not provide protection against a second impact occurring in the same incident. **Always** use your safety belt.
- Always sit with the whole of your back in contact with the backrest of the seat, and with your seat as far back as is practical. Otherwise you will be thrown back against the backrest when the airbag inflates which could cause you injury or death. The airbag needs room in which to inflate.

- Never attach anything to the steering wheel or passenger side of the instrument panel, as this could result in injury if the airbag should inflate. The same applies to anything you might have in your mouth, such as a pipe, for instance.
- Some components of the airbag will be warm for a short time. In some circumstances the airbag can cause minor burns or abrasions to the body when the airbag inflates/deflates.
- Never rest your hands or forearms on the steering-wheel center padding.

- If the airbag warning light  remains on after the car has been started or comes on while you are driving, have the car checked immediately. We recommend that you contact a Saab dealer. The warning light could signify that the airbags may not inflate in a crash, or they could even inflate without a crash. See page 85.
- Fumes are generated by the chemical reaction that inflates the airbag. Skin surfaces that show signs of irritation should be washed with clean water and a mild soap as soon as possible. In the event of eye irritation, flush the eyes thoroughly with clean water for at least 20 minutes. In case of persistent irritation, consult a doctor.

36 Safety


Operation of the steering wheel airbag in a front-end crash



Moment of impact.



Sensors detect a deceleration and send a signal via the control module to a gas generator that inflates the airbag.



The inflating airbag cushions the driver.



Airbag now fully inflated.



The airbag starts to deflate.

Front passenger seat



WARNING

Never secure a rear-facing child seat in the right front seat of a car equipped with a passenger airbag. Inflation of the airbag in the event of a crash could seriously injure or kill a child.

The system is the same as that used on the driver's side.

The airbag systems are interconnected and have a common warning light . The passenger airbag module is housed in the fascia above the glove box and is marked "AIRBAG".

Both airbags will be inflated in the event of a moderate to severe frontal, or near-frontal crash, even if the passenger seat is unoccupied.

The car is equipped as standard with a passenger airbag.

WARNING



• Children can be killed or seriously injured by the airbag

- The **BACK SEAT** is the **SAFEST** place for children 12 and under or shorter than 55 inches (140 cm)
- **ALWAYS** use **SAFETY BELTS** and **CHILD RESTRAINTS**
- **NEVER** put a rear-facing child seat in the front
- Sit as far back as possible from the airbag
- **Never** allow a child to stand in front of the seat or to sit on the lap of a front seat passenger. Serious injury or death could result if the airbag is inflated in a crash.
- The glove box must be closed while travelling. An open glove box door could cause leg injuries in the event of a crash.
- Never place anything on the dash or in front of the seat as, in addition to being a hazard to passengers, this could interfere with the function of the airbag in the event of a crash. The same applies to the mounting of accessories on the dash.

- Keep feet on the floor – never put feet up on the dash, on the seat or out of the window.
- Do not carry anything in your lap.

Passenger Sensing System


Vehicles with a passenger sensing system have indicator LEDs on the fascia. The indicators will be lit during the system check when you turn the ignition switch to ST or ON. When the system check is complete, either the ON or the OFF LED, will be lit. See Airbag warning light on page 85.

The passenger sensing system will turn off the right front passenger's frontal airbag and side airbag under certain conditions.

The driver's airbags is not part of the passenger sensing system.


The passenger sensing system works with sensors that are part of the right front passenger's seat and safety belt. The sensors are designed to detect the presence of a properly-seated occupant and determine if the passenger's frontal airbag should be enabled (may inflate) or not.

Accident statistics show that children are safer if they are restrained in the rear rather than the front seat.



Passenger Airbag Status Indicator, U.S.

Passenger Airbag Status Indicator, Canada



38 Safety

Saab recommends that child restraints be secured in a rear seat, including an infant riding in a rear-facing infant seat, a child riding in a forward-facing child seat and an older child riding in a booster seat.

Your vehicle has a rear seat that will accommodate a rear-facing child restraint. A label on your sun visor says, "Never put a rear-facing child seat in the front." This is because the risk to the rear-facing child is so great, if the airbag deploys.

WARNING

A child in a rear-facing child restraint can be seriously injured or killed if the right front passenger's airbag inflates. This is because the back of the rear-facing child restraint would be very close to the inflating airbag.

Even though the passenger sensing system is designed to turn off the passenger's frontal airbag if the system detects a rear-facing child restraint, no system is fail-safe, and no one can guarantee that an airbag will not deploy under some unusual circumstance, even though it is turned off. Saab recommends that rear-facing child restraints be secured in the rear seat, even if the airbag is off.

The passenger sensing system is designed to turn off the right front passenger's frontal airbag if:

- the right front passenger seat is unoccupied
- the system determines that an infant is present in a rear-facing infant seat
- the system determines that a small child is present in a forward-facing child restraint
- the system determines that a small child is present in a booster seat
- a right front passenger takes his/her weight off of the seat for a period of time
- the right front passenger seat is occupied by a smaller person, such as a child who has outgrown child restraints
- or if there is a critical problem with the airbag system or the passenger sensing system.

When the passenger sensing system has turned off the passenger's frontal airbag, the off indicator will light and stay lit to remind you that the airbag is off.

Saab recommends that child restraints be secured in a rear seat, but if a child restraint has been installed and the on indicator is lit, turn the vehicle off. Remove the child restraint from the vehicle and reinstall the child restraint following the child restraint manufacturer's directions and refer to Installation of child restraint using the standard safety belt on page 31.

If after reinstalling the child restraint and restarting the vehicle, the on indicator is still lit, check to make sure that the vehicle's seatback is not pressing the child restraint into the seat cushion. If this happens, slightly recline the vehicle's seatback and adjust the seat cushion if possible. Also make sure the child restraint is not trapped under the vehicle head restraint. If this happens, adjust the head restraint.

If the on indicator is still lit, secure the child in the child restraint in a rear seat position in the vehicle and check with your dealer.

The passenger sensing system is designed to enable (may inflate) the right front passenger's frontal airbag anytime the system senses that a person of adult size is sitting properly in the right front passenger's seat. When the passenger sensing system has allowed the airbag to be enabled, the on indicator will light and stay lit to remind you that the airbag is active.

For some children who have outgrown child restraints and for very small adults, the passenger sensing system may or may not turn off the right front passenger's frontal airbag, depending upon the person's seating posture and body build. Everyone in your vehicle who has outgrown child restraints should wear a safety belt properly — whether or not there is an airbag for that person.

If a person of adult-size is sitting in the right front passenger's seat, but the off indicator is lit, it could be because that person is not sitting properly in the seat. If this happens, turn the vehicle off and ask the person to place the seatback in the fully upright position, then sit upright in the seat, centered on the seat cushion, with the person's legs comfortably extended. Restart the vehicle and have the person remain in this position for about two minutes. This will allow the system to detect that person and then enable the passenger's airbag.

 **WARNING**

If the airbag readiness light in the instrument panel cluster ever comes on and stays on, it means that something may be wrong with the airbag system. If this ever happens, have the vehicle serviced promptly, because an adult-size person sitting in the right front passenger's seat may not have the protection of the frontal airbag. See Airbag warning lamp on page 43 for more on this, including important safety information.

Aftermarket equipment, such as seat covers, can affect how well the passenger sensing system operates. You may want to consider not using seat covers or other aftermarket equipment if your vehicle has the passenger sensing system. See Adding Equipment to Your Airbag-Equipped Vehicle for more information about modifications that can affect how the system operates.

 **WARNING**

Stowing of articles under the passenger's seat or between the passenger's seat cushion and seatback may interfere with the proper operation of the passenger sensing system.

40 Safety

Head protection

The pillar trim and headlining (not Convertible soft top) are designed to absorb energy, softening possible blows to the head. After a crash, these items must be changed in the seat positions that were occupied. Never fit accessories to the pillar trim or headlining as these could reduce the effectiveness of the head protection and inflatable curtain (SportSedan and SportCombi).

Side-impact protection



WARNING

- This car is equipped with side airbags and no extra seat cover should be fitted. Failure to observe this warning could result in the side airbags not inflating as intended and thus not providing the intended protection either.
- Never place any object in the area that would be occupied by the inflated airbag.
- For optimum protection, sit upright in the seat, with your safety belt correctly fastened.

- The side-impact protection will only be activated in the event of a side-on crash and not in the event of a rear-end crash or the car rolling over. For the Convertible's Roll-over protection see page 76.

- Damage or wear to the seat cover, or the seat seam, in the area of the side airbag must be repaired immediately. We recommend that you contact a Saab dealer.


The side airbags, which help protect the upper body (head also in Convertible), are integrated in the outside edges of the front seat backrests. The side impact protection of the SportSedan and SportCombi also includes inflatable curtains (see page 42).

The side impact protection will be activated if certain predetermined conditions are met such as the force and angle of the impact, the speed of the car on impact, and at which point on the car's side the impact occurs.


The side-impact protection is only activated on the side of impact, while the safety belt pretensioners on both sides are deployed. The front seats and outer rear seats have safety belt pretensioners.

There are two sensors on each side of the car, one at the rear of each door sill and one in the lower part of each C-pillar.

Convertible: The Convertible has two side impact protection sensors, one on each side of the car. These are located at the rear of the sills.



Inflated side airbag and inflatable curtain, SportSedan and SportCombi



Inflated side airbag with head protection, Convertible

42 Safety

Inflatable curtains, SportSedan and SportCombi

WARNING

- Do not sit with your head resting against the side window. The inflatable curtain is designed to inflate between the window and the head. Resting the head against the window could prevent the inflatable curtain from providing the intended protection.
- Hang only light clothes from the hooks on the rear seat courtesy handles. The items of clothing must not contain heavy or sharp objects. Do not use wire coat hangers.


- Do not position a sun visor or similar item in the area that would be filled by the inflatable curtain.
- To reduce the risk of head injuries in the event of a crash, the roof pillars and headlining incorporate cushioning material. Do not attach anything to the car's headlining, roof pillars or side panels as this could prevent the side-impact protection from providing the intended protection.
- Do not stack loads so high that they could encumber the inflatable curtain in the event of a crash.

The inflatable curtains, which protect the head, are concealed along the lengths of the headlining (all the way from front to rear roof pillars).

The inflatable curtains inflate at the same time as the side airbags in the front seats in case of a side-on impact.

The inflatable curtains reduce the risk of head injuries to the occupants of the car's outer seats. The inflatable curtains deploys into the window area between the front and rear roof pillars.

If the airbag system registers forces equivalent to a high-speed frontal crash (Stage II for the steering wheel and passenger airbags), the inflatable curtains will also be deployed.



Inflated inflatable curtain, SportSedan



Prohibited seating position

For optimal protection, do not sit too close to the door. Bear this in mind, for example, if someone is sleeping in the car. The inflatable curtain comes down from the headlining and covers a large portion of the side windows.

Airbag warning lamp

WARNING

- If the airbag readiness light stays on after you start your vehicle, it means the airbag system may not be working properly. See page 85.
- The airbags in your vehicle may not inflate in a crash, or they could even inflate without a crash.
- To help avoid injury to yourself or others, have your vehicle serviced right away if the airbag readiness light stays on after you start your vehicle.

What Will You See After an Airbag Inflates?

After an airbag inflates, it quickly deflates, so quickly that some people may not even realize the airbag inflated. Some components of the airbag module - the steering wheel hub for the driver's frontal airbag, the instrument panel for the right front passenger's frontal airbag or the ceiling of your vehicle near the side windows - will be hot for a short time. The parts of the bag that come into contact with you may be warm, but not too hot to touch. There will be some smoke and dust coming from the vents in the deflated airbags. Airbag inflation does not prevent the driver from seeing or being able to steer the vehicle, nor does it stop people from leaving the vehicle.

44 Safety

WARNING

When an airbag inflates, there is dust in the air. This dust could cause breathing problems for people with a history of asthma or other breathing trouble. To avoid this, everyone in the vehicle should get out as soon as it is safe to do so. If you have breathing problems but can not get out of the vehicle after an airbag inflates, then get fresh air by opening a window or a door. If you experience breathing problems following an airbag deployment, you should seek medical attention.

In many crashes severe enough to inflate an airbag, windshields are broken by vehicle deformation. Additional windshield breakage may also occur from the right front passenger airbag.

- Airbags are designed to inflate only once. After an airbag inflates, you will need some new parts for your airbag system. If you do not get them, the airbag system will not be there to help protect you in another crash. A new system will include airbag modules and possibly other parts. The service manual for your vehicle covers the need to replace other parts.

- Your vehicle is equipped with a crash sensing and diagnostic module which records information after a crash. See Vehicle Data Collection and Event Data Recorders on page 282.
- Let only qualified technicians work on your airbag system. Improper service can mean that your airbag system will not work properly. See your dealer for service.

Notice: If you damage the covering for the driver's or the right front passenger's airbag, or the side impact airbag covering on the ceiling near the side windows, the bag may not work properly. You may have to replace the airbag module in the steering wheel, both the airbag module and the instrument panel for the right front passenger's airbag, or side impact airbag module and ceiling covering for the roof-mounted side impact airbag. Do not open or break the airbag coverings.

Servicing the airbag system

The airbag system must be inspected as part of the normal service program but otherwise may be regarded as maintenance-free.

Scrapping or working on airbag and belt pretensioners

WARNING

- Under no circumstances should any modifications be made that affect the steering wheel or the airbag's electrical circuitry.
- During any welding, **both** battery cables must be disconnected and covered.
- Before quick drying paint in the vicinity of the electronic control module, the module's grounding points and wiring must be covered.
- Airbags and safety belt pretensioners must be deployed under controlled conditions before the car is scrapped or any of the system's components are removed. Airbags or belt pretensioners that have been deployed as a result of a crash must be replaced by new ones.

- The car's impact protection consists of several different safety features including the airbags, safety belts, steering wheel, seats and dashboard. These parts are co-ordinated with each other to provide optimum protection in the event of a collision, so never install an airbag from one car into another.
There is no guarantee that it would then work satisfactorily in the event of a collision.
- All work involving the scrapping or replacement of airbags or belt pretensioners must be carried out by authorized personnel only.

Frequently asked questions on function of the airbag

Do you still need to wear a safety belt if airbags are fitted?

Yes, always! The airbag system components merely supplement the car's normal safety system. Moreover, the front airbags will only be actuated in a moderate to severe frontal, or near-frontal crash, which means, of course, that they provide no protection in minor frontal crashes, major rear- or side-crashes or if the car rolls over.

The safety belts help to reduce the sideways movement of the body in a crash.

But they also ensure that, if a crash occurs in which the airbags are inflated, the airbag will make the optimum contact with the occupant, i.e. square on from the front. If the occupant meets the airbag in an offset position, the protection afforded will be reduced.

In addition, airbags provide no protection against a secondary impact occurring in the same incident. So there is no doubt about the benefit of wearing safety belts at all times.

Do not sit too close to the airbag: it needs room to inflate.

The airbag inflates very quickly and powerfully in order to protect an adult, before they are thrown forward, in a serious frontal crash.

How do I position the seat to leave room for the airbag to inflate?

Don't have your seat too far forward.

Recline the seat back to increase the distance between you and the airbag. For short drivers, special accessory pedal extensions are available through your Saab dealer.

Airbags inflate extremely rapidly and with great force – to be fast enough to protect an adult in the seat.

When do the airbags in the steering wheel and passenger side of the dash board inflate?

The airbag will only be inflated under certain predetermined conditions in a moderate to severe frontal, or near-frontal crash, depending on such factors as the force and angle of the impact, the speed of the car on impact, and the resistance to deformation of the impacting object.

The airbag can only be activated once in the same incident.

Do not attempt to drive the car after an airbag has been inflated, even if it is possible.

What won't trigger the airbag?

The airbag will not be activated in all frontal crashes. For instance, if the car has hit something relatively soft and yielding (e.g. a

46 Safety

snow drift or a hedge) or a solid object at a low impact speed, the airbag will not necessarily be triggered.

How loud is the inflation?

The noise of the inflation is certainly loud, but it is of a very short duration and will not damage your hearing. For a short time afterwards you could experience a buzzing noise in your ears.

Most people who have experienced it cannot remember the noise of the inflation at all – all they remember is the noise of the crash.

Can you still use a child seat in the front if a passenger airbag is installed?

Definitely not!

Children 12 and under or shorter than 55 inches (140 cm) can be killed by the airbag.

The back seat is the safest place for children.

Never put a rear-facing child seat in the front.

Sit as far back as possible from the airbag.

Always use seat belts and child restraints.

What should I do if the AIR-BAG warning light comes on?

If the warning light is on, it means that a fault has been detected in the system. The airbag cannot be relied on to operate as intended and it might even be activated erroneously. You should therefore take the car to a workshop. We recommend that you contact a Saab dealer as soon as possible.

Are the dust and fumes given off when the airbag operates at all harmful?

Most people who have remained in a car with little or no ventilation for several minutes complained only of minor irritation of the throat and eyes. Avoid as much as possible getting dust on your skin as there is a risk of skin irritation.

If you suffer from asthma, the incident may bring on an attack, in which case you should follow the normal procedure advised by your doctor. It is advisable to consult a doctor afterwards.

Adding Equipment to Your Airbag-Equipped Vehicle

Is there anything I might add to the front or sides of the vehicle that could keep the airbags from working properly?

Yes. If you add things that change your vehicle's frame, bumper system, front end or side sheet metal or height, they may keep the airbag system from working properly. Also, the airbag system may not work properly if you relocate any of the airbag sensors. If you have any questions about this, you should contact Saab Customer Assistance before you modify your vehicle. The phone numbers and addresses for Customer Assistance can be found on page 280.

Because I have a disability, I have to get my vehicle modified. How can I find out whether this will affect my advanced airbag system?

Changing or moving any parts of the front seats, safety belts, the airbag sensing and diagnostic module or the inside rearview mirror can affect the operation of the advanced airbag system. If you have questions, call Customer Assistance. The phone numbers and addresses for Customer Assistance can be found on page 280.

Security

Doors _____	48
Central locking _____	48
Car alarm _____	56



BB-453

* Asterisk means: equipment not fitted in all cars (can depend on model variant, engine variant, market specification, options or accessories).

48 Security

Doors

Open the door by lifting the door handle.

The following message appears on the Saab Information Display (SID) if a door is not closed (text displayed first when vehicle speed exceeds 15 mph (25 km/h) and the door has still not been closed):



Close doors.

Central locking



WARNING

Leaving children or pets unattended in a locked car is dangerous. It is also dangerous to leave children in a vehicle with the ignition key. A child or others could be badly injured or even killed.

Remote control

The remote control and ignition key are integrated in one unit, and referred to in this manual as the remote control.

The remote control contains a mechanical key, referred to in this manual as the traditional key. This traditional key can be used in an emergency to lock or unlock the driver's door from outside (see page 50). This key does not fit the ignition switch.

A key code number is supplied with your car. This number needs to be quoted for ordering a new traditional key (contained in the remote control). Therefore, keep this number in a safe place.


The remote control contains an electronic code that is unique to your car. When the remote control is inserted into the ignition switch, this code is checked. If the code is incorrect, the car will not start.

The car is supplied with two remote controls. It is possible to have up to five remote controls programmed for the car at any one time. If one is lost, a replacement should be obtained as soon as possible. We recommend that you contact a Saab dealer. When a new key is programmed into the car, the lost key will be deprogrammed automatically.

Note

If a new remote control has to be ordered and programmed, at least one old one is required for the locking system's electronic unit to recognize the new (ordered) remote control.

Once the new remote control has been programmed, the old unit that is lost will not work. Therefore you should carry two remote controls separately, especially on long journeys.



Remote control

- 1 Locks car
- 2 Unlocks car and turns on cabin lighting
- 3 Unlocks and opens trunk lid.
- 4 Turns on exterior and cabin lighting.
Activates panic function

NOTICE

The remote control contains delicate electronics.

- Do not expose it to water.
- Avoid rough handling.
- Do not place the remote control where it may be subjected to high temperatures, e.g. on the instrument panel.
- Warm the remote control in your hands for a couple of minutes if it has become very cold to prevent malfunction.
- For details on **changing the battery**, refer to page 54.

Remote control functions

Button	Pressed once	Pressed twice	Hold and press the button more than 2 seconds
	Locks all doors.	–	–
	Unlocks driver's door.	SportSedan: The other doors are unlocked. SportCombi: The other doors and tail-gate are unlocked.	Comfort opening, see page 119.
	SportSedan: Unlocks and slightly opens the trunk lid. SportCombi: Unlocks the tail-gate. Checks number of remote controls, see page 53.	–	–
	Turns on exterior and cabin lighting *) (for 30 seconds) or turns off lighting and deactivates panic alarm.	–	Panic alarm (activates alarm manually), see page 58.

*) parking lights, side direction indicators, tail-lights and license plate lighting.

50 Security

Locking/unlocking the car

WARNING

Leaving children or pets unattended in a locked car is dangerous. It is also dangerous to leave children in a vehicle with the ignition key. A child or others could be badly injured or even killed.

Never lock anyone in the car.

Remote locking and unlocking also control the car alarm.

Remote locking

Press the  button once:

SportSedan: all doors locked.

SportCombi: all doors and tailgate locked.

The hazard warning lights will flash once to confirm.

Remote unlocking

Pressing the  button once: the driver's door is unlocked.

Pressing a second time:

SportSedan: the rest of the doors are unlocked.


SportCombi: the rest of the doors and tailgate are unlocked.

The hazard warning lights will flash twice to confirm.

Saab Information Display (SID), see page 89.

Intermittent malfunctioning

Equipment in the vicinity of the car that uses the same frequency as the remote control may cause interference to the remote control signal. In this case, retry from another angle and aim at the receiver located by the steering wheel.



Locking/unlocking the front left-hand door with the traditional key

- 1 Lock
- 2 Unlock

If remote unlocking should fail to work

- 1 Remove the traditional key from the remote control by pressing the emblem on the reverse of the remote control. (This key only fits the front left-hand door.)
- 2 Unlock the door with the key.


The car alarm will be tripped. To silence the alarm, insert the remote control into the ignition switch.

Locking a car with dead battery

The steering wheel lock requires sufficient battery voltage to lock and unlock. If the battery voltage drops below a certain level while the remote control is in the ignition switch, you will not be able to remove the remote control.

If you must leave the car, proceed as follows:

- 1 Lock the car by pressing down the lock buttons on the doors.
- 2 Lock the front left door from outside with the traditional key (see page 50). The car is now locked but the car alarm will remain inactive.



Opening button on driver's door

Trunk lid/Tailgate

Opening

SportSedan: The trunk lid is unlocked and slightly opened when the  button on the remote control or on the inside of the driver's door is pressed once.

SportCombi: The tailgate is unlocked (not opened) when the  button on the remote control or on the inside of the driver's door is pressed once.

The hazard warning lights will flash three times to confirm.

Closing

SportSedan: The trunk lid is locked when closed.

If you unlock and/or open the trunk lid from outside the car with the  button on the remote control, you must lock the car with the  button to arm the car alarm

SportCombi: The tailgate is not locked when closed. It is locked together with the doors when  button on the remote control is pressed once.

52 Security

Switches on front doors

The central locking can also be operated from inside the car using the button by each front door handle.


Locking the car with the remote control renders these buttons inoperative.

SportSedan


If you are sitting in the car and pressing the  button on the driver's door, the driver's door will unlock. Pressing the button a second time will unlock the remaining doors.

SportCombi

If you are sitting in the car and pressing the  button on the driver's door, the driver's door will unlock. Pressing the button a second time will unlock the remaining doors and the tailgate.



Central locking switch



Child safety locks

The button on the passenger door works in the same way except that this first unlocks the passenger door. During this operation the rear doors remain locked.

If the car is left with one or more doors open, the interior lighting will be switched off automatically after 20 minutes. This is to prevent the battery from running flat. Also, if the car has electrically adjustable seats, these will cease to operate.

Child safety locks


WARNING

If small children are carried in the rear seat, the safety locks on the rear doors should be activated to prevent unintentional opening from the inside.

The rear doors are equipped with child safety locks that are activated by means of a catch next to the door latch.

Insert a screwdriver or the traditional key (enclosed in the remote control) and turn it 45°.

When the child safety lock is in the locked position, the door can only be opened from outside the car.



Trunk Release Handle

Trunk Release Handle

There is a glow-in-the-dark trunk release handle located inside the trunk on the latch. This handle will glow following exposure to light. Pull the release handle down to open the trunk from inside.

NOTICE

The trunk release handle was not designed to be used to tie down the trunk lid or as an anchor point when securing items in the trunk. Improper use of the trunk release could damage it

Reprogramming lock system functions

Certain lock system functions can be reprogrammed. We recommend that you contact a Saab dealer (see page 293).

Checking the number of remote controls

To check the number of remote controls that are programmed for the car:

- 1 Insert the remote control into the ignition switch and turn it to ON.
- 2 Press and hold the  button for more than 2 seconds within 30 seconds after the ignition switch has been turned to the ON position.
- 3 The Saab Information Display (SID) will now display the number of remote controls that are programmed for your car, and which of these (1–5) is in the ignition switch.

Example of SID message:



Number of keys:
Active key number:

54 Security

Changing the key battery

WARNING

Keep the battery and other small components of the remote control out of reach of children.

NOTICE

The electronics of the remote control are sensitive to electrostatic discharge. Incorrect handling when changing the battery can damage the remote control. Avoid touching electronic components of the remote control with your hands.

When the voltage of the remote control battery drops below a certain level, the Saab Information Display (SID) will display:


 **Remote control battery low. Replace battery.**

Change the battery as soon as possible to avoid malfunctioning.

Battery type: For optimum performance in all temperatures and good service life, Saab recommends the use of a Sony or Panasonic CR2032, 3V lithium battery.

The battery should last for about 4 years of normal use.

The battery type is marked on the inside of the remote control. Avoid leaving fingerprints on the faces of the battery.



Press the emblem to remove the traditional key

- 1 Press the emblem on the reverse of the remote control to remove the traditional key.
- 2 Insert the tip of the key into the small slot and turn the key to split the remote control.



Change the battery and fit together the two halves of the remote control

- 3 Change the battery. Fit the new battery so that it is positioned in the same way as the old battery, with the positive (+) side facing down.
- 4 Fit the two halves of the remote control together and press them together until you hear several clicks. Avoid pressing the buttons. Reinsert the traditional key into the remote control.

- 5 After changing the battery in the remote control, it is only possible to use the remote control a limited number of times before synchronization with the car is lost. Therefore, do not press the buttons on the remote control repeatedly directly after changing the battery. Unlock the car and insert the remote control into the ignition switch to synchronize the remote control and car.

If the central locking system does not work after changing the battery and the car is locked, proceed as follows:

- 1 Unlock the front left door with the traditional key. If the car has a car alarm, this will be tripped.
- 2 Open the door and insert the remote control into the ignition switch. If the car has a car alarm, this will be silenced. The remote control and receiver unit are now synchronized.

Immobilizer

The remote control contains an electronic code that is unique to your car. When the remote control is inserted into the ignition switch, this code is checked and the LED on the dashboard double-flashes for 3 seconds. If the code is correct, the car can be started.

Each time you remove the remote control from the ignition, the electronic starting interlock is activated, the LED double-flashes for 3 seconds and the car becomes immobilized. If an incorrect remote control is now inserted into the ignition switch (e.g. the remote control of another car), the immobilizer will remain operative (the LED will not flash for 3 seconds) and it will not be possible to start the car.

If, when inserted into the ignition switch, there is a problem checking the electronic code of the remote control, the following message will appear on the SID:



**Key not accepted.
Contact service.**

Visit a Saab dealer to have the problem checked and rectified.

56 Security

Car alarm

WARNING

Leaving children or pets unattended in a locked car is dangerous. It is also dangerous to leave children in a vehicle with the ignition key. A child or others could be badly injured or even killed.

The car alarm is armed when the car is locked with the remote control.

The car alarm will not be armed if you lock the car with the traditional key (see page 50).

All the doors, the hood and the trunk lid are monitored by the alarm.

The alarm is armed 11 seconds after the car has been locked by remote control.

During the delay period, the LED shines constantly. It will then start to flash once every 3 seconds. The LED is located on the dashboard.

If a door or the trunk lid is open when the car is locked with the remote control, the LED will flash 3 times per second for 11 seconds. Check that the doors, hood and trunk lid are closed.

If the signal persists, contact a Saab dealer to have the problem checked and rectified.

Locking the trunk lid

SportSedan

If you open the trunk lid from outside the car with the  button on the remote control, you must lock the car with the  button to arm the car alarm.

SportCombi

If you unlock and/or open the trunk lid from outside the car with the  button on the remote control, you must lock the car with the  button to arm the car alarm.

To avoid any inconvenience, make sure that anyone using the car is familiar with how the car alarm and the locking system work.

If the alarm has been tripped since the car was last locked, the Saab Information Display (SID) will display:



Alarm tripped during last arming period.

If a fault arises in the car alarm system, the Saab Information Display (SID) will display:



Theft protection failure. Contact service.

Arming the car alarm

The alarm is armed when all doors, the hood and the trunk lid are closed and you lock the car with the remote control.

What trips the alarm?

The alarm will be tripped if:

- a door, the hood or the trunk lid is opened
- somebody tries to hot-wire the car

Signals when the alarm is tripped

If the alarm is triggered, the following alarm signals will be set off:

- all direction indicators flash for 5 minutes.
- the horn sounds for 30-second intervals with 10-second breaks (max. 10 cycles).

The signals can vary between markets and due to legal and insurance requirements.

Switching off the alarm if tripped

If the alarm has been triggered (direction indicators flashing and horn sounding) it can be turned off by pressing one of the buttons on the remote control or, if you are sitting in the car, by turning the ignition to ON (see below).

	Turns off lights and horn. Unlocks car.
	Turns off lights and horn. Car remains locked.
	Turns off lights and horn. Unlocks trunk.
	Turns off lights and horn. Turns on exterior and cabin lighting. Car remains locked.
If sitting in the car: Turn the ignition switch to ON in the ignition switch	

NOTICE

- It is possible to inadvertently deactivate the car alarm and at the same time unlock the car, if the button on the key is pressed by mistake when the car is still within its range.
- When locking the car by remote control in extremely cold weather, it is advisable to check that the lock system has operated properly. To do so, check that the interior locking buttons are all down.
If not, unlock and re lock the car again.

58 Security

Panic function

The car alarm includes a panic function. This function allows the alarm to be started manually, for example, to attract attention.

The panic alarm can only be activated while the car is stationary. The alarm is silenced if the car is driven off.

When the alarm is tripped, the lights and horn come on for 3 minutes or until you press one of the remote control buttons.

To start the alarm manually proceed as follows:

- Press and hold the  button on the remote control for more than 2 seconds, or if you are sitting in the car...
- Press and hold the  or  button on one of the front doors for more than 2 seconds.

To switch off the alarm:

- Press one of the remote control buttons or, if you are sitting in the car, the  or  buttons on one of the front doors.

Overview of functions


Locking/arming	Direction indicators flash once.
Unlocking/disarming	Direction indicators flash twice.
Unlocking/disarming trunk lid	Direction indicators flash three times.
Alarm triggered	Direction indicators flash for 5 min. The horn sounds for 30-second intervals with 10-second breaks (max. 10 cycles) or until you press one of the remote control buttons or turn the ignition switch to the ON position.
Remote control	Normal range: 5–16 yds. (5–15 metres). In favorable conditions the range can be significantly greater.
Remote control battery	Normal life: approx. 4 years. Change the battery when the SID displays: Remote control battery low. Replace battery. See Changing the key battery , page 54.

Some car alarm functions and indications can be reprogrammed. Contact a Saab dealer for details of the possibilities and refer to page 293.

Quick guide, LED and Saab Information Display (SID) messages





Activity	LED signal
Arming (delay period)	Illuminates for 11 seconds.
Alarm armed	Flashes once every 3 seconds.
Disarming	Extinguishes.
Alarm not armed	Off.
A door, the hood or the tailgate is open or opened during the delay period.	Flashes for 11 s then flashes once every 3 seconds.
Car immobilized but not locked.	Off.
Change of status of immobilizer system, valid remote control inserted or removed from ignition switch.	Double-flashes for 3 seconds.

SID message	Reason/action
Key not accepted. Contact service.	Error when remote control inserted into ignition switch.
Remote control battery low. Replace battery.	Battery needs replacing. See page 54.
Number of keys: Active key number:	Check of the number of remote controls programmed for your car. See page 53.
Alarm tripped during last arming period.	The alarm has been tripped since the car was last locked.




60 Security

(This page has been left blank.)



9-3 Convertible



Advice on soft top operation _____	62	Head restraints _____	74
Operating the soft top _____	63	Safety belts, rear seat, Convertible _____	75
Raising the soft top manually _____	68	Rollover Pop-up Bars _____	76
SID warnings and messages _____	71	Electric windows _____	77
"Easy entry" _____	73	Interior lighting _____	79
		Unlocking the trunk lid manually _____	80

* Asterisk means: equipment not fitted in all cars (can depend on model variant, engine variant, market specification, options or accessories).

62 9-3 Convertible

Advice on soft top operation

- Once you have raised the soft top and before driving off, always check that the soft top is properly engaged with the windshield rail, see page 66.
- Once you have folded the soft top and before driving off, check that the soft top cover is locked, see page 64.
- Do not operate the soft top in temperatures below 23 °F (−5 °C).
- Note that certain automatic car washes can damage the soft top. This applies to car washes that use mechanical feelers bearing against the body. Saab advises against washing the Convertible in an automatic car wash.
- After rain or washing the car, allow the soft top to dry completely before folding it. Folding a wet or damp soft top can cause water damage in the car and mildew to form on the soft top.
- Roof racks and ski holders must not be mounted on the soft top.
- Under no circumstances should anything be put into the stowage space of the soft top (under the soft top cover) since this could cause an obstruction when the soft top is being folded away.
- Do not place any objects on the covers over the roll bars as this can hamper their function.
- When operating the soft top, raise or fold it fully until notified that operation is complete by the SID. Do not leave the soft top partially open/closed. If the soft top is left in an intermediate position it will collapse progressively after 20 seconds to prevent overloading the drive system.
- **Washing the soft top**, see page 267.

WARNING

- Never touch the hinges and struts of the soft top nor the upper rail of the windshield while operating the soft top.
- Do not operate the soft top while there are bystanders close to the car.

Operating the soft top

WARNING

- Do not touch the hinges or struts of the soft top during opening due to the pinch hazard.
- Keep children out of reach.
- Do not operate the soft top while there are bystanders close to the car.
- Make sure that the soft top cover has locked properly after folding the soft top.
- Check that the soft top engages properly with the upper edge of the windshield after raising.

NOTICE


If you drive off while raising or folding the soft top, operation is halted when the speed of the car exceeds 20 mph (30 km/h). This speed can be programmed (0–20 mph/0–30 km/h). We recommend that you contact a Saab dealer. The movement of the car and force of the wind can seriously damage the components of the soft top system.

Read the "**Advice on soft top operation**" section on page 62 before operating the soft top.

The soft top is operated with the switch on the instrument panel. Hold the switch in the desired position until the soft top is fully folded or raised.

The completion of folding or raising the soft top is indicated by a chime.

Error messages that can appear on the SID are shown on page 71.



Switch for operating the soft top


- a Raising
- b Folding

64 9-3 Convertible

Opening

The following conditions must be fulfilled for the soft top to be folded:

- Vehicle speed must not exceed 20 mph (30 km/h).
- Battery voltage must exceed 10 V.
- Outside temperature must exceed 23 °F (-5 °C).
- The trunk lid must be locked.
- There must be sufficient space in the trunk for the soft top.




Folding

- 1 Start the engine and let it idle. Clearance for soft top operation: height, min. 7.2 ft (2.2 m); behind car, min. 2" (5 cm).

- 2 Press and hold the soft top button until the soft top is fully folded and the soft top cover raised. Completed folding is indicated by a chime. If there is a malfunction a text message will be shown on the SID. Refer to page 71.
Do not press any of the buttons on the same section of the instrument panel as the soft top switch while folding the soft top. This will cause the soft top to stop and then sink after about 20 seconds.


Remote opening ✱

You can fold the soft top when outside the car by pressing and holding the  (unlock) button on the remote control. See also page 119.




1 Rear window raised. Soft top storage in luggage compartment lowered.

2 The soft top cover is opened.




3 Soft top folded.



4 The soft top cover is closed.

a 7.2 ft (2.2 m)

b 2" (5 cm)




66 9-3 Convertible

Raising

The following conditions must be fulfilled for raising the soft top:

- Vehicle speed must not exceed 20 mph (30 km/h).
- Battery voltage must exceed 10 V.
- The trunk lid must be locked.




Raising

- 1 Start the engine and let it idle. Clearance for soft top operation: height, min. 7.2 ft (2.2 m); behind car, min. 2" (5 cm).


- 2 Press and hold the soft top button until the soft top is fully raised and the soft top cover closed. Completed raising is indicated by a chime. If there is a malfunction a text message will be shown on the SID. Refer to page 71.

Do not press any of the buttons on the same section of the instrument panel as the soft top switch while raising the soft top. This will cause the soft top to stop and then sink after about 20 seconds.


Check that the hooks in the soft top hold it securely to the upper edge of the windshield.



1 The soft top cover is opened.




2 The soft top is raised.



3 The soft top cover is closed.

4 The rear window is lowered.

a 7.2 ft (2.2 m)
b 2" (5 cm)



Raising the soft top manually

WARNING


Only raise the soft top manually in an emergency (e.g. due to an electrical fault).

Do not touch the soft top button on the instrument panel while closing the soft top manually. This could cause personal injury and damage the soft top mechanism.

Do not fold the soft top having closed it manually. This can damage the soft top mechanism.

If the soft top has been folded mechanically there will be a delay of 20 seconds before it is possible to raise it manually (the pressure must be released from the hydraulic system).

If the car is without electrical power, the trunk must be unlocked manually. Refer to page 80.



Wire catch for unlocking soft top cover


- 1 Find the lug wrench, Allen key and screwdriver located under the luggage compartment floor.
- 2 Remove the two covers from the side trim in the trunk, one from either side.


If there are two of you, it is easiest if you stand on either side of the car and perform steps 3-6 and 9-10 together.

- 3 Unlock the soft top cover by pressing forward the two wire catches, one on the left and one on right-hand side.

- 4 Close the trunk lid fully as otherwise it will obstruct the soft top cover.

Tools under luggage compartment floor





Soft top cover opened

Manual closing started

Soft top pulled towards windshield

5 Open the soft top cover, upward and backward.


6 Tip forward the front seat backrests.

! WARNING

- Do not touch the hinges and struts of the soft top during raising.
- Keep your hands clear of the front windshield rail.
- Pinch hazard may cause personal injury.


7 Before raising the soft top, the two catches in the leading edge of the soft top must be opened. Stand in the rear seat and pry off the cover with the screwdriver (the cover is fitted on the covering in between the catches). Using the tool (the lug wrench and the Allen key), turn clockwise to open the catches. Stand in the rear seat and raise the soft top. Pull it towards the windshield. This operation requires 7.2 ft (2.2 m) of vertical clearance.

70 9-3 Convertible



Soft top locked to windshield rail

- 8 Sit in one of the front seats and lock the soft top to the windshield rail. Use the lug wrench and the Allen key. Turn roughly 1/4 turn **counterclockwise**. Check that the soft top is properly locked in place by pressing up the front edge. The soft top must not move upward.




Closing the soft top cover

- 9 Lift up the rear window **fully** and hold it there. Close the soft top cover. It is not possible to lock the soft top cover after manual raising.

NOTICE

To avoid damaging the paintwork on the soft top cover and the trunk lid, take care when closing the soft top cover.

- 10 Press down the rear edge of the soft top as far as possible towards the soft top cover.



Rear window locked to soft top cover

- 11 Now lock the rear window to the soft top cover. Sit in the rear seat and insert the tool (the same tool as used to lock the soft top to the windshield rail) into the hexagonal hole in the soft top mechanism. Turn roughly 1/4 turn, counterclockwise on the right hand side of the soft top and clockwise on the left-hand side. Look at the soft top cover when locking the rear window. The rear window must make a tight seal against the soft top cover.

The soft top system must be checked and rectified without delay. We recommend that you contact a Saab dealer.

SID warnings and messages

The following messages associated with the soft top system and can be displayed on the SID together with a chime:

		Cause	Suitable action
	Soft top front not locked.	Failure of the soft top to lock automatically to the windshield.	<ul style="list-style-type: none"> • Move the car so that it is standing level if on a steep slope. • Press the soft top button to fold the soft top slightly. Fold the soft top again.
	Soft top power pack overheated.	This message appears if the soft top is operated continuously for more than 3 minutes.	Wait 6 minutes to allow the hydraulic pump to cool down.
	Move goods away from soft top storage area.		Move the object hindering soft top operation.
	Operation at low temp. may damage soft top.	Displayed if the soft top is folded at temperatures below 23 °F (–5 °C).	
	Only manual operation possible.		
	Soft top cover not locked. Try again.		

72 9-3 Convertible


	Battery low.	The voltage of the car battery is too low to allow soft top operation.	
	Soft top obstructed. Clear obstacles.		
	Complete soft top operation to open trunk.		Complete soft top operation.
	Complete soft top operation before driving		Complete soft top operation.
	Close trunk.		Close the trunk lid.
	Driver seat unlocked.	The backrest is not locked.	Raise the backrest fully to locked position, see page 73.
	Passenger front seat unlocked.	The backrest is not locked.	Raise the backrest fully to locked position, see page 73.

"Easy entry"

WARNING

- **Always** check that the backrest locks properly when returned to normal position.
- Check that the fore-and-aft position of the seat is properly locked. The backrest and the entire belt-in seat must be locked in position; otherwise the occupant of the seat is at risk of injury during braking or in the event of a crash, especially if a rear-facing child seat is fitted behind the backrest.

To facilitate getting in and out of the rear seat, the front seats can be slid forward.



"Easy entry" function. Illustration shows an electrically adjustable seat *

Manually adjusted passenger seats *

- 1 Raise the handle by the head restraint on the seat.
- 2 Tip the backrest and slide the seat forward.

Repositioning

- 1 Tip back the backrest.
- 2 Slide the seat back to the desired position.

Make sure the backrest and seat are properly **locked** in position. Correct locking is indicated by a clear clicking noise.

Electrically adjustable front seats *

- 1 Raise the handle by the head restraint on the seat.
- 2 Tip the backrest forward.
- 3 The seat now moves to its foremost position.

Repositioning

- 1 Tip the backrest back to its normal position.
- 2 Raise and hold the handle while the seat is moved back. Release the handle when the seat has been moved to the

74 9-3 Convertible

required position. Correct locking is indicated by a clear clicking noise.

Repositioning (seats without memory)

- 1 Tip the backrest back but not to its normal position.
- 2 Raise and hold the handle until the seat has returned to its previous position.
- 3 Release the handle and move the backrest to locked position. Correct locking is indicated by a clear clicking noise.

Head restraints


WARNING

- Adjust the head restraint so that the head is optimally supported and the center of the head restraint is at ear height, thus reducing the likelihood of neck injury in a crash.
- Raise the head restraints in the seats that are occupied.

The front seats are equipped with Saab Active Head Restraints (SAHRs). These are designed to reduce the risk of neck injury if the car is hit from behind.

The SAHR is a mechanical system, actuated by body weight. The mechanism is built into the top of the backrest, where it is connected to the head restraint.


In the event of a rear-end crash, the body is forced back against the backrest. This, in turn, causes the mechanism to press the head restraint forward and upward, thus limiting the backward movement of the head.



Front head restraint

The front head restraints can be raised and lowered to a number of positions, the rear has two positions.

- Raising: grasp the head restraint on both sides and pull it straight up.
- Lowering the front head restraints: press in the left catch and press the head restraint down.



Rear head restraint

The rear head restraints can be fully lowered to improve rearward vision when the rear seats are unoccupied.

Safety belts, rear seat, Convertible

The two rear seats have three-point safety belts with inertia reels.

Fasten the belt by pulling the belt and inserting the tongue in the buckle. Check that it is securely fastened.

Position the lap part low across the hips.

Grasp the shoulder belt close to the buckle and pull the belt towards the shoulder to tighten the lap belt part.

The belt must be as far in on the shoulder as possible.

Press the red button on the belt buckle to release the belt.


Refer to page 266 for how to check the function of the safety belts, cleaning, etc.

WARNING

- If cargo has to be placed on a seat, it must be properly secured with the safety belt. This reduces the risk of the cargo being thrown about during hard braking or a crash, which could cause personal injury.
- Check that the belt is not twisted or lying against sharp edges.
- Make sure you use the correct safety belt buckle.

For how to secure loads on the rear seat, refer to page 17.

76 9-3 Convertible



Safety belts, rear seat, Convertible

Rollover Pop-up Bars


The Rollover Pop Up Bars, which are located behind each rear seat head restraint, are designed to deploy in the event of a crash or rollover.

⚠ WARNING

You can be severely injured or killed in a crash if you are not wearing your safety belt - even if you have airbags and Rollover Pop Up Bars. Wearing your safety belt during a crash helps reduce your chance of hitting things inside the vehicle or being ejected from it.

- The Rollover Pop Up Bars have powerful springs that rapidly extend the bars in rollover crashes, as well as in moderate to severe crashes in which the airbags deploy. Rollover Pop Up Bars are supplemental to the safety belts. They are designed to work with safety belts but do not replace them.

- Rollover Pop Up Bars deploy with great force, and you could be injured if your arm or other body part, or if an object is covering the bars when they deploy. Don't put anything on the cover of the Rollover Pop Up Bars. The path of the Rollover Pop Up Bars must be kept clear.
- The Rollover Pop Up Bars are designed to deploy only once. If they deploy, take your vehicle to a workshop immediately to have the Rollover Pop Up Bars repaired so that they operate properly in the event of a crash or rollover. We recommend that you contact a Saab dealer.



Rollover Pop-up Bars

NOTICE

To avoid the risk of damage to the soft top **do not** operated the soft top while the bars are extended.


Electric windows

WARNING

Bear in mind the pinch hazard when closing the side windows. May cause serious or fatal injuries!

- **Always** remove the remote control from the ignition switch when you leave the car to prevent personal injury caused by the activation of the electric windows, for example, due to children playing.
- The person operating the electric window is responsible for ensuring that no one, especially a child, has their head, hands or fingers in the window openings, before raising the window.
- Do not stick any part of the body or the head out through an open window while the car is moving.

78 9-3 Convertible



Window switches

To open

Soft top raised – The windows open individually.

Soft top folded – The button for the front window opens both side windows.

Automatic opening

Press the button all the way down and release it. If the soft top is folded, the rear side window is also lowered.

To close

Soft top raised – The windows are operated individually.

Soft top folded – The button for the front window closes both side windows.

Automatic closing of a front side window

Raise the button all the way and release it. The rear side window must be fully closed. Pinch protection * is available for the front side windows.

For further information on the electric windows, refer to page 119.

Deactivating the passenger door window button

With the  button on the driver's door, you can deactivate the window button on the passenger door.

The illuminated switch will change color from green to amber (deactivated).

Calibrating front electric windows with pinch protection *

The window lifts should be calibrated if automatic closing does not work or if the battery has been disconnected. The pinch protection will not work if the windows are not calibrated.

Perform calibration as follows:

- 1 Make sure the soft top is raised.
- 2 Make sure the doors are closed.
- 3 Let the engine idle.
- 4 Make sure the rear side windows are closed, then operate each front window switch for moving the corresponding window fully down and fully up, repeat up to 3 times depending on conditions. Keep switch pressed a few seconds in fully up position after each "up" movement. When a chime is heard, the calibration is completed.

If calibration fails twice in a row, have the car checked and rectified. We recommend that you contact a Saab dealer.

Interior lighting

The interior lighting consists of a front roof light, two front reading lights, footfall lighting and courtesy lighting in the doors. The light switches are located in the roof console.

The cabin lighting comes on


- When a door is opened and the ignition is OFF.
- When the remote control is removed from the ignition switch.

The lighting goes out

- When the car is locked.
- When the ignition is turned on.
- Approx. 20 seconds after closing all doors.

The lights are dimmed out gradually.

If a door is left open with the ignition OFF, the interior lighting goes out automatically after 5 minutes so as not to drain the battery.



Front interior lighting - Convertible

- 1 Left-hand reading light
- 2 Cabin light
- 3 Right-hand reading light

The interior lighting can be switched off completely.

- 1 Open the driver's door.
- 2 Turn off the cabin lighting with the center button, see illustration.

This is canceled when the ignition switch is turned to position ON or when the car is locked with the remote control.

Glove box

The glove box lighting comes on when the compartment is opened and goes out when it is closed.

For changing bulbs, refer to page 228.

Sun visor

An illuminated vanity mirror is provided on the inside of the sun visors. The lighting comes on when the cover is raised and goes out when it is closed.

Trunk lighting

The trunk lighting comes on and goes out when the trunk lid is opened and closed.

If the trunk lid is left open, the lighting will be switched off automatically after 20 minutes to prevent the battery from running flat.

For changing bulbs, refer to page 230.


80 9-3 Convertible

Unlocking the trunk lid manually

If the trunk lid is not unlocked by the central locking system, it can be unlocked manually.

- 1 Take the traditional key out of the remote control by pressing the emblem on the reverse (see page 54).
- 2 Carefully prise off the round cover using your nails, a credit card or similar so as not to damage the paintwork.
- 3 Unlock the trunk lid using the traditional key.

We recommend that you contact a Saab dealer to have the central locking system checked.



Unlocking the trunk lid manually

Spoiler on trunklid *

WARNING

Some models have a spoiler on the trunklid. Avoid getting fingers and hands trapped between the spoiler and rear fender when closing the trunklid.

Wind deflector *

A wind deflector is available as an accessory. Follow the fitting instructions supplied with the wind deflector carefully.

Instruments and controls




Warning and indicator lights _____	82
Instruments _____	87
Saab Information Display (SID) _____	89
Switches _____	97
Wipers and washers _____	103
Automatic climate-control system (ACC) _____	107

* Asterisk means: equipment not fitted in all cars (can depend on model variant, engine variant, market specification, options or accessories).

82 Instruments and controls

Main instrument panel



U.S. shown, Canada similar

Main instrument panel

- | | |
|---------------|----------------------------|
| 1 Tachometer | 5 Engine temperature gauge |
| 2 Speedometer | 6 Information display |
| 3 Turbo gauge | 7 Trip meter reset button |
| 4 Fuel gauge | |

Warning and indicator lights

The warnings and indications that can be shown depend on the engine variant and equipment level.



Antilock braking warning

This warning light illuminates when a fault arises in the antilock brake system.

The following message is shown on the Saab Information Display (SID):



**Antilock brake malfunc.
Contact service.**

The brake system will continue to function but without ABS modulation. See also page 170.

IP4516

**Charge warning light**

This light comes on when the battery is not being charged by the alternator. If the light comes on during driving, stop as soon as possible and switch off the engine.

The following message is shown on the Saab Information Display (SID):



**Battery not charging.
Make a safe stop.**

Check the drive belt, see page 215.

**Warning, tire pressure**

The light illuminates if the tire pressure in one or more tires is too low or if a fault has arisen in the system, see page 253.

Below is an example of the message simultaneously shown on the SID:



**Tire pressure low,
rear left. Check tires.**

**Warning, oil pressure
(engine oil)**

This light will come on if the engine oil pressure is too low. If the warning light flashes or comes on while you are driving, stop immediately in a safe place, switch off the engine and check the oil level (see page 208).

NOTICE

Never drive the car when the oil pressure warning lamp is on. Low oil pressure can cause serious engine damage.

The following message is shown on the Saab Information Display (SID):



**Oil pressure low.
Make a safe stop.**

**Service Engine Light also
known as CHECK ENGINE****! WARNING**

An illuminated Service Engine Light also known as CHECK ENGINE indicator light indicates an engine-related problem.

While your car may be able to be driven with the “Service Engine Light also known as CHECK ENGINE” indicator light illuminated (limp-home mode), you are advised to have your car serviced at an authorized Saab dealer as soon as possible.

Continued driving without this problem being corrected might cause serious further damage to your car and create unsafe driving conditions. The operator should be prepared to take action if such unsafe conditions arise (e.g. brake smoothly, engage neutral, stop in a suitable place, switch off the engine, etc.)

This light indicates a malfunction in the fuel or ignition system.

Did you recently put fuel into your vehicle?

If so, reinstall the fuel cap, making sure to fully install the cap. See **Fuel cap** on page 157. The diagnostic system can determine if the fuel cap has been left off or improperly installed. A loose or missing fuel

84 Instruments and controls

cap will allow fuel to evaporate into the atmosphere. A few driving trips with the cap properly installed should turn the light off.

The following message is shown on the Saab Information Display (SID):



Tighten fuel filler cap.

If the light is still on the car may still be driven with care but the performance of the engine will be somewhat diminished (see page 153).

The following message is shown on the Saab Information Display (SID):



Reduced engine power. Contact service.

NOTICE

The car should be checked immediately at a Saab dealer to prevent more serious faults from arising.



High beam Indicator

This light shows when the high beam is on (see page 99).



Front fog lights *

This light indicates when the front fog lights are on (see page 100).

The front fog lights are switched off automatically when the engine is switched off. When the fog lights are next needed, they will have to be switched on manually.



Brake warning light

This light should come on briefly when you turn the ignition key to ON. If it doesn't come on, have it fixed so it will be ready to warn you if there is a problem. This light indicates when the brake fluid level is too low (see page 212).

The following message is shown on the Saab Information Display (SID):



Brake fluid level low. Make a safe stop.

WARNING

- Never drive the car if these two lights are on at the same time. Danger of brake failure!
- If the level of brake fluid in the reservoir is below the MIN mark, the vehicle should be transported on a recovery vehicle.
- Have the brake system checked immediately at a Saab dealer.

For safety reasons, stop the car and check the level of the brake fluid (see page 212).

If the level is normal, depress the brake pedal firmly two or three times. Now check the level again. If the level is still normal, you may drive the car, with considerable caution, to the nearest workshop to have the brake system checked. We recommend that you contact a Saab dealer.

The brake system provides Electronic Brakeforce Distribution (EBD). This distributes the brake pressure between the front and rear wheels, in such a way as to achieve optimum braking performance irrespective of the car's load.

If a fault arises in the EBD function, the ,  and  lights will come on. Also, the following message will appear on the Saab Information Display (SID):

 **Brake malfunction.
Make a safe stop.**

If this is the case, drive carefully and contact a workshop as soon as possible. We recommend that you contact a Saab dealer. Refer to Brake warning light on page 84, Antilock braking warning on page 82 and ESP[®] OFF indicator on page 86.



Safety belt reminder

This light reminds the driver to buckle up, see page 12.



Parking brake warning light

This light comes on when the parking brake is applied (see page 177).

The parking brake is mechanical and operates on the rear wheels.

If the parking brake is applied when the car starts off, the following message will appear on the Saab Information Display (SID):

 **Release park brake.**

WARNING

- **Always** apply the parking brake when parking, see page 177.
- **Always** apply the parking brake before removing the remote control.
- Do **not** apply the parking brake while the car is moving.



Airbag warning light

This light comes on if a potentially serious fault has occurred in the airbag system, see also page 32.

The following message is shown on the Saab Information Display (SID):



Airbag malfunction. Contact service.

WARNING

- If the airbag readiness light stays on after you start your vehicle, it means the airbag system may not be working properly. One or more of the following conditions may occur:
 - Non-deployment of the airbags in the event of a crash.
 - Deployment of the airbags without a crash.
 - Deployment of the airbags in crashes less severe than intended.
- To help avoid injury to yourself or others, have your vehicle serviced right away if the airbag readiness light stays on after you start your vehicle.

This light will come on for about four seconds when the ignition switch is turned to the Start or Drive position.

86 Instruments and controls



Indicator, fuel

This light comes on when there is less than about 2.5 gallons (10 liter) of fuel left in the tank.

NOTICE

If the car runs out of fuel, air can be drawn in with the fuel, which, in turn, can cause the catalytic converter to be damaged by overheating.



Headlight and parking light indicator

This light indicates that the headlights or parking lights are on.



Cruise control indicator light

This light comes on when the system is engaged.



ESP® indicator

This symbol lights up when the system is operative.

Operation of the ESP® indicates reduced cohesion between the tires and the road, and that extra care should be taken by the driver.



ESP® OFF indicator

! WARNING

The system improves stability and maneuverability under slippery road and extreme driving conditions. It must however not be regarded as a system to enable the driver to maintain higher speeds. The same precautions as normal for safe cornering and driving on slippery roads must be adopted (see pages 173/ 175).

This symbol lights up when the system is disengaged, see page 176.

If there is a malfunction, the symbol cannot be turned off by pressing the ESP® button.


The following message is shown on the Saab Information Display (SID):



Stability control failure. Contact service.

If so, have the system checked at a Saab dealer.

See also Electronic Stability Program ESP® on page 175.



Autochecking of lights, main instrument panel

The warning and indicator lights shown above should come on when the ignition switch is turned to ON. They should go out after about 4 seconds once the engine has started or after the fault-free self-diagnosis of each system or function.




Instruments

Tachometer

The tachometer displays the engine speed in thousands of revolutions per minute.

A protective function (interruption of the fuel supply) limits the engine speed within the red zone.



Speedometer

(U.S. speedometer shown)

Cars sold in U.S.: The speedometer displays the speed of the car in miles per hour (mph).

Cars sold in Canada: The speedometer displays the speed of the car in kilometres per hour (km/h).

It receives information about vehicle speed from the ABS's wheel sensors.

88 Instruments and controls



Temperature gauge

The temperature gauge shows the temperature of the coolant. The needle should be in the middle of the scale when the engine is at normal operating temperature.

If the needle goes into the red zone (which can occur at high outside air temperatures or under heavy engine loads), choose the highest possible gear ratio and the lowest possible engine speed, and avoid shifting down.

NOTICE

If the needle, despite the above action, enters the red zone, stop the car in a suitable place and allow the engine to idle. If the needle continues to rise, switch off the engine.

If the needle repeatedly enters the red zone, stop the car as soon as it is safe to do so and check the coolant level (see page 210).

! WARNING

Never open the cap of the expansion tank completely when the engine is hot, open with care. The pressure in the cooling-system can cause hot coolant and steam to be released. Failure to heed this warning may result in personal injury.



Turbo gauge

The turbo gauge indicates the air volume used for combustion, which is equivalent to the engine load.

At low loads and when the engine is used for braking, the needle will move within the white zone.

Under certain barometric conditions the needle may enter the first part of the red zone without necessarily indicating that a fault has arisen.

If the needle repeatedly enters the red zone and the engine at the same time loses power, because the monitoring system is limiting the boost pressure, you should contact a Saab dealer as soon as possible.

If the speed of the car exceeds 143 mph (230 km/h) (this speed varies between different engine variants), acceleration is limited by reducing the boost pressure. The pressure gauge then moves towards the middle of the white field, indicating a drop in engine power and consequently the car's speed.



Fuel gauge

When less than about 2.5 gallons (10 liter) of fuel is left in the tank, a warning light on the main instrument panel comes on.

Because of the fuel remaining in the tank, the amount of fuel required to fill the tank may be less than the specified tank capacity.

Refueling, see page 156.

Saab Information Display (SID)

- Various types of information are shown on the SID: warnings, indications, trip computer information and information from the car's Infotainment System.



- Selected gear is shown on the left-hand side of the display. When gears are selected manually, the letter M (manual) and the selected gear are displayed (see page 168) (cars with automatic transmission).
- In the first row trip computer information is displayed and in the second row odometer and tripmeter is displayed.

90 Instruments and controls

When a message is displayed

The odometer and tripmeter is temporarily turned off when a two row message is displayed. The icon is displayed in the left part of the display.


The warnings and indications that can be shown on the SID are listed on page 294.

If there is more than one message on the SID, a plus sign will be displayed to the left of the first message. Each message will be displayed for 10 seconds.

Press the CLR button to acknowledge a SID message. If you acknowledge a message but do nothing about it, the message will be displayed again the next time you start the car.

When the engine is switched off the warning/indicator lights still active are displayed, this is to remind the driver. At this point the warning/indicator lights previously acknowledged with the CLR button are also displayed.

You can adjust the settings of several of the car's systems, such as the alarm *, rain sensor * and climate control system. These are known as **Settings** se page 94.



SID, control unit and display

Odometer and trip meter

The odometer records the distance travelled in miles on U.S. vehicles and on Canadian vehicles the distance indicated is in kilometres, and the trip meter in miles and tenths (kilometres and tenths of kilometres on Canadian vehicles).

Reset button

The reset button is positioned immediately to the left of the speedometer.

Press once to resets the trip meter, the ignition shall be in position ON.

Trip computer function of the SID

WARNING

It is strongly recommended that the SID settings be changed only when the car is stationary. The driver's attention can otherwise easily be distracted from the road.

SID contains the following functions:

Temp	Outdoor temperature
D.T.E.	Estimated range (distance to empty fuel tank). When the possible range is less than 18 miles (30 km) then the text Refill fuel now is displayed.
Fuel Ø	Average fuel consumption since function last reset
Dist	Distance to destinations. Function can also be used as a trip meter
Speed Ø	Average speed since function last reset
Speed W	Speed warning (chime)
Settings	Settings of features such as alarm clock, language and rain sensor *

When the engine is started, the function that was selected when the engine was switched off is displayed, with the following exceptions:

- **Temp** is displayed if the outside temperature is between 26 and 38°F (–3 and +3°C).
- **D.T.E.** is displayed if less than or equal to 30 miles (50 km).

Outdoor temperature



WARNING

Remember that roads can be icy even at temperatures of above 38°F (+3°C), especially on bridges and stretches of road that are sheltered from the sun.

The **Temp** function is always activated (even in NIGHTPANEL mode) if the outdoor temperature rises or falls to between 26 and 38 °F (–3 and +3 °C).

If the temperature sensor, located under the front bumper, is covered by snow or ice, temperature readings will be unreliable.

Setting values

- 1 Select one of the functions using the steering wheel controls,  or .
- **Dist** (preset to 100 miles (100 km) if not previously set)
- **Speed Ø**
- **Speed W** (preset to 55 mph (90 km/h).
- 2 Press and hold the SET button until given audible confirmation.
- 3 Use the steering wheel controls to select the value. (Press CLR to reset the value.)
- 4 Press the SET button to finish setup.

Using DIST as a trip meter

- 1 Select **Dist** using the steering wheel controls,  or .
- 2 Press and hold the CLR button for approx. 1 second.

An arrow will now appear on the right-hand side of the display, indicating that the trip meter is running.

Resetting a single function

- 1 Select the function you wish to reset using the steering wheel controls,  or .
- **Fuel Ø**
- **Speed Ø**
- **Trip** (Dist used as trip meter).
- 2 Press and hold the CLR button for approx. 1 second.

The selected function will now be reset.

92 Instruments and controls

Resetting the trip computer

Press and hold the CLR button (approx. 3 seconds) until audible confirmation is given.

The following functions will be reset:

- **Fuel Ø**
- **Speed Ø**
- **D.T.E.** (the value is reset to the distance possible on the remaining fuel if fuel consumption is 10l/100 km, lower consumption means a longer possible distance)
- **Trip** (Dist used as trip meter).

Speed warning

This value is preset to 55 mph (90 km/h). The value can be set to between 0 and 150 mph (0 and 250 km/h).

- 1 Select **Speed W** using the steering wheel controls,  or .
- 2 Press and hold the SET button until given audible confirmation.
- 3 Adjust the speed using the steering wheel controls.
- 4 Confirm the setting by pressing the SET button.

Go back/modify using the CLR-button.

The word **ON** on the right-hand side of the display indicates when the speed warning function is active.

An audible alarm will sound if the set speed is exceeded.

Disengage the function with the CLR button. Re-engage the function using the SET button.

Calculating the arrival time

(When will I arrive if I know how far I have to drive?)

This function should be used before starting out a journey.

To calculate the arrival time, the distance must first be given.

- 1 Select **Dist** using the steering wheel controls,  or .
- 2 Press and hold the SET button until given audible confirmation.
- 3 Set the distance to the destination using the steering wheel controls.
- 4 Confirm the setting by pressing the SET button.

The calculated arrival time will now appear on the right-hand side of the display.

If you take a break, this time will be added to the previously calculated arrival time.

You can check the distance left by selecting **Dist**. At the same time you can check the calculated time of arrival.

After the distance to destination has decreased to zero, **Dist** will function as a trip meter (see Using DIST as a trip meter). The starting value for the trip meter will be the last distance set for the **Dist** function.

Example: The **Dist** function is set to 100 miles. After the count-down has reached 0 miles, **Dist** will act as a trip meter beginning at 100 miles.

Calculating the arrival time if a specified average speed is maintained

(When will I arrive if I know how far I have to drive and know what my average speed will be?)

This function should be used before starting out a journey.

First, set the distance under **Dist**.

- 1 Then select **Speed Ø** function.
- 2 Press and hold the SET button until given audible confirmation.
- 3 Set the estimated average speed using the steering wheel controls.
- 4 Confirm the setting by pressing the SET button.

The distance and the calculated time of arrival is now displayed.

The time of arrival is updated during the journey based on the average speed since **Dist** was set. The speed of the car must exceed 12 mph (20 km/h).

By selecting **Dist** during the journey, you can see how much distance is left to travel.

When **Dist** reaches zero it acts as a trip meter. The trip meter starts from the distance that was set previously.

NIGHTPANEL

To improve night-driving conditions inside the car, the Night Panel mode can be selected. In this mode, the amount of information displayed is reduced, and only the most important instruments and displays will be illuminated.

When the NIGHTPANEL button is pressed, only the speedometer will be illuminated.

All other instrument lighting will be switched off and the needles drop to zero.

Note: All indicator and warning lights and messages will operate normally if required.

Temp (when the outside temperature falls or rises to between 26 and 38 °F (-3 and +3 °C)) and **D.T.E.** (when the remaining fuel is only sufficient for approx. 80 miles (50 km) of driving) are even shown in Night Panel model.

94 Instruments and controls

Under **Settings** you can choose whether the entire speedometer scale (0–160 mph) or only part of the scale (0–90 mph) should be illuminated in NIGHTPANEL mode.

- 1 Select **Settings** using the steering wheel controls,  or .
- 2 Press and hold the SET button until given audible confirmation.
- 3 Select **Speed Scale Illum.**
- 4 Press the SET button.
- 5 Select 0–160 mph or 0–90 mph.
- 6 Confirm the setting by pressing the SET button.

Settings
Speed Scale Illum.
0–160 mph
0–90 mph

Alarm

- 1 Select **Settings** using the steering wheel controls,  or .
- 2 Press and hold the SET button until given audible confirmation.
- 3 Select **Alarm Clock** using the steering wheel controls.
ON or **OFF** is displayed.
 - If **OFF** is shown and the alarm time is to be set, press SET button (do not keep held in) and wait for the audible signal. The previously time set is now shown. Press SET button.
 - If **ON** is shown and the alarm time is to be activated, press SET button once, **OFF** is shown in the display. Press SET button again to activate the function.
- 4 Select alarm time using the steering wheel controls.
- 5 Confirm the setting by pressing the SET button.

Go back/modify using the CLR-button.

When the alarm sounds push one of the left steering wheel controls.

Settings

Under this heading you can select for example language and units.

- 1 Select **Settings** using the steering wheel controls,  or .
- 2 Press and hold the SET button until given audible confirmation.
- 3 Select heading using the steering wheel controls.
- 4 Press the SET button.
- 5 Select using the steering wheel controls.
- 6 Confirm the setting by pressing the SET button.

Select **EXIT** once you have made the desired settings.

The number of systems that are displayed on the SID depends on the car's equipment level. The list shown below includes the systems that can be found in your car.

Rain Sensor, page 103.
HIGH
MEDIUM
LOW
Theft Alarm, page 56.
FULL ALARM
DOOR ONLY

Park Assistance , page 180.
ON
OFF
Alarm Clock , page 94.
ON
OFF
Language.
ENGLISH UK
ENGLISH US
FRANCAIS
DEUTSCH
ITALIANO
ESPANOL
SVENSKA
Speed Scale Illum.
0–160 mph
0–90 mph
Speed Scale Sel.
BOTH SCALES
ONLY MPH SCALE

Unit
METRIC
US
IMPERIAL
Climate System , page 115.
Next Service: xx%.
INTERMEDIATE
MAIN
Time for Service.
INTERMEDIATE
MAIN
MAIN & INTERMED
Reset Service Ind? YES NO
TCS , page 173.
ON
OFF
ESP , page 175.
ON
OFF

Explanation of the various selections under **Settings**.

Rain Sensor

The sensitivity has three levels.

Park Assistance

The Park Assistance can be shut off by choosing OFF.

Alarm Clock

Setting of alarm clock is possible.

Language

Select the desired language. The number of languages can vary between markets.

Speed Scale Illum.

Select the proportion of the speedometer to be illuminated in NIGHT-PANEL mode.

Speed Scale Sel.

Select if both scales or just mph-scale shall be illuminated in NIGHTPANEL mode.

96 Instruments and controls

Unit

Select the desired group of units.

Next Service: xx%

The SID includes two mutually independent counters, one for the main service and one for the intermediate service. When a service is carried out, e.g. intermediate service, the counter is reset for the intermediate service. The counter for the other service type, main service, continues unaffected. This means that once a service has been carried out, the counter may show e.g. 47% even though a service has just been carried out. The percentage refers, then, to the other service type.

MAIN

Main services are carried out at specific meter settings. This interval varies depending on market and engine variant. Contact a workshop for more information. We recommend that you contact an authorised Saab workshop.

INTERMEDIATE

The intermediate service, on the other hand, is carried out depending on the number of cold starts and the climate conditions in which the car is driven, for example. This is why the interval for this type of service varies.

MAIN & INTERMED

A combined service is carried out when the counters of both service types are close to one another.

Time for Service.

A service indication must only be reset after the service has been performed.

TCS/ESP

Select whether the system shall be on or off. The car has either TCS or ESP.

Resetting the service indication

Reset the service indication in accordance with the following:

- 1 Turn the ignition switch to the ON position, the engine must be switched off.
- 2 Select **Settings** using the steering wheel controls,  or .
- 3 Press and hold the SET button until given audible confirmation.
- 4 Select **Time for Service**.
- 5 Press the SET button.
- 6 To the question **Reset Service Ind?** select **YES** (Press CLR button to undo).

Clock

Adjustments can be made in the Infotainment system.

See separate Manual.


Switches

AUTO Daytime Running Lights (DRL)

When the switch is in the AUTO position, there is an automatic switch between low-beam and Daytime Running Lights (DRL) based on the amount of daylight. Two sensors located at the top of the windshield detect upward and forward light intensity. This makes it possible for the system to automatically perform functions such as activating low beam when you drive into a tunnel on a sunny day.

Parking lights are turned off.

In cold and damp weather, the inside of the headlamp lens may temporarily mist up. This misting does not affect the function or service life of the light fitting. When the lamps are on, the mist will eventually disappear.



Light switch

Cars with xenon lights: The bulbs for DRL are in the inner of the two bulb holders in the bulb housing. The bulb is visible from the outside.

Cars with halogen lights: These cars do not have a separate DRL bulb. Low beam instead shines with reduced output.

A fault in the system will produce the following message on the Saab Information Display (SID):



Automatic light control malfunction.

When the engine is started and the switch is in the AUTO position

Cars with automatic transmission: DRL or low beam (which depends on the amount of daylight) comes on when the gear selector is moved out of the P position. The light goes out when the ignition switch is turned to the OFF position (engine is turned off).

Cars with manual transmission: If the parking brake is applied when the engine is started, DRL or low beam (which depends on the amount of daylight) comes on when the parking brake is released. Otherwise, the light comes on when the ignition switch is turned to the ON position. The light goes out when the ignition switch is turned to the OFF position (engine is turned off).

High beam cannot be activated in the DRL mode but headlight flasher can.

98 Instruments and controls

Parking lights

The parking lights can be turned on irrespective of the position of the ignition switch. If the parking lights are on and the driver's door is opened, a reminder to turn them off will sound.

Do not use the parking lights alone while driving.

When the switch is in the  position, there is no automatic shift between low beam and DRL.

When it is time to turn on low beam the following message appears in SID:

 **Turn on the lights.**

Headlights

Low beam headlights are turned on when the ignition switch is turned to ON and turned off when the switch is turned back to LOCK.

If the switch is in the  position, there is no automatic switch between DRL and low beam. Low beam comes on when the ignition switch is in the ON position.

Headlight levelling *


Cars with xenon headlights are equipped with an automatic headlight levelling system, which self-calibrates each time the vehicle is started.

If a fault arises in the automatic headlight levelling system, the headlights will be angled down to avoid dazzling drivers in oncoming traffic. Adjust your speed accordingly as the range of the headlights will be reduced. Check fuse 20 in the engine bay fuse box (see page 238).

A fault in the system will produce the following message on the Saab Information Display (SID):

 **Headlight levelling malfunction.**

Special equipment is required for adjusting the basic headlight alignment.




Xenon cornering headlights *

When the car speed exceeds approx. 6 mph (10 km/h), the main headlight will be angled when the steering wheel is turned. The beam can be angled maximum 15 ° to the right or left compared to a car without cornering headlights.

If a fault occurs in the cornering headlights, there is no angling when the steering wheel is turned. The beam continues to shine straight ahead and the following message appears in SID:



Cornering headlights malfunction



Dimmer switch

- 1 Headlight flasher
- 2 High/low beam

High/low beam

To switch between high and low beam, pull the control stalk all the way towards the steering wheel. (Headlight switch must be ON.)

The  symbol on the main instrument panel shows when the high beam is on.

Headlight flasher

To flash your headlights, pull the control stalk half-way towards the steering wheel. The high beam will remain on until you release the stalk.

Courtesy Headlamp Feature


A delay function allows the low beam headlights and back-up lights to remain on for about 30 seconds after the driver's door has been closed.

To activate this function:

- 1 After turning off the engine, remove the remote control.
- 2 Open the driver's door.
- 3 Pull the control stalk all the way towards the steering wheel.

The low beam headlights and reversing lights will come on and remain on for 30 seconds when the door is closed.

100 Instruments and controls



Adjusting instrument illumination

IB4433

Instrument lighting


The brightness of the instrument lighting can be adjusted by pressing the button (+ or – signs on the button above the NIGHT-PANEL button).

Front fog lights *

The front fog lights should be used in poor visibility.


These are automatically turned off when the engine is switched off. When the car is next started, the fog lights will have to be switched back on manually by pressing the fog light switch. If the engine is restarted within 30 seconds, the front fog lights will remain on but not if the light switch is in position AUTO.

Acquaint yourself with the legal provisions governing the use of front fog lights.



Front fog light switch

IB4433



Rear fog light switch

Rear fog light

To turn on the rear fog light, press the rear fog light button on the instrument panel. The headlights or front fog lights must be on.

The rear fog light is automatically turned off when the engine is switched off. When the car is next started, the rear fog light will have to be switched back on manually by pressing the rear fog light switch. If the engine is restarted within 30 seconds, the rear fog light will remain on but not if the light switch is in position AUTO.

Rear fog light consists of one bulb.


Acquaint yourself with the legal provisions governing the use of rear fog light.

Turn signal & lane change indicators

The stalk switch has an intermediate, spring-loaded position that is useful for signalling when changing lanes or passing. The stalk switch also has fixed positions for indicating a right or left turn, that are cancelled automatically when the steering wheel is centered.

If an indicator bulb breaks, the frequency with which the indicators flash will be doubled.

This frequency is also doubled if a trailer is being towed and one of its indicator bulbs breaks.



Turn signal & lane change indicators

- 1 Right
- 2 Left

102 Instruments and controls

Hazard warning lights

WARNING

Switch on the hazard flashers if the car has to be left at the roadside on account of a crash, engine trouble or a flat tire.


If you carry a warning triangle or flares, they should be set up along the side of the road 50–110 yds. (50–100 metres) behind your vehicle. If the car is not clearly visible (e.g. over the brow of a hill or bridge), place the triangle/flare even further back.

The button for the hazard warning lights is located on the climate control panel.


When the button is pressed, all the direction indicators and the symbol in the button flash simultaneously.

If an indicator bulb breaks, the frequency with which the indicators flash will be doubled.

Hazard warning lights should only be used if, because of an accident or breakdown, the car constitutes a hazard to other road users.



Hazard warning light switch



Button for accessory *

This button can be used for accessories, such as extra lights.

Back-Up

The back-up lights come on automatically when reverse gear is engaged or selected with the ignition switched on.

Priority of audible information

If two or more functions are active simultaneously, the most important function at that time will be prioritized.

If, for example, the direction indicators are active when you engage reverse, the parking assistance (if fitted) will be heard instead of the direction indicators. When reverse is disengaged, the direction indicators will be heard, if they are still active.

Wipers and washers

Windshield wipers

Position 1 is a spring-loaded position that will produce a single sweep of the wipers.

The wipers always return to their home position when the ignition is turned off.

To leave the wipers positioned vertically on the windshield, proceed as follows:

- 1 Switch off the engine and remove the remote control.
- 2 Activate the wipers within the next 16 seconds by pressing the stalk switch down.

When the ignition is next switched on the wipers will return to their home position.

Changing wipers blades, see page 216.

Rain sensor

WARNING

Turn the rain sensor off if the ignition is ON to avoid personal injury when clearing snow and ice from the windshield.

NOTICE


Turn the rain sensor off before washing the car in an automatic carwash, to avoid damaging the windshield wipers.

When the rain sensor is activated the following symbol is displayed in SID .

The rain sensor automatically controls the windshield wipers. The sensor is located on the windshield beside the rearview mirror.

The system varies the frequency of wiping between single sweeps and continuous wiping, depending on the amount of precipitation.

104 Instruments and controls



Windshield wipers with rain sensor

- 0 OFF
- 1 Single sweep
- 2 AUTO - rain sensor engaged
- 3 Low speed
- 4 High speed
- 5 Windshield and headlight washing *

Activate the rain sensor by lifting the stalk switch to the AUTO position. The wipers make one sweep for reference to see how much water is on the windshield. Thereafter the sensor compares the amount of water on the windshield with this reference value.

If the stalk switch is left in the AUTO position when the engine is switched off, when the engine is next started it must first be moved to the 0 or 3 position and then back to AUTO to reactivate the sensor.

If the system malfunctions, the wipers will operate at low speed when the stalk switch is set to the AUTO position and SID will show:



Washers

Activate the washers by pulling the stalk switch towards the steering wheel.

When the washers are operated, the wipers will make 3, 4 or 5 sweeps, depending on how long the washers were kept on. If the speed of the car is less than 12 mph (20 km/h), the wipers will make an additional sweep after roughly 8 seconds.

When the washer fluid level drops below 1 quart (1 liter), the headlight washers (if equipped) are deactivated. This is in order to prioritize the windshield. The following message is displayed on the SID:



**Washer fluid level low.
Refill.**

Headlight washers *

The headlights are washed at the same time as the windshield if the headlights are on.

The headlights are washed every fifth time the windshield washers are used or if two (2) minutes have elapsed since the windshield was last washed.

The headlight washers are not activated at speeds in excess of 125 mph (200 km/h).

Adjusting sensitivity

The sensitivity of the rain sensor can be adjusted under **Settings**.

- 1 Select **Settings** using the steering wheel controls,  or .
- 2 Press and hold the SET button until given audible confirmation.
- 3 Select **Rain Sensor**.
- 4 Press the SET button.
- 5 Select the sensitivity.
- 6 Confirm this selection by pressing the SET button.

Go back/modify using the CLR-button.

Rain Sensor
HIGH
MEDIUM
LOW

The sensitivity of the sensor is also affected by the amount of daylight. The sensor is somewhat more sensitive at night. This adjustment is automatic.

Explanation of sensor sensitivity.

HIGH

The sensor is set to high sensitivity. The wipers start when there is only a small amount of water on the windshield.

MEDIUM

*The sensor is set to normal sensitivity. This is one of the **Default Settings**.*

LOW

The sensor is set to low sensitivity (wipers operate only with a large amount of water on the windshield, i.e., down-pour).

106 Instruments and controls

Rear window wiper, SportCombi

To obtain:

- a single sweep: move the control to position 2, the control springs back to the home position.
- intermittent wiping, 6 seconds: move the control to position 2.
If the windshield wipers are activated then the rear window wiper will automatically changeover to intermittent wiping when reverse gear is engaged and the engine is running.
- washing and wiping: move the control to position 3.
The control returns to the home position. The wiper makes 3 sweeps after the washing has finished. If the speed of the car is below 25 mph (40 km/h) when the washing has finished the wiper makes an extra sweep after 5 seconds to wipe off any washer fluid residue.


The washer jet is not adjustable.

Changing wiper blade, see page 216.

When the washer fluid level drops below 1 liter, the rear window washer is deactivated. This is in order to prioritize the windshield. The following message is displayed on the Saab Information Display (SID):



**Washer fluid level low.
Refill.**



Rear window wiper, SportCombi

- 1 OFF
- 2 Intermittent wiping
- 3 Washing and wiping

Automatic climate-control system (ACC)


Fresh air for the cabin is drawn in through an inlet at the bottom edge of the windshield. It passes through an effective filter before reaching the climate control system and delivery into the cabin. The air is evacuated via openings in the parcel shelf. It is then led through outlets on either side of the car behind the rear bumper.

The Automatic Climate-Control system (ACC) automatically maintains the desired cabin temperature, regardless of the weather outside.

The system will achieve the desired temperature in the quickest possible way.

Note that heating or cooling is not more rapid by setting the temperature higher or lower than the final temperature you desire.

To optimize the performance of the air conditioning system, all windows and the moonroof * should be shut. The air vents in the fascia must be open.



ACC panel


- | | |
|--|---------------------------------------|
| 1 Temperature setting: left-hand side | 6 Recirculation |
| 2 AUTO (automatic regulation) | 7 Seat heating, front right seat * |
| 3 Fan speed | 8 Rear window and door mirror heating |
| 4 Manual setting of air distribution | 9 A/C OFF |
| 5 Temperature setting: right-hand side | 10 Seat heating, front left seat * |

The incoming air is treated in three stages: first it passes through a filter; it is then dehumidified and cooled; and finally, if required, it is heated.

The filter is a combined particle and charcoal filter. It is so efficient that levels of noxious substances such as benzene and toluene are also reduced.


To reduce potential misting on the insides of the windows, the glass should be cleaned with a quality glass cleaner. How often this will need to be done depends on how clean the air is - if there are smokers in the car, the windows will need to be cleaned more frequently.

108 Instruments and controls



Sun- and cabin sensor, SportSedan and SportCombi

- 1 Sun sensor
- 2 Cabin temperature sensor



Sun- and cabin sensor, Convertible


- 1 Sun sensor
- 2 Cabin temperature sensor

The system uses seven sensors:

- Outside air temperature sensor
- Cabin air temperature sensor (by the interior rearview mirror)
- Sun sensor (on the fascia)
- Blended air temperature sensors 2 (located in the front floor vents).
- Blended air temperature sensors 2 (located in the outer panel vents).

Note

If the sun sensor is covered, the ACC system will not be able to regulate the cabin climate as intended.



Panel vent

Air vents

The air vents swivel universally, so that air can be directed as desired. In winter, for instance, the outer vents can be directed onto the door windows for enhanced demisting.

The amount of air can be individually controlled by the regulator on each vent. If you wish to reduce the airflow, start by half-shutting the vent in question.

Certain variants have an air vent on the rear of the floor console.

Temperature control

The cabin is divided into two temperature zones:

- 1 Driver's zone.
- 2 Passenger zone.

The temperature in the rear seat will be a mixture of the two zones.

The cabin temperature can be set to between 61–79 °F (16–26 °C).

The selected temperature is not the actual air temperature but corresponds to the comfort level normally experienced at that temperature after allowance has been made for the airflow, relative humidity, solar radiation, and so on, currently prevailing inside the car.

Instruments and controls 109

- The most usual temperature setting is between 64–75 °F (18–24 °C), depending on personal preference and what clothing is worn.
- Change the temperature setting in 2 °F (1 °C) steps.

Make sure the air vents are open when cooling the cabin in warm weather.

When the ignition is switched off, only the temperature control affects the system the next time the engine is started. The system will warm up/cool down to the temperature to which the control is set.



110 Instruments and controls


MAX heat (red indicator):

MAX heating is obtained when the temperature knob is turned to the first position past 79 (to the red LED).

The driver's side selection controls air distribution and the recirculation status. The temperature can be adjusted on the passenger side.

MAX heating produces:

- Max heat
- Air distribution to windscreen and floor
- Recirculation OFF
- High fan speed.




MAX cooling (blue indicator):

MAX cooling is obtained when the temperature knob is turned to the first position past 61 (to the blue LED).

The driver's side selection controls air distribution and the recirculation status. The temperature can be adjusted on the passenger side.

MAX cooling produces:



- Max cooling effect (A/C compressor will run even if AC OFF has been selected)
- Air distribution through panel vents
- Max fan speed
- Recirculation ON.



Condensation water

When the A/C compressor is on, the incoming air is dehumidified. The resulting condensation water is drained away through an outlet under the car.

It is therefore perfectly normal for water to be seen dripping from this outlet when the car is parked. The warmer the ambient air and the higher the humidity, the more condensation will form.




Functions

Pressing AUTO will cancel all manual settings.

If a manual function is selected, it will be locked in but other functions will be controlled automatically.


The selected temperature is always maintained automatically.

	<p>Temperature, air distribution, fan speed and recirculation will be controlled automatically. Pressing AUTO once will cancel all previous manual air distribution selections. When the engine is started, the ACC system will be in AUTO mode.</p>
	<p>The A/C-compressor is turned off. The incoming air is not cooled or dehumidified. Temperature, air distribution, fan speed and recirculation will be controlled automatically.</p>
	<p>Turn the fan control counterclockwise until "OFF" lights up. ACC-system OFF. Fan OFF. A/C-compressor OFF. Air distribution selections locked in current settings. Recirculation can be selected manually. Heating * of the front seats is deactivated. Pressing AUTO-button will put the system into automatic mode. Reactivation by turning the fan control clockwise one click causes the system to resume any manual selections.</p>

	<p>The rear window and door mirror heating is controlled manually. Deactivate the heating as soon as the rear window is clear of ice and misting to avoid imposing a heavy load on the battery longer than necessary. Note, however, that heating will deactivate automatically after a set time.</p>
	<p>Turn the fan control to increase fan speed. If fan speed 0 is selected, the A/C-compressor will be disengaged and the indicator on the AC OFF button will illuminate.</p>
	<p>The recirculation is controlled automatically for optimum cooling. If necessary, recirculation can also be switched on manually for shorter times to avoid unpleasant air from entering the cabin for example. Poor air quality in the cabin could lead to tiredness. For this reason you should only drive in the recirculation position temporarily. If recirculation is switched on when the outside temperature is lower than about +37 °F (+3 °C) (A/C compressor disengaged) then the air humidity in the cabin increases which could cause misting on the windows.</p>

112 Instruments and controls

Air distribution



B4442


One press: When the defroster is chosen manually, all the windows (except the rear side windows, where the air flow is off) are demisted by:

- High fan speed.
- The air is directed to the defroster vents.
- Temperature increases somewhat.
- Recirculation OFF.
- Activation of rear window/door mirror heating.

The defroster function remains engaged until another selection is made. Heating of the rear window/door mirrors will, however, deactivate after a set time period.


Two presses: Air is directed to the windscreen without the fan speed being increase or the rear window heating being switched on.

To revert to a previous setting, press the AUTO button.




B4445

Defroster and floor vents




B4444

Floor vents



B4446

Floor and panel vents



Start in cold weather

To start with, the system will automatically select the defroster setting, maximum heat and low fan speed.

As the engine warms up, air will also be distributed through the floor vents and the fan speed will be increased.

As the temperature inside the car nears the selected value, both the fan speed and the heat will be decreased to a level determined by the system.

Start in warm weather

The system will automatically distribute air through the panel vents at high fan speed and will activate the A/C compressor (unless the AC OFF switch has been pressed).

If the ambient air temperature is over 77 °F (25 °C), the recirculation cuts in after 0-15 seconds, if this is required in order to reach the desired temperature.

As the temperature inside the car nears the selected value, the fan speed will be decreased to a value determined by the system.

114 Instruments and controls

Formation of ice and mist in extreme weather conditions

It is only in the most extreme conditions that icing and misting of window glass are likely to be a problem, such as in torrential rain or severe cold coupled with high relative humidity, or when passengers are perspiring heavily or wearing wet clothes. The following measures are recommended if such problems should occur:

- 1 Select AUTO and set the temperature to 70 °F (21 °C)
- 2 Push one time on the defroster button. If this is not enough...
- 3 Increase the fan speed. If this is not enough...
- 4 Select a higher temperature.



Electric heating, front seats *

The seat cushions and backrests of the front seats are heated.

Heating is thermostatically controlled.

The heating has two effect steps.

We do not recommend prolonged use of the higher level for people with sensitive skin.

Heating is controlled manually but can also be automatic. Refer to **Settings** on page 115.

Calibration

Calibration is performed automatically every 40:th time the car is started after having been switched off for more than 2 hours or if the battery has been disconnected.

Programming

A number of functions can be customized under **Settings** (see page 115).

Tips

(before contacting a dealer. We recommend that you contact a Saab dealer)

- If you feel that the ACC system is not functioning satisfactorily, select "**Default Settings**" under **Settings**, see page 115.

ACC- Convertible

When the soft top is folded, several functions in the ACC-system is effected.

The system adjusts itself as follows:

- the sensitivity of the temperature knob changes
- air distribution and fan speed can only be adjusted manually
- Recirculation and rear window heating are cut out
- The A/C compressor is switched off (manual activation is possible by pressing the AC OFF button).

All manual selections are possible with the exception of rear window heating and defroster function.

When the soft top is raised, the system reverts to the AUTO mode and the set temperature.

Note: When the soft top or all the windows are open in a hot, humid climate, turning the air conditioning on manually can cause condensation to form on cold surfaces, such as the air ducts.

Settings

Some of the functions of the ACC system can be customized.

- 1 Select **Settings** using the steering wheel controls,  or .
- 2 Press and hold the SET button until given audible confirmation.
- 3 Select **Climate System**.
- 4 Press the SET button.
- 5 Select the **Rear Defroster, Heated Seats, Fan Settings, A/C Mode or Default Settings**.
- 6 Press the SET button.
- 7 Make your selection.
- 8 Confirm your selection by pressing the SET button.

Settings	
Climate System	
Rear Defroster	
	AUTO
	MANUAL
Heated Seats	
	AUTO
	MANUAL
Fan Settings	
	HIGH SPEED
	MEDIUM SPEED
	LOW SPEED
A/C Mode	
	AUTO
	OFF
Default Settings	
Are you sure?	
	YES NO

Explanation of how the ACC system can be customized under **Settings**.

Rear Defroster

AUTO

The rear window and door mirror heating is controlled automatically. This is one of the Default Settings.

MANUAL

The rear window and door mirror heating is switched on with the button on ACC panel.

Convertible: The rear window heating cannot be turned on when the soft top is folded.

Heated Seats

AUTO

The front seat heating is controlled automatically. Select the level by repeatedly pressing the appropriate button on the ACC panel.

MANUAL

*See **Electric heating, front seats** * on page 114. This is one of the Default Settings.*

Fan Settings

HIGH SPEED

This selection give a slightly higher fan speed than MEDIUM SPEED though with continued automatic regulation.

MEDIUM SPEED



116 Instruments and controls



Normal automatic fan speed. This is one of the Default Settings.

LOW SPEED

This selection give a slightly lower fan speed than MEDIUM SPEED though with continued automatic regulation.

Convertible: Fan speed is not regulated automatically when the soft top is open.

A/C Mode

Auto

Automatic engagement and disengagement of the A/C. This is one of the Default Settings.


A/C off

A/C compressor OFF (see also page 111). The A/C compressor can be activated temporarily by pressing the AC or AUTO button while on the road and if the outside temperature is above 41°F (+5°C). The A/C will be off the next time the engine is started, if the engine has been switched off for more than 2 hours.

Convertible: The A/C compressor is switched off when the soft top is folded down.

Further customizations to this function can be made at a workshop. We recommend that you contact a Saab dealer.

- The A/C compressor can be on even when the soft top is folded down.
- The A/C compressor can be set to operate as when the soft top was last folded down.



Interior equipment



Steering wheel adjustment _____	118
Electric windows _____	119
Rear view mirrors _____	122
Moonroof * _____	128
Interior lighting _____	131
Cup holder * _____	133
Power Outlet * _____	134
Storage compartments _____	134
Trunk _____	136

* Asterisk means: equipment not fitted in all cars (can depend on model variant, engine variant, market specification, options or accessories).

118 Interior equipment

Steering wheel adjustment

WARNING

Only adjust the steering wheel while the car is stationary so that you are not distracted from the traffic.


The height and reach of the steering wheel can be adjusted.

There is a release lever under the steering column.


- 1 Pull down the lever to release the steering wheel.
- 2 Adjust the position of the steering wheel.
- 3 Raise the lever to the locked position to lock the steering wheel in position.

When returning the release lever to its locked position, you may need to adjust the position of the steering wheel slightly to allow the lock mechanism to engage correctly.

Steering wheel lock, see page 151.



Lever for steering wheel adjustment



Horn signal

Activate the horn by pressing one of the three areas shown above on the steering wheel pad.

Electric windows

WARNING


Bear in mind the pinch hazard when closing the side windows. May cause serious or fatal injuries!

- **Always** remove the remote control from the ignition switch when you leave the car. This will prevent personal injury caused by the activation of the electric windows, for example, due to children playing.
- The person operating the electric window is responsible for ensuring that no one, especially a child, has their head, hands or fingers in the window openings, before raising the window.
- Do not stick any part of the body or the head out through an open window while the car is moving.

The electric windows are operated by means of switches in the door armrests.

For the electric windows to work, the ignition switch must be in the ON position.

At the end of a journey and having removed the remote control, you can still operate the windows, so long as neither of the front doors has been opened.



Window switches


Windows having the automatic closing function (option) can be operated as long as the car is unlocked and until 20 minutes has passed since the remote control was removed from the ignition switch.

To open

Press down the front edge of the button one step.

The window will stop when it is fully open or when the button is released.

Automatic opening: Press the button all the way down and release it.



Window switch in rear door

Comfort opening *

Comfort opening is the remote opening of windows and the moonroof.

Press and hold the unlocking button on the remote control until the windows and optional moonroof start to open (approx. 2 seconds).

During comfort opening of the windows, moonroof * and soft top (Convertible), the range is reduced by approximately half.

Convertible: For the remote opening * of the soft top, refer to page 64.

120 Interior equipment

To close

WARNING

Take care when closing a window to ensure that no one gets caught.

Raise the front edge of the button one step. The window will stop when it is fully closed or when the button is released.

Automatic closing *: Raise the button all the way and release it. If the window does not close automatically, refer to Calibration on page 121.

Pinch protection *

On certain model variants, the front electric windows are equipped with pinch protection. This is activated if something gets trapped between the window pane and door frame when the window is closed. The window will stop and lower slightly.

Temporary overriding the pinch protection


WARNING

Make sure nothing obstructs the window when it is closed without pinch protection.

If dirt, ice or similar create so much resistance that the pinch protection cuts in (the window cannot be closed), the pinch protection can be temporarily disengaged and the window closed.

- 1 Make sure the ignition is ON.
- 2 Press and hold the  button on the driver's door while operating the window in question.
- 3 Close the window in question.

The pinch protection will be active the next time a window is operated.



Button for temporary deactivation of rear door window switches and temporary override of window pinch protection

Calibration

WARNING

The pinch protection will not be engaged after a power break until the electric windows have been calibrated.

The front electric windows should be calibrated if automatic closing does not work or if the battery has been disconnected. The pinch protection * will not work if the windows are not calibrated.

Calibration is performed as follows:

- 1 Close the doors.
- 2 The car must be running at idling speed. A battery charger must not be connected to the car's battery during calibration.
- 3 Open the window fully, the button must be kept depressed the whole time.
- 4 Close the window fully, the button must be kept raised the whole time and for approx. 1 second after the window has closed.
- 5 Open the window fully, the button must be kept depressed the whole time and for approx. 1 second after the window has fully opened.
- 6 Close the window fully, and keep the button raised until the calibration is confirmed with a "chime".

Repeat steps 3–6 for the windows which require calibration.

Deactivating the rear window switches

The  in the driver's door deactivates the window switches in the rear doors.

The illuminated switch will change color from green to orange (deactivated).

122 Interior equipment

Rear view mirrors

Door mirrors

To adjust


The door mirrors are electrically adjustable and heated. The controls for adjusting the mirrors are on the driver's door:

- 1 Select a door mirror with the upper button.
- 2 Adjust the mirror using the touch pad.

The mirror glass can also be adjusted manually by gently pressing the glass in the desired direction.

The mirror heating is turned on together with the rear window heating.


If the car has an electrically adjustable driver's seat with memory, the mirror settings are stored in the memory (see page 20).



- 1 Selection of mirror
- 2 Touch pad for adjustment
- 3 Reversing position *

Manual retraction


The door mirrors are designed to fold back if knocked. The mirrors can also be retracted manually. This can be useful when parking in tight spaces, such as on the car deck of a ferry. Remember to return the door mirrors to their normal positions before driving off.



Retracting a door mirror

Reversing position *

On certain model variants, the passenger-side mirror glass can be angled down to facilitate reversing. Press the  button shown in the illustration. This is located under the touch pad. Return the mirror to its normal position by pressing the button again. The mirror will also return to its normal position if you drive forward approximately 22 yds. (20 meters).



Mirror position lever
 1 Normal position
 2 Anti dazzle position

Interior rear view mirror

The interior rear view mirror is of the auto dimming type and can be deflected with the lever on its underside. Certain variants have an auto dimming rear view mirror.

The lever should be in the normal position when you adjust the mirror.


Interior rear view mirror with garage opener, auto dimming function and compass *

! WARNING

Make sure that people and objects are out of the way of moving door or gate to prevent potential harm or damage.

When programming the garage opener, you may be operating a garage door or gate operator. Therefore it is advised to park outside of the garage.

Do not use the garage opener with any garage door opener that lacks the safety stop and reverse feature as required by federal safety standards. (This includes any garage door opener model manufactured before April 1, 1982.). A garage door opener which cannot detect an object, signaling the door to stop and reverse, does not meet current federal safety standards. Using a garage door opener without these features increases risk of serious injury or death.



Buttons for garage opener, auto dimming and compass

- 1–3 Garage opener
- 4 LED
- 5 Auto dimming/compass ON/OFF
- 6 Compass bearing

Retain your original garage door opener (transmitter) for future programming procedures (i.e., new vehicle purchase). It is also suggested that upon the sale of the vehicle, the programmed garage opener buttons be erased for security purposes, see page 126.

124 Interior equipment

Preparations for first-time programming

Before programming the garage opener for the first time, you must delete any factory codes.

Press and hold the two outer buttons until the indicator light begins to flash-after 20 seconds. Release both buttons. Do not hold for longer than 30 seconds. The garage opener is now in the train (or learning) mode and can be programmed at any time beginning with "Programming" - step 2.

Programming

The garage opener can record and store the frequencies of three different remote controls.

The battery in the remote control should be fairly new for programming to work well.

Do not repeat "Programming" - step two to train additional devices to a second or third button. Begin with "Programming" - step three.

- 1 Turn the ignition ON.
- 2 Press and hold the two outer buttons (buttons one and three) - releasing only when the indicator light begins to flash (after 20 seconds). **Do not** hold the buttons for longer than 30 seconds and **do not repeat step two** to program a second and/or third hand-held transmitter to the remaining two buttons.
- 3 Position the end of your hand-held transmitter 1-3 inches (5-14 cm) away from the button you wish to program while keeping the indicator light in view. The transmitter should face the mirror from below or left side of the mirror.
- 4 Simultaneously press and hold both the chosen and hand-held transmitter buttons. **Do not release the buttons until step 5 has been completed.**

Note: Some gate operators and garage door openers may require you to replace this Programming Step 4 with procedures noted in the "Gate Operator / Canadian Programming" section.

- 5 After the indicator light changes from a slow to a rapidly blinking light, release both the mirror and hand-held transmitter buttons.
- 6 Press and hold the just-trained button and observe the indicator light. If the indicator light **stays on constantly, programming is complete** and your device should activate when the button is pressed and released.

Note: To program the remaining two buttons, begin with "Programming" - **step three. Do not repeat step two.**

If the indicator light blinks **rapidly for two seconds and then turns to a constant light continue with "Programming" steps 7-9** to complete the programming of a rolling code equipped device (most commonly a garage door opener).

- 7 At the garage door opener receiver (motor-head unit) in the garage, locate the "learn" or "smart" button. This can *usually* be found where the hanging antenna wire is attached to the motor-head unit.
- 8 Firmly press and release the "learn" or "smart" button. (The name and color of the button may vary by manufacturer.)

Note: There are 30 seconds in which to initiate step nine.

- 9 Return to the vehicle and firmly **press, hold for two seconds and release** the programmed button. Repeat the "**press/hold/release**" sequence a second time, and, depending on the brand of the garage door opener (or other rolling code equipped device), repeat this sequence a third time to complete the programming process. The garage opener should now activate your rolling code equipped device.

Note: To program the remaining two buttons, begin with "Programming" - **step three. Do not repeat step two.**

Gate Operator / Canadian Programming

Canadian radio-frequency laws require transmitter signals to "time-out" (or quit) after several seconds of transmission - which may not be long enough for the garage opener to pick up the signal during programming. Similar to this Canadian law, some U.S. gate operators are designed to "time-out" in the same manner.

If you live in Canada or you are having difficulties programming a gate operator by using the "Programming" procedures (regardless of where you live), **replace "Programming" step 4** with the following:

Note: If programming a garage door opener or gate operator, it is advised to unplug the device during the "cycling" process to prevent possible overheating.

Continue to press and hold the button while you **press and release - every two seconds** ("cycle") your hand-held transmitter until the frequency signal has successfully been accepted by the garage opener. (The indicator light will flash slowly and then rapidly.)

Proceed with "Programming" step five to complete.

NOTICE

Switch off the power supply to the garage door or gate (or park the car beyond the range of the remote control) while programming using the "cycling" method to prevent damaging the electrical motor.

Reprogramming a single button

To program a device to the garage opener using a button previously trained, follow these steps:

- 1 Press and hold the desired button. **DO NOT** release the button.
- 2 The indicator light will begin to flash after 20 seconds. Without releasing the button, proceed with "Programming" - step 3.

126 Interior equipment


Erasing the three buttons

To erase programming from the three buttons (individual buttons cannot be erased but can be "reprogrammed" as outlined below), follow the step noted:

Press and hold the two outer buttons until the indicator light begins to flash-after 20 seconds. Release both buttons. Do not hold for longer than 30 seconds. The garage opener is now in the train (or learning) mode and can be programmed at any time beginning with "Programming" - step 3.

Opening a garage door

To operate, simply press and release the programmed button. Activation will now occur for the trained device (i.e. garage door opener, gate operator, security system, entry door lock, home/office lighting, etc.). For convenience, the hand-held transmitter of the device may also be used at any time.



Buttons for garage opener, auto dimming and compass

- 1-3 Garage opener
- 4 LED
- 5 Auto dimming/compass ON/OFF
- 6 Compass bearing

Auto dimming

Press button 5 briefly to switch auto dimming on or off. When auto dimming is switched on, a 1 is displayed briefly in the compass window. A 0 indicates that auto dimming is switched off.

Compass

The compass is built into the rear view mirror. The compass bearing is displayed in the top right-hand corner of the mirror and is updated every other second. The compass displays the car's direction of travel: N, NE, E, etc.

Switch the compass display on and off by pressing button 5 for 3 seconds, see illustration on page 126.


Changing zones

The earth's magnetic field varies depending on one's position on the globe. If you drive your car from one magnetic zone to another the compass setting will need to be changed to ensure a correct bearing.

- 1 Study the illustrations to determine the correct zone.
- 2 Press and hold button 5 until "ZONE" is shown in the display on the mirror (6 s). The zone number is now also shown.
- 3 Press button 5 repeatedly to change the zone number. There are 15 zones from which to choose. Once the correct zone is selected, release the button and wait 4 seconds. The compass will now display the bearing.



Compass zones in USA



Compass zones in Canada

Calibration

Calibration is performed automatically during travel.

If, for any reason, a manual calibration is needed perform as follows:

- 1 Press and hold button 5 until "CAL" and the compass bearing are displayed (approx. 9 s).
- 2 Drive in circles (max. 5 mph/8 km/h) or drive as normal until "CAL" is no longer displayed.

Moonroof ✱


⚠ WARNING

Bear in mind the pinch hazard when closing the electric moonroof. Risk of serious or fatal injuries!

- **Always** remove the remote control from the ignition switch when you leave the car. This will prevent personal injury caused by the activation of the electric moonroof, for example, due to children playing.
- The person operating the electric moonroof is responsible for ensuring that no one, especially a child, has their head, hands or fingers in the opening, before closing the moonroof.
- Do not stick any part of the body or the head out through an open window while the car is moving.

The moonroof is operated by the control in the roof console. For the moonroof to work, the ignition switch must be in the ON position.

If the car is equipped with windows having the automatic closing function, the moonroof can be opened and closed so long as the car is unlocked until 20 minutes has passed since the remote control was removed from the ignition switch.



Moonroof control

- 1 Manually controlled opening
- 2 Automatic opening

- 3 Manually controlled closing
- 4 Automatic closing
- 5 Ventilation position

To open

Manually controlled opening

Slide the control rearward to its first position. The moonroof will halt when you release the control. If you do not release the control, the moonroof will open to the comfort position. To open the moonroof further, release the control and then once again press it rearward.

Automatic opening

Slide the control rearward to the second position and release it. The moonroof will open to the comfort position. To open the moonroof further, slide the control rearward a second time.

Moonroof without automatic opening

Slide the control rearward to position 1 (see illustration). The moonroof will stop when you release the control or once it is fully open.

To close

**WARNING**

Exercise great care when closing the moonroof to ensure that nothing gets trapped.

Manually controlled closing

Slide the control forward to its first position. The moonroof will halt when you release the control.

Automatic closing *

Slide the control forward to its second position and release it. The moonroof will close fully.

The moonroof pinch protection halts closing and opens the moonroof slightly if something obstructs closing.

Moonroof without automatic closing *

Slide the control forward to position 3 (see illustration). The moonroof will stop when you release the control or once it is fully closed.

Ventilation position (rear edge of moonroof open)

- To open – press in the control.
- To close – slide the control forward to the second position.

It is also possible to select the ventilation position when the moonroof is open by pressing in the control. The moonroof will then close automatically. Press the control once more to open the moonroof to its ventilation position.

If you wish to open the moonroof fully from the ventilation position, you must first close it (slide the control forward). You can then slide the control rearward to open the moonroof.

The moonroof incorporates an interior, manual, sliding sun blind.

Moonroof without automatic closing *

- To open – press the control up.
- To close – slide the control forward to position 3.

Comfort opening *

Comfort opening is the remote opening of windows and the moonroof.

Press and hold the unlocking button on the remote control until the windows and optional moonroof start to open (approx. 2 seconds).

During comfort opening of the windows, moonroof (option) and soft top, the range is reduced by approximately half.

If the moonroof is in the ventilation position, it will not open.

Convertible: For the remote opening of the soft top, refer to page 64.

130 Interior equipment

Pinch protection *

WARNING

Make sure nothing obstructs the moonroof when it is closed without pinch protection.


The moonroof is equipped with pinch protection. This is activated if something gets trapped when the moonroof is being closed. The moonroof will stop and open slightly.

Temporary overriding the pinch protection


If dirt, ice or similar create so much resistance that the pinch protection cuts in (moonroof cannot be closed), the pinch protection can be temporarily disengaged.

- 1 Make sure the ignition is ON.
- 2 Press and hold the  button on the driver's door while operating the window in question.
- 3 Close the moonroof with the button on the roof console.

The pinch protection will be operative the next time the moonroof is operated.



Button for overriding the moonroof pinch protection




Emergency operation of the moonroof

In an emergency, such as if there is an electrical failure, the moonroof can be operated with a screwdriver.

Remove the lens from the roof console. Use a screwdriver to press in the pin in the slot in the center of the motor shaft and turn the screwdriver.

Turn clockwise to close the moonroof when in ventilation position.

Turn counter-clockwise to close when in open position.



- 1 Interior lighting always off
- 2 Interior lighting controlled by the doors
- 3 Interior lighting on continuously

Interior lighting

The interior lighting consists of one front and one rear roof light, floor lighting, and courtesy lights in the doors (certain variants only). The light switch for the interior lighting is located on the roof console by the rear view mirror.


When the switch is in the mid-position (door-activated), the interior lighting will come on:

- When the car is unlocked
- When a door is opened and the ignition is OFF
- When the remote control is removed from the ignition switch.

The lighting goes out:

- When the car is locked
- When the ignition is turned on
- Approx. 20 seconds after closing all doors.

The lights are dimmed out gradually.




Rear lighting

- 1 Reading lights
- 2 Roof light

If a door is left open and the light switch is in position 2 or 3 and the ignition is OFF, the interior lighting will be switched off automatically after 20 minutes to save the battery.

The glove box lighting is switched on and off automatically when the glove box is opened and closed.

132 Interior equipment



Sun visor with vanity mirror


Sun visor

Illuminated vanity mirrors are provided on the sun visors. The lighting comes on when the cover is raised.

Trunk lighting

The trunk lighting is switched on and off when the trunk lid is opened and closed.

If the trunk lid is left open, the lighting will be switched off automatically after 20 minutes to prevent the battery from running flat.



Fastening the floor mat

Floor mats

WARNING

Secure the loose floor mats into the floor, otherwise they could slide forward. This is particularly important on the driver's side as the mat could otherwise slide under the pedals and interfere with driving.

Press the loose mat down over the two floor brackets. Then check that the mat is firmly secured.

Cup holder *


WARNING

- The cup holder should not be used to hold cups made of china or glass as these can cause personal injury in the event of a crash.
- Use only paper mugs, plastic bottles or aluminium cans.
- Avoid spillage, particularly of hot drinks.


NOTICE

Take care not to spill any liquid on the audio system, the ignition switch or the like when using the cup holders. Soft drinks in particular can cause malfunctions.

Cup holders are provided in the fascia, in the center console compartment between the front seats and rear seat cushion (Sport-Sedan and SportCombi). The cup holder between the seats can be raised if you wish to use the compartment for storage.




Cup holder in fascia



*Cup holder in center console compartment between front seats **

*Cup holder in rear seat cushion * Sport-Sedan and SportCombi*



134 Interior equipment

Power Outlet *

WARNING

The maximum output of the cigarette lighter socket is 240 W (20 A). The rating of the socket in the compartment between the seats is the same. Overloading can result in melting or even fire.


You can use the electrical socket in the storage compartment under the armrest between the front seats to charge a mobile phone, for example. There is a recess on each side of the compartment which will accept a lead so that you can close the lid without damaging the charger lead.

Storage compartments


WARNING

The glove box must be closed while travelling. An open glove box door could cause personal injury in the event of a crash.


There are additional storage compartments below the front ashtray and in the doors (cars with Bose® Centerpoint® Surround Sound System do not have storage compartments in the rear doors).




*Open the glove box with the button on the left of the moulding.
Convertible has lockable glove box. Use the traditionally key, see page 54.*



*Sliding cover in glove box to admit cold air.
This allows the storage of chocolate during hot weather for example.*




Storage compartment between front seats



*Storage pocket on front edge of seats **

*Storage pocket on back of seats **



136 Interior equipment


Trunk

Folding down the rear seat, SportSedan

Convertible: The rear seat cannot be folded.

WARNING

- Never drive the car if the backrest is not correctly locked into position as this increases the risk of personal injury in the event of heavy braking or a crash.
- Never leave a child or animal unattended in the car. During sunny weather the temperature in the passenger and trunk can climb to 160–180 °F (70–80 °C). Small children are very susceptible to heat stroke.
- Keep hands well clear of all moving parts.
- Never place heavy objects on the parcel shelf. There is always a danger of loose objects being thrown forward and causing injury if the car should brake suddenly or be involved in a crash. See also page 192.
- When folding the backrest back upright, make sure that it is locked correctly on both sides. This is imperative since the center safety belt is mounted in the backrest.



- When folding the backrest back upright, make sure that it is locked correctly on both sides. This is imperative since otherwise objects in the trunk could force their way into the cabin during heavy braking or a crash.
- Adjust the head restraints for the rear seats to be occupied to a suitable height before riding in the car.

The tail pipe of the exhaust system can become very hot during driving. Bear in mind when loading and unloading the car so that children, for example, do not burn themselves.

For greater flexibility, the rear seat is split so that the narrow and the wide part can be folded down separately.

Next to the hinges in the trunk are handles for unlocking the rear seat backrests.

The operation is easier if the front seats are not too far back and the rear seat head restraints are fully lowered.

- 1 Unlock the backrest by pulling the appropriate handle in the trunk.
- 2 Fold the backrest forward.
Note: When returning the backrest to its upright position, make sure that it locks properly in place and that the safety belt does not get caught.

If the left-hand backrest is not properly locked in position, the following message is displayed on the SID (equivalent message displayed for right-hand backrest):



Trunk Release Handle, see page 139.

Emergency opening of the narrow backrest, SportSedan, see page 140.


138 Interior equipment

Load-through hatch, SportSedan

Convertible: There is no load-through hatch.

WARNING

- Always secure the load firmly, for example using the middle safety belt. This reduces the danger of personal injury resulting from the displacement of the load on hard braking or in the event of a crash.
- Do not exceed the load capacity of the car, as this will alter its handling characteristics (see page 284).



A load-through hatch is incorporated in the rear seat backrest to enable long, narrow items to be carried inside the car.


Before loading or unloading long items, switch off the engine and apply the parking brake. This avoids the danger of the car moving off if a long item were to knock the gear or selector lever into gear.

- Fold down the armrest and open the hatch by lifting the handle.

There is a lock on the rear side of the hatch. Use this to lock or unlock the hatch.

To lock: Open the hatch and lock the lock. Close the hatch. The hatch is now locked.

To unlock: Fold down the wide section of the backrest and unlock the lock. Alternatively, you can unlock the hatch from the trunk.




Trunk Release Handle

Trunk Release Handle

There is a glow-in-the-dark trunk release handle located inside the trunk on the latch. This handle will glow following exposure to light. Pull the release handle down to open the trunk from inside.

NOTICE

The trunk release handle was not designed to be used to tie down the trunk lid or as an anchor point when securing items in the trunk. Improper use of the trunk release could damage it.



Tie down eyes in the trunk

Tie down eyes, SportSedan

There are tie down eyes in the trunk that should be used to secure loads. In general, loads should be placed as far forward and as low down as possible in the trunk.

⚠ WARNING

- Lay heavy bags on the floor. Place smaller and lighter bags on top.
- Secure heavy and bulky items using the lashing eyes provided in the trunk. This will avert the danger of luggage flying around if the car should brake suddenly or be involved in a crash.
- Secure small items if the backrest is folded down. Small items can also be thrown around inside the car and cause personal injury.
- The elastic cargo net * is only designed for light objects that are to be kept in place while driving
- Elastic cargo net *: WARNING. Avoid eye injury. DO NOT overstretch. ALWAYS keep face and body out of recoil path. DO NOT use when strap has visible signs of wear or damage.
- The rear seat must be in the upright position to protect against load displacement in the event of a crash.


140 Interior equipment

- Do not exceed the load capacity of the car, as this will alter its handling characteristics (see page 284).
- Match your speed and driving style to how the car is loaded. The handling characteristics of the car can be affected since a load in the trunk will alter the car's center of gravity.

Trunk lighting

On the underside of the parcel shelf is a light that is switched on and off when the trunk is opened and closed.

If the trunk lid is left open, the lighting will be switched off automatically after 20 minutes to prevent the battery from running flat.



Cover over emergency opening lever, on parcel shelf

Emergency opening of the narrow backrest, SportSedan

The narrow section of the backrest can be opened in an emergency if the car is without electricity (not possible to open trunk lid) and you need to access the trunk for a warning triangle, for example.

- Remove the cover and depress the yellow lever forward.

Tools and spare wheel, see page 256.

Folding down the rear seat backrest, SportCombi

WARNING


- Never drive the car if the backrest is not correctly locked into position as this increases the risk of personal injury in the event of heavy braking or a crash.
- Never leave a child or animal unattended in the car. During sunny weather the temperature in the passenger and trunk can climb to 160–180 °F (70–80 °C). Small children are very susceptible to heat stroke.
- Keep hands well clear of all moving parts.
- When folding the backrest back upright, make sure that it is locked correctly on both sides. This is imperative since the center safety belt is mounted in the backrest.
- Adjust the head restraints for the rear seats to be occupied to a suitable height before riding in the car.

The tail pipe of the exhaust system can become very hot during driving. Bear in mind when loading and unloading the car so that children, for example, do not burn themselves.

For greater flexibility, the rear seat is split so that the narrow and the wide part can be folded down separately.

It is easiest to fold down the rear seat backrests if the front seats are slid forward.

- 1 Unlock the backrest by pulling the appropriate handle forward. An unlocked backrest has a red indicator by the handle.
- 2 Fold the backrest forward.



When returning the backrest to its upright position, make sure that it locks properly in place. The red indicator by the handle must not be visible. Also make sure that the safety belt does not get caught.

If the left-hand backrest is not properly locked in position, the following message is displayed on the SID (equivalent message displayed for right-hand backrest):



**Rear left seat
backrest unlocked.**






142 Interior equipment



WARNING

- Lay heavy bags on the floor. Place smaller and lighter bags on top.
- Elastic cargo net : **WARNING**. Avoid eye injury. **DO NOT** overstretch. **ALWAYS** keep face and body out of recoil path. **DO NOT** use when strap has visible signs of wear or damage.
- Secure heavy and bulky items using the lashing eyes provided in the trunk. This will avert the danger of luggage flying around if the car should brake suddenly or be involved in a crash.
- Secure small items if the backrest is folded down. Small items can also be thrown around inside the car and cause personal injury.
- Do not exceed the load capacity of the car, as this will alter its handling characteristics (see page 284).



Load-through hatch, SportCombi


⚠ WARNING

- Always secure the load firmly, for example using the middle safety belt. This reduces the danger of personal injury resulting from the displacement of the load on hard braking or in the event of a crash.
- Do not exceed the load capacity of the car, as this will alter its handling characteristics (see page 284).

A load-through hatch is incorporated in the rear seat backrest to enable long, narrow items to be carried inside the car.

Before loading or unloading long items, switch off the engine and apply the parking brake. This avoids the danger of the car moving off if a long item were to knock the gear or selector lever into gear.

- Fold down the armrest and open the hatch by lifting the handle.




144 Interior equipment

Tie down eyes, SportCombi

There are tie down eyes in the trunk that should be used to secure loads. In general, loads should be placed as far forward and as low down as possible in the trunk.

Driving with the trunk lid open, see page 193.



WARNING

- Put heavy loads as low down and as far forward as possible in the luggage compartment, i.e. against the back of the rear seat.
- Never stack cargo so high that any part of the cargo lies above the edge of the backrest, if a cargo guard ❄ is not being used.
- Always tie down the cargo so that it cannot be thrown forward during heavy braking or in the event of a crash.
- Unsecured and heavy cargo can increase the risk of injury during hard braking, sudden avoidance manoeuvres and in the event of a crash.
- Use the lashing eyes and suitable anchorage straps ❄ for optimum securing of loads.
- Provide protection on sharp edges to prevent damage to the cargo straps.

- If possible, avoid having the rear seat folded down when driving with a heavy load, because the anchoring possibilities are restricted when the rear seat is in this position. **That the rear seat is in the upright is a basic requirement for protection against cargo displacement in the event of a crash.**
- Improve safety by fastening the outer safety belts. Check that the red "indicator-flag" next to the opening handles is not visible. If the red "indicator-flag" is visible the backrest is not locked.
- Match your speed and driving style to how the car is loaded. The handling characteristics of the car can be affected since a load in the trunk will alter the car's center of gravity.
- An object weighing 55 lbs. (25 kg) corresponds to a weight of 2200 lbs. (1,000 kg) in a front-end collision at 32 mph (50 km/h).
- Adjust the car's load (passengers and luggage) so that the gross vehicle weight and the axle weight are not exceeded, see page 284.

Cargo net *

WARNING

- **Never** overload the cargo net *. If the elastic breaks this may cause personal injury. Do not use a cargo net that shows signs of wear.
- Never use the elastic floor net * and elastic side net * when the rear seat is folded down. These nets are only intended to keep light objects tidy, not for the anchoring of loads.
- Secure the load in the luggage compartment firmly. Using a cargo net is not considered as load securing.
- The only purpose of a cargo net is to prevent light objects from being thrown forward into the cabin during heavy braking.

146 Interior equipment


Cargo net, vertical *, SportCombi

Fit the net behind the rear seat backrest.


- 1 Remove the rear cover panels in the roof.
- 2 Fit the net's upper fasteners into the two rear attachment points in the roof.
- 3 Secure the net's hooks in the two anchorage eyes closest to the rear seat. Tension the straps.

The cargo net can also be fitted behind the front seats when the whole rear seat is folded.

- 1 Remove the front cover panels in the roof.
- 2 Snap the net's upper fasteners into the two front attachment points in the roof.
- 3 Lengthen the straps with the enclosed extra straps. Secure the hooks in the two outer eyes furthest back on the front seats' rails down by the floor. Tension the straps.



Attaching the cargo net to the roof




Cargo net fitted in front anchorage eye

Storage


When the cargo net is not in use it should be stored in the bag supplied. Position the bag on the floor in the luggage compartment, closest to the backrest and secure it in the front anchorage eyes using the Velcro fasteners.

Storing the cargo net




Cargo net, floor mounted ✱, SportCombi

- 1 Fold up the floor. Position the edges of the floor in the slots in the side pieces.
- 2 Fit the bag/carrier on the lower floor and secure the net's hooks in the folded-up floor.



Cargo net, floor mounted, SportCombi

- 1 Upper bracket. Make sure that the rubber bands are not twisted
- 2 Lower anchorage point



Cargo net, floor mounted, SportCombi with subwoofer ✱

- 1 Upper bracket. Make sure that the rubber bands are not twisted
- 2 Lower anchorage point

148 Interior equipment

Cargo guard ✱, SportCombi

NOTICE


Do not place any objects on the extended cargo guard. It is designed to shield against view and not for storage.

To fit

- 1 Hold the cartridge so that the extendible part faces backward.
- 2 Position the cartridge over the pin (1) on the left and right-hand sides. Press the cartridge down and rotate it slightly forward until a click is heard.
- 3 Check the fitting by pulling the cartridge up, it should now be fitted firmly.

WARNING

A cassette that is incorrectly fitted can detach and cause personal injury in the event of a collision, heavy breaking or similar.




Fitting the cargo guard

- 1 Pin on which the cargo guard is fitted
- 2 Handle for removing the cargo guard

To remove

- 1 Retract the cargo guard into the cartridge.
- 2 Pull the handle (2) back and lift up the cartridge. Repeat this on the other side.




Opening the cargo guard

Opening the cargo guard

The cargo guard can be opened halfway in order to facilitate loading objects into the luggage compartment (and to avoid stretching in over the luggage compartment to reach the cargo guard).

- 1 Open the tailgate.
- 2 Press the rear lip of the cargo guard down, e.g. with an elbow. The cargo guard now opens halfway so that objects can be more easily loaded into the luggage compartment.
- 3 Pull the cargo guard down to the lower position

Starting and driving



IB4730

Ignition switch _____	150	Parking _____	177
Steering wheel lock _____	151	Saab Parking Assistance * _____	180
Starting the engine _____	152	Economical driving _____	183
Important considerations for driving _____	153	Driving in cold weather _____	185
Refueling _____	156	Driving in hot climates _____	187
Engine Break-in Period _____	160	Towing a trailer * _____	188
Manual transmission _____	161	Driving with a roof rack load _____	192
Automatic transmission * _____	162	Driving with a load _____	192
Cruise Control _____	169	Driving with the trunk lid open _____	193
Braking _____	170	Driving in deep water _____	193
All-wheel drive (XWD) * _____	173	Towing the car _____	193
Traction Control System (TCS) _____	173	Jump starting _____	197
Electronic Stability Program ESP® _____	175	For long trips _____	199
Parking brake _____	177		

* Asterisk means: equipment not fitted in all cars (can depend on model variant, engine variant, market specification, options or accessories).

150 Starting and driving

Ignition switch

The ignition switch is located on the center console between the front seats. In cars with automatic transmission, the remote control can only be removed when the selector lever is in position P.

NOTICE

Take care not to spill drinks or to drop crumbs over the ignition switch. If dirt or liquid gets into it, the switch may not operate properly.

If snow from clothing falls into the ignition switch and melts, the ignition switch can seize (freeze). Brush snow off clothing before getting into the car.

WARNING

- Always remove the remote control before leaving children unattended in the car.
- Apply the parking brake before removing the remote control.
- Never remove the remote control while the car is moving. This will activate the steering wheel lock and make it impossible to steer the car.

To allow the various systems in the car time to register that the remote control has been inserted into the ignition switch, do not turn the remote control for roughly half a second.



LOCK position

The parking lights, hazard warning lights and interior lighting can be turned on.

Cars with automatic transmission: Move the gear lever to P.

The gear lever is locked in position. This is the only position in which the remote control can be removed.

Cars with manual transmission: The remote control can be removed regardless of the position of the gear lever.

OFF position

Parts of the electrical system are operative.

Do not leave the remote control in the OFF position with the engine not running as this could cause the battery to run flat in a matter of hours.

Cars with automatic transmission: The gear lever is not locked. See also page 163.

If the ignition switch is turned from ON to OFF before the car is stationary then turning to LOCK may not be possible. In which case turn the ignition switch to the ON position until the ABS lamp goes out,

approx. 2 seconds. Following which, turn it back to OFF.

ON position

The entire electrical system is operative. **Do not leave the remote control in the ON position when the engine is not running.** Turn the ignition switch to the OFF position to disconnect the electrical system.

When you turn the ignition switch to ON, some indicator and warning lights will come on in the main instrument panel. These should go out after about 3 seconds.

ST - starter position

The starter motor operates (automatic transmission: selector lever must be in P or N) when the ignition switch is turned to this position. When released, the ignition switch will spring back to the ON position.

The car has an electronic restart lock. If the engine fails to start, the ignition switch must first be turned back to a position between OFF and LOCK before the starter motor can be operated again.

Steering wheel lock

The steering wheel lock is electronic. The lock engages when the remote control is removed from the ignition and unlocks when the remote control is inserted. A click can be heard when the steering wheel lock locks and unlocks.

If the car is parked with one front wheel touching the curb, for example, you may need to turn the steering wheel slightly when you insert the remote control to allow the steering wheel lock to unlock. If you do not succeed on first attempt you must remove the remote control before trying again. Turn the steering wheel and insert the remote control into the ignition switch.

If the steering wheel lock does not disengage it will not be possible to turn the remote control in the ignition switch.

The following message is shown on the SID:



Pull out key, turn steering wheel. Restart.

If a fault arises affecting the steering wheel lock, the following message will be displayed on the SID:



**Steering lock malfunc.
Make a safe stop.**

If the steering wheel lock malfunctions while the remote control is in the ignition switch, this may prevent the removal of the remote control or prevent the car from being restarted once the engine has been switched off.

If you have to leave the car, lock the car by pressing down the lock buttons on the doors. Lock the front left door from outside with the traditional key (see page 50). The car is now locked but the alarm is inactive.

152 Starting and driving

Starting the engine

WARNING

- When starting the engine:
 - Sit down in the driver's seat.
 - Depress the clutch pedal fully (M/T). If the gear lever is not in the neutral position, the clutch pedal must be fully depressed or the car will jump forwards or backwards, which may cause a crash.
 - Never start the car from outside the vehicle, e.g. through a window that is down. This could lead to serious personal injury.
- Cars with automatic transmission: select position P to remove the ignition key. The key can only be removed in this gear position.
- Carbon monoxide (CO) is a colorless, odorless, poisonous gas. Be alert to the danger of CO – always open the garage doors before starting the engine in the garage.
- Do not rest or sleep in the car when parked with the engine running. There is a risk of depressing the accelerator which could lead to engine damage.
- There is also a danger of CO poisoning if the exhaust system is leaking.

Starting the engine

Avoid racing the engine or loading it heavily before it has warmed up. Do not drive away before the warning and indicator lights have gone out.

The engine has an automatic choke and should be started as follows:

Cars with manual transmission

To start the engine the clutch pedal must be fully depressed.

- 1 Make sure the parking brake is applied.
- 2 Depress the clutch pedal but do not touch the accelerator.
- 3 Start the engine. Let the ignition switch spring back as soon as the engine has started and is running smoothly.

Allow the engine to idle for about 10 seconds. Do not apply full throttle for at least 3 minutes after starting.

Cars with automatic transmission

The selector lever must be in the P or N position.

- 1 The selector lever must be in the P or N position.
- 2 Keep your foot on the brake pedal.
Note! Once the engine has started, the brake pedal will sink. This is perfectly normal.
- 3 Start the engine. Let the ignition switch spring back as soon as the engine has started and is running smoothly.

Allow the engine to idle for about 10 seconds. Do not apply full throttle for at least 3 minutes after starting.

Useful tips on starting the engine

If the engine has failed to start after several attempts in very cold weather, proceed as follows:

- 1 Turn the ignition switch to ON (it is essential that you turn the ignition to ON before depressing the accelerator).
- 2 Press the accelerator to the floor and run the starter motor for 5-10 seconds. This will prevent the engine being flooded (fully depressed accelerator cuts off the fuel supply).
- 3 Now start the engine in the normal way - do not touch the accelerator.

If the engine stalls immediately after starting (e.g. if the clutch was released too quickly), do not touch the accelerator when restarting the engine.

Important considerations for driving

1 Starting and driving

- Do not use full throttle until the engine is warm, so as to avoid unnecessary wear. If the needle of the turbo gauge repeatedly enters the red zone, the engine may suddenly lose power, due to the initiation of a monitoring system that limits the boost pressure. We recommend that you contact a Saab dealer as soon as possible.
- Under certain barometric conditions (high outside temperature and/or high altitude) the needle may enter the first part of the red zone without necessarily indicating that a fault has arisen.
- A protective function (interruption of the fuel supply) limits the engine speed.

2 Stopping the engine

- Do not rev the engine immediately before switching it off - stop the engine when it is idling.

3 Regulating the boost pressure

- One of the advantages of boost pressure regulation is that the engine can also be run safely on gasoline with a lower octane rating, although not lower than AON 87. However, engine performance will fall slightly and heavy loading and laboring should be avoided. For optimum performance, use the recommended grade of fuel.
- The maximum boost pressure is regulated according to the tendency of the engine to knock. Short-lived knocking is perfectly normal. This can occur when the engine is running at about 3,000 rpm under a heavy load. The extent of this knocking will depend on the grade of fuel in the tank.
- Isolated instances of knocking can occur with low-octane fuel. This controlled form of knocking, followed by a reduction in the boost pressure, is a sign that the control system is working normally, and is perfectly safe for the engine.

154 Starting and driving

NOTICE

- If the engine sounds strange there is a malfunction. We recommend that you contact a Saab dealer immediately.
- The use of fuel with too low an octane rating can cause serious engine damage.



Limited performance.

The light comes on in the event of an engine or gearbox fault (cars with automatic gearbox), which may cause driveability problems but that does not affect exhaust emission. The car can still be driven but perhaps with limited performance.

Contact a dealer whenever an opportunity occurs. We recommend that you contact a Saab dealer.

Limp-home

The engine management system has a diagnostic feature that checks a number of internal functions. If a fault is detected in the throttle valve, the engine management system will set the throttle system to the limp-home mode. This means:

- idling control will be poor (uneven idling since regulated by ignition and fuel supply)
- engine performance will be reduced
- the cruise control will not function
- the capacity of the A/C compressor will be limited.

If the diagnosis function detects a fault in the engine management system, the  light "Service Engine Light also known as CHECK ENGINE" indicator light in the instrument panel will come on (see page 83). Have the car checked at a workshop as soon as possible. We recommend that you contact a Saab dealer.

NOTICE

If  "Service Engine Light also known as CHECK ENGINE" indicator light warning light starts to flash (indicating that the engine is misfiring and the catalytic converter can be damaged), ease off the accelerator slightly. The light should go out or start to shine constantly. If the light continues to flash despite easing off the accelerator, you may continue to drive the car but at the minimum throttle permitted by the current traffic situation. Have the car checked as soon as possible. We recommend that you contact a Saab dealer.

Important considerations with catalytic converters

The catalytic converter is an emission control device incorporated in the car's exhaust system. It consists of a metal canister with a honeycomb insert, the cells of which have walls coated in a catalytic layer (precious metal alloy).

NOTICE

Use only unleaded gasoline. Leaded gasoline is detrimental to the catalyst and oxygen sensor and will seriously impair the function of the catalytic converter.

To ensure that the catalytic converter continues to function properly, and also to avoid damage to the converter and its associated components, the following points must be observed:

- Have the car serviced regularly in accordance with the service program.
- Always be alert to any misfiring of the engine (not running on all cylinders) and any loss of power or performance. At the first sign of a malfunction, reduce speed and take the car to a workshop. We recommend that you contact a Saab dealer.

- If the engine fails to start (in severe cold or if the battery is flat), the car can be bump started (manual transmission only) or started using jump leads to a donor battery. However, as soon as you have started the engine, it is important that it runs on all cylinders. If it is misfiring, allow it to idle for up to 5 minutes to give it time to settle and run smoothly. If, after this time, the engine still fails to run properly, switch off the engine to avoid serious damage to the catalytic converter. We recommend that you contact a Saab dealer for advice.
- Never park the car on dry grass or other combustible material. The catalytic converter gets very hot and could therefore start a fire.
- Never drive off if the engine is misfiring.
- If you bump start the car when the engine is already at normal working temperature, the engine must start to run on all cylinders. Abort bump starting if the engine fails to start immediately.

Failure to strictly follow these instructions can result in damage to the catalytic converter and associated components, and could represent a breach of the warranty conditions.

NOTICE

If the car runs out of gas, air may be drawn in with the fuel, which, in turn, can cause the catalytic converter to be damaged by overheating.

⚠ WARNING

If the engine is being run with the car on a rolling road or dynamometer, to ensure adequate cooling, air must be blown into the engine compartment and under the car at a rate equivalent to the ram-air effect that would obtain at the corresponding road speed.

Refueling

WARNING

If you spill fuel and then something ignites it, you could be badly burned. Fuel can spray out on you if you open the fuel cap too quickly. This spray can happen if your tank is nearly full, and is more likely in hot weather. Open the fuel cap slowly and wait for any “hiss” noise to stop. Then unscrew the cap all the way.

Gasoline fumes are highly explosive. Therefore:

- **never** smoke while refueling.
- **never** use gasoline for any purpose other than as engine fuel.
- gasoline is extremely flammable and can cause severe burns. No open or exposed flames near gasoline.
- **do not** use a mobile phone at the same time as refueling.

If a fire starts while you are refueling, do not remove the nozzle. Shut off the flow of fuel by shutting off the pump or by notifying the station attendant. Leave the area immediately.

NOTICE

- Do not overfill. Fuel should not come right up the filler pipe as room for expansion is needed for when the temperature rises.
- The use of fuel with too low an octane rating can cause serious engine damage.
- Clean fuel from painted surfaces as soon as possible.
- Do not use additives with E85-fuel.

NOTICE

The engine control module (ECM) monitoring the engine parameters also stores fault codes.

Under certain circumstances, this may cause constant illumination of the “Service Engine Light also known as CHECK

ENGINE” indicator light , thus indicating a fault that must be checked by your Saab dealer, see page 83.

NOTE: always observe the following two measures:

- Make sure that the fuel filler cap is screwed on correctly before the engine is started. Screw on the fuel filler cap until you hear **3 clicks**.
- Avoid driving with the fuel low level indicator illuminated. The symbol illuminates when less than approximately 2.5 gallons (10 liters) of fuel remains in the tank.

Refueling

WARNING

If a fire starts while you are refueling, do not remove the nozzle. Shut off the flow of fuel by shutting off the pump or by notifying the station attendant. Leave the area immediately.

- 1 Switch off the engine.
- 2 Open the fuel cap, located in the right-hand rear fender.
- 3 Insert the fuel pump nozzle beyond the flange on the filler pipe and let the first mark (a ring, a pimple or the first spring-coil) rest on the flange. Do not withdraw the nozzle while filling is in progress.
- 4 Cease refueling the first time the pump stops, and wait a few seconds after you've finished pumping before you remove the nozzle.

NOTICE

Do not overfill. Fuel should not come right up the filler pipe as expansion room is needed when the temperature rises.


- Fill to maximum filling capacity.
- Stop filling after the first time that the nozzle trips to shut off the flow of fuel.
- Filling capacity can differ between different fuel stations and outside temperature. Fuel tank volume when nozzle trips to shut off, may vary by 0.5 gal. (2 liters).
- Do not fill fuel all the way up the filler pipe. The gasoline must be allowed room for expansion especially during hot weather.

Fuel cap

To remove the fuel cap, turn it slowly to the left (counterclockwise). The fuel cap has a spring in it; if you let go of the cap too soon, it will spring back to the right.

When you put the fuel cap back on, turn it to the right (clockwise) until you hear **3 clicks**. Make sure the cap is fully installed.

The diagnostic system can determine if the fuel cap has been left off or is improperly installed. See "**Service Engine Light also known as CHECK ENGINE**" on page 83.



When refueling, hang the fuel cap inside the fuel door

If the fuel cap has been left off or is improperly installed the following message is shown on the Saab Information Display (SID):



Tighten fuel filler cap.

158 Starting and driving

The most effective way to prevent condensation forming in the tank (and thus avoid possible running problems) is to keep the tank full.

Refer to page 185 for information regarding gasoline anti-freeze.

The fuel door has a built in filler cap holder slot located on the fuel door. Slide the white ring on the cap into the slot.

Notice: If you need a new fuel cap, be sure to get the right type. Your dealer can get one for you. If you get the wrong type, it may not fit properly.

Filling a portable fuel container

WARNING

Never fill a portable fuel container while it is in your vehicle. Static electricity discharge from the container can ignite the gasoline vapor. You can be badly burned and your vehicle damaged if this occurs. To help avoid injury to you and others:

- Dispense gasoline only into approved containers.
- Do not fill a container while it is inside a vehicle, in a vehicle's trunk, pickup bed or on any surface other than the ground.
- Bring the fill nozzle in contact with the inside of the fill opening before operating the nozzle. Contact should be maintained until the filling is complete.
- Do not smoke while pumping gasoline.

Fuel (Gasoline Engine)

Fuel

Use of the recommended fuel is an important part of the proper maintenance of your vehicle.

Gasoline Octane

Use regular unleaded gasoline with a posted octane of 87 or higher.

If the octane is less than 87, you may get a heavy knocking noise when you drive. If this occurs, use a gasoline rated at 87 octane or higher as soon as possible. Otherwise, you might damage your engine. A little pinging noise when you accelerate or drive uphill is considered normal. This does not indicate a problem exists or that a higher-octane fuel is necessary. If you are using 87 octane or higher-octane fuel and hear heavy knocking, your engine needs service. Although not required, use higher octane fuel for optimum performance- 90 octane for the 2.0T engine and 93 octane for the 2.8 V6.

Gasoline Specifications

It is recommended that gasoline meet specifications which were developed by automobile manufacturers around the world and contained in the World-Wide Fuel Charter which is available from the Alliance of Automobile Manufacturers at www.autoalliance.org/fuel_charter.htm. Gasoline meeting these specifications could provide improved driveability and emission control system performance compared to other gasoline.

NOTICE

Gasolines containing oxygenates, such as ethers and ethanol, and reformulated gasolines may be available in your area. We recommend that you use these gasolines, if they comply with the specifications described earlier. However, E85 (85% ethanol) and other fuels containing more than 10% ethanol must not be used in vehicles that were not designed for those fuels.

California Fuel

If your vehicle is certified to meet California Emission Standards (see the under hood emission control label), it is designed to operate on fuels that meet California specifications. If this fuel is not available in states adopting California emissions standards, your vehicle will operate satisfactorily on fuels meeting federal specifications, but emission control system performance may be affected. The malfunction indicator lamp may turn on and your vehicle may fail a emission system inspection. See Service Engine Light also known as CHECK ENGINE on page 83. If this occurs, return to your authorized Saab dealer for diagnosis. If it is determined that the condition is caused by the type of fuel used, repairs may not be covered by your warranty.

Additives

To provide cleaner air, all gasolines in the United States are now required to contain additives that will help prevent engine and fuel system deposits from forming, allowing your emission control system to work properly. You should not have to add anything to your fuel. However, some gasolines contain only the minimum amount of additive required to meet U.S. Environmental Protection Agency regulations. Saab recommends that you buy gasolines that are advertised to help keep fuel injectors and intake valves clean. If your vehicle experiences problems due to dirty injectors or valves, try a different brand of gasoline.

Gasolines containing oxygenates, such as ethers and ethanol, and reformulated gasolines may be available in your area to contribute to clean air. Saab recommends that you use these gasolines, particularly if they comply with the specifications described earlier.

Notice: Your vehicle was not designed for fuel that contains methanol. Do not use fuel containing methanol. It can corrode metal parts in your fuel system and also damage the plastic and rubber parts. That damage would not be covered under your warranty.

Some gasolines that are not reformulated for low emissions may contain an octane-enhancing additive called methylcyclopentadienyl manganese tricarbonyl (MMT); ask the attendant where you buy



160 Starting and driving

gasoline whether the fuel contains MMT. Saab does not recommend the use of such gasolines.

Fuels containing MMT can reduce the life of spark plugs and the performance of the emission control system may be affected. The malfunction indicator lamp may turn on. If this occurs, return to your authorized Saab dealer for service.

Fuels in Foreign Countries

If you plan on driving in another country outside the United States or Canada, the proper fuel may be hard to find. Never use leaded gasoline or any other fuel not recommended in the previous text on fuel. Costly repairs caused by use of improper fuel would not be covered by your warranty.

To check the fuel availability, ask an auto club, or contact a major oil company that does business in the country where you will be driving.



Engine Break-in Period

Pistons, cylinder bores and bearings need time to obtain uniform, wear-resistant surfaces.

If a new engine is driven too hard, this gradual process of bedding-in will not be possible and the life of the engine will be shortened.






During the first 1,200 miles (2,000 km), do not exceed 5,000 rpm.

In addition, refrain from driving the car at full throttle, other than for brief instances, during the first 1,800 miles (3,000 km).

Wearing in new brake pads

New brake pads take time to bed in, about 90 miles (150 km) if the car is driven largely under stop-and-go conditions or about 300 miles (500 km) of highway driving.

To extend the useful life of the pads, avoid hard braking as much as possible.




Manual transmission

Clutch interlock

To start the car, the clutch pedal must be depressed.

When changing gear, fully depress the clutch pedal and then release it smoothly. It is inadvisable to drive with your hand resting on the gear lever, as this can increase the wear on the gearbox.

Before reverse (R) can be engaged, you must lift the ring underneath the gear knob.



Gear positions

NOTICE


When reverse gear is to be engaged, the car must be at a standstill with the accelerator fully released.

162 Starting and driving

Automatic transmission *

WARNING

- Depress the brake pedal when shifting the selector lever from P or N.
- The car must be at a standstill before P, R or N is selected. You have to have your foot on the brake pedal to move the lever out of P. If the car is still moving when a drive position is subsequently selected, this could cause a crash or damage the automatic transmission.
- Never park the car with the selector lever in a drive position, even if the parking brake is on.
- If you want to leave the car with the engine running, move the selector lever to P or N and apply the parking brake.




Selector lever

1 Position for manual gear selection

The automatic transmission has an electronic control module. The control module receives information including accelerator position and road speed. Using this and other information, it controls the hydraulic pressure of the transmission to ensure that gear changing is as smooth as possible.

The remote control can only be removed when the selector lever is in the P position.

A black rectangular display on the instrument panel. It shows 'D' in a large white font on the left. To the right of 'D', it shows 'Temp 00 °C' and '00000 000,0' in white text.


Indication of gear position on main instrument panel

The engine can only be started when the selector lever is in the P or N position.

When the car is stationary, the engine must be idling when you move the selector lever from one position to another. If not, the transmission could be damaged.

NOTICE

After selecting a drive position, pause briefly to allow the gear to engage (the car starts to pull a little) before you accelerate.



Selector lever detent

Park Brake Shift Lock

The transmission has a security function known as Park Brake Shift Lock. To move the gear selector lever out of the P or N position, the gear selector lever detent (catch) must be pressed in at the same time as the brake pedal is held depressed.


The detent button on the selector lever has to be pressed in before the lever can be moved between certain positions.

Temporary override of Park Brake Shift Lock, see page 166.

Adaptive gear change patterns

The adaptive gear change pattern function adapts gear changing to the prevailing driving conditions. The transmission control module senses the engine load, vehicle speed and temperature of the transmission. A suitable gear change pattern is then selected automatically to avoid unnecessary gear changes and undesired increases in transmission temperature.

Certain variants use a special change pattern for the first few minutes after a cold start so that the catalytic converter reaches its working temperature more quickly.



Sport mode

Sport mode is selected using the **S 1** button, while the word SPORT illuminates

on the SID **SPORT**. Changing up occurs later and changing down occurs earlier at the same accelerator pedal position.

Sport mode will deselected if:

- The Sport button is depressed again
- The engine is switched off.

164 Starting and driving

Thermal transmission protection

The transmission has built-in protection against overheating. If the temperature of the transmission fluid exceeds 302 °F (150 °C), engine torque will be limited to 147 ft.lbs. (200 Nm).

The following message is shown on the SID:



Gearbox too hot. Make a safe stop. Open hood.

If this message appears, stop the car as soon as it is safe to do so and allow the engine to idle until the message has gone out. The selector lever should be in position P.

Lock-up

The transmission's torque converter has a lock-up function. This can lock the torque converter, thus reducing the engine speed and fuel consumption.

Kick-down

When the accelerator is pressed down fully, a down change is made to optimize acceleration, e.g. for overtaking.

Following this, the next higher gear will be selected at the optimum engine speed, unless you ease off the accelerator before reaching this.

Driving in hilly country with a heavy load

The transmission fluid can overheat when the gearbox is strained, for example, when driving with a trailer on hilly roads. To avoid the transmission fluid overheating, always drive with the selector lever in the D position. The adaptive gear change patterns are then active.

High air temperatures or a faulty oil cooler can also cause the transmission fluid to overheat. Overheating reduces the service life of the fluid.

WARNING

Remember to use the braking effect of the engine (1st, 2nd or 3rd gear) when you are descending long or steep hills to spare the brakes.

Overheating can cause the brakes to fade!

Towing

Towing of cars with automatic transmission, see page 193.

Descending hills

If the speed of the car increases while descending a steep hill, despite the accelerator being released, the control module will change down. If you desire more powerful engine braking, manually select a lower gear (see page 168).

Limp-home

NOTICE

Do not tow a trailer if limp-home mode is engaged.

If the transmission malfunctions, the control module will activate limp-home mode. Driveability will be affected to varying degrees.

Cars with 5-speed transmission *

In this mode, only 2nd and 5th gears are available. Select 2nd gear when driving at low speeds and 5th gear at higher speeds. 2nd gear must be selected manually. Select 5th gear manually or move the selector lever to D, see page 168.

Cars with 6-speed transmission *

- The car may be totally powerless. If this is case, have the car transported to a workshop to have the problem rectified.
- The car may feel weak but can be driven carefully to a workshop to have the problem rectified.
- Driveability may barely be affected.

Irrespective of the driveability of the car, the car must be taken to a workshop to have the problem checked and rectified.

166 Starting and driving


Temporary override of Park Brake Shift Lock

NOTICE

Due to electrical problems it may not be possible to move the selector lever out of the park position, even if the ignition is ON. If for some reason the selector lever has to be moved out of the park position (i.e. to tow the car a short distance) do as described below.

- 1 Apply the parking brake.
- 2 Lift up the rubber mat in the storage compartment ahead of the selector lever.
- 3 Under the floor of the storage compartment is a yellow plastic lever. Use a thin tool, such as a screwdriver, to press and hold the plastic lever while moving the selector lever from P to N.
- 4 Remove the tool.
- 5 Release the parking brake if the car is to be moved immediately, otherwise it should remain on.



Check fuse 6 in the engine bay fuse box. If the fuse is OK the battery may be dead. Contact a workshop to have the problem checked and rectified. We recommend that you contact a Saab dealer.



Temporary override of Park Brake Shift Lock

Selector lever positions

	<p>P The selector lever is locked and the transmission is mechanically blocked. The engine can be started. To move the selector lever out of the P position, depress the brake pedal and press in the detent (catch) on the selector lever. Only select the park position (P) when the car is stationary.</p>
	<p>R Only select the reverse position (R) when the car is stationary. The detent release button must be pressed before the selector lever can be moved to R. Wait until reverse gear has engaged before touching the accelerator.</p>

	<p>N You must press the brake pedal to move the selector lever from the neutral position (N). In neutral, the transmission is disengaged from the engine. The engine can be started but make sure the parking brake is on to prevent unexpected movement. To prevent the engine and transmission becoming hotter than necessary, select N for long stops with the engine running, e.g. when stuck in a traffic jam. At traffic lights, leave the selector lever in the drive position (D).</p>
	<p>D The drive position (D) is the normal one for forward driving. The transmission shifts automatically between all gears from 1st to 5th or 6th, the timing of which depends on factors such as the current accelerator position and the speed of the car. Pause for a moment before applying the accelerator, to allow the gears to engage.</p>

168 Starting and driving

M3



Sentronic, manual gear selection

Move the selector lever to the manual position (M) (to the left position D) to select gear manually.

Select a higher gear by pressing the selector lever forward or a lower gear by pulling it back. The selector lever will return to a position adjacent to the letter M after each gear change.

An example of when you may wish to make manual gear changes is when overtaking, to enable you to remain in a low gear for an extended period of time.


If the road surface is slippery, you may wish to start off in 2nd or 3rd to reduce the risk of wheel spin.

When descending steep hills you should select a low gear to increase the braking effect of the engine and thus spare the brakes.

Manual gear selections are displayed on the main instrument panel. The letter M and the current gear are displayed.

When the selector lever is in the M position, as opposed to the D position, the engine is much more responsive to changes in accelerator position. The accelerator has a different feel.

When changing down, the desired gear can be selected but the transmission will not change down until the engine speed is low enough to avoid overrevving.



*Steering wheel controls for manual gear selection **

Certain variants also have steering wheel controls for manual gear selection. On these models, it is possible to change gear manually using the selector lever and the steering wheel controls. The steering wheel controls are only active when the selector lever is in the M position.

Select a higher gear by pressing the right-hand button and a lower gear by pressing the left-hand button.

Cruise Control

(Cruise control system)

⚠ WARNING


Do not use the cruise control system in wet or icy conditions, in dense traffic or on winding roads.

For safety reasons (brake system function), the brakes must be applied once when the engine has started, before the cruise control system can be activated.

The following message is shown on the SID:



Tap brakes lightly before using cruise ctrl.



Cruise control switches

The system has the following functions:

- 1 ON: engaged
- 2 OFF: disengaged
- 3 SET/+: sets the speed and increases the set speed
- 4 SET/-: sets the speed and decreases the set speed
- 5 RESUME: re-engages the system at the set speed

The CRUISE indicator light in the main instrument panel comes on when the switch is slid to ON. If you switch off the engine while the cruise control is ON, the system will be ON the next time the engine is started.

To set the desired speed

- 1 Slide the switch to ON.
- 2 Move the thumb wheel up to SET/+ or SET/- when the car has reached the desired speed (above 15 mph (25 km/h)).

To increase the preset speed

You can increase the speed in any of the following ways:

- Accelerate to the desired speed. Jog the control to SET/+ or SET/-.
- Jog the control to SET/+ to increase the speed by 1 mph (1.6 km/h) (when cruise control already engaged).
- Hold the control in the SET/+ position until the desired speed is reached (when cruise control already engaged).

170 Starting and driving

To reduce the preset speed

You can reduce speed in any of the following ways:

- Brake to the desired speed. Jog the control to SET/+ or SET/-.
- Jog the control to SET/- to reduce the speed by 1 mph (1.6 km/h).
- Hold the control in the SET/- position until the desired speed is reached.

Temporary increase in speed

Accelerate, without shifting down (manual transmission), to exceed the set speed such as for overtaking. When you release the accelerator, the car will return to the set speed.

To disengage the system temporarily

Slide the switch to the left towards OFF, but only as far as to disengage the cruise control. Allow the switch to spring back.

To re-engage the system

Slide the switch to RESUME. The car will return to the previously set speed. Vehicle speed must exceed 15 mph (25 km/h).

To disengage the system

The system will be disengaged:

- As soon as the brake or clutch pedal is depressed (cars with manual transmission).
- When the switch is slid towards OFF. See also heading "To disengage the system temporarily".
- When the switch is slid to OFF.
- When the TCS/ESP[®] system is operative.
- When position N is selected (cars with automatic transmission).

Braking

It is good practice to try your brakes periodically while driving. This is particularly important when driving in heavy rain, on roads with a lot of surface water, in snow or in salty slush. In such conditions a slight delay in the braking effect may be noticed. To minimize this delay, dry the brakes by applying them lightly now and again. This should also be done after the car has been washed, and in extremely damp weather.

To avoid the brakes becoming overheated, such as when negotiating long descents with a drop of several hundred yards (hundred metres), select a low gear to utilize the braking effect of the engine. If the car has automatic transmission, select 1st or 2nd gear.

You can help to prolong the life of the brakes by thinking ahead and braking harder over short periods, rather than braking more moderately over long stretches.

⚠ WARNING

- It is prudent to try your brakes from time to time, especially when driving in heavy rain, through water collected on the road, in snow, on a wet road surface or in salty slush. In such conditions, the brakes may take longer than normal to take effect. To rectify this, touch the brake pedal periodically to dry the brakes out.
- The same applies after the car has been washed or when the weather is very humid.
- Avoid parking the car with wet brakes. Before parking, and if the traffic conditions allow, brake quite heavily so that the brake discs and pads warm up and dry.
- The brakes are power assisted and it should be kept in mind that the servo unit only provides the power assistance when the engine is running.
- The brake pressure required when the engine is off, (e.g. when the car is being towed) is roughly four times the normal pedal force required. The pedal also feels hard and unresponsive.
- Overheating can cause the brakes to fade!

ABS brakes**⚠ WARNING**

- The additional safety afforded by the ABS system is not designed to allow drivers to drive faster but to make normal driving safer.
- To stop as quickly as possible, without loss of directional stability, whether the road surface is dry, wet or slippery, **press the brake pedal down hard without letting up (do not pump the pedal), declutching simultaneously, and steer the car to safety.**

The Antilock Braking System (ABS) modulates the brake pressure to each wheel. The pressure is automatically reduced just before the wheel locks up and then increases again to the point at which the wheel is just about to lock. The wheel sensors send information to the brake system's electronic control module for every 4 or so inches (decimeter) that the car rolls. This information is processed continuously to ensure that the adjustment of the brake pressure will be as exact as possible. Adjustment takes place up to 12 times per second.

The brake system provides Electronic Brakeforce Distribution (EBD). This distributes the brake pressure between the front and rear wheels, in such a way as to achieve optimum braking performance irrespective of the car's speed or load.

The ABS has a built-in diagnostics function which will switch on the ABS warning light if a fault is detected in the system (see page 82).

Note. The following message will appear on the SID (and corresponding symbol on main instrument unit) if a fault is detected:



**Antilock brake malfunc.
Contact service.**

172 Starting and driving

The ABS system will not reduce the braking distance on loose gravel, snow or ice but, because the wheels cannot lock up, steering control is retained.

When the ABS system operates you will feel the brake pedal pulsate and hear a ticking noise, both of which are perfectly normal.

Apply the brake pedal with **full force** (you cannot press too hard), declutch and if necessary steer to safety.

Do not release the brake pedal before the car has come to a halt or the danger is past!


The above is critical.

If the road is slippery, the ABS system will operate even when only light pressure is applied to the brake pedal. This means that the driver can brake gently to test the condition of the road and adapt their driving accordingly.

It is well worth practising the use of ABS brakes on a skid pad or other suitable facility.



*Braking with ABS brakes.
Indication that the system is operating:
pulsating brake pedal and ticking noise*



Braking with ABS – evasive steering

All-wheel drive (XWD) *

Essentially, the system consists of a PTU (Power Take off Unit), propeller shaft, RDM (Rear Drive Module which contains an electronically controlled plate clutch, final drive gear and differential) and driveshafts. This system enhances driving characteristics and stability. The system is always active and cannot be deactivated. It works together with the ESP system and the engine and transmission control modules.

When driving at a constant speed, approx. 95% of the torque is distributed to the front wheels and approx. 5% to the rear wheels. The torque is distributed steplessly and instantaneously between the front and rear wheels, depending on the driving conditions. If the car is fitted with eLSD (electronically controlled plate clutch between the rear wheels), the torque can also be distributed individually to the relevant rear wheel.

For optimum system function, the car's tires should not have varying degrees of wear. When the XWD system requires service, the following message is shown on the SID:



Service XWD.

When the service message is displayed, the XWD system may have limited functionality (or be completely disabled in some cases, i.e. the car switches to front-wheel drive). Contact a workshop for information. We recommend that you contact an authorised Saab dealer.

Traction Control System (TCS)

Anti-spin system



WARNING

When driving normally, the TCS system helps to improve the car's stability, and driveability under slippery road and extreme driving conditions. The TCS must not be regarded as a system to enable the driver to maintain higher speeds. The same precautions must be adopted as normal for safe cornering and driving on slippery roads.

How the system works

The Traction Control System (TCS) is designed to prevent wheelspin. This enables the car to achieve the best possible grip and, hence, maximum tractive effort, together with greater stability.

The TCS system uses information from the ABS system's wheel speed sensors to determine whether any wheel is spinning. If any wheel is spinning, this is reduced on all-wheel drive cars initially by changing the torque distribution, secondly by reducing the engine torque, and thirdly with the aid of the wheel brakes. On front-wheel drive cars, wheelspin is reduced initially by reducing the engine torque, and secondly with the aid of the wheel brakes.

174 Starting and driving

The advantages of the TCS system are most apparent when road surface friction is so low that a lot of wheelspin can occur rapidly:

- When the car is pulling away or accelerating with the front wheels on different surfaces (e.g. one slippery and one dry), the TCS functions like an electronic differential lock, making sure that both wheels rotate at the same speed. The system also functions when the car is reversing.
- When cornering, if the inside front wheel rotates faster than the other wheels.

TCS OFF

 lights up if:

- The system has been switched off manually. It cannot be switched off if the car is travelling faster than 35 mph (60 km/h).
- There is a fault in the ABS system
- **A fault has been detected and the system has therefore been switched off and at the same time the following message is shown on the SID:**



**Traction control failure.
Contact service.**

TCS indicator

When the ignition switch is turned to the ON position, the lamp is lit for about 4 seconds while the system performs self-diagnosis.

The  light comes on when the TCS is operative, that is when one of the wheels has lost its grip.

The fact that the TCS is operative indicates that the limit for grip has been exceeded and that the driver must exercise greater care.

Temporarily turning the TCS off

The TCS is switched on automatically when the engine is started.

It may be necessary to switch off the system if the car has become bogged down, for instance.

If a fault is detected in the ABS, the TCS will be switched off automatically.

The cruise control system (if active) will automatically be disengaged if the TCS is operative.

Disengage the system in Settings.

- 1 Select **Settings** using the steering wheel buttons,  or .
- 2 Hold the SET button depressed until a chime sounds.
- 3 Select **TCS**.
- 4 Press the SET button.
- 5 Select **ON** or **OFF**.

End by pressing the SET-button.

Go back/undo using the CLR-button.


Electronic Stability Program ESP®

Anti-skid system



When driving normally, the ESP® system helps to improve the car's stability and maneuverability under slippery road and extreme driving conditions. The ESP® system must not be regarded as a system to enable the driver to maintain higher speeds. The same precautions must be adopted as normal for safe cornering and driving on slippery roads must be adopted.

The ESP® system employs both the antilock braking system (ABS) and the traction control system (TCS). It is a system that helps the driver to stabilize the car in unusual circumstances that can otherwise be more difficult to handle.



The illustration shows how the system brakes one or more wheels (and with varying braking force for each wheel) in order to increase the car's chances of following the direction in which the driver wants to drive.

How the ESP® system works

The ESP® system can help to prevent the car from skidding by braking one or several wheels independently of the driver. The engine output is then also reduced to prevent the driving wheels from spinning. The car has sensors that measure wheel speed, yaw rate, lateral acceleration, steering wheel position and braking pressure. The values provided by these sensors are used to calculate the actual direction of the car, the intentions of the driver and whether the ESP® system should be engaged.

If this direction does not agree with that intended by the driver, calculated from the steering wheel position, the ESP® system is engaged.

The ESP® system improves the driver's chances of retaining control over the car in a critical situation.

176 Starting and driving

ESP® system OFF

 lights up if:

- The system is turned off manually. The car must be travelling slower than 35 mph (60 km/h). The TCS is also disengaged.
- A fault is detected in the ABS-system.
- **A fault has been detected in the system and the system has therefore been switched off. The following message will be displayed on the SID:**



**Stability control failure.
Contact service.**

ESP® system indicator light

When the ignition switch is turned to the ON position, the lamp is lit for about 4 seconds while the system performs self-diagnosis.

The  light comes on for a short period of time when the ESP® system is operative.

Operation of the ESP® system indicates reduced cohesion between the tires and the road, and that extra care should be taken by the driver during continued driving.

Temporarily turning ESP® system off

The ESP® is switched on automatically when the engine is started.

It may be necessary to switch off the system if the car has become bogged down, for instance.

The ESP® system is always engaged during braking, even if it has been switched off manually with the ESP® button.

The cruise control system (if active) will automatically be disengaged if the ESP® system is operative.

NOTICE

Changes to the chassis, such as a change of wheels, shock absorbers or springs, could affect the function of the ESP® system.

Always consult a workshop before changing any chassis components. We recommend that you contact a Saab dealer.

Disengage the system in Settings.

- 1 Select **Settings** using the steering wheel buttons,  or .
- 2 Hold the SET button depressed until a chime sounds.
- 3 Select **ESP**.
- 4 Press the SET button.
- 5 Select **ON** or **OFF**.

End by pressing the SET-button.

Go back/modify using the CLR-button.


Parking brake

WARNING

- **Always** apply the parking brake when you park the car. If the car is to be left parked for a long time, refer to page 179.
- **Always** apply the parking brake before removing the remote control.
- Do not use the parking brake while driving.
- Grasp the parking brake lever in such a way that no fingers get trapped when you release the parking brake.

The parking brake lever is situated between the front seats. The brake acts on the rear wheels. When the parking brake is applied, the  indicator light on the main instrument panel will come on.

To release the parking brake, lift the lever slightly, pull the release button on the underside of the lever and lower the lever.



Correct hold

If conditions allow, it is best if the brake pedal is not depressed, or only depressed as little as necessary so as to stop the car from rolling, when the parking brake is applied.

To facilitate releasing the parking brake, depress the brake pedal. This is especially appropriate if the car is standing on a hill.

If the parking brake is applied when the car starts off, the following message will appear on the SID:



Release park brake.

Parking

WARNING

- **Never** leave children or pets unattended in the car. In warm, sunny weather, the temperature inside the car can reach 160–180 °F (70–80 °C).
- Park where the vehicle will not create an obstruction or a hazard to other road users.
- Do not park on dry grass or other combustible material. The catalytic converter gets very hot and could start a fire.
- Apply the parking brake, remove the remote control and lock the car.

178 Starting and driving

NOTICE


Empty the car yourself and bear in mind:

- Never leave a mobile phone, camera, computer or similar object visible in the car.
- Clothing, packages and bags attract thieves.
- Do not leave small objects such as CDs, sunglasses and coins visible.
- If possible, park in a well-lit, conspicuous parking space.
- Thieves strike whenever and wherever they are given the opportunity.

Parking on a hill

When parking on a steep hill, turn the front wheels so that they will be blocked by the curb if the car should move.

If the car is parked with one front wheel touching the curb, for example, you may need to turn the steering wheel slightly when you insert the remote control to allow the steering wheel lock to unlock.



1 Downhill with curb.

Turn the wheels toward the curb and edge the car forwards until the wheel lightly touches the curb.

2 Uphill with curb.

Turn the wheels away from the curb and edge the car backward until the wheel lightly touches the curb.

3 Uphill or downhill without curb.

Turn the wheel towards the edge of the road so that the car, should it move, will not roll towards the middle of the road.

Long-term parking

If the car is not going to be used for some time, e.g. three to four months, the following steps are recommended:

- Drain the washer fluid reservoir and hoses.
- Wash and wax the car. Clean the rubber seals on the hood, trunk lid and doors, and lubricate them with glycerol (glycerine).
- After washing the car, dry the brake discs to avoid corrosion by taking the car out on the road and applying the brakes a few times.
- Fill the fuel tank to prevent condensation forming in it.
- Top up the coolant and check the anti-freeze before the onset of winter.

- Park the car in a dry, covered and well-ventilated building. Leave the parking brake OFF!
- **Convertible:** If the car is stored, the soft top should be closed.
- If necessary, use wheel chocks and leave the parking brake off.
- Disconnect the negative (–) battery lead. If frost is likely to occur during the storage period, remove the battery and store it in a frost-free place.
- If it is not possible to stand the car on axle stands, increase the tire pressure to 43 psi (3 bar).

Leave all the door windows open a crack and cover the car with a non-plastic tarpaulin – not one made of plastic which will not breath.

Saab Parking Assistance *

Saab Parking Assistance


⚠ WARNING

Responsibility **always** lies with the driver when reversing.

- The parking assistance system can facilitate parking and reversing.
- Bear in mind that small objects, such as a child lying on the ground, and narrow objects cannot always be detected by the system.


Saab Parking Assistance facilitates parking and reversing. There are four sensors in the rear bumper that detect objects up to 6 ft (1.8 meters) behind the car.

If the car is heavily laden, the system may falsely indicate that there is an object within the detection range. This is since the sensors are angled towards the ground when the car is tail-heavy.



Area monitored by the sensors seen from the side

The system uses four sensors in the rear bumper. These emit ultrasound signals that bounce back to the sensors off any objects behind the car. The system, however, cannot always detect small or narrow objects, such as a post, since the surface area presented to the car is too small.



Area monitored by the sensors seen from above

The system is activated automatically when reverse is engaged or selected. Audible confirmation is given and the following text is shown on the SID:

Parking Assistance active

If a warning message, such as the safety belt reminder, is shown on the SID when reverse is engaged, the audible signals from the parking assistance system will not be heard since the warning message has priority.

When the sensors detect an object within the monitored area, pulses of sound (- - -) will be heard. The frequency of these pulses

increases as the car comes closer to the object.

If you stop the car with reverse gear engaged, the sound pulse will stop after 2 seconds. The sound pulses will return if you continue to reverse. If the car rolls forward while reverse is engaged, the system is silenced.

When the distance to the object is less than 1 ft. (30 cm), a continuous tone will be heard.

When an object is approximately 3 ft. (90 cm) from the car, the sound pulses change character markedly (frequency increases). A distance of about 3 ft. (90 cm) is suitable if you wish to load or unload the trunk.

If the distance between an object and a corner sensor does not change for 3 seconds, for example if you are reversing alongside a wall, the system will switch to monitoring straight back. The system indicates if the distance to the wall decreases again.

If a trailer is hitched up and correctly connected to the trailer contact by the towbar, the system is automatically deactivated.

NOTICE

The sensors must be kept clean to function well. Ice, snow and dirt can affect their sensitivity.

Large quantities of snow or dirt covering the sensors can prevent the parking assistance system from detecting any objects.

Do not spray the sensors with a pressure washer, as this can damage them.

Reversing alongside a wall

If the distance between an object and a corner sensor does not change for 2 seconds, for example if you are reversing alongside a wall, the system will switch to monitoring straight back. The system indicates if the distance to the wall decreases again.

Cars with trailer hitch

If the car has a trailer hitch and its wiring is correctly connected to the car's electrical system, the Saab Parking Assistance automatically compensates for the protrusion of the towbar.

If a camper or trailer is hitched up and the trailer hitch wiring is correctly connected to the car's electrics, the system is automatically deactivated.

You can temporarily deactivate the Saab Parking Assistance as follows:

Engage reverse and press the CLR button on the steering wheel.

The system will be reactivated the next time you engage reverse.

182 Starting and driving

Error messages

If the system malfunctions, the following message will appear on the SID:

 **Parking assistance malfunction. Service.**

If the system is subject to interference, the following message will be shown on the SID:

 **Parking assistance sensor interference.**

If this message appears, clean the sensors. The sensors are located in the black trim on the rear bumper

The system can be switched off using **Settings**.

- 1 Select **Settings** using the steering wheel controls,  or .
- 2 Press and hold the SET button until given audible confirmation.
- 3 Select **Park Assistance**.
- 4 Press the SET button.
- 5 Select **ON** or **OFF**.
- 6 Confirm the setting by pressing the SET button.

Park Assistance
ON
OFF

Explanation of **ON** and **OFF**.

ON

Saab Parking Assistance is activated automatically when reverse is engaged. The system warns of objects behind the car.

If a trailer is hitched up and correctly connected to the trailer connector, the system will be deactivated automatically. You can also deactivate the system temporarily with the CLR button if reverse has been engaged and the system is active.

OFF

Saab Parking Assistance deactivated.

Economical driving

Factors affecting fuel consumption

The fuel consumption of a car is greatly affected by driving conditions, climate, road conditions, speed, driving technique, etc.

Breaking-in

Fuel consumption may be somewhat higher during the break-in period (the first 3,000–4,000 miles (5,000–7,000 km)).

Weather conditions

Summer temperatures give better fuel economy than winter ones. The difference can be as much as about 10%. Consumption increases in cold weather because the engine takes longer to reach its normal operating temperature. The transmission and wheel bearings also take longer to warm up. Even distance affects consumption: short journeys of 3–5 miles (5–8 km) do not give the engine enough time to reach its optimum temperature. Wind conditions also have a marked effect on fuel consumption.


How to read the diagram:

If fuel consumption with the engine at normal temperature is 28 mpg (10 l/100 km), the actual fuel consumption 3 miles (5 km) after the engine has started from cold will be:

- 23.5 mpg (12 l/100 km) at outside temp. of 68 °F (+20 °C) (increase of 20 %).
- 17.7 mpg (16 l/100 km) at outside temp. of 32 °F (0 °C) (increase of 60 %).
- 14 mpg (20 l/100 km) at outside temp. of –4 °F (–20 °C) (increase of 100 %).

It is clear from the diagram that both distance driven and outside temperature have a significant impact on fuel consumption, after a cold start.

If the car is normally driven on short journeys, 3–5 miles (5–8 km), for example to and from work, the average consumption will be 60–80% above the normal level.



Percentage increase in fuel consumption of engine starting from cold compared to engine at normal temperature.

Driving techniques

- To obtain the best running economy, with regard to fuel consumption and general wear, the car must be serviced regularly.
- High speed, unnecessary acceleration, frequent braking and much changing down all give higher fuel consumption.
- Frequent gear changing in traffic, starting in cold weather, the use of studded tires and roof racks, and towing a camper all increase fuel consumption.
- Do not warm up the engine while the car is stationary. If idling, the engine will take much longer

184 Starting and driving

to reach its optimum temperature, and engine wear is at its greatest during this period. Drive off as soon as possible after starting the engine and avoid high engine speeds.

- Drive as smoothly and thoughtfully as possible. Match your driving to the prevailing traffic conditions.
- Driving in a low gear gives rise to higher fuel consumption than driving in a high gear because of the higher engine speed for any given road speed. Always shift up as soon as traffic conditions allow and drive in the highest gear as much as possible.
- Check the tire pressure once a month. Incorrect tire pressure increases tire wear. It is preferable for the tire pressure to be slightly high than too low. Under-pressure increases fuel consumption.
- Check the fuel consumption regularly. Increased fuel consumption can indicate that something is wrong and that the car needs to be checked. We recommend that you contact a Saab dealer.

Practical road tests have demonstrated that substantial savings in fuel consumption can be made if the above advice is followed.

WARNING

Never switch off the engine while driving as the effect of the brakes and power steering will be greatly reduced.

Road conditions

Wet roads increase fuel consumption, as do unpaved roads and driving in hilly country (the amount of fuel saved driving downhill is less than the additional amount required to climb the hill).

Engine block heater ❄

If block heater is installed the cord can be found coiled in the engine compartment.

The following are just some of the benefits to the car and the environment of using an engine block heater:

- Lower fuel consumption
- Reduced wear on the engine
- Inside of car warms up faster
- Exhaust emissions substantially reduced over short runs.

The engine heater is effective at outside temperatures up to 60–70 °F (+15 – +20 °C). The warmer it is outside, the shorter the time the engine heater needs to be connected.

- If the outside temperature is -22 °F (-30 °C) the heater needs to be connected at least 3 h.
- If the outside temperature is -14 °F (-10 °C) the heater needs to be connected at least 2 h.

- If the outside temperature is 32 °F (-0 °C) the heater needs to be connected at least 1.5 h.

To have the heater connected less than 0.5 h is no use but can lead to driveability problems.

If the car is equipped with a removable, electric cabin heater that is not in use, store this in the trunk.

Driving in cold weather

In cold weather, special attention should be paid to the following:

- Before driving off, make sure that the wiper blades have not frozen to the windshield.
- Remove any snow from the heating system air intakes between the hood and the windshield.
- If necessary, inject oil into the locks to prevent them from freezing. Use molybdenum-sulfide oil (MoS₂). If the locks freeze, exercise care when unlocking the car (manual unlocking) to avoid breaking the key. Warm up the key or use a de-icer.
- It is particularly important when the roads are slippery that the brakes and tires are in good condition.
- For how to check the level of antifreeze in the engine coolant, see page 210.

- Add gasoline anti-freeze when refueling several times before the onset of winter. This will prevent condensation water in the fuel tank from freezing and causing interruptions in the fuel supply. The likelihood of condensation is lowest when the fuel tank is full. If the car is parked outside and the temperature is below zero, gasoline anti-freeze is of little use as it cannot remove water that has already frozen. Park the car in a warm place so that any ice that may have built up melts, then add gasoline anti-freeze when refueling. Condensation is caused by temperature fluctuations, either in the outside temperature alone or when the car is alternately parked outdoors and in a garage.
- **Convertible:** Avoid operating the soft top at temperatures below 23 °F (–5 °C).

- The car is equipped with tires designed to provide optimum grip on both wet and dry roads, although this has been achieved at the expense of somewhat reduced grip on snow and ice. For regular driving on snow and ice, we therefore recommend that winter tires be fitted. However, winter tires achieve this extra grip at the expense of grip on bare road surfaces.

Winter tires, particularly studded tires, generally make driving safer on snow and ice.

Acquaint yourself with the legal provisions governing the use of different types of winter tires and snow chains. Studded tires are not allowed in some countries. If winter tires are fitted, the same type must be fitted to all four wheels. Your Saab dealer will be pleased to advise you on the best tires for your car.

186 Starting and driving

Remember that tires age: it may therefore be necessary to change winter tires before they reach the legal wear limit, as they gradually lose their friction properties with age.

If you get into a front wheel skid and the car has a manual transmission, the best response is to freewheel, which means declutching so that the wheels neither drive nor brake, and to cautiously steer in the desired direction.

If the car has automatic transmission, ease off the accelerator slightly and steer cautiously in the desired direction.

If you get into a rear wheel skid, steer in the same direction as the movement of the rear of the car.

Driving with tire chains ❄

Snow chains must only be fitted to the wheel and tire dimensions that Saab recommends in "Technical data" on page 283.

We recommend that you contact a Saab dealer regarding approved tire chains. See also page 247.

WARNING

- Do not drive at speeds above 30 mph (50 km/h) when tire chains are fitted.
- Tire chains can reduce directional stability.
- Do not fit tire chains to the car's rear wheels.

NOTICE

- Check the links frequently for wear.
- Check that the chains do not foul the wheel arch liner at full lock.
- Refer to the "Technical data" section on page 283, for information on wheel and tire dimensions approved for the fitting of tire chains.

Driving in hot climates

Always check the coolant level before starting a journey. When the engine is cold, the coolant shall lie on or just above the KALT/COLD mark on the expansion tank (boundary between the upper and lower sections of the tank).

At the end of a journey, allow the engine to idle for 2–3 minutes before switching it off.

If the needle on the temperature gauge enters the red zone, the following message will be shown on the SID:



Hot engine. Make a safe stop. Idle engine.

- 1 Stop the car but do not switch off the engine. **Do not** remove the cap on the cooling system expansion tank, even if the tank is empty. The engine temperature should decrease. If the temperature continues to rise with the engine idling, the engine must be switched off.

- 2 If the engine is idling and the needle on the temperature gauge falls, wait until a normal temperature is shown (about in the middle of the scale) before switching off the engine. If the coolant needs to be topped up, **carefully** unscrew the expansion tank cap.

Fill as required with a mixture of 50 % antifreeze and 50 % clean water. Use an antifreeze approved by Saab.

WARNING

- Exercise care when opening the hood if the engine is overheated. Never remove the expansion tank cap completely when the engine is hot.
 - The cooling system is pressurized - hot coolant and vapor can escape. These can cause injury to your eyes and burns. Open the cap slowly to release the pressure before removing it.
- 3 Have the car's cooling system checked. We recommend that you contact a Saab dealer.

188 Starting and driving

Towing a trailer ***⚠ WARNING**

- Do not drive with a trailer on inclines steeper than 15 %. The load on the drive (front) wheels will be so low that the wheels can start to spin and prevent further progress.
- In addition, the car's parking brake may not always be sufficient to hold the car and trailer securely, as the wheels may start to slide.
- Always apply the trailer's parking brake when unhitching it. There is otherwise a risk of personal injury or damage to the bumper should the trailer start to roll.
- When you hitch up the trailer be sure to attach its safety chains to the holes by the hitch.

Make sure you are familiar with the legal requirements regarding speed limits for towing, maximum trailer weights, trailer braking requirements, and also any special driving licence provisions.

Trailer hitch attachment *

Trailer hitch attachments are available as accessories. These are designed for a maximum trailer weight of 3500 lbs (1588 kg), with trailer brakes.

The towbar must not be installed on certain models. Contact an authorised Saab dealer for information.

An electrical connection * for the towbar and an electrical unit are provided in the electrical center on the left-hand side of the luggage compartment.


If the car has a 13-pin Saab genuine electrical socket then it is possible to supply a trailer/caravan with rear fog lights and reversing lights. The caravan can also have interior and exterior lighting even when the car's ignition is switched off. **In which case, remember not to load the battery for too long so that it is discharged and prevents the car from starting.**

There is also access to power in the caravan during a journey, the caravan battery can be charged for example.

Also, if the car has SPA, this is deactivated automatically if a trailer is hitched up and correctly connected to the Saab genuine trailer socket.

Saab recommendations:

- Use a genuine Saab trailer hitch that is designed and tested for your Saab.



- Contact your Saab dealer for advice on which trailer hitch is designed for your car.

NOTICE

- Only use a towbar that has been approved for your car. We recommend that you entrust towbar installation to an authorized Saab dealer, which can also provide important information such as trailer weight. Your authorized Saab dealer has information on how the towbar is to be installed and whether other measures must be undertaken that could affect the cooling system or other equipment
- We recommend that you contact a Saab dealer for guidance on how to connect a trailer hitch.
- Exercise care when driving on uneven roads or against the curb if the car is heavily laden. This particularly applies to cars with 17" and 18" wheels.

Recommendations for cars with automatic transmission

The following driving time limits are based on the capacity of the cooling system in hot weather, i.e. approximately 86°F (+30°C).

Gradient of hill, %	Max. trailer weight, lbs. (kg)	Time limit, minutes
6-8	3330 (1500)	unlimited
9-11	3080 (1400)	max 15
12-14	2645 (1200)	max 15
max 15	2200 (1000)	max 15

The following driving time limits are based on the capacity of the cooling system in hot weather, i.e. approximately 104°F (+40°C).

Gradient of hill, %	Max. trailer weight, lbs. (kg)	Time limit, minutes
6-8	2200 (1000)	unlimited
9-11	1760 (800)	max 15
12-14	1100 (500)	max 15
max 15	880 (400)	max 15

When negotiating long hills, bear the following important considerations in mind.

Rises in coolant temperature are indicated by the temperature gauge in the main instrument panel.

The following steps are taken in order as the temperature of the transmission increases:

- Gear change pattern is altered
- A/C compressor is switched off
- Max. engine torque is reduced.

The following message will be displayed on the SID if the transmission fluid becomes too hot:



Gearbox too hot. Make a safe stop. Open hood.

If this message appears, stop the car as soon as it is safe to do so and allow the engine to idle until the message has gone out. The selector lever should be in position P.

190 Starting and driving

When continuing your journey, manually select a low gear in which the engine speed is about 3,500 rpm until the incline eases (see page 168).

WARNING

Remember to use engine-braking (selector position M1, M2, or M3) to spare the brakes when you are driving on a long or steep downhill slope.

Overheating can cause the brakes to fade!

Recommendations for cars with manual transmission

Rises in coolant temperature are indicated by the temperature gauge in the main instrument panel.


When the needle is just outside the red zone, the A/C compressor will be switched off and, on certain engine variants, the maximum engine torque will be limited.

When continuing your journey, select a low gear in which the engine speed is about 3,500 rpm until the incline eases.

WARNING

Remember to use engine-braking (selector position 1, 2, or 3) to spare the brakes when you are driving on a long or steep downhill slope.

Overheating can cause the brakes to fade!



Distribution of load in trailer

- a Light
- b Moderate
- c Heavy

Trailer hitch load

The weight distribution on the trailer makes a lot of difference to the handling properties of the car and trailer combination. With a two-wheel trailer, concentrate the load over the wheels and keep it as low as possible.

The trailer should be loaded so that the load on the towball is 110–165 lbs. (50–75 kg). Note that this load must be included in the total load for the car. If this now exceeds the specified load capacity, the load in the trunk may have to be reduced by the corresponding amount.

Checks before driving

Make sure that the car and trailer are in good working order. This is essential since towing a trailer increases the strain on the car.

- Check and if necessary adjust the tire pressure of the car and trailer.
- Make sure all wheel bolts are properly tightened.
- Make sure that the equipment joining the car and trailer is properly secured and adjusted.
- Make sure the trailer's electrical cable is properly connected and is not so long that it drags along the ground. Also, make sure the cable is not too short and risks breaking when turning a corner.
- Check all bulbs.
- Check the car and trailer brakes.
- Make sure that all items on or in the camper or trailer are properly secured.
- Make sure that the trailer's jockey wheel is raised and locked.
- Check the distribution of the load so that the car and trailer are well balanced.
- Check that the rear view mirrors provide the best possible rearward vision.
- Make sure the trailer's safety cable is correctly attached.

Driving considerations

Always take extra care when towing a trailer, as the car's handling will be different and its braking performance reduced. The trailer's braking system and suspension also have a considerable effect on these characteristics. See also "**Driving with a load**" on page 192.

Drive carefully:

- Descending hills
- On uneven roads
- Over railway crossings
- When meeting large vehicles.

If the car has automatic transmission, select gear M1 when ascending or descending steep hills.

Reversing

Get someone to help you keep an eye out behind the trailer as the door mirrors do not always provide sufficient rearward vision when reversing.

192 Starting and driving

Driving with a roof rack load

WARNING

- A roof load will affect the car's center of gravity and aerodynamics. Be aware of this when cornering and driving in crosswinds.
- Adjust your speed to the prevailing conditions.
- Due to higher aerodynamics drag, fuel economy may suffer when driving with a roof rack.

The maximum permissible roof load is 220 lbs. (100 kg). Note that the roof load must be included in the car's maximum permissible payload and axle load.

Strong, sturdy roof carriers designed specially for your car are available from your Saab dealer. Always secure roof loads securely.

Driving with a load

The handling characteristics are affected by how the car is loaded.

NOTICE

- Place the heaviest load as far forward and as low as possible in the trunk.
- Secure the load to the lashing eyes (see page 139).
- Heavy loads mean that the car's center of gravity is further back. As a result, the car will sway more during evasive steering.
- Never exceed the permissible load of the roof box, even if there is room for more.
- Ensure that the tire pressure is correct – slight overinflation is preferable to underinflation.

- The braking distance of a loaded car is always greater. Keep your distance from the vehicle in front.
- Do not exceed the car's permissible gross vehicle weight or axle load (see page 284).
- Roof loads can negatively affect telecommunication.

For further information on tires see page 240.

Driving with the trunk lid open

WARNING

Avoid driving with the trunk lid partly or fully open, since exhaust fumes can be drawn into the cabin.

If you must drive with the trunk lid open, close all windows and the moonroof (if equipped) and set the cabin fan to its highest speed setting.

Driving in deep water

NOTICE

Do not drive in puddles or water deeper than 7 in. (20 cm) and do not drive faster than 3–4 mph. Water can otherwise be sucked into the engine. The engine will be seriously damaged if water enters the intake system.

Towing the car

WARNING

- Remember that the brake servo does not operate when the engine is off. Much greater pressure than normal will therefore be required to operate the brake pedal.
- Nor does the steering servo operate when the engine is off. The steering will therefore be much heavier than usual.
- The towing vehicle should always be heavier than the vehicle on tow.
- Never allow passengers to ride in the car when it is on tow.

- Always seek professional help if the car needs to be recovered.
- The ignition switch must be in the ON position if the car is moved with the engine not running.
- The steering wheel lock must be disengaged before towing the car.
- The steering wheel lock disengages when the remote control is inserted into the ignition switch, if the battery has sufficient charge.


194 Starting and driving

Front towing eye

WARNING

- Make sure that the towing eye is screwed in tightly. It has a **left-hand thread!**
- The towing eye is only designed for towing the car on roads. **It must not be used** to pull the car out of a ditch, for example.
- Make sure that all bystanders keep a suitable distance, in case the towing eye or tow rope should snap. The towing eye or tow rope could catapult off and cause seriously injury.
- Never drive with the towing eye fitted to the front bumper. Return it to its designated storage space.


The front towing eye is stowed by the spare wheel. On the left-hand side of the bumper is a cover concealing the attachment point (tapped hole) for the towing eye.



Front towing eye fitted.
The towing eye has a left-hand thread!

- 1 Open the cover first at the lower edge with a screwdriver for example. Watch out for the paintwork.
- 2 Screw in the towing eye. **The towing eye has a left-hand thread!**
- 3 Insert the wheel wrench into the eye to tighten it properly.

To refit the cover: Start by inserting the top edge of the cover. Then click in the lower edge.




Rear towing eye

Rear towing eye

The car has a permanent towing eye at the rear under the bumper.

If the car is equipped with a towbar, this can be used instead of the towing eye.



Never use the towing eyes to pull the car unstuck.

Towing the car

Cars with manual transmission

NOTICE

- **Never** use the towing eyes to pull the car unstuck.
- If the car is to be towed with the front wheels off the ground, make sure the parking brake is off, as this acts on the rear wheels.

Saab 9-3 XWD with manual transmission: If the car is towed with all four wheels on the ground then there are no technical limitations for speed and distance. If both front wheels **or** both rear wheels have been raised, and if the law permits, the maximum towing speed is 30 mph (50 km/h). There are no limitations as to the distance over which the car can be towed.

Engage neutral. Turn on the parking lights.

Drive carefully and do not exceed the speed limit for vehicles on tow.

Always try to keep the towrope taut by gently applying the brake of the car on tow, as necessary. This will avoid the towrope being jerked violently.

Cars with automatic transmission

NOTICE

- **Never** use the towing eyes to pull the car unstuck.
- The car must be towed front first.
- If the car is to be towed with the front wheels off the ground, make sure the parking brake is off, as this acts on the rear wheels.

Saab 9-3 XWD with automatic transmission:

If the car is towed with all four wheels on the ground then it may be towed at a maximum speed of 30 mph (50 km/h) and for a maximum of 30 miles (50 km).

If both front wheels have been raised, and if the law permits, the car may be towed at a maximum speed of 30 mph (50 km/h). There are no technical limitations as to the distance over which the car can be towed.

Move the selector lever to N. Turn on the parking lights.


Drive carefully and do not exceed the speed limit for vehicles on tow.

Always try to keep the towrope taut by gently applying the brake of the car on tow, as necessary. This will avoid the towrope being jerked violently.

196 Starting and driving

Whatever the speed limit, the car must not be towed at speeds exceeding 30 mph (50 km/h) nor for a distance of more than 30 miles (50 km). If the car needs to be transported over a longer distance, a tow truck or flatbed truck must be called out.

The engine cannot be started by towing or pushing the car. In an emergency, the engine can be started as described under "**Jump starting**" on page 197.



Attachment points for anchorage straps

Transporting the car

NOTICE

If a car with sports (lowered) chassis is transported, for example on a flat bed truck, take extra care not to damage the spoiler and/or underbody.

Vehicle recovery

If the car has to be transported on a flatbed truck, or similar, it must be securely strapped down. There are attachment points for this purpose on the underside of the car. The attachment points are oblong holes that have been reinforced to cope with the stresses that arise during this type of transport.

Jump starting

WARNING

- When working on the battery, highly explosive gas can build up. A spark could ignite this gas that collects around the battery. Therefore, always avoid sparks and open flames in the vicinity of the battery.
- The battery contains corrosive sulfuric acid. Always wear a face mask or goggles when working on the battery.
- If battery acid gets into the eyes or splashes onto skin or clothing, wash the affected area liberally with water. If acid gets into the eyes or a large quantity makes contact with the skin, seek medical help.

NOTICE

Ignoring these steps could result in costly damage to your vehicle that would not be covered by your warranty.

Trying to start your car by pushing or pulling it could damage your vehicle, even if you have a manual transmission. If you have an automatic transmission, your vehicle cannot be started by pushing or pulling it.

It is essential when a donor battery is to be used to jump start the car that the jump leads be connected correctly to prevent arcing.

To jump start your vehicle

- 1 Check the other vehicle. It must have a 12-volt battery with a negative ground system.

NOTICE

If the other system is not a 12-volt system with a negative ground, both vehicles can be damaged.


- 2 Get the vehicles close enough so the jumper cables can reach, but be sure the vehicles are not touching each other. If a poor connection on the negative jumper cable should exist, it is possible for damage to be caused to electrical systems/components of either vehicle should inadvertent contact be made. You would not be able to start your car and bad grounding could damage the electrical systems.

WARNING

You could be injured if the vehicles roll. Set the parking brake firmly on each vehicle. Put an automatic transmission in P (Park) or a manual transmission in Neutral.

- 3 Turn off the ignition on both vehicles. Turn off lights that are not needed, and radios. This will avoid sparks and help save both batteries and it could save your radio.

198 Starting and driving



Jump starting

NOTICE

If you leave your radio on, it could be badly damaged. The repairs would not be covered by your warranty.

4 Open the hood and locate the battery.

Find the positive (+) and negative (-) terminals on the battery.

! WARNING

An electric fan can start up even when the engine is not running and can injure you. Keep hands, clothing and tools away from any under hood electric fan.

! WARNING

Using a match or flame of any kind near a battery can cause battery gas to explode. You can suffer burns or be blinded. Use a flashlight if you need more light.

Be sure the electrolyte in the battery is not frozen. Discharged batteries will freeze. When connecting jumper cables to a frozen battery, gas from the chemical reaction inside the battery can build up under the ice and cause an explosion.

Battery fluid contains acid that can burn you. Do not get it on you. If you accidentally get it in your eyes or on your skin, flush the area with water and get medical help immediately.

5 Check that the jumper cables do not have loose or missing insulation. If they do, you could get a shock and also the vehicles could be damaged. Before you connect the cables, here are some basic things you should know. Positive (+) will go to positive (+) and negative (-) will go to negative (-). Do not connect (+) to (-) or you will get a short that could injure you or would damage the battery and maybe other parts as well.

6 Connect the red positive (+) cable to the positive (+) terminal of the vehicle with the discharged battery.

7 Do not let the other end touch metal. Connect it to the positive (+) terminal of the good battery. Use a remote positive (+) terminal if the vehicle has one.

8 Now connect the negative (-) cable to the good battery's negative terminal.

9 Attach the cable to the discharged battery's negative terminal.

10 Start the vehicle with the good battery and run the engine for a while.

11 Try to start the vehicle with the discharged battery. If it does not start after a few tries, it probably needs service.

Note. If the current in the low battery is too low it might be necessary to wait several minutes with the cables connected before you can start the engine with the low battery.

12 Remove the cables in reverse order to prevent electrical shorting. Take care that they do not touch each other or any other metal.

Using a battery charger */starter unit

To avoid damaging the car's electrical system and electronics, the following rules must be followed when charging the battery or jump starting the car.

- If the charger or starter unit can be set to different voltages (6 V/12 V/18 V/24 V), 12V must be selected.
- Follow the manufacturer's instructions supplied with the charger or starter unit.
- No other apparatus that are grounded or connected to the mains must be connected to the car during charging or jump starting.
- The charger or starter unit must under no conditions produce a voltage greater than:
 - 16 V continuous
 - 18 V for 60 minutes.

If you are unsure about the charge rating of the unit, disconnect the battery clamp from the positive terminal before connecting the unit to the battery.

For long trips

Before starting off on a long journey, it is advisable to have your car inspected by your Saab dealer.

Obtain a few important items to take along on your journey, such as spare bulbs, wiper blades, fuses, a drive belt (poly-V-belt) and the like.



You can check some points yourself beforehand:

- Check that no oil or fuel leaks out of the engine or gearbox/transmission.
- Check the coolant and power steering fluid levels. Check also for leaks.
- Inspect the drive belt (poly-V-belt) and replace if it shows any signs of wear.
- Check the battery charge.
- Check the tires for tread pattern and air pressure, including the compact spare tire.
- Take an extra remote control and keep it separate.
- Check the brakes.
- Check all bulbs.
- Check for the presence of the tool kit and jack in the car.



200 Starting and driving

(This page has been left blank.)



Car care



BB4731

Hood _____	202	Tires _____	240
Engine _____	203	Automatic tire pressure monitoring system _____	253
Engine bay, 4-cyl engine	206	Compact spare _____	256
Engine bay, V6 engine _	207	Changing a tire _____	258
Engine oil _____	208	Safety belts _____	266
Air filter _____	209	Upholstery and trim _____	266
Transmission fluid _____	210	Textile carpeting _____	267
Coolant _____	210	Engine bay _____	267
Brake/clutch fluid and brake pads _____	212	Washing _____	267
Power steering _____	213	Waxing and polishing _____	270
Battery _____	214	Touching up the paint _____	270
Drive belt _____	215	Anti-corrosion treatment	271
Wipers and washers _____	216	Recovery and/or recycling of automotive materials _____	272
Wiper blades _____	216	Air conditioning (A/C) _____	273
Changing bulbs _____	218		
Fuses _____	233		

* Asterisk means: equipment not fitted in all cars (can depend on model variant, engine variant, market specification, options or accessories).


202 Car care

Hood


The hood release handle is located on the left under the instrument panel. Open the hood in the following way:

- 1 Pull the release handle.
- 2 The hood moves to the half-locked position and is stopped by a safety catch at the front edge.
- 3 Press the lever of the catch upwards and raise the hood.

When you close the hood you should drop it from a height of about 12 inches (30 cm), **without** slamming it.



Hood release handle



Hood release catch plate



Engine

Turbo 4-cylinder engine

The engine is a transverse four-cylinder in-line engine with twin overhead camshafts and 16 valves.

The engine is equipped with two balance-shafts that reduce engine vibrations to a minimum.

The balance shafts are chain-driven and rotate at twice the speed of the crankshaft. They produce forces and torques that are opposed to those generated by the pistons and connecting rods. The effect occurs twice in each revolution of the engine, counteracting the vibration from its moving parts, and at the same time reducing unwanted engine noise.

The gearbox, located on the right (viewed from the front), is integrated with the engine.

Turbo V6 engine

The V6 engine is a turbocharged V6 engine produced completely of aluminium with 60° between the cylinder banks, 4 valves per cylinder, 2 camshafts per bank.

The camshafts are driven via a chain transmission. The engine is equipped with a turbo whose turbine collects exhaust pressure from both banks of cylinders.



To obtain optimum performance, fuel consumption and low emission levels the engine is equipped with CVCP (Continuous Variable Cam Phasing). This means that the engine's intake camshafts can be adjusted to achieve optimum functionality. The switches are hydraulic.

Engine families

Saab cars imported into the United States and Canada meet all applicable emission control standards. The engine family and appropriate tune-up specifications are identified on a label in the engine bay.

These engine families meet applicable EPA Federal Standards, California State Standards and Canadian Federal Standards and are equipped with the following systems:

- Sequential multiport fuel injection system
- Three way catalytic converter
- Crankcase emissions control system
- Evaporative emission system.



204 Car care

Emission control systems

The systems for controlling emissions to the atmosphere require regular checking and adjustment at the intervals specified in the service program.

In addition to meeting the exhaust emission regulations and thereby helping to keep the environment clean, a correctly tuned engine will also give maximum fuel economy.

WARNING

Engine exhaust, some of its constituents, and certain vehicle components contain or emit chemicals known to the State of California to cause cancer and birth defects and reproductive harm. In addition, certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Saab Trionic engine management system, 4-cyl engine

The Saab Trionic engine management system is a unique Saab development that combines sequential multiport fuel injection, electronic distributorless ignition and turbo-charger boost pressure control into one system.

The Trionic engine control module (ECM) monitors many different engine parameters such as:

- Intake manifold pressure
- Intake air temperature
- Crankshaft position
- Engine coolant temperature
- Throttle position
- The oxygen content of the exhaust gases.

The ECM receives information regarding engine knocking from a sophisticated feedback function in the ignition discharge unit.

By processing all of this information, the Trionic system can control fuel injector opening duration, ignition timing and turbo-charger boost pressure to provide excellent engine performance while maintaining low emissions and fuel consumption.

NOTICE

The Trionic engine management system continuously monitors the operation of these systems and has on-board diagnostic capabilities (OBD II). If the Service Engine Light also known as CHECK ENGINE light in the main instrument illuminates, the Trionic ECM has detected a problem. The car will continue to operate, but performance may be diminished. You should have your car checked by a workshop as soon as possible. We recommend that you contact a Saab dealer.

Bosch ME9 engine management system, V6 engine

The Bosch ME9 engine management system is a system that combines sequential multipoint fuel injection, electronic distributorless ignition and turbocharger boost pressure control into one system and intake camshaft phasing control.

The ME9 engine control module (ECM) monitors many different engine parameters such as:

- Charge air pressure
- Intake air temperature
- Crankshaft position
- Engine coolant temperature
- Throttle position
- The oxygen content of the exhaust gases.

By processing all of this information, the ME9 system can control fuel injector opening duration, ignition timing, intake camshaft phasing and turbocharger boost pressure to provide excellent engine performance while maintaining low emissions and fuel consumption.

NOTICE


The ME9 engine management system continuously monitors the operation of these systems and has on-board diagnostic capabilities (OBD II). If the Service Engine Light also known as CHECK ENGINE light in the main instrument illuminates, the ME9 ECM has detected a problem. The car will continue to operate, but performance may be diminished. You should have your car checked by a workshop as soon as possible. We recommend that you contact a Saab dealer.

ORVR (Onboard Refueling Vapor Recovery)

All hydrocarbons formed when refueling will be recovered by the car and not released into the atmosphere. The hydrocarbons are absorbed in an evaporative emission canister. When the engine is subsequently started, the evaporative emission canister is gradually purged as air is sucked into it through a shut-off valve. The hydrocarbon/air mixture passes through the evap canister purge valve and into the engine where it is burned. "**Refueling**", see page 156.

When refueling, make sure you screw the filler cap on and keep turning until it has clicked 3 times.


Engine bay, 4-cyl engine



- 1 Oil filler cap
- 2 Coolant reservoir
- 3 Brake and clutch fluid reservoir
- 4 Battery
- 5 Fuse box
- 6 Washer-fluid reservoir
- 7 Power-steering fluid reservoir
- 8 Engine-oil dipstick

BB2322

Engine bay, V6 engine



- 1 Power-steering fluid reservoir
- 2 Coolant reservoir
- 3 Brake and clutch fluid reservoir
- 4 Battery
- 5 Fuse box
- 6 Washer-fluid reservoir
- 7 Oil filler cap
- 8 Engine-oil dipstick

EB3758

208 Car care

Engine oil

Checking the oil level

Check the engine oil level regularly.


- 1 Park the car on a level ground.
- 2 Switch off the engine and wait for 2–5 minutes. The engine should be at normal operating temperature.
- 3 Take the dipstick out and wipe it off with a clean rag before carrying out the check.

The level must not be below the MIN mark on the dipstick, but nor should it be above the MAX mark. Excess engine oil could result in abnormal oil consumption.

The distance between the MIN and MAX marks is equivalent to 1.0 qt (1.0 l).

NOTICE

Too high oil level can damage the engine.




Oil filler cap and dipstick, 4-cyl engine

4-cyl engine: The engine oil level is checked each time the engine is started. If the oil level is low, the following message appears on the SID:



Low engine oil level.

If this occurs the oil level must be checked first. If the level is too low then it must be topped up.



Oil filler cap and dipstick, V6 engine

V6 engine: The engine has an oil level sensor that checks the oil level when the engine is running. If the oil level drops too low, the following message appears on the SID:



Low engine oil level.

If this occurs the oil level must be checked first. If the level is too low then it must be topped up.

Make sure you screw on the oil filler cap properly after topping up the oil to avoid running problems.

It is normal for an engine to consume a certain amount of oil. It is therefore often necessary to top up the oil between services. Check the engine oil level regularly.

During the Break-in Period (approx. 3,000 miles or 5,000 km) and when driving at high speeds or with a trailer, the oil consumption may be higher than normal.

NOTICE

Change of engine oil and oil filter may be required more frequently if the car is being used under certain conditions, see page 279.

WARNING

- Prolonged and repeated exposure of the skin to engine oil can cause serious skin disorders. Avoid prolonged skin contact whenever possible.
- Used engine oil contains chemicals that have caused cancer in laboratory animals. Always protect your skin by washing thoroughly with soap and water.
- Keep oil out of reach of children.
- Do not touch the turbocharger or exhaust manifold. These get very hot when the engine has been running.
- Do not spill oil on hot parts of the engine as this could cause a fire. Used engine oil is particularly flammable.
- Protect the environment. Do not dispose of oil into the ground or down a drain. Dispose of all used oil and oil filters at an appropriate disposal facility.

NOTICE

- Do not run the engine with the oil level too low.
 - Change engine oil and oil filter in accordance with the service programme.
 - Only use the recommended type of oil.
- Observe the above three points to avoid serious damage to the engine.
- For oil volumes and grades**, refer to page 286.

Air filter

WARNING

To ensure reliable operation, only use an air filter recommended by Saab Automobile AB.

210 Car care

Transmission fluid

Manual transmission

Check and top up the oil in accordance with the service program.

Automatic transmission

Check and top up the oil in accordance with the service program.

Coolant

WARNING

- Proceed with caution if the radiator is boiling when you open the hood. Never remove the expansion-tank filler cap when the radiator is boiling.
- The cooling system is pressurized – hot coolant and vapor can escape when the filler cap is released. These can cause injury to your eyes and burns. Loosen the cap carefully, and let the engine cool before removing the cap.
- Exercise care when adding coolant. Coolant on hot surfaces constitutes a fire risk.

There is an overpressure in the cooling system. Coolant temperatures can sometimes exceed 212° F (100° C).

If the coolant level drops too low, the following message appears on the SID:



Coolant level low. Refill.

The properties of the coolant are retained for the entire service life of the car. Therefore, it is not necessary to change the coolant.

The coolant contains 45 % antifreeze and anti-corrosion fluid. This ratio gives the best cooling effect. Lower concentrations should be avoided, in view of the corrosion risk.

Coolants of a different brand could damage the engine or cooling system. We therefore recommend strict use of coolants that have been approved by Saab.


NOTICE

If the cooling system needs topping up, mix the antifreeze with the appropriate quantity of drinking water or distilled water before adding it to the system.

If undiluted antifreeze is added, the engine could still freeze and be damaged. This is because the antifreeze will not mix properly with the coolant before the thermostat has opened to allow full circulation.

Note

If incorrect coolant is used or added, the life-time properties will be affected. Even if the coolant is flushed from the system and replaced with life-time coolant, life-time properties are no longer retained and the coolant must then be drained and replaced at regular intervals.




Coolant expansion tank, 4-cyl engine

4-cyl engine: The expansion tank is transparent to facilitate checking the coolant level.

When the engine is cold, the coolant shall lie on or just above the KALT/COLD mark on the expansion tank (boundary between the upper and lower sections of the tank, see illustration).

Top up with a mixture of equal parts of Saab-approved concentrated coolant and clean water. We recommend that you contact an authorized Saab dealer.


If the expansion tank is empty when coolant is added, run the engine until warm so that the thermostat opens. Top up the tank again, as necessary.



Coolant expansion tank, V6 engine

V6 engine: The expansion tank is not transparent. The cap must be unscrewed so that the coolant level can be checked. When the cap is screwed off there are two level markings, HOT and COLD.

When the engine is cold, the coolant shall lie on or just above the COLD mark in the expansion tank.



Level markings, V6 engine

- 1 HOT
- 2 COLD

212 Car care

Brake/clutch fluid and brake pads

WARNING

Brake fluid deteriorates as it becomes old. Because it is hygroscopic, it absorbs water from the air and, in time, could allow vapor to form in the brake system, thus reducing its performance. It is therefore important that brake fluid be changed regularly, as specified in the service program.

Checking

Brake fluid should be changed according to the service program. Refer to the Warranty and Service Book.

The brake and clutch fluid reservoir is transparent to facilitate checking of the fluid level.

The fluid level should lie between the MAX and MIN marks.

If the level drops too low, the following message appears on the SID:


 **Brake fluid level low.
Make a safe stop.**

Top up as necessary with **DOT 4** brake fluid. **Do not** use DOT 5 fluid.

Use only new brake fluid from a sealed container.

The brake fluid level will fall somewhat as the brake pads wear. The MAX level in the reservoir corresponds to the amount of brake fluid required with new brake pads. If the fall in fluid level is moderate, due to normal brake pad wear, topping up is not necessary.

If the brake fluid should require changing, this must be carried out at a Saab dealer. We recommend that you contact a Saab dealer.



Brake fluid reservoir

The foot brake and parking brake are self-adjusting.

It is not possible to detect, through abnormal pedal or parking brake lever travel, whether the brake pads are worn and need replacing. It is therefore essential that brake pads be checked regularly, as specified in the service program.

NOTICE

Avoid spilling brake fluid onto paintwork, since it can cause the paint to bubble and lift. If any brake fluid is spilled, the area should be flushed with large quantities of water as quickly as possible.

Brake pads should only be changed at a workshop. We recommend that you contact a Saab dealer.

Power steering

⚠ WARNING

Power steering fluid on hot engine components constitutes a fire risk.


Check the level of the power steering fluid in the reservoir regularly, in accordance with the service program.

The wheels should point directly forwards during this check.


Clean round the cap before unscrewing it. Wipe the dipstick. To check the level, screw down the cap completely and then remove it again.

The oil level should lie between the MAX and MIN marks when the oil temperature is about 68°F (+20°C). If the oil is colder, the level will be lower, and at a higher temperatures the level will be higher.

Top up with CHF 11S or CHF 202 power steering fluid.



Power steering fluid reservoir, 4-cyl engine



Power steering fluid reservoir, V6 engine

214 Car care

Battery**⚠ WARNING**

- When working on the battery, highly explosive gas can build up. A spark could ignite this gas that collects around the battery. Therefore, always avoid sparks and open flames in the vicinity of the battery.
- The battery contains corrosive sulfuric acid. Always wear a face mask or goggles when working on the battery.
- If battery acid gets into the eyes or splashes onto skin or clothing, wash the affected area liberally with water. If acid gets into the eyes or a large quantity makes contact with the skin, seek medical help.
- Battery posts, terminals and related accessories contain lead and lead compounds. Wash your hands after handling

NOTICE

A discharged battery can freeze and fracture. Batteries should therefore always be stored away from sub-zero temperatures.


The battery is maintenance free.

If frequent short journeys are made, the battery may need extra charging. This can be done with a battery charger or by taking the car for a long run.

If the battery is not being charged while the engine is running, the following message will appear on the SID:

**! Battery not charging.
Make a safe stop.**


Check the drive belt (see page 215). If the belt is damaged, the engine may overheat, the battery may not be charged and the A/C compressor may not work.



Turn the two retainers a quarter turn to unlock the battery cover.

Always connect the positive (red) cable to the battery's positive (+) terminal, and the negative (black) cable to the negative (-) terminal of the battery. Always disconnect both battery leads when boost charging the battery.

A car with standard equipment specifications and a fully charged battery can be left for up to 40 days and still have a sufficient charge for starting. If extra equipment is fitted, such as a mobile phone, the charge may only be sufficient for about 15 days.



Battery bracket

Drive belt

WARNING

- Keep hands and clothing clear of drive belts when engine is running.
- Always stop the engine before inspecting the drive belt.
- The radiator fan is electric and can start **even** when the engine is switched off.

NOTICE

Serious damage can be done to the car's electrical system if an alternator lead is disconnected while the engine is running.

NOTICE

- If boost charging never use anything but a 12-volt charger, see page 197.
- **Do not connect the battery terminals, + and –, incorrectly.**
- Serious damage can occur to the car's electrical system if a battery or alternator lead is disconnected while the engine is running.
- Exercise special care when removing and fitting the positive (+) cable so as not to damage the battery disconnect switch.

The alternator is situated on the right-hand side of the engine. It is driven by a poly-V-belt from the crankshaft pulley.

A slipping or broken poly-V-belt can result in:

- No charge to the battery
- No A/C compressor function.

The belt tension is critical and is adjusted automatically by the belt tensioner.

216 Car care


Wipers and washers

Wiper blades


Check and clean all wiper blades regularly.

If poor wiper performance is experienced, clean the windshield with washer fluid. This is particularly important if the car has been through an automatic car wash, as these sometimes leave a wax coating on the windshield.

If wiper performance is still unsatisfactory, fit new blades.



Change of wiper blades, windshield



Change of wiper blades, rear window, SportCombi

Windshield

- 1 Press in the two catches (1) together.
- 2 Hold the wiper arm and move the wiper blade out and diagonally up.


Fitting the wiper blade

- 1 Align the wiper arm's guide lug in the blade's corresponding slot.
- 2 Move the blade in towards the wiper arm until the two catches grip the blade. Check that the blade is fitted firmly.

Rear window, SportCombi

- 1 Detach the blade from the arm by pressing on the mounting for the blade from below.
- 2 Fit the new blade by pressing the shaft of the blade into the arm's mounting.

The washer jet, which is located next to the high-mounted brake light, is not adjustable.



Washer fluid reservoir

The reservoir capacity is approx. 6 qts. (5.8 liters).


When the washer fluid level drops below 1 quart (1 liter), the headlight washers (if equipped) are deactivated. This is in order to prioritize the windshield. The following message is displayed on the SID:



**Washer fluid level low.
Refill.**

Headlight washers are only available on certain markets.

Fill with a mixture of washer fluid and water as recommended by the table on the packaging to reduce the risk of freezing and to ensure effective cleaning (see also page 104).



Washer jets

The washer jets, which are adjustable, can be cleaned with a pin if necessary.

WARNING

Take care not to spill washer fluid concentrate onto hot surfaces. Washer fluid concentrate can contain flammable ingredients such as alcohol.

218 Car care

Changing bulbs

WARNING

Before changing a bulb in the engine bay, switch off the engine to avoid the danger of fingers and hands being injured by moving parts.

The radiator fan can cut in even when the engine is switched off.

NOTICE

Switch off the ignition before changing a bulb, to avoid possible short-circuiting.

Auto checking of lights

The bulbs that are most important from the point of view of traffic safety are monitored by the car's electrical system. If one of these bulbs should fail, a message will be displayed on the SID.

Example of SID message:



Left low beam failure.

The following bulbs are not checked: parking lights, front fog lights, reversing lights, license plate lighting, side marker lights and side direction indicators.

SportCombi

The tail lights and brake lights consist of LEDs. If approx. 3/4 of the LEDs on one side are broken then this is indicated in the SID.

If a stop light bulb fails

SportSedan: If a stop light bulb fails, the adjacent taillight will act as a stop light to ensure traffic safety. Change the broken bulb when possible.

All rear light bulbs are of the same type and rated 21 W, with the exception of the license plate lighting which is rated 5 W.

Wrong bulb fitted

If a low or main beam bulb of too high a rating is fitted, a bulb failure message will be shown on the SID (a too high wattage bulb can damage the reflector).

If the following message is displayed but the bulb shines, it is most likely that an incorrect bulb has been fitted.



Right high beam failure.

Note

When changing bulbs, fit the same type of bulb (e.g. Long-Life) as that removed.

Headlight aiming, page 274.

Xenon headlights *



WARNING

Xenon headlights are high tension. All work on xenon headlights, including changing bulbs, must be carried out by dealer personnel.

Xenon headlights produce roughly two times as much light as halogen bulbs and have a significantly longer service life.


The lamp units consist of a gas discharge lamp containing xenon. When the lights are switched on a very high voltage activates the xenon gas. The lamps soon reach full intensity.

Cars with xenon headlights have automatic levelling. The levelling system is comprised of two sensors, one on the front suspension and one on the rear suspension, and a control unit by the engine bay fuse box. Headlight alignment is adjusted automatically to the car's load to prevent dazzling drivers in oncoming traffic.

If a fault is detected in the system, the following message will be displayed on the SID:




Headlight levelling malfunction.



We recommend you to contact a Saab dealer to have a xenon headlight changed

220 Car care



Retainers on the battery cover


Low beam, halogen

Left-hand side

- 1 Lift aside the hose * running along the side of the battery cover.
- 2 Release the two retainers (a quarter of a turn counterclockwise) in the leading edge of the cover and remove the cover.
- 3 Pull up the washer fluid filler pipe.
- 4 Remove the air pipe from the front edge of the battery box.
- 5 Pull up the fuse panel * in front of the battery, see page 239.

Both sides

- 1 Remove the cover from the rear of the headlight.
- 2 Twist the bulb holder counterclockwise and withdraw the holder from the reflector.



Changing the low beam bulb


- 3 Change the bulb without touching the glass with your fingers. Insert the bulb holder into the reflector and twist it clockwise until it locks.
- 4 Refit the cover over the rear of the headlight.

Left-hand side

- 5 Refit the air pipe to the front of the battery box.
- 6 Refit the washer fluid filler pipe.
- 7 Refit the battery cover.
- 8 Refit the hose * running along the side of the battery cover.

NOTICE

Do not fit bulbs with a higher rating than 55 W as this could damage the headlight reflector. Furthermore, the car's wiring is not designed to cope with higher wattages.



Retainers on the battery cover


High beam, halogen

Left-hand side

- 1 Lift aside the hose * running along the side of the battery cover.
- 2 Release the two retainers (a quarter of a turn counterclockwise) in the leading edge of the cover and remove the cover.
- 3 Pull up the washer fluid filler pipe.
- 4 Remove the air pipe from the front edge of the battery box.
- 5 Pull up the fuse panel * in front of the battery, see page 239.

Both sides

- 1 Remove the cover from the rear of the headlight.
- 2 Twist the bulb holder counterclockwise and withdraw the holder from the reflector.
- 3 Change the bulb without touching the glass with your fingers. Insert the bulb holder into the reflector and twist it clockwise until it locks.



Changing the high beam bulb

- 4 Refit the cover over the rear of the headlight.


Left-hand side

- 5 Refit the air pipe to the front of the battery box.
- 6 Refit the washer fluid filler pipe.
- 7 Refit the battery cover.
- 8 Refit the hose * running along the side of the battery cover.

NOTICE

Do not fit bulbs with a higher rating than 55 W as this could damage the headlight reflector. Furthermore, the car's wiring is not designed to cope with higher wattages.

222 Car care



Retainers on the battery cover


Daytime Running Light

Left-hand side

- 1 Lift aside the hose * running along the side of the battery cover.
- 2 Release the two retainers (a quarter of a turn counterclockwise) in the leading edge of the cover and remove the cover.
- 3 Pull up the washer fluid filler pipe.
- 4 Remove the air pipe from the front edge of the battery box.
- 5 Pull up the fuse panel * in front of the battery, see page 239.

Both sides

- 1 Remove the cover from the rear of the headlight.
- 2 Twist the bulb holder counterclockwise and withdraw the holder from the reflector.
- 3 Change the bulb without touching the glass with your fingers. Insert the bulb holder into the reflector and twist it clockwise until






it locks. To facilitate fitting, look in through the headlight lens when fitting the bulb. Check that the new bulb is firmly seated.

- 4 Refit the cover over the rear of the headlight.

Left-hand side

- 5 Refit the air pipe to the front of the battery box.
- 6 Refit the washer fluid filler pipe.
- 7 Refit the battery cover.
- 8 Refit the hose * running along the side of the battery cover.



Front turn signal bulbs

Left-hand side

- 1 Lift aside the hose * running along the side of the battery cover.
- 2 Release the two retainers on the battery cover and remove the cover.
- 3 Pull up the washer fluid filler pipe.
- 4 Remove the air pipe from the front edge of the battery box.

Both sides

- 1 The bulb holder has a bayonet fitting. Turn the bulb holder counterclockwise and withdraw it.
- 2 Hold the bulb holder with a firm grip. Use a screwdriver to pry the bulb from the holder.

Change of front turn signal bulb

- 3 Fit the new bulb.
- 4 To facilitate fitting, look in through the headlight lens when fitting the bulb. Check that the new bulb is firmly seated.


Left-hand side

- 5 Refit the air pipe to the front edge of the battery box.
- 6 Refit the washer fluid filler pipe.
- 7 Refit the battery cover and hose *.

Side-mounted turn signal bulbs

- 1 Slide the lamp fitting forward so that its rear end can be pulled out.
- 2 Turn the bulb holder counterclockwise and withdraw it from the lamp fitting. Change the bulb.
- 3 To fit, engage the two catches on the rear edge of the lamp fitting with the edge of the opening. Then press in the front edge of the lamp fitting so that the groove in the spring engages the plastic edge.

224 Car care



- 1 Undo one screw in the wheel housing. Lower the air shield.
- 2 Remove the protective cover. Release the two spring clips securing the bulb.
- 3 Unplug the connector.
- 4 Change the bulb. Try not to touch the glass part of the bulb with your fingers.

The height of the beam can be adjusted using a screwdriver inserted through the hole in the lower grille adjacent to the lens.


Side marker lights and parking lights

Side marker lights and parking lights consists of LEDs. We recommend that you contact a Saab dealer if they need changing.

Front fog lights *

WARNING


- **Never** crawl under a car that is supported only by a jack. Always use axle stands.
- Refer to the information on jacks on pages 258 and 259.



Taillights, SportSedan


- 1 Turn signals
- 2 Taillights/stop lights
- 3 Reversing lights
- 4 Rear fog light (left-hand side)
- 5 High-mounted stop light

SportSedan: If a stop light bulb fails, the adjacent taillight will act as a stop light to ensure traffic safety. Change the broken bulb when possible.




Taillights, Convertible

- 1 Turn signals
- 2 Taillights/stop lights
- 3 Reversing lights
- 4 Rear fog light (left-hand side)
- 5 High-mounted stop light



Taillights, SportCombi


- 1 Turn signals
- 2 Taillights/stop lights
- 3 Reversing lights
- 4 Rear fog light (left-hand side)
- 5 High-mounted stop light



Stop lights, taillights and turn signal bulbs, SportSedan


- 1 Lower the cover in the trim behind the lights.
Right-hand side: Unlock the plastic rivet by depressing the center no more than 0.1 in. (3 mm). Take hold of the collar of the rivet and pull it out. Refer also to page 226.
- 2 Lift the plastic lug on the lamp housing that secures the bulb holder.
- 3 Carefully remove the entire bulb holder unit from the lamp housing. Change the bulb.
- 4 Refit the bulb holder. Press the bulb holder home so that the plastic lug snaps into place.

226 Car care




Stop lights, taillights and turn signal bulbs, Convertible

- 1 Remove the cover.
- 2 Carefully remove the bulb holder with the broken bulb. The bulb holder has a bayonet fitting.
- 3 Change the bulb.
- 4 Refit the bulb holder and cover.



Turn signals, reversing light and rear fog light, SportCombi

- 1 Remove the cover.
- 2 Remove the bulb holder with the broken bulb. The bulb holder has a bayonet fitting.
- 3 Fit the new bulb.
- 4 Refit the bulb holder and the cover.




Reversing lights and rear fog light, SportSedan

Removing the trunk lid trim

- 1 Remove the two screws securing the grab handle to the inside of the trunk lid.
- 2 Unlock the plastic rivets by pressing in the center of each rivet. Pull out the rivets by taking hold of the rivet's collar.

You can use the button on the handle of the screwdriver supplied with the car to unlock the rivets.




Changing bulbs

- 1 Press down the plastic lug on the bulb holder.
- 2 Carefully remove the entire bulb holder unit from the lamp housing. Change the bulb.
- 3 Refit the bulb holder. Press the lug so that it snaps into place.

To refit the trunk lid trim

- 1 Withdraw the center of the rivets.
- 2 Fit the trim in place on the trunk lid.
- 3 Fit the rivets. Lock the rivets in place by pressing the center buttons in until flush with the collar.




Reversing lights and rear fog lights, Convertible

Removing the trunk lid trim

- 1 Unlock the plastic rivets by pressing in the center of each rivet no more than 3 mm. Pull out the rivets by taking hold of the rivet's collar.

You can use the button on the handle of the screwdriver supplied with the car to unlock the rivets.




Changing bulbs

- 1 Carefully remove the bulb holder with the broken bulb. The bulb holder has a bayonet fitting.
- 2 Fit the new bulb.
- 3 Refit the bulb holder.

To refit the trunk lid trim


- 1 Withdraw the center of the rivets.
- 2 Fit the trim in place on the trunk lid.
- 3 Fit the rivets. Lock the rivets in place by pressing the center buttons in until flush with the collar.

228 Car care




Dome light, front, SportSedan and SportCombi

- 1 Pull down the rear edge of the lens.
- 2 Fit the new bulb.
- 3 Insert the guide lugs on the front edge of the lens and press the lens home.




Dome light, rear, SportSedan and SportCombi

- 1 Remove the entire overhead panel: ease out the trailing end first, and then both sides of the front edge.
- 2 Fit the new bulb.




Dome light, Convertible

- 1 Pull down the rear edge of the light fitting.
- 2 If the center bulb needs replacing, open the hatch over the bulbs. Pull the bulb out of the bulb holder. If one of the outer bulbs needs replacing, turn the light fitting round. Change the bulb from the reverse of the lighting fitting. The bulb has a bayonet fitting.
- 3 Position the front edge of the light fitting and press the fitting up towards the windscreen rail.




Hatch opened for replacement of center bulb



License plate lighting


- 1 Undo the two screws and remove the lens.
- 2 Fit the new bulb.
- 3 Make sure the seal on the lens is correctly seated.
- 4 Refit the lens and tighten the two screws.



Glove box lighting *

- 1 Remove the lamp housing using a short screwdriver.
- 2 Fit the new bulb.
- 3 Insert the connector side first when refitting the lamp.

Reverse side of the light fitting. The arrows mark the outer bulbs





230 Car care

Trunk lighting, SportSedan


The lamp fitting is located under the parcel shelf.

- 1 Remove the lamp fitting by pulling down one end.
- 2 The baffle must be removed before the bulb can be replaced. Point the baffle's tab up with a small screwdriver.
- 3 Fit the new bulb.
- 4 Refit the baffle by first fitting its tab in its bracket between the contact plates. Hold it in place and move the other side down.
- 5 Insert the connector side first when refitting the lamp.




Trunk lighting, Convertible

- 1 Remove the lamp in the rear end first.
- 2 Change the bulb.
- 3 Insert the connector side first when refitting the lamp.



Trunk lighting, SportCombi

- 1 Pull the lamp housing forward slightly and lift it out at the rear. Use a thin and wide tool.
- 2 Fit the new bulb. The bulb is secured in the holder.
- 3 Start by inserting in the front edge of the lamp housing and then pressing in the rear edge.






Courtesy/floor lighting *

- 1 Release one edge of the lamp fitting using a screwdriver.
- 2 Fit the new bulb.
- 3 Insert the connector side first when refitting the lamp.

Other bulbs

If any other bulbs need changing, we recommend that you visit a Saab dealer.

232 Car care

1 	7 
2 	8 
3 	9 
4 	10 
5 	11 
6 	12 

Bulb table

No.	Designation	Watt- age	
1	H7	55	High beam (cars with halogen light)
2	H8	35	Front fog lights *
3	H11	55	Low beam (cars with halogen light)
4	3457 A/AK (yellow)	30 cp	Direction indicator, front
5	P21W	21	Reversing lights
6	PR21W (red)	21	Rear fog light; taillights (SportSedan); brake lights (SportSedan)
7	PY21W (yellow)	21	Direction indicator, rear
8	4157 K	32 cp	Daytime Running Light (cars with xenon light)
9	R10W	10	Rear dome lighting; courtesy lighting *; glove box lighting; trunk lighting, Convertible
10	R5W	5	License plate lighting; trunk lighting, SportSedan
11	T4W	4	Reading light, rear
12	WY5W/W5W	5	Side-mounted turn signal (yellow); front dome lighting

NOTICE

Only fit lamps of the specified rating. Lamps of the wrong wattage could damage the wiring harness and electronics.


Fuses

WARNING

To avoid the risk of short-circuiting and/or fire breaking out in the electrical system, the following should be heeded:

- We recommend that you always consult an Saab dealer before modifying or adding any electrical equipment. Failure to do so can result in the electrical system being damaged.
- Never replace a fuse with one having a higher rating than specified (see page 235). The color of the fuse indicates its amperage.
- If the same fuse blows repeatedly, have the electrical system checked by a workshop. We recommend that you contact a Saab dealer.
- If a MAXI fuse blows, it means that there is a major fault in the electrical system. Have the car checked without delay. We recommend that you contact a Saab dealer.


The fuses are housed in three fuse panels: one behind a hatch on the left-hand end of the dash, one in the engine bay (additional small unit in front of battery) and one on the left-hand side of the trunk. There is space for spare fuses in the hatch on the left-hand end of the dash.



Sound fuse / Blown fuse

To check if a fuse has blown, first remove it from the panel. If the filament is broken, the fuse has blown.

234 Car care



Fuse panel in end of dash

Some fuses and relays may be fitted but not connected to the car's electrical system.


MAXI fuses

The car also has a number of large fuses known as MAXI fuses. These are designed to protect the car's electrical system from being damaged. Each MAXI fuse protects a number of electrical circuits and functions and therefore has a higher rating (amperage) than the standard fuses. No spare MAXI fuses are supplied with the car.

NOTICE

If a MAXI fuse blows, there is a major fault in the electrical system. Have the car checked. We recommend that you contact a Saab dealer.

A special tool for removing fuses is provided on the hatch on the left-hand end of the dash. Simply push the tool onto the fuse, squeeze and remove the fuse.




Fuse panel in end of fascia

No.	Amp.	Function
1	15	Steering wheel lock
2	5	Steering column unit; ignition switch
3	10	Hands-free *
4	10	Main instrument unit; automatic climate control (ACC) *
5	7.5	Control module in front doors; Park Brake Shift Lock (automatic transmission)
6	7.5	Brake light switch
7	20	Dash fuse panel; fuel filler door
8	30	Control module in passenger front door
9	10	Dash fuse panel
10	30	Trailer socket *; electrical socket in storage compartment between seats *
11	10	Data link connection (diagnostics)

12	15	Interior lighting incl. glove box
13	10	Accessories
14	20	Amplifier 2, Sound System 3
15	30	Control module in driver's door
16	5	Passenger Sensing System
17	-	-
18	-	-
19	-	-
20	7.5	Headlight levelling switch *
21	7.5	Hands-free *; brake light switch; clutch pedal switch
22	30	Cigarette lighter *
23	40	Cabin fan
24	7.5	Airbag control module
25	-	-
26	5	Yaw sensor (cars with ESP®)
27	-	-

236 Car care




Trunk fuse panel, SportSedan

Trunk fuse panel, left-hand side


No.	Amp.	Function
1-5	MAXI	-
6	30	Control module in left rear door
7	30	Control module in right rear door
8	20	Trailer *
9	-	-
10	30	Left-hand brake light; rear right turn signal; right tail-light; right reversing light; high-mounted brake light; trailer lights
11	10	XWD
12	-	-
13	-	-
14	-	-
15	15	Seat heating, left seat *
16	15	Seat heating, right seat *
17	7.5	Auto dimming rear view mirror *; rain sensor *
18	15	Moonroof *
19	-	-
20	7.5	XM-radio *; TMC-tuner *
21	7.5	Saab Parking Assistance (SPA) *; control module in rear doors; dome light (Convertible)
22	30	Radio *; navigation *
23	7,5	TPMS (automatic tire pressure monitoring system)
24	10	Movement sensor *; tilt sensor *; dome light (Convertible)
25	30	Electrically adjustable driver's seat with memory *

30	Right-hand stop light; rear left turn signal; left taillight; rear fog light; left reversing light; license plate lighting; trunk lighting; trailer lights
26	
10	Convertible: Lumbar support, electrically adjustable front seat *
27	
15	Telematics *
28	
29	- -



Trunk fuse panel, Convertible

238 Car care




Fuse panel in engine bay

No.	Amp.	Function
1	-	-
2	10	Engine control module; automatic transmission control module *
3	20	Horn
4	10	Engine control module; battery disconnect switch *
5	-	-
6	10	Selector lever, automatic transmission *; clutch pedal switch
7	10	Xenon Cornering Headlights, left *
8	5	Relay for vacuum pump (brake system) *
9	-	-
10	-	-
11	-	-
12	10	Washer fluid pump, rear window *

13	-	-
14	-	-
15	30	Washer fluid pump, headlights *
16	30	Front right parking light; front right turn signal; left and right side turn signal; right high beam; left low beam; front left fog light *
17	30	Windshield wiper motor, low speed
18	30	Windshield wiper motor, high speed
19	20	Parking heater; auxiliary heater *
20	10	Headlight levelling * xenon cornering headlights, right *
21	-	-
22	30	Washer fluid pump, windshield
23	-	-
24	20	Flash-to-pass; high beam, right and left (cars with Daytime Running Lights only)
25	20	Amplifier, sound system II *
26	30	Front left turn signal; front left parking light; front right fog light *; right low beam; left high beam
27	MAXI	
-37		

Relays

R 1	Washer fluid pump, windshield
R 2	-
R 3	-
R 4	-
R 5	Flash-to-pass
R 6	Horn
R 7	-
R 8	Starter motor
R 9	Windshield wipers ON/OFF
R10	Washer fluid pump, rear window *
R11	Ignition +15
R12	Windshield wipers, high/low speed
R13	-
R14	Washer fluid pump, headlights *
R15	-
R16	-



Fuse panel in front of battery *

No.	Amp.	Function
1	-	Air pump, secondary air *
2	20	Fuel pump; preheated oxygen sensors (lambda probe)
3	10	A/C compressor
4	30	Main relay

Relays

1	-
2	A/C-compressor
3	Preheated oxygen sensors (lambda probe)
4	Main relay, engine (ECM/EVAP/injectors)

240 Car care

Tires

Your new vehicle comes with high-quality tires made by a leading tire manufacturer. If you ever have questions about your tire warranty and where to obtain service, see your Saab Warranty and Service Record Booklet for details.

WARNING

Poor maintained and improperly used tires are dangerous.

- Overloading your tires can cause overheating as a result of too much friction. You could have a blow-out and a serious accident. See “Loading Your Vehicle” on page 250.
- Underinflated tires pose the same danger as overloaded tires. The resulting accident could cause serious injury. Check all tires frequently to maintain the recommended pressure. Tire pressure should be checked when your tires are cold.
- Overinflated tires are more likely to be cut, punctured or broken by a sudden impact – such as when you hit a pothole. Keep tires at the recommended pressure.
- Worn, old tires can cause accidents. If your tread is badly worn, or if your tires have been damaged, replace them.

Inflation - Tire Pressure

The Tire-Loading Information label shows the correct inflation pressures for your tires when they're cold. “Cold” means your vehicle has been sitting for at least three hours or driven no more than 1 mile (1.6 km).

Notice: Don't let anyone tell you that underinflation or overinflation is all right. It's not. If your tires don't have enough air (underinflation), you can get the following:

- Too much flexing
- Too much heat
- Tire overloading
- Bad wear
- Bad handling
- Bad fuel economy.

If your tires have too much air (overinflation), you can get the following:

- Unusual wear
- Bad handling
- Rough ride
- Needless damage from road hazards.

Adjust the tire pressure to match the current load and speed of the car (see page 291). The stated tire pressures apply to cold tires, i.e. tires that are the same temperature as the outside air temperature. Tire pressure increases as the tires become warm (e.g. during highway driving) by approximately 4 psi (28 kPa). When the temperature of the tires changes by 50°F (10°C), the tire pressure will change 2 psi (14 kPa).

Never reduce the pressure of a hot tire. If the tires are hot when you check them, only increase the pressure, if necessary.

High speed operation

WARNING

Driving at high speeds, 100 mph (160 km/h) or higher, puts an additional strain on tires.

Sustained high-speed driving causes excessive heat build up and can cause sudden tire failure. You could have a crash and you or others could be killed. Some high-speed rated tires require inflation pressure adjustment for high speed operation. When speed limits and road conditions are such that a vehicle can be driven at high speeds, make sure the tires are rated for high speed operation, in excellent condition, and set to the correct cold tire inflation pressure for the vehicle load.

If you'll be driving at high speeds, speeds of 100 mph (160 km/h) or higher, where it is legal, set the cold inflation pressure to the maximum inflation pressure shown on the tire sidewall, or to 35 psi (244 kPa), whichever is lower. See the example below. When you end this high-speed driving, return to the cold inflation pressure shown on the Tire and Loading Information label. See on page 250.

Example

You'll find maximum load and inflation pressure molded on the tire's sidewall, in small letters near the rim flange. It will read something like this: Maximum load 690 kg (1521 lbs) 300 kPa (44 psi) Max. Press

For this example, you would set the inflation pressure for high-speed driving at 35 psi (244 kPa).

When to check

Check your tires once a month or more.

Don't forget your compact spare tire. It should be at 60 psi (420 kPa).

How to Check

Use a good quality pocket-type gage to check tire pressure. You can't tell if your tires are properly inflated simply by looking at them. Radial tires may look properly inflated even when they're underinflated.

Be sure to put the valve caps back on the valve stems. They help prevent leaks by keeping out dirt and moisture.

Tire Inspection and Rotation

Tires should be rotated every 10,000 miles (16 000 km).

Any time you notice unusual wear, rotate your tires as soon as possible and check wheel alignment. Also check for damaged tires or wheels. See "When It Is Time for New Tires" on page 242 and "Wheel Replacement" on page 246 for more information.

The purpose of regular rotation is to achieve more uniform wear for all tires on the vehicle. The first rotation is the most important.

When rotating your tires, always use the correct rotation pattern. Left front tire to left rear. Left rear tire to right front. Right front to right rear. Right rear to left front.

Don't include the compact spare tire in your tire rotation.

After the tires have been rotated, adjust the front and rear inflation pressures as shown on the Tire-Loading Information label. Make

242 Car care

certain that all wheel nuts are properly tightened. See page 261.

WARNING

Rust or dirt on a wheel, or on the parts to which it is fastened, can make wheel nuts become loose after a time. The wheel could come off and cause an accident. When you change a wheel, remove any rust or dirt from places where the wheel attaches to the vehicle. In an emergency, you can use a cloth or a paper towel to do this; but be sure to use a scraper or wire brush later, if you need to, to get all the rust or dirt off. See "Changing a tire" on page 258.

Flat spotting

All tires get hot, especially on long journeys or when the car is driven hard. After the car has been parked with hot tires and the tires have cooled down, a flat spot can form in the tire, where it is in contact with the ground. The same can occur if the car has not been moved for a long time.

Flat spots can cause vibration that can be felt through the steering wheel, similar to that experienced when the wheels need balancing.


Flat spots of this type disappear once the tires get hot again, usually after 10–15 miles (20–25 km) of driving at cruising speed. If the outdoor temperature is low it takes a longer distance.

When It Is Time for New Tires

One way to tell when it's time for new tires is to check the treadwear indicators, which will appear when your tires have only 1/16 inch (1.6 mm) or less of tread remaining.

You need a new tire if any of the following statements are true:

- You can see the indicators at three or more places around the tire.
- You can see cord or fabric showing through the tire's rubber.
- The tread or sidewall is cracked, cut or snagged deep enough to show cord or fabric.
- The tire has a bump, bulge or split.
- The tire has a puncture, cut or other damage that can't be repaired well because of the size or location of the damage.



Treadwear indicator

Treadwear indicators

The tires incorporate wear indicators in the form of smooth, treadless strips across the width, which become visible when only 2/32" (1.6 mm) of tread remains. As soon as the indicators become visible, new tires should be fitted without delay.

Make sure you are familiar with the legal limit for minimum tread depth in your country and also any regulations governing the use of winter (snow) tires.

Buying New Tires

To find out what kind and size of tires you need, look at the Tire-Loading Information label.

Before changing to wheels/tires of another size, we recommend that you contact an authorized Saab workshop regarding acceptable options. See also page 288

Wheels/tires combinations that are not approved by Saab can negatively affect the car's directional stability, steering and braking in both wet and dry conditions.

The wheels and tires have been carefully matched to the characteristics of the car and play a key role in its outstanding road holding and handling.

Do not take it for granted that a wheel/tire combination will work in the best possible way, just because it can be fitted to the car.

To ensure that the speedometer is as accurate as possible it should be reprogrammed if wheels of a different dimension are fitted. Contact a Saab dealer.

Because of front wheel drive, the front tires tend to wear faster than the rear ones. New tires should always be fitted in pairs, so that tires on the same axle have the same amount of tread.

Store wheels lying flat or hanging – **never** standing upright.

244 Car care

NOTICE

Wide wheels and tires with side walls that are too low can:

- Be damaged in potholes, etc.
- Cause springs, shock absorbers and wheel bearings and body mountings to be overloaded
- Affect the function of the ESP®.

The speed and load limits of the tires must not be exceeded; see page 249.

Wheels larger than 18" must not be fitted on the Saab 9-3 for reasons above. The permissible offset is 1.61 inch (41 mm).

⚠ WARNING

Mixing tires could cause you to lose control while driving. If you mix tires of different sizes or types (radial and bias-belted tires), the vehicle may not handle properly, and you could have a crash. Using tires of different sizes may also cause damage to your vehicle. Be sure to use the same size and type tires on all wheels. It's all right to drive with your compact spare temporarily, it was developed for use on your vehicle. See "Compact spare" on page 256.

⚠ WARNING

If you use bias-ply tires on your vehicle, the wheel rim flanges could develop cracks after many miles of driving. A tire and/or wheel could fail suddenly, causing a crash. Use only radial-ply tires with the wheels on your vehicle.

Uniform Tire Quality Grading

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width. For example:

Treadwear 200 Traction AA Temperature A

The following information relates to the system developed by the United States National Highway Traffic Safety Administration, which grades tires by treadwear, traction and temperature performance. (This applies only to vehicles sold in the United States.) The grades are molded on the sidewalls of most passenger car tires. The Uniform Tire Quality Grading system does not apply to deep tread, winter-type snow tires, space-saver or temporary use spare tires, tires with nominal rim diameters of 10 to 12 inches (25 to 30 cm), or to some limited-production tires.

While the tires available on General Motors passenger cars and light trucks may vary with respect to these grades, they must also conform to federal safety requirements and additional General Motors Tire Performance Criteria (TPC) standards.

Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. For example, a tire graded 150 would wear one and a half (1.5) times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

Traction – AA, A, B, C

The traction grades, from highest to lowest, are AA, A, B, and C. Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance. Warning: The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

Temperature – A, B, C

The temperature grades are A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

Warning: The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

Wheel Alignment and Tire Balance

The wheels on your vehicle were aligned and balanced carefully at the factory to give you the longest tire life and best overall performance.

Scheduled wheel alignment and wheel balancing are not needed. However, if you notice unusual tire wear or your vehicle pulling one way or the other, the alignment may need to be reset. If you notice your vehicle vibrating when driving on a smooth road, your wheels may need to be rebalanced.

246 Car care

Wheel Replacement

Replace any wheel that is bent, cracked or badly rusted or corroded. If wheel nuts keep coming loose, the wheel, wheel bolts and wheel nuts should be replaced. If the wheel leaks air, replace it (except some aluminum wheels, which can sometimes be repaired). See your dealer if any of these conditions exist.

Your dealer will know the kind of wheel you need.

Each new wheel should have the same load-carrying capacity, diameter, width, offset and be mounted the same way as the one it replaces.

If you need to replace any of your wheels, wheel bolts or wheel nuts, replace them only with new Saab original equipment parts. This way, you will be sure to have the right wheel, wheel bolts and wheel nuts for your vehicle.

WARNING

Using the wrong replacement wheels, wheel bolts or wheel nuts on your vehicle can be dangerous. It could affect the braking and handling of your vehicle, make your tires lose air and make you lose control. You could have a collision in which you or others could be injured. Always use the correct wheel, wheel bolts and wheel nuts for replacement.

Notice: The wrong wheel can also cause problems with bearing life, brake cooling, speedometer or odometer calibration, headlamp aim, bumper height, vehicle ground clearance and tire or tire chain clearance to the body and chassis.

See “Changing a tire” on page 258.

WARNING

When fitting just **one** new pair of tires, these should be fitted to the rear wheels, as these are more critical to the directional stability of the car (e.g. on braking or in a skid). The existing rear wheels should therefore be moved to the front.

Used Replacement Wheels

WARNING

Putting a used wheel on your vehicle is dangerous. You can't know how it's been used or how far it's been driven. It could fail suddenly and cause a crash. If you have to replace a wheel, use a new GM original equipment wheel.

Tire Chains

WARNING

If your vehicle has 235/45 R17 size tires, don't use tire chains, there's not enough clearance.

Tire chains used on a vehicle without the proper amount of clearance can cause damage to the brakes, suspension or other vehicle parts. The area damaged by the tire chains could cause you to lose control of your vehicle and you or others may be injured in a crash.

Use another type of traction device only if its manufacturer recommends it for use on your vehicle and tire size combination and road conditions. Follow that manufacturer's instructions. To help avoid damage to your vehicle, drive slowly, readjust or remove the device if it's contacting your vehicle, and don't spin your wheels.

If you do find traction devices that will fit, install them on the front tires.

Notice: If your vehicle does not have 235/45R17 size tires, use tire chains only where legal and only when you must. Contact your Saab dealer regarding suitable snow chains. Install them on the front tires and tighten them as tightly as possible with the ends securely fastened. Drive slowly and follow the chain manufacturer's instructions. If you can hear the chains contacting your vehicle, stop and retighten them. If the contact continues, slow down until it stops. Driving too fast or spinning the wheels with chains on will damage your vehicle.

If a Tire Goes Flat

It's unusual for a tire to "blowout" while you're driving, especially if you maintain your tires properly. If air goes out of a tire, it's much more likely to leak out slowly. But if you should ever have a "blowout", here are a few tips about what to expect and what to do:

If a front tire fails, the flat tire will create a drag that pulls the vehicle toward that side. Take your foot off the accelerator pedal and grip the steering wheel firmly. Steer to maintain lane position, and then gently brake to a stop well out of the traffic lane.

A rear blowout, particularly on a curve, acts much like a skid and may require the same correction you'd use in a skid. In any rear blowout, remove your foot from the accelerator pedal. Get the vehicle under control by steering the way you want the vehicle to go. It may be very bumpy and noisy, but you can still steer. Gently brake to a stop – well off the road if possible.

If a tire goes flat, the next part shows how to use your jacking equipment to change a flat tire safely.

248 Car care

Tire Sidewall Labeling

Useful information about a tire is molded into it's sidewall.

Tire size: The tire size ia a combination of letters and numbers used to define a particular tire 's width, height, aspect ratio, construction type and service description.

Department of Transportation (DOT): The Department of Transportation (DOT) code indicates that the tire is in compliance with the U.S. Department of Transportation Motor Vehicle Safety standards.

Tire Identification Number (TIN): The letters and numbers following DOT code are the Tire Identification Number (TIN). The TIN shows the manufacturer and plant code, tire size, and date the tire was manufactured. The TIN is molded onto both sides of the tire.

Tire Ply Material: The type of cord and number of plies in the sidewall and under the tread.

Uniform Tire Quality Grading (UTQG):

Tire manufacturers are required to grade tires based on the performance factors: treadwear, traction and temperature resistance. For more information see "Uniform Tire Quality Grading" on page 244.

Maximum Cold Inflation Load Limit: Maximum load that can be carried and the maximum pressure needed to support that load. For information on recommended tire pressure see "Recommended lowest tire pressure, cold tires" on page 291 and "Loading Your Vehicle" on page 250.

Tire Size

The following illustration shows an example of a typical passenger car tire size.

215	/	55	R	16	93	H
a		b	c	d	e	f

- a Tire Width
- b Aspect Ratio
- c Belt Rating
- d Rim diameter
- e Load range
- f Speed rating

Tire Width: The three-digit number indicates the tire section width in millimeters from sidewall to sidewall.

Aspect ratio: A two-digit number that indicates the tire height-to-width measurements. For example, if the tire size aspect ratio is "55", as shown in item "C" of the illustration, it would mean that the tire's sidewall is 55% as high as it is wide.

Belt Rating: A letter code is used to indicate the type of ply construction in the tire. The letter "R" means radial ply construction; the letter "D" means diagonal or bias ply construction; and the letter "B" means belted-bias ply construction.

Rim Diameter: Diameter of the wheel in inches.

Load range: The load range represents the load carry capacity a tire is certified to carry.

Speed Rating: The maximum speed that a tire is certified to carry a load. Speed ratings range from "A" to "Z".

Tire markings

An example of the meaning of the different markings in a tire size is given below for a tire size of 225/45 R17 94H:

- 225 Tire section width, mm
- Aspect ratio, i.e. the section height as a percentage of the section width
- 45
- R Radial ply
- Wheel rim diameter 17 in at bead
- 17 seats
- 94 Tire load index
- H Speed rating


Tire load indices

- Tire approved for max. 1355 lbs. (615 kg)
- 91
- 93 Max. 1433 lbs. (650 kg)
- 94 Max. 1477 lbs. (670 kg)
- 95 Max. 1521 lbs. (690 kg)
- 97 Max. 1609 lbs. (730 kg)
- 98 Max. 1653 lbs. (750 kg)

Speed ratings

- Tire approved for speeds up to
- Q 100 mph (160 km/h)
- S Max. 112 mph (180 km/h)
- T Max. 118 mph (190 km/h)
- H Max. 130 mph (210 km/h)
- V Max. 149 mph (240 km/h)
- W Max. 168 mph (270 km/h)
- Y Max. 186 mph (300 km/h)

250 Car care



TIN-code

- a Manufacturer's Identification Mark
- b Tire Size
- c Tire Type Code
- d Date of Manufacture

Loading Your Vehicle

TIRE AND LOADING INFORMATION			
SEATING CAPACITY	TOTAL G	FRONT G	REAR G
The combined weight of occupants and cargo should never exceed 000 kg or 000 lbs.			
TIRE	SIZE	COLD TIRE PRESSURE	SEE OWNER'S MANUAL FOR ADDITIONAL INFORMATION
FRONT	000/00000 000	000 kPa, 00 PSI	
REAR	000/00000 000	000 kPa, 00 PSI	
SPARE	0000/00000 00	000 kPa, 00 PSI	

*This label can only be found on vehicles sold in the U.S.
Vehicles sold in Canada have the tire information label in the glove box, see page 292.*

This is an example of what your vehicle's Tire-Loading Information/Certification label might look like. It is located on the B-pillar and shows how much weight your vehicle may properly carry. The label tells you the proper size, and recommended inflation pressures for the tires on your vehicle. It also gives you important information about the number of people that can be in your vehicle and the total weight that you can carry. This weight is called the Vehicle Capacity Weight, and includes the weight of all occupants, cargo and all nonfactory-installed options.

Tire Terminology and Definitions

Air Pressure: The amount of air inside the tire pressing outward on each square inch of the tire. Air pressure is expressed in pounds per square inch (psi) or kilo pascal (kPa).

Accessory Weight: This means the combined weight of optional accessories, for example, automatic transmission, power steering, power brakes, power windows, power seats, radio and air conditioning.

Aspect Ratio: The relationship of a tire's height to its width.

Belt: A rubber coated layer of cords that is located between the plies and the tread. Cords may be made from steel or other reinforcing materials.

Bias Ply Tire: A pneumatic tire in which the ply cords that extend to the beads are laid at alternate angles substantially less than 90 degrees to the centerline of the tread.

Cold Inflation Pressure: The amount of air pressure in a tire, measured in pounds per square inch (psi) or kilo pascal (kPa), before a tire has built up heat from driving. See "Inflation - Tire Pressure" on page 240.

Curb weight: This means the weight of a motor vehicle with standard and optional equipment including the maximum capacity of fuel, oil and coolant, without passengers and cargo.

DOT Markings: A code molded into the sidewall of a tire signifying that the tire is in compliance with the U.S. Department of Transportation motor vehicle safety standards. The DOT code includes the Tire Identification Number (TIN), an alphanumeric designator which can also identify the tire manufacturer, production plant, brand and date of production.

GVWR: Gross Vehicle Weight Rating see page 285.

GAWR FRT: Gross Axle Weight Rating for the front axle, see page 285.

GAWR RR: Gross Axle Weight Rating for the rear axle, see page 285.

Intended Outboard Sidewall: The side of an asymmetrical tire that must always face outward when mounted on a vehicle.

Kilo pascal (kPa): The metric unit for air pressure. There are 6.9 kPa to one psi.

Light Truck (LT-Metric) Tire: A tire used on light duty trucks and some multipurpose passenger vehicles.

Load Index: An assigned number ranging from 1 to 279 that corresponds to the load carrying capacity of a tire.

Maximum Load rating: The load rating for a tire at the maximum permissible inflation pressure for that tire.

Maximum Loaded Vehicle Weight: The sum of curb weight; accessory weight; vehicle capacity weight; and production options weight.

Maximum Permissible Inflation Pressure: The maximum cold inflation pressure to which a tire may be inflated.

Normal occupant weight: The number of occupants a vehicle is designed to seat multiplied by 150 pounds (68 kg). See "Loading Your Vehicle" on page 250.

Occupant Distribution: Designated seating positions.

Outward Facing Sidewall: The side of a asymmetrical tire that has a particular side that faces outward when mounted on a vehicle. The side of the tire that contains a white-wall bears white lettering or bears manufacturer, brand and or model name molding on the other sidewall of the tire.

Passenger (P-Metric) Tire: A tire used on passenger cars and some light duty trucks and multipurpose vehicles.

Recommended Inflation Pressure: Vehicle manufacturer's recommended tire inflation pressure shown on the tire placard, see "Inflation - Tire Pressure" on page 240 and "Loading Your Vehicle" on page 250.

Radial Ply Tire: A pneumatic tire in which the ply cords that extend to the beads are laid at substantially 90 degrees to the centerline of the tread.

Rim: A metal support for a tire or a tire and tube assembly upon which the tire beads are seated.

Sidewall: The portion of a tire between the tread and the bead.

Speed rating: An alphanumeric code assigned to a tire indicating the maximum speed at which a tire can operate.

Traction: The friction between the tire and the road surface. The amount of grip provided.

Treadwear Indicators: Narrow bands, sometimes called "wear bars", that show across the tread of a tire when only 2/32 inch of tread remains. See "When It Is Time for New Tires" on page 242.

252 Car care

Tread Width: The width of the tire's tread.

UTQGS: Uniform Tire Quality Grade Standards, a tire information system that provides consumers with ratings for a tire's traction, temperature and treadwear. Ratings are determined by tire manufacturers using government testing procedures. The ratings are molded into the sidewall of the tire. See "Uniform Tire Quality Grading" on page 244.

Vehicle Capacity Weight: Is the number of designated seating positions multiplied by 150 pounds (68 kg) plus the rated cargo load. See "Loading Your Vehicle" on page 250.

Vehicle Maximum Load on the Tire: Load on an individual tire due to curb weight, accessory weight, occupant weight and cargo weight.

Vehicle Placard: A label permanently attached to a vehicle showing original equipment tire size and the recommended cold inflation pressure. See "Loading Your Vehicle" on page 250.

Steps for Determining Correct Load Limit

- 1 Locate the statement "The combined weight of occupants and cargo should never exceed XXX pounds" on your vehicle's placard.
- 2 Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- 3 Subtract the combined weight of the driver and passengers from XXX kilograms or XXX pounds.
- 4 The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1400 lbs. and there will be five 150 lb. passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs. ($1400 - 750 (5 \times 150) = 650$ lbs.).
- 5 Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.
- 6 If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle.

Winter tires

Winter (snow) tires are recommended for winter climates where the majority of your driving will be done on snow and ice. Winter tires should be fitted to all four wheels to maintain a proper balance. Your Saab dealer can advise you of the correct size tire for your car (if different from the original size) and also supply Saab approved winter tires pre-mounted on steel or alloy rims.

Winter tires normally use a different speed rating compared to summer/all season tires. Make sure not to exceed the stated speed rating on the tires you use.

Make sure that wheels with sensors for tire pressure monitoring are fitted during replacement if the car has automatic tire pressure monitoring.

Tire date code

Tires should be regarded as perishable goods. As the tires age, the rubber becomes progressively harder, and the road holding ability of the tires diminishes. This is particularly true on winter tires.

Tires have a code that specifies their date of manufacture. The first two digits denote the week number and the last two digits the year followed by a filled triangle.

Automatic tire pressure monitoring system

WARNING

The system is an aid to the driver. The driver always has the responsibility that the tires have the correct air pressure.

For optimum safety, economy and comfort tire pressures should be checked regularly even if the automatic tire pressure monitoring has not alarmed.

The system consists of a sensor in each wheel and a common receiver. The sensors are located inside the tire in direct connection with the air pressure valves.

Make sure that wheels with sensors for tire pressure monitoring are fitted during replacement if the car has automatic tire pressure monitoring.

The system will trigger a warning/alarm if the spare wheel is fitted because it has no sensor.

NOTICE

Tire replacement must take place with great care to avoid damaging the sensors that are built together with the valves.

- Remove the rear side first, see page 255.
- Start to remove the tire opposite the valve.
- During removal the tire machine must not come closer than $\pm 10^\circ$ from the valve.
- During fitting, start 20° after the valve and finish 20° before the valve.
- Do not inflate the tire with pressure higher than 102 psi (700 kPa).


Tire pressure information is transmitted wireless to the receiver.

The system checks the tire pressures when speed exceeds 19 mph (30 km/h).


The system is self-programming which means that the wheels can be shifted around without any need for adjustment.

The sensor batteries last for 10 years or around 160 000 km. The battery cannot be replaced. The whole sensor must be replaced.

254 Car care



Valve with sensor



Valve without sensor

The system does not warn if the tire pressure is too high.

If the system has warned or triggered an alarm due to inadequate pressure then the pressure must be reset to the recommended pressure so that the warning/alarm is cleared.

If the tire pressure decreases

If the tire pressure decreases to 6 psi (40 kPa) below the recommended pressure then a warning is shown on the SID as to which tires are affected.



Tire pressure low, front right. Check tires.

Adjust the pressure as soon as possible.

If the tire pressure continues to decrease then an alarm is shown on the SID when the pressure has decreased to 23 psi (160 kPa) which is the lowest permitted pressure for the tire.

An alarm is also received when leakage is greater than 3 psi/min. (20 kPa/min.).



Low tire pressure rear left. Make a safe stop.

Reduce speed (avoid heavy braking and significant steering wheel movement) and stop the car as soon as possible at a suitable location. Replace the defective wheel. The fault message can remain for up to 10 minutes after restarting the car. Then it disappears if the tire pressure is correct.

Check/adjust the pressure in the other tires when a fault message is shown.

Note that the tire pressure can decrease without a puncture. The pressure could decrease around 3 psi (20 kPa) during a three month period.

The outside temperature could also affect tire pressure.

The temperature in the tire also affects the tire pressure. The specified tyre pressures are valid for cold tyres. The increased tyre pressure resulting from extensive driving must not be reduced. **For further information on tire air pressure**, see page 240.


Allow 10 minutes for the system to recognize the wheel/sensors positions after fitting a new set of tires. During this period no low pressure warning or alarm can be triggered.

Malfunctions

! Tire pressure system failure. Contact service.

The above message is shown on the SID if:


- Wheel without pressure sensor has been fitted (e.g. spare wheel)
- One or more pressure sensors are broken or missing
- A fault has arisen in the receiver
- A system error has arisen.



Removing a tire

Remove the tire with a tire machine. It is important to follow the instructions for the tire machine as well.

- Do **not** fit the tire tool in an area $\pm 10^\circ$ from the valve
- Start removing opposite the valve
- Remove the rear side first.



Fitting a tire

Fit the tire with a tire machine. It is important to follow the instructions for the tire machine as well.

- Start to fit about 20° after the valve
- Finish fitting before an area 20° from the valve
- Do **not** inflate the tire to a pressure higher than 102 psi (700 kPa).

256 Car care

Compact spare

WARNING

The spare tire or punctured tire must be stowed under the trunk floor, and secured in place with the retaining nut.

The compact spare is light and easy to handle when changing the tire. Its use is only permitted when a standard tire has sustained a puncture. The maximum life of the tire is only just over 2,000 miles (3,500 km).

Do not exceed 50 mph (80 km/h) with the compact spare fitted.


The tire pressure should be 60 psi (420 kPa). Put the punctured tire in the spare wheel well under the trunk floor.

Have the standard tire repaired and refitted as soon as possible.

NOTICE

To avoid damaging a alloy wheel of a punctured tire, this can be temporarily placed outside up in the spare wheel well but **only** while driving to the closest workshop.

As a general rule, all heavy loads must be well secured in the trunk (see page 139).




The spare tire, the tools and the jack with its crank are carried under a panel in the trunk.


Fold the carpeting forward to ease access to the tools and spare tire.

The screwdriver handle has a “button” for removing plastic rivets. This type of rivet must be removed when changing the light bulb in the trunk lid (see page 226).

Your Saab is equipped with a trip computer and you can use its “Speed warning” function, to monitor driving speed since you must not exceed 50 mph (80 km/h), see page 92.




SportCombi



Tools under a panel in the trunk, SportSedan

SportCombi with subwoofer

Position the loudspeaker on the left-hand side before the spare wheel is removed. The arrow on the loudspeaker must point forwards when the loudspeaker is fitted in the spare wheel.



BH747

258 Car care

Driving with a compact wheel fitted

WARNING

- Do not exceed 50 mph (80 km/h). The tire can overheat affecting the car's road holding.
- Tire pressure: refer to page 291.
- The spare tire or punctured tire must be stowed under the trunk floor, and secured in place with the retaining nut.

Observe the following when the compact spare tire is fitted:

- The compact spare is light and easy to handle when changing a tire.
- Do not drive further than necessary with the compact spare fitted - the maximum life of the tire is only just over 2,000 miles (approx. 3,500 km).
- Refit the standard tire as soon as possible.
- Fitting a spare tire/wheel without pressure sensor will trigger a malfunction message, see page 255.

Important considerations when driving with a compact spare tire:

- The car's ground clearance is reduced.

- The car must not be driven with more than one compact spare tire at a time.
- Avoid driving against the curb.
- Do not use snow chains.
- Do not fit the wheel cover - this would conceal the warning text.

Changing a tire

WARNING

Lifting a vehicle and getting under it to do maintenance or repairs is dangerous without the appropriate safety equipment and training. The jack provided with your vehicle is designed only for changing a flat tire. If it is used for anything else, you or others could be badly injured or killed if the vehicle slips off the jack. Use the jack provided with your vehicle only for changing a flat tire.


Changing a tire can be dangerous. The vehicle can slip off the jack and roll over or fall on you or other people. You and they could be badly injured or even killed. Find a level place to change your tire. To help prevent the vehicle from moving:

- 1 Set the parking brake firmly.
- 2 If you have an automatic transmission, put the shift lever in PARK (P). For a manual transmission, leave the car in gear (1st or REVERSE (R)).
- 3 Turn off the engine and do not restart while the vehicle is raised.
- 4 Do not allow passengers to remain in the vehicle.

To be even more certain the vehicle won't move, you should put blocks at the front and rear of the tire farthest away from the one being changed. That would be the tire, on the other side, at the opposite end of the vehicle.

- The car jack is designed solely for use in changing a tire or fitting snow chains. **It must not be used to support the car during repair work or servicing.**
- **Never** crawl under a car that is supported only by a jack. Always use axle stands.
- Raising your vehicle too high or with the jack improperly positioned can damage the vehicle and even make the vehicle fall. To help avoid personal injury and vehicle damage, be sure to fit the jack lift head into the proper location before raising the vehicle, and raise the vehicle only far enough off the ground so there is enough room for the spare tire to fit (no more than 25 mm or 1 inch clearance between the ground and the bottom of the tire).
- Switch on the hazard warning lights if the car is on a road.

- The jack should be stored correctly under the carpeting in the trunk. If it lies loose in the car, it could be thrown forward and cause personal injury in the event of a crash or if the car rolls over.
- Grit, salt and rust can clog the inner threads of the wheel bolts if the car has been driven for several years exclusively with alloy wheels. If steel wheels are being installed, the bolt hole threads in the brake hubs should be cleaned before the thinner steel wheels are fitted. It may otherwise not be possible to achieve the correct clamping force, despite tightening the wheel bolts to the correct torque.



Jacking points for floor jack


When the car has to be lifted, the jack must be positioned at one of the four jacking points (front or rear) under the sill members.

If a floor jack is used, the lifting plate must be positioned under the normal jacking points, see illustration. If the car is equipped with a towbar, the jack can also be placed under this.


NOTICE

Apply the jack only to the jacking points indicated on the body.


260 Car care



Marking of jacking points




Jacking points




Removing the plastic wheel bolt covers

- 1 Wind the jack up to a suitable height before placing it under the jacking point. Each jacking point is indicated by an arrow on the sill (see illustration). Make sure that the jack fully engages the jacking point in the underside of the sill member and that the entire foot of the jack is steady and flat on the ground. The jack must not stand on snow, ice or similar. Wind up the jack until it just begins to lift the car.


- 2 It is not necessary to remove the wheel cover. If, none the less, you wish to remove the wheel cover, take hold of the outer edge and pull it straight out. Remove the plastic wheel bolt covers. Loosen the wheel bolts half a turn.
- 3 Wind the jack to raise the wheel clear of the ground. Remove the wheel bolts and lift off the wheel.



Clean any rust or dirt from the contact surfaces between the wheel and brake disc.



Do not wipe away the grease in the wheel hub.



Grease the surfaces indicated with a thin layer of grease

4 Clean any rust or dirt from the contact surfaces between the wheel and brake disc. Do not wipe away the grease in the wheel hub.

5 Add a thin layer of grease on the bolts before fitting, see page 261. Fit the wheel and screw in the bolts in the sequence shown on page 262 (opposite pairs). Tighten the bolts enough for the bolts and wheel to be seated correctly.

6 Lower the car and tighten the wheel bolts to torque in sequence as shown on page 262.

Tightening torque

Light-alloy wheels: 80 ft.lb. (110 Nm).
Steel wheels: 80 ft.lb. (110 Nm).

Lubricate the heads of the wheel studs with a small amount of Vaseline or similar and refit the plastic covers on the wheel studs. The Vaseline makes it easier to remove them later on.

NOTICE

- Do not overtighten the bolts using an impact wrench: not only can this damage the wheels but it can also make it impossible to undo the bolts using the wheel wrench in the car's toolkit.
- When refitting a wheel cover, make sure that the valve protrudes through the marked recess in the wheel cover.

7 Retouching the wheel bolts after twenty or so miles.

Tightening torque


Light-alloy wheels: 80 ft.lb. (110 Nm).
Steel wheels: 80 ft.lb. (110 Nm).

We advise against using wheels with large ventilation slots in winter, as the brake components are then more exposed to slush, road salt and grit.

If you fit wheels of a different dimension, the speedometer can be reprogrammed to ensure it is as accurate as possible. We recommend that you contact a Saab dealer.

Driving with tire chains ❄️, see page 186

262 Car care



Tightening sequence, wheel bolts

Tire repair kit *

WARNING

Make sure no one can jog the gear lever, for example, as the engine must be idling when the tire is repaired. There is otherwise a risk of personal injury.

Do not use the repair kit if:

- the damage to the tire is larger than 0.16 in. (4 mm).
- the wheel is damaged.

Do not exceed 50 mph (80 km/h) after repairing one of the car tires with the repair kit.

WARNING

Change the punctured tire as soon as possible.

Replenish the repair kit at a workshop. We recommend that you contact an authorized Saab workshop. The canister of sealant must be changed once every four years. See the date on the canister.

The handling characteristics of the car may be impaired.

Driving with a tire that is underinflated or has a puncture can damage the tire in such a way that it is not possible to repair it with the sealant.

The tire repair kit replaces the spare wheel. The repair kit allows a punctured tire to be temporarily repaired and reinflated without needing to remove the wheel.

Minor damage to the tire, such as a foreign object that has penetrated the tread, can be temporarily repaired with the repair kit. Do not remove the foreign object. Damage larger than 0.16 in. (4 mm) and damage to the sidewalls cannot be repaired with the repair kit.

Follow the instructions supplied with the repair kit carefully.

If the compressor sounds strange or becomes abnormally hot, leave it switched off for at least 30 minutes.

Prevent the compressor getting wet.


The canister of sealant can only be used once. Replace a used canister at a workshop. We recommend that you contact an authorised Saab workshop.

The tire repair kit can be used at temperatures down to -22°F (-30°C). At low temperatures the sealant is more viscous and so is less able to seal slightly larger damage.


If a punctured tire is to be repaired:

- Allow the engine to idle. The compressor will consume some energy.
- Apply the handbrake.
- Turn on the hazard warning light.
- Position the warning triangle to warn other drivers.

The repair kit is stowed under the luggage compartment floor.




- 1 Allow the engine to idle.
- 2 Remove the repair kit from the luggage compartment.




- 3 Remove the electric cable and the air hose from the compartment on the bottom of the compressor.


264 Car care




- 4 Connect the air hose from the compressor to the connection on the canister.
- 5 Insert the canister into the recess in the compressor.
- 6 Unscrew the valve cap from the punctured wheel.



- 7 Connect the air hose from the canister to the valve on the wheel.
- 8 The switch on the compressor must be in the 0 position.
- 9 Connect the compressor's electric cable to the 12 volt socket (cigarette lighter) in the car.



- 10 Start the compressor.
- 11 While the canister of sealant empties (approx. 30 seconds), the gauge on the compressor will briefly show a pressure of up to 87 psi (6 bar). The pressure will then drop.
- 12 Once the canister is empty, pump the tire to the recommended tire pressure (see page 291). It is not necessary to remove the canister.
- 13 The tire should be inflated to the recommended pressure within 10 minutes. Switch off the compressor once the correct pressure is reached.



If the correct pressure is not reached within 10 minutes, the damage to the tire is too large to be repaired with the sealant. Park the car in a suitable place and call for assistance.

If the tire pressure becomes too high, it can be reduced by pressing the button by the pressure gauge on the compressor.

Do not run the compressor for more than 10 minutes.

14 Assemble the repair kit and return it to its designated place in the luggage compartment.

15 Wipe away any sealant that may have leaked out with a rag.

16 Put back the warning triangle.

17 Affix the label in the kit showing the maximum permitted speed so that it is clearly visible to the driver.

18 Drive off immediately so that the sealant is distributed evenly around the tire.


19 Stop after approximately 6 miles (10 km) or 10 minutes (whichever occurs first) and check the tire pressure. To do so, connect the air hose on the compressor directly to the valve on the tire.

If the pressure is greater than 19 psi (1.3 bar), adjust it to the recommended value, see page 291. It may be necessary to check the pressure a number of times on the way to a workshop.

If the pressure falls below 19 psi (1.3 bar), do not drive the car any further but call for assistance.

The most likely reason for a drop in pressure is probably that the damage to the tire is too extensive to be repaired with the repair kit.

20 Return the repair kit to its designated place.



There are four adapters on the underside of the compressor which allow the compressor to be used to inflate other items such as bicycle tires, air mattresses and footballs.

Safety belts

WARNING

If the car is involved in a crash, the safety belts, belt pretensioners and other associated components must be inspected. We recommend that you contact a Saab dealer.

Never make any alterations or repairs to the safety belts yourself. We recommend that you contact a Saab dealer.

Check the function of the safety belts regularly as follows:

- Hold the diagonal strap and pull it sharply. The safety belt should lock and it should not be possible to withdraw it further.

Check the anchorage points in the floor. They must not have suffered rust damage.

If a belt is worn or has any fraying edges, it should be replaced.

Safety belts must not come into contact with substances such as polishes, oil or chemicals. If the belts get dirty, wash them with warm water and a detergent or have them replaced.

Upholstery and trim

To remove fluff and hairs from the seats, door armrests and headlining, use a vacuum cleaner, a moist lint-free cloth, or a clothes brush. Remove spots and dirt using a cloth moistened with lukewarm soapy water.

When using a stain remover, always work from the outside towards the center to avoid leaving a ring. If a soiled ring or spot should remain, it can usually be removed using lukewarm soapy water or water alone.

Spots left by liquids, such as soft drinks or thin oil, must be removed at once with an absorbent material, such as kitchen towel. Then clean with a stain remover.

White spirit is recommended for removing grease and oil stains. A medium stiff brush may also be used.

Cleaning and caring for leather upholstery

The principal reason for treating leather upholstery is to maintain its elegant appearance and to provide it with a protective film. Discoloration caused by dust and wear mainly affects the lighter shades, although this is not detrimental to the leather, indeed, the patina resulting from use is often considered desirable in leather. But if the leather is allowed to become too grubby, it can start to look shabby. Vacuum the leather regularly with a soft brush attachment to remove loose dirt and dust.

The leather upholstery should be cleaned and reconditioned twice a year in conjunction with spring and autumn inspections. In very warm, dry climates the leather may need more regular reconditioning. Use conventional leather care products. Follow the instructions on the packaging.

Do not use harsh polishing agents, cleaning agents, sprays, coarse soap or hot water. Semi-Anilin is a leather that is colored throughout which only has a thin protective finish and is accordingly more sensitive than a surface colored leather and therefore need more care to keep the protection and ageing properties.

Textile carpeting

Textile carpeting should be vacuum cleaned regularly. Carpeting can also be cleaned using a brush or sponge and carpet shampoo.

For safety reasons, vacuum cleaners that are not earthed (grounded) must not be used out of doors.

Engine bay

The engine bay should be cleaned with an engine decreasing and rinsed with hot water. The headlights must be covered over. Do not use a pressure washer. Avoid spraying electrical components and connectors.

Do not use petrol as a cleaning agent or solvent when carrying out repairs or maintenance. Saab recommends the use of environmentally-friendly cleaning solutions.

Washing

The bodywork must be washed frequently. When the car is new, the body should be washed by hand using plain cold water and a clean, soft brush through which the water flows. Automatic carwashes should be avoided when the car is new.

After 5–6 months the paintwork will have hardened. To facilitate cleaning, a suitable detergent can be added to the water, which should be lukewarm.

Remove any bird droppings without delay, as these can discolor the paintwork and prove difficult to polish out. Lay a wad of wet paper on the patch of dirt and leave it for a minute or so. It will then be easy to wash off the dirt.

Use a soft cloth moistened with white spirit to remove splashes of tar or asphalt. Do not use strong cleaners, as these can dry out the paintwork.

NOTICE

Only use liquid detergent when cleaning the plastic lenses of the front and rear lights. Do not use mechanical cleaning. Rinse off the detergent immediately, otherwise cracks may form in the plastic lenses.

The door mirrors should be folded in before the car enters an automatic car wash.

SportCombi: To avoid the wiper arm to break tape it down to the window when using a drive-through car wash.

Try your brakes on leaving a car wash. Wet brake discs reduce the performance of the brakes.

Fixed antennae, such as for a mobile phone, must be removed if the car goes through an automatic car wash.

Cars with Saab Parking Assistance: Do not spray the sensors or closer than 8 in. (20 cm) to the sensors with a pressure washer, as this can damage them.

268 Car care

The underside of the car also needs washing regularly, and this should be done extra thoroughly at the end of winter. Clean the underside of the car by hand if the car is usually washed in an automatic car wash without special facilities for underbody cleaning.

Never wash or leave the car to dry in the sun, but wipe it dry with a chamois leather immediately after washing to avoid smears and streaks.

Clean the inside of window glass using a proprietary window cleaner. This is particularly important when the car is new, as upholstery and trim have a tendency to sweat a little at first.

Keep the glass well polished, as this helps to prevent misting.

Clean the outside of the windows with Saab washer fluid. This is especially important if the car has been washed in an automatic car wash, as sometimes a wax treatment is used that can contaminate the windshield and impair the performance of the wipers.

Saab offers a full complement of car care products. See your dealer or visit us at our website.

Convertible

- If a pressure washer is used be heedful of the following recommendations:
 - On the lower part of the car (not higher than the door handles): max pressure of 100 bar and not closer than 8 in. (20 cm).
 - On the upper part of the car: max pressure of 100 bar and not closer than 32 in. (80 cm).
- Do not use any drying chemicals or waterproofing agents.
- Avoid automatic car washes.

WARNING

- Read and follow the instructions on the packaging of the recommended cleaning agents and waterproofing agents. We recommend that you contact an authorized Saab dealer regarding recommended cleaning agents and waterproofing agents.
- Never treat the soft top with hot wax or similar.

- Never use petrochemical based solvents for cleaning. Only use water with a recommended cleaning agent. Petrochemical based solvents can cause irreparable damage to the soft top.
- Never use a pressure washer to clean the soft top. Only use normal household water pressure.

NOTICE

- Only operate the soft top when it is clean and dry.
- Do not lower the soft top when it is damp. This can cause folds and pressure marks. If the soft top is heavily soiled, the dirt may cause irreparable visible chafe marks.
- Only use water, recommended cleaning agents and a microfibre cloth if the soft top is already damaged, otherwise the damage can become worse.
- At creases, seams and window edges the cleaning motion should be away from the crease, seam or window edge in to the soft top.

When the soft top is only slightly soiled, follow the directions on the cleaning agent packaging. No brushing is necessary.

Check the soft top for water penetration from time to time by spraying a small amount of water on it. If water does not form droplets but disappear into the material, it is recommended to wash normally and then waterproof.

If the soft top is heavily soiled and normal recommended cleaning does not produce a noticeable improvement, carry out the following.

The following cleaning method must be only used if the soft top is heavily soiled and must not be carried out more than twice a year.

- 1 Stop normal cleaning.
- 2 Rinse off the thick dirt thoroughly with water.
- 3 Spray the newly rinsed soft top with the recommended cleaning agent and allow it to work in for 15-20 minutes.

- 4 Move the washing brush backwards and forwards, not diagonally, from side to side or in circles. Use a soft brush, like a clothes brush or a micro fibre cloth so that the cleaning agent foams. Never use a wire brush.
- 5 Then rinse the soft top with warm water and brush using a soft brush in the direction of the vehicle until all foam has disappeared. Brush carefully to prevent damaging the material.

 **WARNING**

Water hotter than 37 °C can burn the skin, cause skin irritation and/or cause injuries. Use suitable protection.

- 6 Dry the soft top using a clean chamois leather or a cloth that does not leave lint on the soft top.
- 7 Allow the soft top to dry fully. Touch with a hand after a while, if the material feels damp, allow it to dry for longer.

- 8 If spots are still visible, repeat the treatment on these spots as before. Press lightly with the brush to prevent damaging the material. Do not use the brush excessively. This can irreparably damage the material. Do not repeat the treatment more than twice.
- 9 When the soft top has fully dried, it must be waterproofed immediately. Only use the recommended waterproofing agent. Follow the instructions on the packaging.
- 10 To obtain even and optimum waterproofing, the car must be closed for 24 hours after treatment. Do not touch the material and do not place any objects on it.

270 Car care

Waxing and polishing

Do not wax a new car during the first three or four months. In fact, there is no need to polish the car before the paintwork has started to dull through oxidation. Other than in exceptional cases, do not use abrasive polishes containing a cutting agent on a new car. Always wash the car thoroughly before waxing or polishing.

Touching up the paint

Damaged paintwork should be treated as soon as it is discovered: the longer it is left, the greater the risk of corrosion. The anti-corrosion warranty does not cover corrosion resulting from untreated defects.

Paintwork damage sustained in a crash is usually extensive and can only be properly restored by professionals.

However, you can repair small scratches and stone chip damage yourself. The necessary tools and materials, such as primer, touch-up paint and brushes, are available from a workshop. We recommend that you contact a Saab dealer.

In the case of minor flaws in the paintwork, where the metal has not been exposed and an undamaged layer of paint remains, touch-up paint can usually be applied directly, after any dirt has been scraped away using a pointed knife.

If corrosion has already set in, such as the result of stone-chip damage, use a pointed knife to scrape off all surface rust. If possible, the damaged area should be taken back to the bare metal. The metal should then be primed with two thin coats of primer applied by brush.

After the primer has dried, apply several thin layers of topcoat until the surface of the repaired area is flush with the surrounding paintwork.


Stir both primer and touch-up paint thoroughly before use and allow each coat to dry before applying the next.

Two-coat enamel

As the name implies, two-coat enamel is applied in two operations. The first coat, the base color, contains the pigment, metal flakes and binder. The second coat consists of a clear enamel, which provides the final gloss for the paintwork and protects the base from moisture and environmental contaminants.

Touch-up stone-chip damage as follows:

- 1 Thoroughly clean the damaged area.
- 2 Then apply the primer, base color and finally, the clear enamel. To achieve the best finish, apply two or three coats of primer.



Surface treatment composition

- 1 Body panel
- 2 Zinc (certain components only) 7.5 µm
- 3 Phosphate coating 3–5 µm
- 4 Cathodic ED 23 µm
- 5 Intermediate coat 35 µm
- 6 Metallic base/solid base 11 µm
- 7 Clear enamel 45 µm

Anti-corrosion treatment

The entire car undergoes a series of anti-corrosion processes during production. These include electrophoretic priming, PVC-based coating to protect against stone chip damage and corrosion, and treatment of body cavities and members with thin, penetrating rust-proofing oil.

In addition, most body panels, such as the hood, doors and floor pan are galvanized.

The anti-corrosion treatment on some parts of the car is constantly exposed to wear and prone to damage. This applies particularly to the underside of the car and inside the wheel arches, where grit, road salt and the like that are thrown up can give rise to corrosion where the underseal has worn away. The extent of this obviously depends on the conditions in which the car is used.

Accordingly, make it a habit to hose the underside of the car often and to inspect the condition of the underseal. The anti-corrosion warranty does not relieve the car owner of the need to carry out normal maintenance to the rust-proofing and to make good any damage.

Use a hose to clean the underside of the car thoroughly. After it has dried, use a brush or spray to apply a viscous anti-corrosion agent to any worn or damaged areas, to prevent the onset of corrosion.

Even after the anti-corrosion warranty has expired, it makes good sense to continue to maintain the rust-proofing.

Seams in the body, especially those in the doors and trunk lid, are particularly vulnerable to corrosion from the outside, caused by grit and salt thrown up from the road, and to corrosion from the inside, largely as a result of condensation. Keep the seams clean and at the first sign of any rust, apply a thin, penetrating, anti-corrosion oil. Your Saab dealer will be pleased to give you further advice.

What causes rust?

Steel body panels of automobiles are subject to rusting whenever air and moisture manage to penetrate the protective finish. Body panels may rust through if the process is unchecked. Rusting can occur wherever water is trapped or where the car's panels are continuously damp.

Damage to paint and undercoating by stones, gravel and minor crashes immediately exposes metal to air and moisture. Road salts used for de-icing will collect on the bottom of the car and promote rusting. Areas of the country with high humidity have a greater potential for rust problems, especially where salt is used on roads or there is moist sea air. Industrial pollution (fallout) may also damage paint and promote rusting.

Preventive maintenance

The following procedures are necessary to help protect against rusting. Refer also to the terms and conditions of the Performance Limited Warranty described in the warranty booklet.

- 1 Wash the car frequently, and wax at least twice a year.** Under adverse conditions, where there is a rapid buildup of dirt, sand or road salt, wash your car at least once a week. After extreme exposure to salted snow or slush, evidenced by a white film on the car, wash the car immediately. Frequent




272 Car care

washing will prevent paint damage from acid rain and other airborne contaminants such as tree sap and bird droppings. If any of these contaminants are noticed on the car the finish should be washed immediately.

- Begin washing by rinsing the entire car with water to loosen and flush off heavy concentrations of dirt (include the underbody).
- Sponge the car with a solution of either a good quality car soap or mild general purpose (dish washing) detergent and water.
 - Rinse car thoroughly with clean water
 - After washing, check and clear all drains in doors and body panels
 - Wipe the car dry, preferably using a chamois.


2 Clean the underside of the car during the winter. Use high pressure water to clean the car's underside (floor panels, wheel wells) at least at mid-winter and in the spring.



3 Inspect the car frequently for leaks or damage, and arrange for needed repairs promptly. After washing or after heavy rain, check for leaks. When washing the car inspect body surfaces for paint damage. While checking for leaks, lift the floor mats and check underneath them. Water can collect in these areas and remain for prolonged periods. Dry any wet areas including the floor mats. Have leaks repaired as soon as possible.

Use touch-up paint to repair small scratches or minor finish damage. Areas where metal is exposed will rust quickly and **MUST** be repaired immediately by touch-up or professional repainting. Rust must be removed, the bare metal primed and painted. Major body damage should be repaired immediately and new panels or exposed areas should be undercoated with anti-corrosion material.

Repairs of this type are the owner's responsibility and are not covered under warranty.



Inspect the undercoating and touch up if necessary. Pay particular attention to the fenders and wheel housings, which are exposed to abrasion by flying gravel, etc. If the composition has worn or flaked off, the steel must be thoroughly cleaned and dried before a fresh coat is applied. The cleaning is best done with a scraper and a steel wire brush, followed by washing with solvent. Apply the new coating thinly, otherwise it may run off or fall off when dry.

Recovery and/or recycling of automotive materials

Information on the scrapping and recycling of car materials is available on www.saab.com.



Air conditioning (A/C)

WARNING

- All repairs and adjustments to the A/C system must be carried out at a Saab dealer authorized for this kind of work.
- The A/C system is pressurized. Do not break any connections or undo A/C system components.
- Escaping gas can cause eye injury or other personal injury.

NOTICE

- The A/C system is designed for use with R134a refrigerant.
- Refrigerant handling requires special equipment and special procedures for charging and draining the system.
- Never mix R 134a with other refrigerants.

Troubleshooting

If a fault occurs in the A/C system, there are a number of checks you can perform yourself. If the fault persists, however, have the system checked at a workshop. We recommend that you contact a Saab dealer.

Note

When the A/C system is running, the intake air is dehumidified. The resultant condensation that forms on the evaporator is drained off under the car. When the car is parked, this may result in a small puddle forming on the ground. The warmer the air and the higher the relative humidity, the more condensation will be produced.

Inadequate cooling

- 1 Check that the condenser (in front of the radiator) has not become clogged with dirt and insects.
- 2 Make sure that the compressor drive belt does not slip (see page 215).
- 3 Check the fuses for the ventilation fans and compressor (see page 235).

Maintenance

NOTICE

Do not use a pressure washer when cleaning the condenser or radiator due to the risk of damage.

- The compressor drive belt should be inspected under the regular service program.
- Clean away dirt and insects from the condenser and radiator to prevent clogging. When washing the car, use the hose to spray the radiator and condenser (located in front of the radiator) from both sides (both from the front of the car and from inside the engine bay). Do not use a pressure washer.
Caution: Do not hose down the radiator and condenser while the engine is hot.

Other than in extremely cold weather, do not screen the radiator, e.g. with netting, as this will greatly diminish its cooling capacity.

- Applicable to the manual climate control system - During cold months the air conditioning should be switched on once or twice a month and run for 5–10 minutes during highway driving once the engine is warm.

This action saves the gaskets in the compressor from being spoiled. The

274 Car care

compressor uses a lubricant that circulates with the coolant.

Note

The A/C system cannot be switched on when the outside temperature is below 32°F (0°C). Turn on the A/C system when the car is standing in a warm place. Simplest is to always have the A/C button pressed in. The A/C system will then cut in automatically when the outside temperature is high enough.

Headlight aiming

⚠ WARNING

Before checking/adjusting the headlight aiming, switch off the engine to avoid danger of fingers and hands being injured by moving parts.

The radiator fan can start up even when the engine is switched off.

The vehicle has a visual optical headlight aiming system equipped with vertical aiming device. The aim has been preset at the factory and should normally not need further adjustments.

If your headlights are damaged in a crash, the headlight aim may be affected. If you believe your headlights need to be re-aimed, we recommend that you take it to your Saab dealer for service. However, it is possible for you to re-aim your headlights as described in the following procedure.


NOTICE

To make sure that your headlights are aimed properly read all instructions before beginning. Failure to follow these instructions could cause damage to headlight parts or a not correctly aimed headlight.

To check the aim, the vehicle should be properly prepared as follows:

- The vehicle shall be placed so that the headlights are 25 ft (7.6 m) from a light colored wall or other flat surface. The aiming area should be darkened, this will improve your ability to see the beam of the low beam headlight being aimed. An optical headlamp aimer can also be used and will then replace the wall.
- The vehicle must have all four wheels on a perfectly level surface which is level all the way to the wall or other flat surface.
- The vehicle should be placed so it is perpendicular to the wall or other flat surface.
- The vehicle should be unloaded and fuel tank full, and one person or 160 lbs. (75 kg) on the drivers seat.
- The vehicle should be fully assembled and all other work stopped while headlight aiming is being done.
- The vehicle should not have any snow, ice or mud attached to it.
- Tires should be inflated to the prescribed pressure.
- Close all doors.
- Rock the vehicle to stabilize the suspension.

Headlight aiming is done with the vehicle low beam lamps. The high beam lamps will



- 1 Wall or garage door.
- 2 25 ft (7.6 m) between wall and headlight lens.
- 3 Measurement from the ground to the low beam aiming marker on the headlight lens.
- 4 Same measurement as (3) but subtract 2 inches.

be correctly aimed if the low beam lamps are aimed properly.

If you find that the headlight needs adjustment follow these steps:

- 1 Open the hood and locate the vertical aiming devices.
- 2 Locate the marker on the lens.
- 3 Measure the distance from the ground to the aim marker No.1 (see illustration) on each lens. Subtract 2 inches.
- 4 At the wall or other flat surface, measure from the ground to the recorded distance (see point 4) and draw a horizontal line the width of the vehicle.


5 Cars with xenon lights:

Xenon lights with automatic headlight levelling system must first do a reference run before aiming: Start the engine and let the headlights do a reference run. Turn off the engine but leave the low beam on.

Cars with halogen lights:
Turn on the low beam headlights.


Both variants:

Place a piece of cardboard or equivalent (although not directly on the lens) in front of the headlight not being aimed. This should allow the beam cut-off of the headlight being aimed to be seen on the flat surface.



Vertical aiming device

- 1 Aiming marker on headlight lens




276 Car care


NOTICE

Do not cover a headlight directly on the lens to improve beam cut-off when aiming. Covering a headlight may cause excessive heat build-up that may cause damage to the headlight.


- 6 Turn the vertical aiming screw until the horizontal cut-off of the headlight is aligned with the horizontal line on the wall.
- 7 If an optical headlight aimer device is used follow point 1 and 2 and center the lens of the optical headlight aimer device at the intersection of the two markers on the headlight lens. Then follow the instructions in the optical headlight aimer instruction manual and point 1, 2, 5, and 6 in this instruction.



Horizontal line on wall or other flat surface




Correctly adjusted low beam







Customer Assistance and Information

Maintenance schedule __	278
Owner assistance _____	280
Reporting Safety Defects (USA) _____	281
Reporting Safety Defects to the Canadian government _____	281
Vehicle Data Collection and Event Data Recorders _____	282



* Asterisk means: equipment not fitted in all cars (can depend on model variant, engine variant, market specification, options or accessories).



278 Customer Assistance and Information

Maintenance schedule

The Maintenance Schedule prescribes a service program to the purchaser/operator of a Saab that is reasonable and necessary to ensure the proper emission control systems function, safety and reliability of the Saab automobile in normal use. Additional maintenance is recommended for specific components when the car is operated under certain severe conditions. Proper maintenance is always a good practice!

Authorized Saab dealers are equipped and trained to meet your Saab's service needs. They regularly receive up-to-date Saab service manuals and parts and technical service bulletins from Saab and are able, through their franchise agreement, to attend Saab service schools, obtain Saab special tools and technical assistance and purchase original equipment service and replacement parts.

Today's complex automobiles should only be entrusted to the most knowledgeable service professionals. A Saab dealer is your best choice.

SERVICE INTERVALS

A time for service message will illuminate on the Saab Instrument Display (SID) when the car is due for regular maintenance.



Time for service.

There are three different service types:

MAIN SERVICE

Main service is performed at fixed odometer intervals. These intervals vary between markets and engine variants. Contact a workshop for more information. We recommend that you contact an authorized Saab dealer.

Failure to perform scheduled maintenance in a timely manner may result in serious damage to key components or systems.

INTERMEDIATE SERVICE

The intermediate service on the other hand, is performed depending on e.g. number of cold starts and the climate conditions which the car is in. Therefore the interval can vary for this service type.

MAIN AND INTERMEDIATE SERVICE

When the counter for these two service types is close enough, a combined service is performed.

Engine oil and filter changes

Changing the engine oil and filter is required at every service point. Use only a Saab approved long-life oil filter and engine oils meeting the classifications stated in the Warranty and Service Record Booklet. The use of extra additives in the oil is not necessary and is not recommended, and may be harmful to turbochargers.

More frequent oil changes are recommended if your vehicle is operated under any of the following conditions:

- Most trips are less than 5–10 miles (8–16 km). This is particularly important when outside temperatures are below freezing.
- Most trips include extensive idling (frequent stop-and-go traffic).
- Most trips are through dusty areas (such as construction zones).
- If the vehicle is used for delivery service, police, taxi or other commercial applications.

If your driving habits match this description, have the engine oil and filter changed in-between normal services. These conditions cause the engine oil to break down faster. The Warranties and Service Record Booklet has provisions to record extra oil changes.

Service record retention

It is the owner's responsibility to retain service records. If possible, you should keep copies of all shop work orders for all service and repairs, whenever performed. As indicated in the new car and emission control system warranties, it is important to document that all necessary maintenance has been done.

HOW THE SERVICE RECORD IS ORGANIZED

The service record is comprised of a series of coupons on which to record services as they are performed. There are additional coupons for documenting extra engine oil and filter changes, extra automatic transmission fluid services necessary for severe service conditions, and brake fluid changes.

HOW TO USE THE SERVICE RECORD COUPONS

When the car is brought to a Saab dealer for scheduled maintenance, present the Warranties & Service Record Booklet to the service manager. When the technician has completed the service, the technician will sign the maintenance record. The person responsible for quality assurance at the dealership will also sign and stamp the record with the dealer identification stamp.

Service costs

Dealer pricing practices and labor for service work vary. Saab's recommended service times for each service point do not include the labor required to replace wear items, such as wiper blades, brake pads or tires. Nor is labor to perform other service or repairs found to be necessary as a result of the inspections included in these times. Additional labor and parts will be charged for such work when necessary, except as covered under an applicable Saab warranty or any optional extended service contract. Transmission fluid changes or suspension alignment, when necessary, are also additional.

Dealer charges for general shop material, regulated hazardous waste removal, recycling expenses or other operation costs may also be applied to service and repair invoices and are apt to vary by dealer and location.



280 Customer Assistance and Information



Owner assistance

Warranties and service problem assistance

For complete information about all applicable warranties, including the New Car Warranty, Perforation Warranty, Vehicle Emission Warranty and Emission Perforation Warranty, consult the Warranties and Service Record Booklet which accompanies this Owner's Manual. It also contains owner assistance information including Saab Roadside Assistance. If the booklet is lost or misplaced, a new one may be ordered through a Saab dealer or by contacting Saab.

In the U.S. there is a national Customer Assistance Center at Saab Automobile USA, Inc. The toll-free number to call from all 50 states is 1-800-955-9007.

In Canada, please call the Saab Customer Assistance Center at 1-800-263-1999.

A list of authorized Saab sales and service dealers is available for those planning to travel in the United States and Canada.




Canadian or U.S. travelers may call the Customer Assistance Center in the country in which they are traveling.


Change of Address Notification (U.S. and Canada)

Two change of address cards are provided at the end of the Warranties and Service Record Booklet. Knowing your current address allows Saab to contact you in the event of a recall or service campaign. Please help us keep our records up to date for your own peace of mind.

Service information

Factory Service Manuals for the Saab 9-3 and 9-5 car lines can be ordered through your dealer. These are comprehensive manuals on CD ROM, geared to use by professional technicians. Consult your Saab dealer for prices for your model.





Reporting Safety Defects (USA)

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Saab Cars USA, Inc.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Saab Cars USA, Inc.

To contact NHTSA, you may call the toll-free Vehicle Safety Hotline at 1-888-327-4236 (TTY: 1-800-424-9153; go to <http://www.safercar.gov>; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington D.C. 20590. You can also obtain other information about motor vehicle safety from <http://www.safercar.gov>.

Reporting Safety Defects to the Canadian government




If you live in Canada, and believe that your vehicle has a safety defect, you should immediately notify Transport Canada, in addition to notifying General Motors of Canada Limited.

You may write to Transport Canada at Box 8880, Ottawa, Ontario, K1G 3J2.

In addition to notifying Transport Canada in a situation like this, we certainly hope you will notify us. In Canada, please call our Saab Customer Assistance Center at 1-800-263-1999.

Or write:

General Motors of Canada Limited
Customer Assistance Center,
1908 Colonel Sam Drive,
Oshawa, Ontario, L1H 8P7.



282 Customer Assistance and Information

Vehicle Data Collection and Event Data Recorders

Your vehicle, like other modern motor vehicles, has a number of sophisticated computer systems that monitor and control several aspects of the vehicle's performance. Your vehicle uses on-board vehicle computers to monitor emission control components to optimize fuel economy, to monitor conditions for air bag deployment and, if so equipped, to provide anti-lock braking and to help the driver control the vehicle in difficult driving situations. Some information may be stored during regular operations to facilitate repair of detected malfunctions; other information is stored only in a crash event by computer systems commonly called event data recorders (EDR).

In a crash event, computer systems, such as the Air Bag Sensing and Diagnostic Module (SDM) in your vehicle may record information about the condition of the vehicle and how it was operated, such as data related to engine speed, brake application, throttle position, vehicle speed, steering wheel angle, lateral acceleration, safety belt usage, air bag readiness, air bag performance, and the severity of a collision. This information has been used to improve vehicle crash performance and may be used to improve crash performance of future vehicles and driving safety. Unlike the data recorders on many airplanes, these on-board systems do not record sounds, such as conversation of vehicle occupants.

To read this information, special equipment is needed and access to the vehicle or the SDM is required.

Saab will not access information about a crash event or share it with others other than

- With the consent of the vehicle owner or, if the vehicle is leased, with the consent of the lessee,
- In response to an official request of police or similar government office,
- As part of Saab's defense of litigation through the discovery process, or
- As required by law.

In addition, once Saab collects or receives data, Saab may


- Use the data for Saab research needs,
- Make it available for research where appropriate confidentiality is to be maintained and need is shown, or
- Share summary data which is not tied to a specific vehicle with non-Saab organizations for research purposes.

Others, such as law enforcement, may have access to the special equipment that can read the information if they have access to the vehicle or SDM.

If your vehicle is equipped with OnStar[®], please check the OnStar[®] subscription service agreement or manual for information on its operations and data collection.




Technical data





BB3377

General data _____	284
Engine _____	286
Engine oil _____	286
Fuel _____	287
Engines _____	287
Electrical system _____	287
Brake system _____	287
Wheels and tires _____	288
Plates and labels _____	292



* Asterisk means: equipment not fitted in all cars (can depend on model variant, engine variant, market specification, options or accessories).



284 Technical data

General data

Overall length, including bumpers:	
SportSedan and Convertible _____	182.9" (4647 mm)
SportCombi _____	183.8" (4670 mm)
Overall width, including door mirrors _____ 80.2" (2038 mm)	
Maximum height incl roof antenna:	
SportSedan front wheel drive, standard chassis _____	57.9" (1473 mm)
SportCombi, front wheel drive, standard chassis _____	60.7" (1543 mm)
SportSedan, all-wheel-drive models _____	58.5" (1488 mm)
SportCombi, all-wheel-drive models _____	61.4" (1530 mm)
Wheelbase _____	105.3" (2675 mm)
Track:	
Front _____	59.8" (1524 mm)
Rear _____	59.3" (1506 mm)
Ground clearance at GVW:	
front wheel drive models _____	approx. 4.7" (120 mm)
all-wheel-drive models _____	approx. 4.8" (122 mm)



V.I.N. label on vehicles sold in U.S.A.



V.I.N. label on vehicles sold in Canada

Permissible load (in addition to the driver) = GVW minus curb weight. The maximum permissible axle load, front or rear, must not be exceeded.

The precise curb weight of the vehicle and load capacity are specified in the vehicle registration documents.

Number of seats (incl. driver):	
SportSedan and SportCombi _____	5
Convertible _____	4
Turning circle measured at vehicle extremities:	
all-wheel-drive models _____	40.0 ft. (12.2 m)
other _____	39.0 ft. (11.9 m)
Trunk length, SportSedan:	
Rear seat raised _____	40.8" (1036 mm)
Rear seat lowered _____	69.8" (1774 mm)
Trunk length, Convertible _____	29.1" (740 mm)
Trunk length, SportCombi:	
Rear seat raised _____	39.9" (1013 mm)
Rear seat lowered _____	70.0" (1777 mm)

Curb weight
(i.e. with full fuel tank, full washer fluid reservoir, standard tools and spare wheel):

SportSedan _____	3220–3880 lbs. (1460–1760 kg)
Convertible _____	3520–3870 lbs. (1595–1755 kg)
SportCombi _____	3310–4010 lbs. (1500–1820 kg)

Gross vehicle weight (GVW):

SportSedan _____	4160–4820 lbs. (1885–2185 kg)
Convertible _____	4420–4650 lbs. (2005–2110 kg)
SportCombi _____	4240–4950 lbs. (1925–2245 kg)

Maximum axle load, front wheel drive:

SportSedan, front _____	2540 lbs. (1150 kg)
SportSedan, rear _____	2230 lbs. (1010 kg)
Convertible, front _____	2560 lbs. (1160 kg)
Convertible, rear _____	2310 lbs. (1050 kg)
SportCombi, front _____	2340 lbs. (1150 kg)
SportCombi, rear _____	2430 lbs. (1100 kg)

Maximum axle load, all-wheel-drive models:

SportSedan, front _____	2600 lbs. (1180 kg)
SportSedan, rear _____	2380 lbs. (1080 kg)
SportCombi, front _____	2600 lbs. (1180 kg)
SportCombi, rear _____	2520 lbs. (1140 kg)

Weight distribution:

Curb weight + driver (150 lbs. (68 kg)), front/rear, SportSedan and SportCombi_	approx. 60/40 %
GVW, front/rear, SportSedan and SportCombi _____	approx. 50/50 %
Maximum roof load, SportSedan and SportCombi _____	220 lbs. (100 kg)
Maximum load in trunk, SportSedan, Convertible and SportCombi _____	175 lbs. (80 kg)
The combined weight of occupants and cargo should never exceed:	
SportSedan and SportCombi _____	926 lbs. (420 kg)
Convertible _____	776 lbs. (352 kg)
Maximum combined weight of driver and passengers _____	
SportSedan and SportCombi (5x150 lbs.)	750 lbs. (340 kg)
Convertible (4x150 lbs.) _____	600 lbs. (272 kg)

286 Technical data

WARNING

- The GVW and maximum axle loads must not be exceeded. Note that if some accessories (e.g. towbar, CD changer) are fitted, the available load capacity is reduced by the weight of these.
- When carrying a load in the trunk, make sure that it is lashed down securely, particularly when part or all of the rear seat is folded down.

Trailer

Trailer with brakes _____	Max. 3500 lbs. (1588 kg)
Trailer without brakes _____	Max. 1000 lbs. (450 kg)
Recommended towball load _____	110–165 lbs. (50–75 kg) See also page 190.

Note that the towbar must not be installed on certain models. Contact a Saab dealer for information.

Maximum theoretical towing speed, trailer with brakes _____	60 mph (100 km/h)
Maximum theoretical towing speed, trailer without brakes _____	National restrictions apply

When towing a trailer, increase the pressure of the rear tires by 20 kPa (3 psi).

The above speed and weight restrictions are those specified by Saab Automobile AB.

Note that national restrictions may apply to trailer speeds and weights (see page 188).

Engine

Type:

4-cyl engine _____	Four cylinders, double overhead camshafts, 16 valves, two balancer shafts
V6 engine _____	Six cylinders, 4 overhead camshafts, 24 valves, the angle between the cylinder rows is 60°

Swept volume:

4-cyl engine _____	122 cu.in. (1.998 l)
V6 engine _____	170 cu.in. (2.792 l)

Engine oil

Information regarding suitable engine oils can be found in Warranty and Service Record Booklet.

Oil capacity, including filter (oil change)

4-cyl engine _____	6.3 qts. (6.0 l)
V6 engine _____	6.3 qts. (6.0 l)

Fuel

Fuel tank capacity _____ 16.05 U.S. gal.
(61 l)

Gasoline Octane

Use regular unleaded gasoline with a posted octane of 87 or higher.

Although not required, use higher octane fuel for optimum performance - 90 octane for the 2.0T engine and 93 octane for the 2.8 V6.

Gasoline with a lower octane rating can be used, although not lower than 87 octane. However, engine performance will fall slightly and heavy loading and laboring should be avoided. For further information on fuel, see page 158.

Engines

2.0T

Rating, SAE at 5300 rpm _____ 210 hp (155 kW)
Maximum torque, SAE at 2500-4000 rpm 221 ft.lb. (300 Nm)

2.8 V6

Rating, SAE at 5500 rpm _____ 280 hp (206 kW)
Maximum torque, front-wheel drive, SAE at 1800-5000 rpm _____ 262 ft.lb. (355 Nm)
Maximum torque, all-wheel-drive models, SAE at 1900-4500 rpm _____ 295 ft.lb. (400 Nm)

Electrical system

Voltage _____ 12 V
Battery capacity _____ 60 Ah

Brake system

Foot brake (ABS) _____ Hydraulic disc brakes with vacuum servo unit. Diagonally split circuits; ventilated discs on front wheels (some variants also have ventilated rear discs). EBD function (see page 171).

Park brake _____ Acts on rear wheels
Brake fluid _____ To DOT 4.
Do not use DOT 5.

Hydraulic unit for soft top, Convertible

Oil capacity _____ 0.6 qt. (0.6 l)
Oil type _____ CHF 11S

288 Technical data

Wheels and tires

All season tires

6.5x16" _____ 215/55 R16 93 H

7x17" _____ 225/50 R17 94 V

7.5x17" _____ 235/45 R17 94 V

Summer tires

7.5x18" _____ 235/45 R18 94 Y

Before changing to wheels/tires of another size, we recommend that you contact an authorized Saab dealer regarding acceptable options.

Winter (snow) tires

6.5x16" _____ 215/55 R16 93 Q
M+S
215/60 R16 95 Q
M+S
225/55 R16 95 Q
M+S

7x17" _____ 215/50 R17 95 Q
RF/XL M+S
225/50 R17 94 Q
M+S

Spare wheel

Compact spare *

Wheel _____ 4x16"

Tire _____ 125/85 R16 99 M

Pressure _____ 420 kPa (60 psi)

Maximum life _____ 2200 miles
(3500 km)

Maximum speed _____ 50 mph (80 km/h)

Full size spare *

Wheel _____ 6.5x16"

Tire _____ 215/55 R16

Pressure _____ 250 kPa (36 psi)

Maximum life _____ 2200 miles
(3500 km)

Maximum speed _____ 50 mph (80 km/h)

Full size spare *

Wheel _____ 7x17"

Tire _____ 215/50 R17 95 W
RF/XL

Pressure _____ 290 kPa (42 psi)

Maximum life _____ 2200 miles
(3500 km)

Maximum speed _____ 50 mph (80 km/h)

NOTICE

Snow chains

Snow chains must **not** be fitted to the rear wheels, and may only be used with the following wheel-tire combinations:

Wheels	Tires
6.5x16" _____	215/55 R16 M+S or 215/55 R16

Before you purchase winter wheels we recommend that you obtain information on the sizes suitable for your car. We therefore recommend that you contact an authorised Saab dealer.

Contact your Saab dealer regarding suitable snow chains.

Snow chains must not protrude more than 0.35 in. (9 mm) from the tire's tread and its inside.

Snow chains must not be fitted to wheels larger than 16".

Snow chains must be tensioned after a short distance.

Max. permissible speed with snow chains fitted is 30 mph (50 km/h).

Snow chains must not be fitted to wheels larger than 16".

NOTICE

Wheels larger than 18" must not be fitted for reasons stated on page 244.

Exercise care when driving on uneven roads or against the curb if the car is heavily laden. This particularly applies to cars with 17" and 18" wheels.

Permitted wheel offset is 41 mm.

NOTICE

Snow chains

For all-wheel-drive models:

Wheel	Tires
6.5x16 _____	225/55 R16 M+S
7x17 _____	215/50 R17 95 RF/XL M+S

Cars with the bigger brake discs (front brake disc diameter 13.58 in. (345 mm), must use 17"-wheels.

Before you purchase winter wheels we recommend that you obtain information on the sizes suitable for your car. We therefore recommend that you contact an authorised Saab dealer.

Contact your Saab dealer regarding suitable snow chains.

Snow chains must not protrude more than 0.35 in. (9 mm) from the tire's tread and its inside.

Snow chains must be tensioned after a short distance.

Max. permissible speed with snow chains fitted is 30 mph (50 km/h).

Snow chains must **not** be fitted to the rear wheels, and may only be used with the following wheel-tire combinations:

290 Technical data

Recommended tire/engine combinations

	2.0 Turbo	V6 engine	all-wheel-drive models
--	-----------	-----------	------------------------

All season tires

215/55 R16 93 H	✓	–	–
225/50 R17 94 V	–	–	✓
235/45 R17 94 V	✓	✓	–

Summer tires

235/45 R18 94 Y	–	✓ *)	✓
-----------------	---	------	---

Winter (snow) tires

215/55 R16 93 Q	✓	✓	–
215/60 R16 95 Q	–	✓ *)	✓
225/55 R16 95 Q	✓	✓	–
215/50 R17 95 Q RF/XL	–	–	✓ **)
225/50 R17 94 Q	–	–	✓ ***)

Wheel sizes

6.5x16"	✓	✓	–
7.5x17"	✓	✓	–
7x17	–	–	✓
7.5x18	–	–	✓

RF/XL = Reinforced (or Extra Load) tire.

*) with XWD

***) with snow chains

***) no snow chains

Recommended lowest tire pressure, cold tires

Tire size	Load/speed mph (km/h) *	Front psi/kPa	Rear psi/kPa
-----------	----------------------------	------------------	-----------------

All season tires

215/55 R16 93 H	1-3 pers./0-100 (0-160)	35/240	35/240
	4-5 pers./0-100 (0-160)	35/240	35/240
	1-5 pers./100- (160-)	41/280	41/280
235/45 R17 94 V	1-3 pers./0-100 (0-160)	35/240	35/240
	4-5 pers./0-100 (0-160)	36/250	36/250
	1-5 pers./100- (160-)	41/280	41/280
225/50 R17 94 V	1-3 pers./0-100 (0-160)	35/240	35/240
	4-5 pers./0-100 (0-160)	36/250	36/250
	1-5 pers./100- (160-)	41/280	41/280

Summer tires

235/45 R18 94 Y	1-3 pers./0-120 (0-190)	36/250	36/250
	4-5 pers./0-120 (0-190)	36/250	36/250
	1-5 pers./120- (190-)	41/280	41/280

Winter tires

215/55 R16 93 Q	1-3 pers./0-100 (0-160)	35/240	35/240
	4-5 pers./0-100 (0-160)	41/280	41/280
215/60 R16 95 Q	1-3 pers./0-100 (0-160)	35/240	35/240
	4-5 pers./0-100 (0-160)	41/280	41/280
225/55 R16 95 Q	1-3 pers./0-100 (0-160)	35/240	35/240
	4-5 pers./0-100 (0-160)	41/280	41/280
215/50 R17 95 Q RF/XL	1-3 pers./0-100 (0-160)	42/290	42/290
	4-5 pers./0-100 (0-160)	42/290	42/290
225/50 R17 94 Q	1-3 pers./0-100 (0-160)	36/250	36/250
	4-5 pers./0-100 (0-160)	42/290	42/290

Tire size	Load/speed mph (km/h) *	Front psi/kPa	Rear psi/kPa
-----------	----------------------------	------------------	-----------------

Compact spare

125/85 R16 99 M *	Max 50 (80)	60/420	60/420
-------------------	-------------	--------	--------

Full size spare *

215/55 R16 93V	When the car has the same tire size, the same load/speed information applies as for the original tires.		
215/50 R17 95 W RF/XL, all-wheel-drive models only	Max 50 (80)	42/290	42/290

* Do not exceed posted speed limits.

By cold tires is meant tires that are the same temperature as the surrounding air temperature.

The values for tire pressure in table above are for tires at 68°F (20°C).

The tire pressure will increase as the tires become warm (e.g. during high-way driving), and decrease as they cool.

When the temperature of the tires increases or decreases by 10 degrees the tire pressure will correspondingly increase or decrease by 2 psi/10 kPa.



Customized systems

Several of the systems in your Saab can be customized to better suit your individual needs. Contact your Saab dealer

Central locking system

Some functions are governed by legal requirements and cannot therefore be reprogrammed.

We recommend that you consult a Saab dealer for further information.

Listed below are a number of examples of programmable functions.



- Audible confirmation of arming/disarming the car alarm
- Automatic unlocking when car stopped and remote control removed from the ignition switch
- Trunk lid locked when car driven off or 30 seconds after being shut.

Courtesy Headlamp Feature

- The length of time the lights are on
- Whether the reversing light or tail lights should come on as well as the dipped beam.

Automatic Climate System (ACC)

- **Convertible:** A/C compressor not switched off when the soft top is open.



294 Technical data

Warning and indications that can be shown on the SID

Which warnings and indications that can be shown depends on engine variant and car specification.

The warnings/indications that contain an exclamation mark are shown together with a warning or check light in the main instrument panel.

Symbol	Text
	Antilock brake malfunc. Contact service.
	Brake malfunction. Make a safe stop.
	Brake fluid level low. Make a safe stop.
	Release park brake.
	Oil pressure low. Make a safe stop.
	Low engine oil level. Fill oil now.
	Reduced engine power. Contact service.

	Tighten fuel filler cap.
	Limited performance.
	Coolant level low. Refill.
	Hot engine. Make a safe stop. Idle engine.
	Airbag malfunction. Contact service.
	Gearbox too hot. Make a safe stop. Open hood.
	Battery not charging. Make a safe stop.
	Headlight levelling malfunction.
	Cornering headlights malfunction
	Tap brakes lightly before using cruise ctrl.
	Traction control failure. Contact service.

	Stability control failure. Contact service.
	Turn on the lights.
	Washer fluid level low. Refill.
	Rain sensor malfunc. Contact service.
	Key not accepted. Contact service.
	Remote control battery low. Replace battery.
	Number of keys: Active key number:
	Steering lock malfunc. Make a safe stop.
	Pull out key, turn steering wheel. Restart.
	Theft protection failure. Contact service.
	Alarm tripped during last arming period.

	Rear left seat backrest unlocked.
	Rear right seat backrest unlocked.
	Parking assistance malfunction. Service.
	Parking assistance sensor interference.
	Close doors.
	Left brake light failure
	Left high beam failure.
	Left low beam failure.
	Rear fog light failure.
	Right brake light failure.
	Right high beam failure.


	Right low beam failure.
	High mounted stop light failure.
	Left front turn signal failure.
	Left rear turn signal failure.
	Right front turn signal failure.
	Right rear turn signal failure.
	Right side-mounted turn signal failure.
	Left side-mounted turn signal failure.
	Left front position light failure.
	Right front position light failure.
	Left front fog light failure.

	Right front fog light failure.
	Left reversing light failure.
	Right reversing light failure.
	License plate light failure.
	Left rear taillight failure.
	Right rear taillight failure.
	Right side day-time running light failure.
	Left side day-time running light failure.
	Tire pressure low, rear left. Check tires.
	Tire pressure low, rear right. Check tires.
	Tire pressure low, front right. Check tires.



296 Technical data

	Tire pressure low, front left. Check tires.
	Low tire pressure rear left. Make a safe stop.
	Low tire pressure rear right. Make a safe stop.
	Low tire pressure front right. Make a safe stop.
	Low tire pressure front left. Make a safe stop.
	Tire pressure system failure. Contact service.
	Time for service.
	Service XWD.



Index

A

ABS brakes	171
ACC	107
Adjustment, steering wheel	118
Air filter	209
Airbag	32
All-wheel drive (XWD)	173
Anchorage eyes, SportSedan	139
Anti-corrosion treatment	271
Antilock braking system	171
Anti-spin	173
Ashtrays	134
Autochecking of lights, warning and indicator lights	87
Autodimming	123
Automatic climate control (ACC)	107
Automatic closing of moonroof	129
Automatic closing of windows, SportSedan and SportCombi	120
Automatic transmission	162
Automatic transmission, Sport mode	163

B

Battery	214
Bedding-in of new brake pads	160
Before towing a trailer	191
Belt height, SportSedan and SportCombi	14

Brake fluid, grade	287
Brakes	170
Braking	170
Bulb changing	218
Bulb table	232
Buying new tires	243

C

Cabin lighting, Convertible	79
Cabin lighting, SportSedan and SportCombi	131
Calibrating front electric windows with pinch protection	78
Calibration of windows, SportSedan and SportCombi	121
Car alarm	56
Car transport	196
Care of air conditioning	273
Cargo guard	148
Cargo guard, SportWagon	148
Cargo net, SportCombi	145
CHECK ENGINE light	83
Change of address notification	280
Changing a tire	258
Changing bulbs	218
Changing the battery, remote control	54
Changing wiper blades	216
Checking the number of remote controls	53
Checks before towing a trailer	191
Child safety	24

Child safety locks, rear doors	52
Child seats	24
Cigarette lighter	134
Cleaning the engine bay	267
Cleaning upholstery	266
Closing the soft top manually, Convertible	68
Closing the soft top, Convertible	64
Clutch interlock	161
Comfort opening of moonroof	129
Comfort opening of windows, SportSedan and SportCombi	119
Compact spare	256
Compact spare wheel fitted, driving with	258
Compass	127
Convertible	61
Convertible, washing	268
Coolant	210
Cornering headlights	99
Crash memory, see EDR	282
Cruise control	169
Cup holder	133

D

Date codes, tires	253
Deactivating rear windows, SportSedan and SportCombi	121
Deactivating the passenger door window button, Convertible	78

298 Index

- | | | | | | |
|--|-----|--|-----|---|-----|
| Deactivating the rear window switches _____ | 121 | Electrically adjustable seats _____ | 20 | Flat spots, tires _____ | 242 |
| Deep water, driving through _____ | 193 | Electric engine heater _____ | 184 | Floor jack _____ | 259 |
| Definitions and terminology, tire _____ | 250 | Electric heating, front seats _____ | 114 | Folding down the rear seat backrest, SportCombi _____ | 141 |
| Determining correct load, tires _____ | 252 | Electric windows _____ | 119 | Folding down the rear seat, SportSedan _____ | 136 |
| Direction indicator stalk switch _____ | 101 | Electric windows, Convertible _____ | 77 | Front fog lights _____ | 100 |
| Direction indicators _____ | 101 | Electronic Stability Program _____ | 175 | Front towing eye _____ | 194 |
| Dome light, Convertible _____ | 228 | Electronic steering wheel lock _____ | 151 | Fuel cap _____ | 157 |
| Dome light, SportSedan _____ | 228 | Emergency opening of the narrow backrest, SportSedan _____ | 140 | Fuel container _____ | 158 |
| Donor battery, boost starting _____ | 197 | Emergency operation of the moonroof _____ | 130 | Fuel gauge _____ | 89 |
| Door handles _____ | 48 | Engine bay, cleaning _____ | 267 | Fuel grade _____ | 287 |
| Door mirrors _____ | 122 | Engine heater _____ | 184 | Fuel information _____ | 158 |
| Drive belt _____ | 215 | Engine immobilizer _____ | 55 | Functions, car alarm _____ | 58 |
| Driver's seat with memory _____ | 21 | Engine management system _____ | 204 | Fuse panel in luggage compartment _____ | 236 |
| Driving in cold climates _____ | 185 | Engine number _____ | 292 | Fuse table _____ | 235 |
| Driving in deep water _____ | 193 | Engine oil, checking _____ | 208 | Fuses _____ | 233 |
| Driving in hot climates _____ | 187 | Engine oil, grade _____ | 286 | | |
| Driving techniques _____ | 183 | Engine temperature gauge _____ | 88 | G | |
| Driving with a compact wheel fitted _____ | 258 | Engine, description _____ | 203 | GDO, garage door opener _____ | 123 |
| Driving with a heavy load on hilly roads _____ | 164 | Engine, technical data _____ | 286 | Gearbox number _____ | 292 |
| Driving with a load _____ | 192 | Engines _____ | 287 | General safety instructions, Convertible _____ | 62 |
| Driving with a roof load _____ | 192 | Event Data Recorders (EDR) _____ | 282 | Glove box _____ | 134 |
| Driving with the trunk lid open _____ | 193 | Extra electrical socket _____ | 134 | Glovebox lighting _____ | 229 |
| | | | | | |
| E | | F | | H | |
| EDR (Event Data Recorders) _____ | 282 | Facilitating entry to rear seat, Convertible _____ | 73 | Handbrake _____ | 177 |
| ESP® _____ | 175 | Factors affecting fuel consumption _____ | 183 | Hazard warning lights _____ | 102 |
| Easy entry, Convertible _____ | 73 | Filler cap _____ | 157 | Head restraint, Convertible _____ | 74 |
| Economical motoring _____ | 183 | Filling a portable fuel container _____ | 158 | Head restraints _____ | 23 |
| Electrical system, technical data _____ | 287 | Filling up _____ | 156 | | |

300 Index

P

Panic function, car alarm _____	58	Reading lights, Convertible _____	79	Safety belts _____	12
Park Brake Shift Lock _____	163	Rear fog light _____	101	Safety belts, rear seat, SportSedan and SportCombi _____	17
Park Brake Shift Lock, temporary override _____	166	Rear seat, folding down, SportCombi	141	SAHR, head restraint _____	23
Parking _____	177	Rear seat, safety belts _____	17	SDM _____	282
Parking aid _____	180	Rear seats, folding down, SportSedan	136	SID _____	89
Parking brake _____	177	Rear towing eye _____	194	SPA _____	180
Parking on a hill _____	178	Rear windows, deactivating, SportSedan and SportCombi _____	121	Seat belts _____	12
Pinch protection, electric windows, SportSedan and SportCombi _____	120	Rearview mirrors _____	122	Seat belts in rear seat, Convertible ____	75
Pinch protection, moonroof _____	130	Recommendations for automatic transmission, towing a trailer _____	189	Seat belts, care _____	266
Plates and labels, location _____	292	Recommendations for manual gearbox, towing a trailer _____	190	Seat belts, checking _____	266
Polishing and waxing _____	270	Recommended snow chains _____	288	Seats _____	18
Poly-V-belt _____	215	Refueling _____	156	Securing a load _____	139
Portable fuel container _____	158	Reinstalling the fuel cap _____	157	Sentronic, manual gear selection ____	168
Position lights _____	98	Remote control _____	48	Service Engine Lamp _____	83
Power steering fluid, checking _____	213	Remote locking malfunction _____	50	Service costs _____	279
Pressure gauge _____	88	Replacement, wheel _____	246	Service information _____	280
Pressure, tires _____	240	Reporting safety defects _____	281	Service intervals _____	278
Profiles, customized settings _____	94	Rev counter _____	87	Service record retention _____	279

Q

Quality grading, tires _____	244
Quick guide, remote control _____	49

R

Rain sensor _____	103
Raising the soft top manually, Convertible _____	68

S

Saab Information Display _____	89	Safety belts _____	12
Saab Parking Assistance _____	180	Safety belts, rear seat, SportSedan and SportCombi _____	17

SAHR, head restraint _____	23	Seat belts _____	12
SDM _____	282	Seat belts in rear seat, Convertible ____	75
SID _____	89	Seat belts, care _____	266
SPA _____	180	Seat belts, checking _____	266
Seat belts _____	12	Seats _____	18
Seat belts in rear seat, Convertible ____	75	Securing a load _____	139
Seat belts, care _____	266	Sentronic, manual gear selection ____	168
Seat belts, checking _____	266	Service Engine Lamp _____	83
Seats _____	18	Service costs _____	279
Securing a load _____	139	Service information _____	280
Sentronic, manual gear selection ____	168	Service intervals _____	278
Service Engine Lamp _____	83	Service record retention _____	279
Service costs _____	279	Signalling, horn _____	118
Service information _____	280	Ski hatch, SportCombi _____	143
Service intervals _____	278	Ski hatch, SportSedan _____	138
Service record retention _____	279	Spare wheel _____	256
Signalling, horn _____	118	Speed ratings, tires _____	249
Ski hatch, SportCombi _____	143	Speedometer _____	87
Ski hatch, SportSedan _____	138	Sport mode, automatic transmission _	163
Spare wheel _____	256	Starting the engine _____	152
Speed ratings, tires _____	249	Steering wheel adjustment _____	118
Speedometer _____	87	Steering wheel lock _____	151
Sport mode, automatic transmission _	163	Steps for determining correct load limit _____	252
Starting the engine _____	152	Storage compartments _____	134
Steering wheel adjustment _____	118		
Steering wheel lock _____	151		

Sun visor _____	132	Transmission, manual _____	161	Washers _____	103
Switches _____	97	Transporting the car _____	196	Washing _____	267
T					
TCS _____	173	Treadwear indicators _____	243	Washing a Convertible _____	268
Technical data _____	284	Trip computer _____	90	Waxing and polishing _____	270
Textile carpeting, cleaning _____	267	Trip meter _____	90	Wear indicators, tires _____	243
Tie down eyes, SportCombi _____	144	Troubleshooting, A/C and ACC _____	273	What Will You See After an Airbag	
Tie down eyes, SportSedan _____	139	Trunk lid, driving when open _____	193	Inflates? _____	43
Tightening torque, wheels _____	261	Trunk lid, opening _____	51	Wheel replacement _____	246
Tire Repais Kit _____	262	Turbo gauge _____	88	Wheels and tires, sizes _____	288
Tire chains _____	247	U			
Tire date code _____	253	Uniform tire quality grading _____	244	When it is time for new tires _____	242
Tire inspection and rotation _____	241	Upholstery care _____	266	Windshield washers _____	103
Tire markings _____	249	Upholstery, cleaning _____	266	Windshield wipers _____	103
Tire sidewall labeling _____	248	Useful tips on starting _____	153	Wing mirrors _____	122
Tire sizes _____	288	V			
Tire terminology and definitions _____	250	Vanity mirror _____	132	Winter driving _____	185
Tire, changing _____	258	Vehicle Data Collection _____	282	Winter tires _____	253
Tire, spare _____	256	Vehicle identification number _____	292	Wiper blades _____	216
Tires _____	240	Vehicle recovery _____	196	Wipers _____	103
Tools and spare wheel _____	256	X			
Touching up paintwork _____	270	XWD, All-wheel drive _____	173	Xenon cornering headlights _____	99
Towbar _____	188	Xenon headlights _____	219	Xenon headlights, headlight levelling _____	98
Towbar load _____	190	W			
Towing _____	193	Warning labels _____	8		
Towing a trailer _____	188	Warning lights _____	82		
Towing the car _____	195	Warning triangle _____	102		
Traction Control System (TCS) _____	173	Warnings and messages on SID,			
Transmission oil, checking _____	210	Convertible _____	71		
Transmission, automatic _____	162	Washer fluid _____	217		
		Washer jets _____	217		

